


CIROS Festo CP-System User Manual

Based on CIROS v7.1.7

Can be used for v6.4.6 and v7.0
with few variations.



Content

1. Introduction to CIROS (→)

- Overview
- Installation
- License
- Application Scenarios
- Help Menu
- Keyboard Shortcuts
- Options Setting
- Window's Size

2. Introduction to Festo CP-System (→)

- Building Blocks
- Product
- Terms and Definitions
- Standard Part Numbers
- Group and Utilities
- Carriers
- Resources and Buffers

Content

3. CIROS Model (→)

- Collaborative Working
- Model's Structure
- Elements and Coordinate Systems
- Create a Model
- Window's Layout
- View and Edit Mode
- Standard Views
- View Used when Creating CIROS Model
- Snapping into Place
- Floor and Background

4. CP-System Model Libraries (→)

- Open Model Libraries Window
- Model Library Festo CP System
- Configuration in Properties Section CP System
- Sources and Sinks
- Adding New Libraries to CIROS

Content

5. Project Management (→)

- CP System Simulation Controller

6. Simulation (→)

- Simulation Kernel
- Reduce Simulation Computing Requirement
- Code Sequence Trace
- Visualising Sensor Data
- Data Logging

Content

7. Virtual Commissioning with MES4 (→)

- Terms and Definitions
- Synchronise CIROS Parts in Storage with MES4 Buffers
- Setting Up CIROS Model for MES4
- Default Procedure for Setting Up MES4
- Import Model from Python Script
- MES4 Communication Interface
- Terminology in MES4 Messages
- MES4 Service Requests
- Running CIROS and MES4 on Different PCs
- Configure Robotino
- Simulation with Robotino
- Running CIROS and Fleet Manager on different PCs

8. Virtual Commissioning with Soft PLC (→)

- Scenario Overview
- Process Summary
- Preparing a CIROS Model
- Starting a PLCSIM Instance
- Creating the Hardware Configuration and IO Tags in TIA Portal
- Configuring the Interface
- Common Issues
- Remote Connection between CIROS and PLCSIM Advanced

Content

9. Python (→)

- Python in Model Libraries
- Python in CIROS
- CP System Construction Helper

10. OPC UA Interface (→)

- CIROS as OPC UA Client

Content

11. Robot Programming

- Mitsubishi Industrial Robot
- Layout and Windows
- CP-F-RASS
- Steps to Configure CP-F-RASS for Simulation
- Steps to Simulate CP-F-RASS
- Simulate Real Robot Program in CP-F-RASS Model
- CP-F-RASS Robot Programming
- Move Robot Manually
- Mount and Release a Gripper Manually
- TCP Tracking
- View TCP Coordinate
- Robot Workspace
- Collision Detection
- Connect to Robot Controller
- Create / Load Robot Controller Backup
- Online Teaching
- Upload / Download Robot Programs

Content

12. VR (→)

- Setting Up VR Glasses

13. Advanced (→)

- Export as High-Resolution Images
- Multiple View Windows
- CIROS Starter
- Model Analysis
- CIROS Part Number for CP System

Content

14. Troubleshooting (→)


- External document “CIROS-CP_Troubleshoot_EN_v7.1_xxxxxx.pdf”

Introduction to CIROS

Overview

CIROS – Computer Integrated Robot Simulation

- Powerful, kinematic real-time 3D simulation
 - Time-discrete simulation kernel (update every 40ms)
 - Large model library: not only CP Lab / Factory, but also >1000 robots from various manufacturers
 - CAD import for user-defined modules / kinematics
 - Several interfaces, e.g. to MES4, Fleet manager, Matlab, Python, VR glasses, Mitsubishi robots, ...
- User interaction during simulation
- Collision analysis
- Fault injection / simulation
- PLC and robot programming
- Online help with introductory examples



Overview



Studio vs. Education

- **CIROS Studio**
 - Full version including all features
 - Designing and saving models from scratch
 - RCI explorer interface to Mitsubishi robot controllers (download/upload of programs, individual step tracking)
 - Fits perfect for preparation of teaching scenarios to be analyzed by students
- **CIROS Education**
 - Limited functionality
 - Already existing models can be analyzed & modified, but not saved
 - No RCI explorer interface to Mitsubishi robot controllers
 - Fits perfect for scenarios, in which CIROS studio models have to be opened, analyzed, and modified only

Overview

Language packs & software releases

- CIROS Studio and Education are two different software products.
- Depending on the license key one is allowed to start CIROS Studio and/or Education.
- Installation of different CIROS releases & language packs on a single PC possible.
- Unfortunately, the desired language must be set during installation (there is no option to change the language during runtime).





Overview

Hardware requirements

- Either USB port for USB dongle or network access for server-based licensing
- Officially supported operating system: Windows 10
- [Hardware requirements](#)
 - High-performance CPU, i.e. Intel i5/i7
 - At least 8 GB main memory
 - At least 4 GB SSD memory
 - NVIDIA graphics card with OpenGL 4.5 support and 4 GB dedicated memory
- When using CIROS in combination with other software (e.g., MES4, PLCSIM Advanced) two screens are highly recommended!
- It is also possible to run CIROS and other software (e.g., MES4, PLCSIM Advanced) on different PCs


Installation

- Open **Start.exe** and select **CIROS Applications**.



Installation


- Select either **CIROS Studio** or **CIROS Education** to be installed.



License

License is managed by CodeMeter.


List of USB dongles currently attached to the system.




View local licenses in CodeMeter WebAdmin

Option 1

Right mouse button opens context menu.



Option 2



CodeMeter WebAdmin

Note: All CIROS related licenses should be placed in the same container.

CodeMeter WebAdmin

Dashboard Container License Monitoring Diagnosis Configuration Info

All Container <no name> (3-4588346) English (US)

<no name> 3-4588346 CmStick 4.10

Licenses CmContainer Info User Data Backup and Restore

101142 Festo Didactic		Unit Counter	Valid Until	License Quantity	Feature Map
Product Code	Name				
191000	MES4	n/a	n/a	1	0x1

102344 Festo Didactic		Unit Counter	Valid Until	License Quantity	Feature Map
Product Code	Name				
400	CIROS 6 Education	n/a	n/a	1	0x1
500	CIROS 6 Supervision	n/a	n/a	200	n/a

6000122 RIF e.V.		Unit Counter	Valid Until	License Quantity	Feature Map
Product Code	Name				
100	CIROS 6.4 Studio MB	n/a	n/a	1	0x1
104	CIROS 6.4 Studio Industry Version	n/a	n/a	1	0x1

List of licenses stored on the attached USB dongle.

Licenses from Server

Allowing CodeMeter WebAdmin to act as a server.

The screenshot displays the CodeMeter WebAdmin interface. At the top, the 'WIBU SYSTEMS' logo is on the left, and 'CodeMeter WebAdmin' is centered. A teal navigation bar contains 'Dashboard', 'Container', 'License Monitoring', 'Diagnosis', 'Configuration', and 'Info'. A dropdown menu is open under 'Configuration', showing 'Basic', 'Server', and 'Advanced'. The 'Server' option is selected, and a sub-menu is visible with 'Server Access' and 'License Access Permissions'. The 'Server Access' sub-menu is highlighted with a blue box labeled '1'. Below the navigation bar, the breadcrumb trail shows 'Server Configuration' > 'Server Access', with 'Server Access' highlighted and labeled '2'. The main content area has two tabs: 'Server Access' (active) and 'License Access Permissions'. Under 'Server Access', there are two sections: 'Network Server' and 'CmWAN Server'. The 'Network Server' section has radio buttons for 'Disable' and 'Enable' (selected), and a text input for 'Network Port *' with the value '22350'. The 'CmWAN Server' section has radio buttons for 'Disable' (selected) and 'Enable'. At the bottom, there are 'Apply' and 'Restore Defaults' buttons, with 'Apply' highlighted and labeled '3'. A large teal circular icon with a server rack symbol is on the right. A note at the bottom states: '(*) Changes only take effect after restarting CodeMeter'.

Licenses from Server

Connecting to a CodeMeter WebAdmin server. (1)

The screenshot displays the CodeMeter WebAdmin interface. At the top, the WJIBU SYSTEMS logo is on the left, and the CodeMeter WebAdmin title is in the center. The navigation bar includes Dashboard, Container, License Monitoring, Diagnosis, Configuration, and Info. A sub-menu is open under Configuration, showing options for Basic, Server, and Advanced. The 'Server Search List' option is selected. Below the navigation, there are tabs for Server Search List, Proxy, WebAdmin, and Backup. The 'Server Search List' tab is active, showing a list with one entry: '1. SDET2220'. A blue box highlights the 'add new Server' button at the bottom left of the list. Another blue box highlights the 'Server Search List' menu item. A third blue box highlights the 'SDET2220' entry in the list. At the bottom right, there are 'Apply' and 'Restore Defaults' buttons. A circular graphic with server icons is visible on the right side of the page.

Licenses from Server

Connecting to a CodeMeter WebAdmin server. (2)

The screenshot displays the CodeMeter WebAdmin interface. The top navigation bar includes 'Dashboard', 'Container', 'License Monitoring', 'Diagnosis', 'Configuration', and 'Info'. The 'Configuration' menu is expanded, showing 'Basic Configuration' and 'Server Search List'. The 'Server Search List' page has tabs for 'Server Search List', 'Proxy', 'WebAdmin', and 'Backup'. The main content area shows a list of servers with one entry 'SDET2220'. Below the list is a form to add a new server, with a text input field containing '172.21.0.99' and an 'Add' button. A blue box highlights the input field, and a blue arrow points to it with the text 'Enter IP address of the PC acting as a server.'



Licenses from Server

Connecting to a CodeMeter WebAdmin server. (3)

The screenshot displays the CodeMeter WebAdmin interface. At the top left is the WJBU SYSTEMS logo. The main title is "CodeMeter WebAdmin". The navigation bar includes "Dashboard", "Container", "License Monitoring", "Diagnosis", "Configuration", and "Info". The "Configuration" menu is expanded, showing "Basic Configuration" and "Server Search List". The "Server Search List" page has tabs for "Server Search List", "Proxy", "WebAdmin", and "Backup". The main content area shows a list of servers:

Server ID	Server Name	Actions
1.	SDET2220	Trash, Down Arrow
2.	172.21.0.99	Trash, Up Arrow

Below the list is a "+ add new Server" button. At the bottom right, there are "Apply" and "Restore Defaults" buttons. A red box highlights the "Apply" button, with a red box containing the number "5" above it. To the right of the list is a circular icon depicting two server racks connected by a line.


Licenses from Server

Connecting to a CodeMeter WebAdmin server. (4)



Refresh to see the available servers.



Application Scenarios



Application Scenarios


Process optimisation

- Assume following process: Front cover → Measuring → Back cover → Pressing → Heating → Delivering
- Which of the two configurations below is more efficient?



Application Scenarios


PLC programming (example with Siemens PLC)



PLC programm




Real PLC



Soft PLC



EasyPort





EzOPC



Help Menu

- Detailed help system with a couple of introductory examples, but not focusing on CP Lab / Factory explicitly.



Keyboard Shortcuts

SHIFT + left mouse button	Move user perspective in view mode
CTRL + left/right mouse button	Rotate user perspective in view mode
+ / -	Zoom in / zoom out
V / H	Front / rear view
A	Top view
R	Right view
L	Left view
SHIFT + O	Full screen
F5	Start / stop simulation
CTRL + F5	Reset simulation
CTRL + E	Toggle between view (default cursor) and edit mode (crosshair cursor)
CTRL + . / CTRL + ,	Rotate selected object by +/-90° in edit mode
CTRL + T	Show model explorer
CTRL + F9	Compile robot / PLC programs
CTRL + SHIFT + M	Show model libraries


Options Setting

- CIROS has two option settings, application options and model options. There are for different configurations
- Application options configure the whole CIROS application, regardless of the models.
- All changes made in model options are only applied to the active model.

Application Options

File → Application options


- Define data import and export
- General display settings
 - Frequently used to reduce computational load.
- Editor settings
- Warning options for modelling and transport
- ORL
- Position and paths
- Programming tools settings
- VR devices configuration
- Workspaces



Model Options

Settings → Model options

- Collision detection
- Model display settings
 - Background
 - Floor
 - Sensors
 - Etc.
- Fault simulation in teacher mode
- Interfaces
 - MES4
 - Fleet Manager
- Data logging
- Model explorer settings
- Modelling
- Online management for Mitsubishi robots
- ORL
- Overlays
- Model Simulations
- Video recorders





Where to look for the options?

- Structure and elements of models
 - Modell Explorer: [Modelling](#) → [Model Explorer](#) or Ctrl+T
 - Often used
- Properties of elements in the model
 - Properties: [Modelling](#) → [Properties](#) or Alt+Enter
 - Assistant
 - For example [Settings](#) → [Collision detection](#)
 - Often used
- Properties of model
 - Model options: [Settings](#) → [Model options](#) or Ctrl+I
 - Used fairly
- Properties of CIROS program
 - Application options: [Files](#) → [Application options](#) or Ctrl+Shift+I
 - Seldom used

Window's Size


- Windows size for Application Window and Modell Window can be adjusted.




Introduction to Festo CP-System

Building blocks

Resource




Module / Ressource



Carrier


Building Blocks

Carrier and product



Carrier

+



Palette

+



Product



Product (Smartphone)


Back cover

Inlay (optional)

- PCB
- Fuses

Front cover

- Slot for screen
- An opening for Button
- Able to drill holes for screw thread



Covers are available in four colours




Terms & Definitions

Parts


- Set of all objects, except Robotinos, that are moving around within a CP Lab / Factory.
- Parts get identified by a unique part number (PNo).
- Six different subclasses.

External production parts	Parts not produced by CP Lab / Factory
Production parts	Parts produced by CP Lab / Factory
Boxes	Transport workpieces from one production facility to another
Pallets	Mounted on top of the carriers
Carriers	Move (external) production parts on the conveyor belts.
Undefined	Containing all unknown parts or objects, typically used to represent faulty parts.


External production part



Carrier



Production part




Box



Undefined



Pallet



Standard Part Numbers


Supported part numbers

25 31	Pallet Carrier
110 / 109 / 108 / 107	Raw material front cover black / grey / blue / red
111 / 112 / 113 / 114	Back cover black / grey / blue / red
210 / 310 / 410 / 510	Front cover black / grey / blue / red
x11 / x12 / x13 / x14 (x = 2, 3, 4, 5)	Front cover in black / grey / blue / red including PCB / front fuse / rear fuse / both fuses
1y11 / 1y12 / 1y13 / 1y14 (y = 2, 3, 4, 5)	Front and back cover in black / grey / blue / red including PCB / front fuse / rear fuse / both fuses
26 / 120 / 130	Unknown workpiece / PCB / fuse


- Supported part numbers are parts that can be booked into a high-bay warehouse at simulation time t=0s.
- All other part numbers – in particular user-defined parts – can be generated and stored into a high-bay warehouse during production, but not replicated in a warehouse at simulation startup at t=0s.

Standard Part Numbers


Some examples




Part number 412
(blue, PCB, front fuse)



Part number 513
(red, PCB, rear fuse)



Part number 1214
(black, both fuses, back cover)



Part number 109
(grey, raw material front cover)

Groups and Utilities

- **Groups** define sets of parts somehow belonging to each other.
- Besides the list of parts belonging to a group each group also contains a unique ID and a description.
- There is no restriction on the number of different types of parts a group consists of.
- Parts can be attached to an arbitrary number of groups or not attached to any group at all.
- Typically, groups are used to define **zones** and **restrictions** wrt. buffer positions of a high-bay warehouse.
- **Utilities** defines a special subclass or group of parts, containing all carriers, boxes, and pallets, which are the ones that are responsible for transport purposes.



Carriers

- In CIROS two different kinds of carriers are supported
- CP-F-CARRIER: Carriers without Pallets




- CP-L-CARRIER: Carriers including Pallets



- **Carriers without Pallets** must be used in cases in which a CP Factory high-bay warehouse is part of the CIROS model, since the workpieces will be stored and released together with pallets in this situation!
- In all other cases **Carriers including Pallets** should be used
- Rule of thumb according to the number of carriers used within a CIROS model: **One carrier per conveyor belt.**

Resources and Buffers

- **Resources** are the production facilities (modules) of the CP Lab / Factory.
- Each resource is represented by a unique ID.
- Periodically, each resource sends a status update to MES4 and gets process data back when initiating a corresponding service call.
- Robotino is a special kind of a mobile resource.
- Some resources contain **buffers**, like the high-bay warehouse, the robot assembly station, Robotinos, and the branches.
- Each buffer consists of at least one buffer position to store parts, one per buffer position.
- MES4 could be configured in such a way that, based on **zones** and **restrictions**, buffer positions are allowed to store specific types of parts only.




CIROS Model

CIROS Model

- Preliminary remark: Each CIROS model not only consists of the [modx/ini](#) files but also the folders [CF](#) and [Textures](#), storing the internal PLC programs and textures
- It is highly recommended, to store each CIROS model in a separate folder!
- **Important:** Do not copy the [modx/ini](#) files only, but the entire folder containing the subfolders [CF](#) and [Textures](#), too!

A CIROS project folder:



Name	Änderungsdatum	Typ	Größe
CF	09.04.2019 10:29	Dateiordner	
Textures	09.04.2019 10:29	Dateiordner	
CIROS.ini	09.04.2019 10:33	Konfigurationseinstellungen	61 KB
CIROS.modx	09.04.2019 10:33	CIROS Model	88.236 KB


Collaborative Working

- Several users can work on the same model at the same time.
- When a user changes the model, other users will receive a notification.
- However, simultaneous changes and changes that crossed over time cannot be merged together.

Model's Structure



Elements in a model

- Structures of elements
 - Model / Environment
 - Objects: Logical unit
 - Sections: Static body
 - Hulls: Geometries
- Positions based on coordinate system
- Hulls
 - Geometric primitives
 - Box, sphere, etc.
 - Polyhedron
 - Vertex, Facet



Model's Structure

- Objects in the structure tree
 - Placed on the highest hierarchy in the model or
 - Placed under an object
- Object's nomenclature
 - Parent object: superordinate object
 - Child object: child of a parent object
- Usage
 - For a clear structure
 - Definition of static assembly
- Moving child objects
 - During modelling: always
 - During simulation: only when the object is an object assembly
 - Select **object** → **right click** → **Edit** → **Assembly**



Elements and Coordinate Systems




- Different coordinate systems, each might has same or different origins
 - World : based on world coordinate system
 - Object : based on coordinate system of the parent object
 - Section : based on coordinate system of the section it belongs to
 - Hull : based on coordinate system of the hull

CIROS Model

Create a CIROS model

- Recommended way of defining a new CIROS Model


1. Choose **FILE** → **New** → **Model assistant**
2. Specify the model's name and enable **Create a subfolder with the same name as the model**.
3. **Important:** Do not select a robot, these ones are not the ones integrated within CP Lab / Factory! Choose **Empty model** instead!



Window Layout

Model explorer →

Properties window →



← View window

Available model libraries

Model vs. real time
 If the model time is printed in red, the system is not able to perform the simulation in real time.

Toolbar can be configured

- ✓ Standard
- ✓ View
- ✓ Controller

- ✓ Programming
- ✓ Modeling extensions
 - Collision detection
- ✓ I/O monitors
 - PLC Switch
- ✓ Fault simulation
 - 3D marker
 - Mitsubishi online connection
 - OPC server
 - OPC UA server
 - Python
 - RAPID programming tools
 - VR
 - Simulation film
 - Video recorder

- Hide all

- Save as default
- Use default
- Reset default

View and Edit Mode

View mode

- Change user perspective onto scene
- Default cursor:




Edit mode

- Place, move, rotate objects within scene
- Crosshair cursor:



Standard Views



Standard Views



Default setting




Front view




Rear view




Top view



Left side view




Right side view



Bottom view



View Used when Working with CIROS Model

- With respect to the z-axis all CP Lab / Factory modules within the library have been prepared in such a way that
 - Conveyor belts, CNC milling stations, robot assembly stations, warehouses, and Robotinos are placed on the floor ($z = 0\text{mm}$)
 - Carriers, deflections, sources, sinks, and application modules flush with the conveyor belts' upper edges ($z = 975\text{mm}$)
- **Important**
 - Switching to **Top View** ensures that the z-values remain constant when moving components within the scenery!
 - **Snapping into place** of modules works well in **Top view** only!



Snapping into Place


- When placing application modules onto conveyor belts, it is not necessary to adjust them as precisely as possible.
- Just putting the phrases **Application**, **CPLab**, **Modul**, etc. on top of each other is all one has to do!
- Same holds for mounting deflections, docking kits, and so on.



Floor and Background


- Floor can be activated or deactivated.

1. Right click in [view window](#).
2. Check or uncheck [Floor](#).




- Floor's size and muster can be adjusted.

- Open [Settings](#) → [Model options](#) → [Display](#) → [Floor](#).



- Background can be adjusted.

- Open [Settings](#) → [Model options](#) → [Display](#) → [Background](#).




Import Data

- It is possible to import a model from CAD data.

CP-System Model Libraries

Open Model Libraries Window

Modelling → Model libraries




Model Library Festo CP System

- There are four groups containing CP Lab / Factory modules

Name	Description
CP-Application	Application modules
CP AR	AR Marker for Festo Didactic Augmented Reality
CP Factory	CP-Factory based modules and stations
CP Lab	CP-Lab based modules
CP Mobile Robots	Robotino related modules
CP-Models	CP-Lab standard systems with configured MES4 v1 database

- For each module there is a brief description and a tiny image.




Model Library Festo CP System

CP Application

Module	Description
CP-AM-CAM	Camera inspection
CP-AM-DRILL	Drilling
CP-AM-HEAT	Heating tunnel
CP-AM-iDRILL	Drilling module with own PLC
CP-AM-iPICK	Pick by light with own PLC
CP-AM-LABEL	Labelling printer
CP-AM-MAG_BACK	Back cover magazine
CP-AM-MAG_FRONT	Front cover magazine
CP-AM-MANUAL	Manual working place
CP-AM-MEASURE	Analog measurement
CP-AM-MPRESS	Muscle press
CP-AM-OUT	Workpiece output
CP-AM-PRESS	Pressing
CP-AM-TURN	Workpiece flipping


- CP Application
 - CP-AM-CAM
 - CP-AM-DRILL
 - CP-AM-HEAT
 - CP-AM-iDRILL
 - CP-AM-iPICK
 - CP-AM-LABEL
 - CP-AM-MAG_BACK
 - CP-AM-MAG_FRONT
 - CP-AM-MANUAL
 - CP-AM-MEASURE
 - CP-AM-MPRESS
 - CP-AM-OUT
 - CP-AM-PRESS
 - CP-AM-TURN
 - CP AR
 - CP Factory
 - CP Lab
 - CP Mobile Robots
 - CP-Models



Model Library Festo CP System

CP AR

Module	Description
CP-AR-GUI	CP-AR QR-Code to the AR server.




Model Library Festo CP System

CP Factory

Module	Description
CP-F-ASRS20-B 	Automated Storage Retrieval System for boxes
CP-F-ASRS32-P	Automated Storage Retrieval System for parts and pallets
CP-F-BRANCH	Branch base module
CP-F-BUF-B 	Manual working place with automated box transfer
CP-F-BUFROB-B 	Part transfer between box and CP-Factory line with robot
CP-F-BUFROBM-B 	CNC milling application attached to robot and box transfer
CP-F-BYPASS	CP-Factory base module with bypass belt
CP-F-CARRIER	15 carriers for CP-Factory base modules without pallet
CP-F-DEFLECTION180	Passive 180° deflection
CP-F-FEEDROBM	CNC milling application attached to robot and CP-F linear
CP-F-LINEAR	CP-Factory base module with two parallel conveyor belts
CP-F-RASS	Robot assembly station
CP-F-SINK	Sink to remove carriers, pallets, workpieces
CP-F-SOURCE	Source to generate carriers, pallets, workpieces

- Festo CP System
 - CP Application
 - CP AR
 - CP Factory
 - CP-F-ASRS20-B
 - CP-F-ASRS32-P
 - CP-F-BRANCH
 - CP-F-BUF-B
 - CP-F-BUFROB-B
 - CP-F-BUFROBM-B
 - CP-F-BYPASS
 - CP-F-CARRIER
 - CP-F-DEFLECTION180
 - CP-F-FEEDROBM (Mitsubishi)
 - CP-F-LINEAR
 - CP-F-RASS (Mitsubishi)
 - CP-F-SINK
 - CP-F-SOURCE
 - CP Lab
 - CP Mobile Robots
 - CP-Models



Add

CP System


CP System Modellbibliothek

Model Library Festo CP System

CP-Models





Module	Description
CP Lab 404-1	Standard CP Lab system with four stations and configured MES4 v1 1. Front cover magazine 2. Analog measurement 3. iDrill 4. Workpiece Output
CP Lab 406-1	Standard CP Lab system with six stations and configured MES4 v1 1. All modules in CP Lab 404-1 2. Back cover magazine 3. Pressing
CP Lab-408-1	Standard CP Lab system with six stations and configured MES4 v1 1. All modules in CP Lab 406-1 2. Pick by light 3. Labelling
CP Lab 410-1	Standard CP Lab system with six stations and configured MES4 v1 1. All modules in CP Lab 408-1 2. Camera inspection 3. Turning
SAP4School	Model for virtual commissioning of SAP4School

- v Festo CP System
 - > CP Application
 - > CP AR
 - > CP Factory
 - > CP Lab
 - > CP Mobile Robots
 - v CP-Models
 - CP Lab 404-1
 - CP Lab 406-1
 - CP Lab 408-1
 - CP Lab 410-1
 - SAP4School



Configuration in Properties Section CP System


- For almost all components there is a section **CP System** as being part of the corresponding Properties menu.
- Represents the options that can be defined at the HMIs of a real CP Lab / Factory
 - MES ID
 - Traffic jam control
 - Energy saving (stopping the belts whenever possible)
 - Behavior of branches
- Additionally, one can configure some CIROS internal parameters not available on a real CP Lab / Factory.



Configuration in Properties Section CP System

Define MES ID (1)

- MES ID = 0 → Default mode without using MES4
- MES ID > 0 → MES4 mode
- Note, that the default mode of CIROS is not equal to the default mode of a real CP Lab / Factory!
- If the MES ID of at least one component is greater 0, running the CIROS simulation without MES4 results in an error message!




```
Messages
10061 -> Connection refused
MES connection:
Connect error #10061
10061 -> Connection refused
MES connection:
Connect error #10061
10061 -> Connection refused
MES connection:
Connect error #10061
10061 -> Connection refused
```

Configuration in Properties Section CP System

Define MES ID (2)

- Typically, MES ID is defined with one of the two ideas below:
 - Based on the MES IDs of a similar real CP Lab / Factory.
 - According to the default process to be performed, starting with MES ID = 1 for the component which is executing the first step of the process.
- Constraints
 - MES IDs must be unique throughout the entire model .
 - Each MES ID must be greater 0.
 - Definition of IDs within CIROS and MES4 must match each other.




CP-AM-iDRILL

Configure x-axis linear drive

1. Configure axis lower limit, upper limit and maximum velocity.
 1. In Model Explorer, select CP-AM-iDRILL → Mechanik.
 2. In Properties, select Axes → Axis parameters.
 3. Adjust Lower limit, Upper Limit and Max. velocity.


2. It is possible to see the position of the drill bit in model window.
 1. In Properties, select Axes → DH parameters.
 2. By dragging the scale XAchse at bottom, the drill bit will move accordingly



CP-AM-iDRILL

Object Mechanik (1)

- The object **Mechanik** has type **Mechanism**. It is a **double acting cylinder**.
- Object type double acting cylinder in CIROS has following attributes, which can be assigned to I/O. By default, following attributes are connected.
- The attributes can be viewed in **CP-AM-iDRILL → Mechanik → Section XAchse → Properties → Mechanism**.



Note: Terms might varies in different language.

Type Cylinder, double-acting	
Attribute	Value
Retract [I/O]	XAchse_nach_links
Extend [I/O]	XAchse_nach_rechts
Speed [input]	
Retracted [output]	XAchse_links
Extended [output]	XAchse_rechts
Actual position [output]	
Movement characteristics (.csv)	
Min. limit defined by grip relation [gpp]	
Max. limit defined by grip relation [gpp]	
Pressure switch retracting [output]	
Pressure switch extending [output]	

CP-AM-iDRILL

Object Mechanik (2)

- It is possible to assign own I/O to the attribute.
- In this example, An analog output ActualXPosition is assign to the attribute Actual position.

Output	Index	Type	Value	Connected inputs
XAchse_links	000	Digital	0	1
XAchse_rechts	001	Digital	0	1
ZAchse_oben	002	Digital	1	1
ZAchse_unten	003	Digital	0	2
ZAchse_nach_oben_BremseLos	004	Digital	0	0
ZAchse_nach_unten_BremseLos	005	Digital	0	0
ActualXPosition	000	Analog	0.000000	0

1. Add a new analog output with name **ActualXPosition** in object **Mechanik**.
2. In Model Explorer, select **CP-AM-iDRILL** → **Mechanik** → Section **XAchse**.
3. In Properties, select **Mechanism**.
4. In Attribute table, select the row **Actual position [output]**.
5. Click on the drop down list at the bottom, select **ActualXPosition**.
6. Click **Apply**.

Attribute	Value
Retract [I/O]	XAchse_nach_links
Extend [I/O]	XAchse_nach_rec...
Speed [input]	
Retracted [output]	XAchse_links
Extended [output]	XAchse_rechts
Actual position [output]	ActualXPosition
Movement characteristics (.csv)	
Min. limit defined by grip relation ...	
Max. limit defined by grip relation...	
Pressure switch retracting [output]	
Pressure switch extending [output]	

<Nothing> 5 Wizard Apply ?

ActualXPosition

CP-AM-iPICK


Configuration in properties section CP System

Property	Description
Working time (s)	Working time required by the worker to finish an operation (valid for CIROS and CIROS/MES4).
Target number	Part number of the part to be replicated by the worker (valid for CIROS default mode only).

1 object selected

Properties


Property	Value
CP-AM-iPICK	
Working time (s)	5.00
Target number	210



CP-AM-MAG_BACK

Configuration in properties section CP System

Properties	Description
Automatic Mode	In “Automatic Mode” the magazine will be filled automatically during simulation.
Colour Workpiece	Defines the color of the back covers stored in the magazine. By enabling “Manual Override” the user can specify the color of each individual cover to be replicated.




CP-AM-MAG_FRONT

Configuration in properties section CP System

Properties	Description
Automatic Mode	In "Automatic Mode" the magazine will be filled automatically during simulation.
Colour Workpiece	Defines the color of the front covers stored in the magazine. By enabling "Manual Override" the user can specify the color of each individual cover to be replicated.
Workpiece	Defines the front cover type, is it a raw plastic block, front cover without drilled holes or final front cover.
Percentage Rotated Workpieces	Fault injection option, defines percentage of faulty part filled to the magazine.

Default orientation



Rotated orientation

Properties

Parameter	Value
WS_Quelle_Senke_1	
Automatic Mode	Enabled
Color Workpiece	Black
Workpiece	Manual Override
Replicator_WS_1	
Percentage Rotated Wo...	Black
	Grey
	Blue
	Red


Color Workpiece
Color of the workpiece to be replicated

Workpiece
Front cover without holes
Raw material
Front cover without holes
Front cover

CP-AM-MANUAL


Configuration in properties section CP System

Properties	Description
Working time (s)	Working time required by the worker to finish an operation (valid for CIROS and CIROS/MES4).
Target number	Part number of the part to be replicated by the worker (valid for CIROS default mode only).
Percentage Faulty Fuses	Fault injection option. In case the worker must replicate workpieces with fuses, one can specify the percentage of “faulty” fuses assembled (faulty fuses are highlighted in red) .
Percentage Rotated Workpieces	Fault injection option. Percentage of workpieces placed in a rotated orientation (upside down).



Faulty fuses are shown in red

Default orientation



Rotated orientation

Properties X


<ul style="list-style-type: none"> General Pose Dimension Visualization Extended Info ORL Bus client Collision detection Connectors Gamepad IO Fault Measuring Physics simulation Process geometry CP System 	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Property</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td colspan="2"><input checked="" type="checkbox"/> CP-AM-MANUAL</td> </tr> <tr> <td>Working time (s)</td> <td>5.00</td> </tr> <tr> <td>Target number</td> <td>210</td> </tr> <tr> <td colspan="2"><input checked="" type="checkbox"/> Replicator_WS</td> </tr> <tr> <td>Percentage Faulty Fuses Rear</td> <td>0.00</td> </tr> <tr> <td>Percentage Faulty Fuses Front</td> <td>0.00</td> </tr> <tr> <td>Percentage Rotated Workpieces</td> <td>0.00</td> </tr> </tbody> </table>	Property	Value	<input checked="" type="checkbox"/> CP-AM-MANUAL		Working time (s)	5.00	Target number	210	<input checked="" type="checkbox"/> Replicator_WS		Percentage Faulty Fuses Rear	0.00	Percentage Faulty Fuses Front	0.00	Percentage Rotated Workpieces	0.00
Property	Value																
<input checked="" type="checkbox"/> CP-AM-MANUAL																	
Working time (s)	5.00																
Target number	210																
<input checked="" type="checkbox"/> Replicator_WS																	
Percentage Faulty Fuses Rear	0.00																
Percentage Faulty Fuses Front	0.00																
Percentage Rotated Workpieces	0.00																



CP-AM-MEASURE


Configuration in properties section CP System

Properties	Description
Measurement Variation	Fault injection option, adds some random “noise” with Gaussian filter to the measured value.



Properties X



Property	Value
<input checked="" type="checkbox"/> Messen <ul style="list-style-type: none"> Measurement Variation 0.300 	



CP-AM-OUT

Configuration in properties section CP System



Properties	Description
Automatic Mode	In “Automatic Mode” workpieces will be removed from the ramps automatically during simulation. Otherwise, one might run into a traffic jam due to slides full!



CP-AM-TURN

Configuration in properties section CP System


Properties	Description
Gripper Position	Before starting the simulation, one must specify whether front covers or entire workpieces (i.e., front & back covers pressed together) should be rotated upside down.



CP-F-BRANCH / CP-L-BRANCH

Configuration in properties section CP System



Properties	Description
Traffic Jam	Stop carrier if conveyor belt is occupied.
Conveyor Belt	Stop conveyor belt while application is running.
Behaviour of Carrier Shunt	Percentage of carriers without an order turning to the right.



CP-F-RASS

Configuration in properties section CP System

Properties	Description
Traffic Jam	Stop carrier if conveyor belt is occupied.
Conveyor Belt	Stop conveyor belt while application is running.
Behaviour of Carrier Shunt	Percentage of carriers without an order turning to the right.
Automatic Mode	In automatic mode PCBs in the box will be created automatically regardless of buffer in MES4.
ID for the box	If the box is not created by MES, this will be the ID of the box.
Percentage Faulty Fuses	Percentage of “faulty” fuses assembled by the robot assembly station. Faulty fuses are highlighted in red.





CP-MR-C / CP-MR-B

Configuration in properties section CP System

Properties	Description
RFM ID	Unique ID, mandatory for the Festo Fleet Manager to get access to a particular Robotino .

Note:


- CP-MR-C stands for Cyberphysical-Mobile Robot-Carrier.
- CP-MR-B stands for Cyberphysical-Mobile Robot-Box.
- RFM stands for Robot Fleet Manager.



CP-MR-DOCK


Configuration in properties section CP System

Properties	Description
Station ID	Unique ID, mandatory for the Festo Fleet Manager to differ between the various docking positions a Robotino could dock to within a model.
Dock position	Number of conveyor belts available for exchanging workpieces (always 1 for carrier Robotinos).



Sources and Sinks


- Sources and Sinks can be used to dynamically replicate and remove workpieces during the simulation, either via pushing the corresponding button or automatically controlled by CIROS.
- There are different versions of sources and sinks, one set to be applied to CP Lab conveyor belts and one set to be used in combination with CP Factory components.
- Typically, sources and sinks come into play whenever one wants to model a single conveyor belt & application module.



Sources and Sinks

Remarks


- Depending on the model, sources and sinks may have to be rotated to operate correctly!



Sources and Sinks



Configuration in properties section CP System

Properties	Description
Automatic Mode	If enabled carriers / pallets / workpieces within the range of the sink will be removed automatically during simulation.



Adding New Libraries to CIROS

1. Open an already existing model or create a new CIROS model like shown before.
Note: Model libraries window can only be opened when a CIROS model is opened or created!
2. Open the model libraries window
 - MODELING → Model libraries or
 - CTRL + SHIFT + M
3. Click on the right mouse button within the tree view part of the model libraries to open the corresponding context menu
4. Execute [Add folder to list...](#)
5. Select the folder in which the model library to be added is stored and press **OK**



Project Management

CP System Simulation Controller

Industrial Robotic Language (IRL)

- Located in [⟨project file⟩\CF\CPSystems](#).
 - Scripts can be opened in CIROS in project management window.
 - [Programming](#) → [Project management](#)
 - Main simulation controller.
 - Communicates with MES4 and Fleet Manager.
 - Control the model movements.
 - Read input values and write the output values.
-
- Note: RFID data structure in CIROS is different from in real system.

Python

- Located in [⟨project file⟩\CF\py](#).
- Translate MES4 part number to CIROS part number.
- Replicates workpieces and boxes.
- Send string requests to MES4

CP System Simulation Controller

Controllers > SPS_A

Project assignment

Project: CPSystem_Overall

Configuration

Code sequence trace

Projects > CPSystem_Overall (IRL)

General

Name: CPSystem_Overall
 Path: C:\Users\festo\Documents\CIROS\Projects\TrainingAdv_2\CF\CPSystems\CPSystem_Overall.prjx
 Compiler: cirosCompilerIRL

Projects > CPSystem_Overall (IRL) > Files

File name	Path
Main program	
CPSystem_Overall.irl	[Project]\
Program files	
MES_200.irl	[Project]\Shared\
RFID_100.irl	[Project]\Shared\
Application_Storage.irl	[Project]\Shared\
Application_LabStorage.irl	[Project]\Shared\
Application_Robot.irl	[Project]\Shared\
Applications.irl	[Project]\Shared\
MES_Com.irl	[Project]\Shared\
CPLab.irl	[Project]\Shared\
CPLabBridge.irl	[Project]\Shared\
CPLabStorage.irl	[Project]\Shared\
CPFactory.irl	[Project]\Shared\
CPFactoryBranch.irl	[Project]\Shared\
CPFactoryByPass.irl	[Project]\Shared\
CPFactoryStorage.irl	[Project]\Shared\
CPFactoryRobot.irl	[Project]\Shared\
CPBoxStorage.irl	[Project]\Shared\
CPBoxBuffer.irl	[Project]\Shared\



Annotations:

- A project is assigned to the controller. (Arrow from SPS_A to Project assignment)
- A project contains different controller scripts. Main program is called cyclically and sub programs are called in main program. (Arrow from Project assignment to Files table)
- Project information. (Arrow from General section to Project assignment)

Simulation

Simulation Kernel

- Settings → Model options allows for configuring the way in which the simulation status will be updated during simulation.
- Mainly characterized by two parameters,
 - model computation
 - relationship model time / real time




Simulation Kernel

Model computation

- **Simulation increment** specifies the intervals in which the simulation status and its visualization will be updated.
- Default of 0.04s means 25 updates per second of **model** time.
- Provided that the computer CIROS is running on is powerful enough, this results in real-time behavior!
- Increasing the **Simulation increment** leads to fewer calculations of simulation states which might lead to some strange behavior.


Rule of thumb: Do not touch the default value for the simulation increment!



Simulation Kernel

Relationship model time / real time (1)


- **Progress preferably in real time**
 - Progress of model time is restricted to real time.
 - Default option, ensuring that a CIROS model behaves like a similar real CP Lab / Factory system (wrt. process times).
- **Allow the skipping of model visualizations**
 - By default, the visualization gets updated with every simulation increment.
 - Skipping some of these calculations might give CIROS the chance to keep track with real time.
- **Allow the skipping of waiting times**
 - To keep track with real time, one can also skip simulation updates when nothing has changed.



Simulation Kernel

Relationship model time / real time (2)


- Progress faster than real time (if possible)
 - Allows CIROS to simulate as fast as the underlying hardware environment allows.
 - Skipping some visualizations results in even faster computations.
 - The speed can be set to adjust how fast the simulation should be in **Model visualization after __ simulation increments ...**
 - For example, to simulate 5x faster than real time, configure it as follow: Model visualization after 5 simulation increments ...



Simulation Kernel

Relationship model time / real time (3)

- Progress slower than real time
 - Mainly for debugging purposes.



Simulation Kernel

Remarks

- Timestamps in CIROS are based on **model** time, while in MES4 timestamps are based on **real** time!
- Example of what could happen if model time differs from real time.
 - Assume that a single step of an MES4 workplan takes 10s of real time on a corresponding real application module.
 - If CIROS is keeping track with real time (model time = real time), the step will be simulated in 10s of real time, too.
 - If CIROS is running faster, this step still requires 10s of model time, but CIROS can simulate that 10s of model time in (to give an example) 2s of real time. MES4 will record that the operation required only 2s of real time!
- Therefore, if CIROS is simulating **faster/slower than real time** the process times the MES4 is measuring are **no longer reliable**!
- Due to the different ways of measuring time, it is **not** possible to simulate the annual production of a CP Lab / Factory within a few hours!

Reduce Simulation Computing Requirement


Disabling shadow simulation

- Calculating shadows during simulation allows for a more natural appearance of the model but requires a lot of CPU/GPU performance. **Simulation might slow down significantly!**
- For less powerful hardware environments disabling shadows improves overall simulation performance.
 - Screen Space Ambient Occlusion (SSAO)
 - Shadow light sources


Reduce Simulation Computing Requirement

Screen Space Ambient Occlusion (SSAO) (1)

- SSAO is a computer graphics technique for efficiently approximating the ambient occlusion effect, caused by ambient lighting, in real time.
- While the implementation in principle is quite fast, it nevertheless requires substantial computation power.



without SSAO





with SSAO

Reduce Simulation Computing Requirement

Screen Space Ambient Occlusion (SSAO) of a model (2)


- Use [Model Explorer](#) → [Model](#) → [Lightning](#) → [Ambient light](#) → [Properties](#) to disable or enable Screen Space Ambient Occlusion.




Reduce Simulation Computing Requirement

Shadow light source 1

- Usually, light source 1 is causing shadows, while light sources 2 to 7 and headlight do not have that option
- If enabled the simulation of that shadow depends on the position of light source 1 and its properties



without shadows caused by light source 1





including shadows

Position & direction of
light source 1

Reduce Simulation Computing Requirement

Shadow light source 1 of a model


- Use [Model Explorer](#) → [Model](#) → [Lighting](#) → [Light source 1](#) → [Properties](#) to disable or enable shadow simulation.



Reduce Simulation Computing Requirement

SSAO and shadow source of CIROS application.




- Disabling shadows like shown on the slides before is valid for a particular model only!
- To disable or enable shadows regardless of the model use [File](#) → [Application options](#) → [Display](#).



Code Sequence Trace

- Simulation is controlled by the chosen controller in the project and its code, whether PLC controller or robot program, can be traced during the simulation.


- The function can be activated in [Programming](#) → [Project Management](#).
- To enable or disable tracing of a particular controller, check the option [Code sequence trace](#) for the controller.
- To enable or disable tracing of all controllers in the project, right click on [Controllers](#) and choose the option.



Visualising Sensor Data


- Depending on the model options, measured range and values are not visualized by default in view window.
- Displaying sensors can be achieved by configuring [Settings](#) → [Model options](#) → [Display](#) → [Sensors](#)
- Measured value depends on the sensor type

Light barrier	Obstacle detected
Distance sensor	Distance to obstacle
Colour sensor	Colour




Visualising Sensor Data

- In rare cases one must enable the visualization of sensor data by modifying the properties of each individual sensor.



Sensor visualisation off



Sensor visualisation on

Model Explorer

Name	Type
Outputs	Folder
Basis	Section

1 object selected

Properties



General
Pose
Dimension
Visualization
Extended
Info
ORL
Bus client
Sensor
Collision detection
Connectors
Gamepad IO
Fault
Measuring
Physics simulation
Process geometry

SEN Sensor description of Sensor_FS_Lagerichtig

- Sen Sensor type: <Optical sensor>
- Delay element
- Watch lists
- Display**
 - Measuring range: <On>
 - Measured value(s): <On>**
 - Output graph
 - Range graph
 - Measuring range
 - Switching distance: <0.00 mm>
 - Principle of measurement: <Phase correlation>



Data Logging

- Data logging in CIROS allows for storing and visualization of values of inputs, outputs, variables, etc. during simulation.
- Example shown here: Visualization of the time needed for performing a status update.
- Configuration of data logging is available at [Settings](#) → [Model options](#) → [Logging](#).



Data Logging

Simulation speed restricted to real time




Almost all the 40ms the simulation is waiting to avoid being faster than real time.

Time required for updating the simulation status is almost zero in this setup.

Data Logging

Simulation speed as fast as possible without manual working place



Time required for updating the simulation status.

without SSAO shadows

without both, SSAO and light source 1 shadows


Data Logging

Create new profile

- Apart from default data logging profiles, it is possible to log own data to simulate the model built.
- To log own data, a logging profile containing desired data must be created, it can be created in [Settings](#) → [Model Options](#) → [Logging](#) → [Profiles](#).

1. In section [Profile](#), select [New...](#)
2. Give a Name.
3. Use the filter option to filter the selection.
 - Possible data are robot positions, joint coordinates and IOs of the objects.
4. Use the [arrow buttons](#) to select and deselect data.
5. Finally, click [Apply](#) to create the profile.

- Profile created can then be added to logging window in [Settings](#) → [Model Options](#) → [Logging](#), section [General](#).




Virtual Commissioning with MES4

Basic knowledge in Festo MES4 and Fleet Manager is required.

Terms & Definitions

Customers, orders, order number & order position

- MES4 maintains a list of registered customers which are allowed to place customer orders.
- Each **order** has a unique **order number (ONo)** and may consist of a couple of different products and parts to be produced.
- Each production part within an order has its own **order position (OPos)**, ranging from 1 up to the total number of parts of a particular order.
- (ONo, OPoS) is a unique representation of an individual part.




Picture source: MES4 v2 or lower


Terms & Definitions

Operations and parameters

- **Operations** define the functionality of a production step and are executed by resources.
- But, MES4 separates between operations and resources, since there might be several resources able to perform the same type of operation, i.e., operations are not sub-objects of resources but allocated to them.
- Vice versa, some resources can execute more than just one operation.
- Each operation has its own unique ID (**OpNo**) and might have no, one or even quite several parameters to adjust the production step.




Picture source: MES4 v2 or lower



Picture source: MES4 v2 or lower

Synchronise CIROS Parts in Storage with MES4 Buffers

- During the initialization phase of a CIROS simulation run, CIROS will ask for the buffer contents of high-bay warehouses automatically .
- But, whenever the buffer of a high-bay warehouse has changed within the MES4 while the CIROS simulation is running, one must click the **MES 4** button in CIROS view window to transmit these changes to CIROS.




Setting Up CIROS Model for MES4

Import models from model libraries

1. Switch to [Top View](#) within the list of views.
2. Open the model libraries.
3. Select all modules needed and add them to the model.
Note: take care, that components properly snap into place.
4. After adding all modules, select each passive deflection and snap it into place again!
5. Depending on the model,
 1. Integrate sources and sinks if required.
 2. Adjust floor and background.
 3. Disable shadow simulation
 4. Configure the [CP System](#) options for each component, the MES ID in case the CIROS model should be controlled by MES4.

Default Procedure for Setting up MES4

- According to the CIROS model add all resources in MES4.
 - Application modules and Robotino.
 - CP Lab branches (Remark: CP Factory branches are defined implicitly by the MES4 topology) .
 - Define the MES4 ID, IP address, type of PLC (i.e. Siemens) of each resource.
 - Specify the system's topology.
- Start the CIROS simulation and check in MES4 [Production Control](#) → [Resources](#) whether all resources are available and active.
- Define all parts that are required by the various work plans.
- Add work plan(s).
- In case a high-bay warehouse is part of the model, specify the initial load of the corresponding buffers.
- Clear all other buffers (branches, Robotino!).
- Start a production or customer order and check that everything works fine.



Picture	ID	Name	MESMode	AutomaticMode	ManualMode	Busy	Reset	Error1	Error2	IP	Connected
	1	CP-F-GRS								127.0.0.1	
	2	CP-AM-DR								127.0.0.1	
	3	CP-F-RASS								127.0.0.1	
	4	CP-AM-CAM								127.0.0.1	
	5	CP-AM-MA								127.0.0.1	
	6	CP-AM-MP								127.0.0.1	
	7	CP-AM-TU								127.0.0.1	

Picture source: MES4 v2 or lower

Import Model from Python Script


- Python script to generate model with configured MES4 resource ID can be generated from Festo Factory View, which is the successor of Festo MES4 Software.
- The script can be executed in CIROS to configure the CP System setup for virtual commissioning.
- With this option, time to insert the models and to configure the resource IDs is saved.
- However, the carriers are not generated from the code. Thus, they have to be added manually from Festo CP System Model Library.

Import Model from Python Script

1. Create a CIROS model.
2. Select **Extras** → **Python** → **Execute**.
3. Select the python script generated, for example, from Factory View, and click open.
Note: Last python script can be executed again by selecting **Extras** → **Python** → **Execute Again** or shortcut key Ctrl+Shift+W.
4. Go to **top view** or shortcut key A.
5. Open **Model Library** or shortcut key Ctrl+Shift+M.
6. Insert carriers and delete extra carriers.
7. Snap the remaining carriers in place.
8. The model is ready.

Hint:


- In the python script exported from FactoryViews, the modules are snapped in place and MES ID of the resources are set.
- To reduce graphic power consumption and avoid crash, close all windows and minimize Model Window before loading the script.



MES4 Communication Interface


Cyclic status message

- The resources send a status update to MES4 in every second.



Service requests

- Resources or other applications query data from MES4 or write data to MES4.




Terminology in MES4 Messages

Term	Meaning
BoxID	Box ID
BoxPNo	Box part number
BoxPos	Position in box
BufNo	Buffer number
BufPos	Buffer position
ONo	Order number
OPos	Order position
Op	Operation
OpEnd	Operation end
OpNo	Operation number

MES4 Service Requests

- MES4 offers many services that are required for the operation of a plant.
- None of the plants use all services, but all services are available at any time and can be called not only by PLCs but also by other business applications via a TCP/IP connection. In addition, a skilled operator can implement additional services, if they can be mapped to an SQL query of theMES4 database.
- Service calls always follow the request response paradigm, i.e., a client sends a call and MES4 response back.
- Internal controller of CIROS model is the virtual representation of PLC. Thus, it communicates the same way as a real PLC.



MES4 Service Requests

Message classification

- Services are uniquely identified by two characteristics:
 - [MClass](#) (service class)
 - [MNo](#) (service number)
- The MNo is only unique within an MClass. This means that the service with MClass 100, MNo 6 is different from MClass 150, MNo 6.
- They also have a name, but this is of no relevance to the client or to MES4. It is only used for recognition by humans.
- All the messages available can be seen in MES4
 - [Tools](#) → [Com. Simulator](#)
- The messages can be edited
 - [MES4](#) → [Tools](#) → [Config SQL](#)
 - **Note:** Only Administrator can access Config SQL
 - Administrator's password is [SolutionCenter](#)

Example:

MClass	MNo	Name
100	6	GetOpForONoOPos
100	33	GetStepDescription
101	20	OpEnd
150	5	GetBufPos

MES4 Service Requests

Classes

- Service classes on the right are frequently used. For user defined services, any other classes can be used.

MClass	Description
100	Get information from orders and work plans
101	Write information to orders and work plans
110	Request topology related data
150	Request buffers and utilities (incl. boxes) status
151	Write buffers and utilities (incl. boxes) status
200	Request logistic and Robotino information
201	Write logistic and Robotino information

MES4 Service Requests

Message packet overview

Request

Header

- Defined in HeaderGet.xml

Standard input parameters

- Defined in HeaderGet.xml

Service specific parameters

- Defined in MES4 DB

Response

Header

- Defined in HeaderSend.xml

Standard output parameters

- Defined in HeaderSend.xml

Service specific parameters

- Defined in MES4 DB

MES4 Service Based Requests

Data coding

- MES4 allows two different encoding procedures for service requests and responses.
- The first three or four bytes of each packet are TCP Ident header, which indicates which method the packet uses.
- **Binary coding**
 - Binary coding is primarily used for communication with [PLCs](#) on which it is fundamentally easier to handle fixed-address binary data than strings.
 - In the binary procedure, a distinction is still made between the [Siemens](#) format and the [CODESYS](#) format. MES4 also responds to each binary-coded request in the binary procedure of the same format.
- **String coding**
 - Well suited for implementation in high-level languages or for manual tests. Parameter names and values are transmitted in human-readable form.
 - The string procedure also has two forms.
 - The [complete](#) format can be used for both calls and responses.
 - The [abbreviated](#) format is only used in MES4 responses if this was requested in the call. was requested.

Message Request from CIROS

- CIROS behaves the same as PLC in terms of MES4 communication. Thus a **bit** coding is used.
- The messages are written in IRL format and can be found in [CIROS → Programming → Project Management → Projects → CPSystem_Allgemein → Files](#).
- CIROS can communicate with MES4 via **string** coding, too!
- It can be done using one of the functions in CIROS built in python function list, `Environment.sendMESMessage()`.

Project Management


Projects > CPSystem_Allgemein (IRL) > Files

Files

File name	Path
Main program	
CPSystem_Allgemein.irl	[Project]\
Program files	
MES_200.irl	[Project]\Shared\
RFID_100.irl	[Project]\Shared\
Applikation_Lager.irl	[Project]\Shared\
Applikation_LabLager.irl	[Project]\Shared\
Applikation_Roboter.irl	[Project]\Shared\
Applikationen.irl	[Project]\Shared\
MES_Com.irl	[Project]\Shared\
CPLab.irl	[Project]\Shared\
CPLabBridge.irl	[Project]\Shared\
CPLabLager.irl	[Project]\Shared\
CPFactory.irl	[Project]\Shared\
CPFactoryWeiche.irl	[Project]\Shared\
CPFactoryByPass.irl	[Project]\Shared\
CPFactoryLager.irl	[Project]\Shared\
CPFactoryRoboter.irl	[Project]\Shared\
CPBoxLager.irl	[Project]\Shared\
CPBoxBuffer.irl	[Project]\Shared\

Running CIROS and MES4 on Different PCs


CIROS → Settings → Model Options



Address = IP-Address of PC which MES4 is running.

Configure Robotino

- **Note:** MES4 is not communicating with Robotino(s) directly!
- Communication is carried out via the Fleet Manager.
- MES4 is just sending transportation orders like “Go to position A, grab a workpiece, move to position B, and release the workpiece over there” to the Fleet Manager
- Fleet Manager itself selects one of the available Robotino(s) and sends commands like “dock to position A” to the Robotino to fulfill the MES4 order.



Configure Robotino

Fleet Manager

- Command Center
- Position Settings
- Robotino Settings**
- Preferences


List of Robotino's

Robotino ID	MES ID	MES Tag	Robotino Type	Chassis Type
9	9	Carrier-9	Carrier Transporte	Robotino-

Apply Cancel

Parameter	Value
RFMController	
RFM ID	9

Robotino CP-MR-C



Parameter	Value
RFMStation	
Position ID	1
Dock position	1

Docking kit CP-MR-DOCK

Parameter	Value
RFMStation	
Position ID	2
Dock position	1

Position Info

No. of Positions taught: 2

Position List


Position ID	MES ID	Buffer No	Position Tag	Pose Type	Default station	Reserve AGV	Package Typ
1	28	0	Branch 1	CP System	<input type="radio"/>	<input type="checkbox"/>	Carrier
2	28	0	Branch 2	CP System	<input type="radio"/>	<input type="checkbox"/>	Carrier

Apply Cancel

Configure Robotino

Fleet Manager v3 and above

- Option **Fleet Manager used with CIROS** must be activated.




Simulation with Robotino

CIROS, MES4 and Fleet Manager

- Start simulation
 1. Start [MES4](#), [CIROS](#), and [Fleet Manager](#) in any order, but **do not** start the CIROS simulation yet.
 2. In Fleet Manager, if the server is not started, start the Robotino server via the [Start Server](#) button.
 3. Start the CIROS simulation.
 4. Fleet manager: Select all available Robotinos and switch them to [Automatic](#).
 5. Place your MES4 orders.
- Stop simulation
 1. Stopping simulation in CIROS.
 2. Reset the CIROS simulation to $t=0s$.
 3. Fleet manager: Stop the Robotino server via [Stop Server](#).
Note: Server must be stopped!
 4. MES4: Clear all Robotino-related buffers.

Message Request from CIROS


- Like PLC, CIROS Robotino model is the virtual representation of real Robotino. Thus it communicates with Fleet Manager the same way as a real Robotino.
- The communication messages are written in IRL format and can be found in [CIROS](#) → [Programming](#) → [Project Management](#) → [Projects](#) → [RFM_MR](#).



- **Note:** RFM = Robot Fleet Manager, MR = Mobile Robot

Running CIROS and Fleet Manager on Different PCs

CIROS → Settings → Model Options



Virtual Commissioning with Soft PLC


Basic knowledge in PLC programming and TIA Portal is required.

Scenario Overview

- Program your PLC against a virtual mechatronic model
- No risk to your hardware if students make mistakes in program code
- Program modules that you don't physically own or let dozens of students program the same module even if you only own it once

Scenario Overview

All on single PC



Software on different PCs



Process Summary

1. Prepare a CIROS model with the hardware you want to program
2. Create your hardware configuration and I/O tags in TIA Portal
3. Create a PLCSIM Advanced instance and download the hardware configuration
4. Configure the interface between CIROS and your instance
5. Start programming!

Important: CIROS v7.1 is only compatible with Siemens **PLCSIM Advanced v3.0** or above!

Preparing a CIROS Model


- Two approaches are possible:

1. Create a model from scratch

- Maximum flexibility
- Program any CP station you like

2. Load a premade model from the model library


- Get started quickly with minimum effort
- Limited selection of CP systems available



Preparing a CIROS Model

Your model usually needs three basic elements to serve for virtual commissioning with PLCSIM Advanced:


- The **mechatronic system** you want to program
- A **source and sink** to generate and remove carriers with parts
- A **SimController** so CIROS is able to simulate your model



Exercise

Preparing a CIROS model from scratch

1. Create a new empty model.
2. Add your mechatronic system from the model library.
For this exercise, add a CP-L-CONV.
3. Add a source and sink from the model library that matches your system.
For this exercise, add a CP Lab source and sink.
4. Connect the source and sink to your CP Lab module.
5. Switch the PLC in your CP Lab module (it's named **SPS_A**) to PLCSIM Advanced mode.




Starting a PLCSIM Instance

Feel free to choose any PLCSIM Advanced settings that work for you. The only setting relevant to CIROS is the **instance name**. Choose one you like and remember it. You'll need it later.

Some recommendations:

- For **Online Access**, choose **PLCSIM** unless your simulated PLC needs to communicate over the network. This mode makes the connection to TIA Portal effortless
- Leave **Time Scaling** off. CIROS has its own time scale and will make sure the PLC keeps track if you speed up the simulation beyond real-time
- Choose **ET 200SP** for **PLC type** as that matches the physical PLC in most CP hardware systems



Creating the Hardware Configuration and IO Tags in TIA Portal

Hardware configuration



You can configure your PLC in any way you like. Ideally, it should have at least the number of digital and analog I/Os that the physical PLC inside your chosen CP system has.

IO tags

You can freely name your inputs and outputs, as long as the address and the type of an input/output is correct.

If you like you can skip the inputs and outputs that are not connected to anything in your CP system.

Refer to the Festo Didactic [Infoportal](https://ip.festo-didactic.com) (<https://ip.festo-didactic.com>) for an I/O listing of your CP system. Alternatively, find the relevant information in your manual or circuit diagram.



Exercise

Creating the hardware configuration


Detailed instructions how to do the hardware configuration in TIA Portal are beyond the scope of this document. Refer to the courseware 'Device configuration' if you're having trouble.

For this exercise, we're configuring the PLC as we would a real CP-L-CONV module with a Siemens IO-Link 1.1 conformant RFID device.

1. Create a new TIA project
2. Add a S7-1512SP F-1 PN PLC to your project (6ES7 512-1SK01-0AB0)
3. Add two DI 8x24VDC HF (6ES7 131-6BF00-0CA0)
4. Add two DQ 8x24VDC/0.5A HF (6ES7 132-6BF00-0CA0)
5. Add a CM 4xIO-Link (6ES7 137-6BD00-0BA0)
6. Add a server module (6ES7 193-6PA00-0AA0)
7. Set the IO-Link master's input/output type to 64/64 and shift the starting I/O addresses to address 10

Exercise

Creating the hardware configuration



Exercise

Setting up the I/O tags

1. Find the list of I/O addresses for the CP-L-CONV at <https://ip.festo-didactic.com/InfoPortal/CPFactoryLab/hardware/base/datasheet.php?model=CP-L-CONV&lang=en>
2. Create a new tag table
3. Enter all tags listed on the Infoportal into your tag table

Note:

Depending on the revision of a physical CP-L-CONV, any address listed on the Infoportal in byte 18 might require to be shifted to byte 42. This is only relevant if you plan to download this TIA project to a real CP-L-CONV. In CIROS the absolute I/O addresses don't matter.

Exercise

Setting up the I/O tags

CP Lab Conveyor (CP-L-CONV) Overview Datasheet Documentation Media

PLC inputs & outputs

Digital inputs

Description	Reference tag	PLC address
TRUE = Start button pushed	+P1-SF1	%I1.0
FALSE = Stop button pushed (n.c.)	+P1-SF2	%I1.1
Select operation mode (FALSE = Setup mode, TRUE = Automatic mode)	+P1-SF3	%I1.2
TRUE = Reset button pushed	+P1-SF4	%I1.3
TRUE = Carrier detected at stopper position (corresponds to ident code bit 0)	+G1-BG1	%I1.4
FALSE = Emergency stop button pushed (n.c.)	+P1-SF5	%I1.5
TRUE = Carrier detected at conveyor entry	+G1-BG5	%I1.6
TRUE = Carrier detected at conveyor exit	+G1-BG6	%I1.7
TRUE = Carrier ident code bit 0 detected	+G1-BG1	%I18.0
TRUE = Carrier ident code bit 1 detected	+G1-BG2	%I18.1
TRUE = Carrier ident code bit 2 detected	+G1-BG3	%I18.2
TRUE = Carrier ident code bit 3 detected	+G1-BG4	%I18.3
Switch S1 on 'A': TRUE = Encoder A signal detected S1 on 'R': FALSE = Coupling signal right detected	+G1-KG1 oder +G1-BG7	%I18.4
Switch S2 on 'B': TRUE = Encoder B signal detected; S2 on 'L': FALSE = Coupling signal left detected	+G1-KG2 oder +G1-BG8	%I18.5

Siemens - C:\Users\hmm\Documents\Automation\Projects\CIROS_Training\CIROS_Training

Totally Integrated Automation PORTAL

CIROS_Training > PLC_1 [CPU 1512SP F-1 PN] > PLC tags > myTags [36]

Tags User constants


Name	Data type	Address	Retain	Acces...	Writa...	Visibl...	Supervis...
xSF1	Bool	%I1.0					
xSF2	Bool	%I1.1					
xSF3	Bool	%I1.2					
xSF4	Bool	%I1.3					
xBG1	Bool	%I1.4					
xSF5	Bool	%I1.5					
xBG5	Bool	%I1.6					
xBG6	Bool	%I1.7					
xBG1_BCD0	Bool	%I42.0					
xBG2_BCD1	Bool	%I42.1					
xBG3_BCD2	Bool	%I42.2					
xBG4_BCD3	Bool	%I42.3					
xG1_BG7_KG1	Bool	%I42.4					
xG1_BG8_KG2	Bool	%I42.5					
xKF21_IN6	Bool	%I42.6					
xG1_BG9	Bool	%I42.7					
byAnalogIn0	Byte	%I42.8					
byAnalogIn1	Byte	%I48					
xPF1	Bool	%Q1.0					
xPF4	Bool	%Q1.1					
xPF2	Bool	%Q1.2					
xPF3	Bool	%Q1.3					
xQA1_A1	Bool	%Q1.4					
xQA1_A2	Bool	%Q1.5					
xQA1_A3	Bool	%Q1.6					
xMB1	Bool	%Q1.7					
xPH2_A	Bool	%Q42.0					
xPH2_B	Bool	%Q42.1					
xPH2_C	Bool	%Q42.2					
xPH2_D	Bool	%Q42.3					
xGF1	Bool	%Q42.4					
xGF2	Bool	%Q42.5					

Note the addresses are shifted from 18.x to 42.x.

Exercise

Enabling simulation support


1. Open the [project properties](#).
2. On the [Protection](#) tab, check [Support simulation during block compilation](#).
3. Compile and download it again. It should work without a problem now



Exercise


Downloading project to PLC instance

1. Compile the project.
2. Download it to your simulated PLC.
If Online Access in PLCSIM Advanced is set to PLCSIM mode, this is almost fully automatic.



Configuring the Interface

The virtual PLC in CIROS has a large number of inputs and outputs, most of which are unused or used for internal processes inside CIROS. A few virtual I/Os correspond to the I/Os of the PLC inside a real CP system, though. These are named DIN0_x0 to DIN18_x7 and DOUT0_x0 to DOUT18_x7, after the absolute addresses of the real PLC's I/Os.



Name of a virtual I/O, corresponding to %I0.0 in the real CP module.

I/O address inside CIROS. Completely irrelevant to your TIA project.

Current value of a virtual I/O. For inputs these come from simulated sensors. For outputs, they control a simulated actuator.

Configuring the Interface

You can connect each virtual PLC in your CIROS model to exactly one PLCSIM Advanced instance.

You have to configure our CIROS PLC to connect to the right instance and to hook up the virtual CIROS I/Os to the correct TIA I/Os.

The screenshot displays the TIA Portal interface with several key components:

- Model Explorer:** Shows a project structure with 'Objects' containing 'CP-L-CONVEYOR' and 'SPS_A'. 'SPS_A' is highlighted with a blue box and an arrow pointing to the PLC instance.
- Start Virtual S7-1500 PLC:** A control panel showing '1 Active PLC Instance(s): CIROS_Training / 192.168.0.1'. This instance is highlighted with a blue box and an arrow from 'SPS_A'.
- Input Table:** A table listing digital inputs. 'DIN1_x0' is highlighted with a blue box and an arrow pointing to the 'xSF1' tag in the 'myTags' table.
- myTags Table:** A table of PLC tags. 'xSF1' (Bool, %I1.0) and 'xBG3_BCD2' (Bool, %I42.2) are highlighted with blue boxes and arrows from the 'Input' table.

Input	Index	Type	Value
DIN0_x0	000	Digital	0
DIN0_x1	001	Digital	0
DIN0_x2	002	Digital	0
DIN0_x3	003	Digital	0
DIN0_x4	004	Digital	0
DIN0_x5	005	Digital	0
DIN0_x6	006	Digital	0
DIN0_x7	007	Digital	0
DIN1_x0	008	Digital	0
DIN1_x1	009	Digital	1
DIN1_x2	010	Digital	0
DIN1_x3	011	Digital	0
DIN1_x4	012	Digital	0
DIN1_x5	013	Digital	1
DIN1_x6	014	Digital	0
DIN1_x7	015	Digital	0
DIN18_x0	016	Digital	0
DIN18_x1	017	Digital	0
DIN18_x2	018	Digital	0

Name	Data type	Address
xSF1	Bool	%I1.0
xSF2	Bool	%I1.1
xSF3	Bool	%I1.2
xSF4	Bool	%I1.3
xSF5	Bool	%I1.5
xBG5	Bool	%I1.6
xBG6	Bool	%I1.7
xBG1_BCD0	Bool	%I42.0
xBG2_BCD1	Bool	%I42.1
xBG3_BCD2	Bool	%I42.2
xBG4_BCD3	Bool	%I42.3
xG1_BG7_KG1	Bool	%I42.4
xG1_BG8_KG2	Bool	%I42.5


Exercise

Configuring the interface

Configure your CP-L-CONV model to connect to your instance.

All of this is done in CIROS. TIA doesn't know anything about the CIROS interface.

1. Open the [properties](#) of your virtual PLC (SPS_A)
2. On the [PLCSIM Advanced](#) page, select [Find instance by name](#).
3. Enter the name of your PLCSIM Advanced instance




Exercise

Configuring the interface

1. Go to the subpage [Items](#)
2. Click on [Connect](#)
3. Open either the entry that says [all](#) or [HMI visible](#), depending on your preference. The latter only offers you I/O tags that have been declared as *Visible in HMI engineering* inside TIA
4. Under this entry, open [I/O](#)

Note that you're also offered [Memory](#), [Counters](#) and [Timers](#) and [Data blocks](#). You can hook up CIROS I/Os to any of these but in this exercise, we'll only use I/Os.



Exercise

Configuring the interface

Virtual I/Os of the CIROS PLC

The screenshot displays the TIA Portal configuration environment. On the left, a sidebar lists various configuration options, with 'PLCSim Advanced' and 'Items' selected. The main 'Items' list contains the following entries:

Name	Item
DIN0_x7	
DIN1_x0	
DIN1_x1	
DIN1_x2	
DIN1_x3	
DIN1_x4	
DIN1_x5	
DIN1_x6	
DIN1_x7	
DIN18_x0	
DIN18_x1	
DIN18_x2	
DIN18_x3	
DIN18_x4	

The 'Connect' dialog on the right shows a tree view of the PLC's I/O configuration:

- CIROS_Training (HMI visible)
 - CIROS_Training (all)
 - I/O
 - Merker
 - Zähler und Zeiten

Below the tree view, a table lists the configured I/O tags:

Name	Dat...	Acc...	Item
xBG5	Bool	R/W	xBG5
xBG6	Bool	R/W	xBG6
xBG1	Bool	R/W	xBG1
xF1	Bool	R/W	xF1
xF5	Bool	R/W	xF5
xF2	Bool	R/W	xF2
xF4	Bool	R/W	xF4
xBG1 B...	Bool	R/W	xBG1 BCD0

Buttons for 'Apply' and 'Discard' are visible at the bottom right of the dialog.

I/O tags configured in TIA

Exercise

Configuring the interface

1. From the list of I/O tags on the right, **drag and drop** each I/O to the matching entry on the left
2. When done, click **Apply**
3. Optionally, click **Connect** again to disconnect

Hint: You can select multiple I/Os from the right if they are in the right order and drag them to the left at once.

The screenshot shows the 'Items' configuration window. On the left, a tree view shows 'PLCSim Advanced' expanded to 'Items'. The main area contains two tables. The top table, titled 'Items', has columns 'Name' and 'Item'. The bottom table, titled 'Connect', has columns 'Name', 'Dat...', 'Acc...', and 'Item'. A blue arrow points from the 'xSF1' entry in the 'Connect' table to the 'xSF1' entry in the 'Items' table, with the text 'Drag and drop' next to it. The 'Apply' button is highlighted with a blue box.



Name	Item
DIN0_x7	
DIN1_x0	xSF1
DIN1_x1	xSF2
DIN1_x2	xSF3
DIN1_x3	xSF4
DIN1_x4	
DIN1_x5	
DIN1_x6	
DIN1_x7	
DIN18_x0	
DIN18_x1	
DIN18_x2	
DIN18_x3	
DIN18_x4	

Name	Dat...	Acc...	Item
xBG5	Bool	R/W	xBG5
xBG6	Bool	R/W	xBG6
xBG1	Bool	R/W	xBG1
xSF1	Bool	R/W	xSF1
xSF3	Bool	R/W	xSF3
xSF2	Bool	R/W	xSF2
xSF4	Bool	R/W	xSF4
xBG1 B...	Bool	R/W	xBG1 BCD0

Exercise

Run the simulation



1. Click the play button to **start the simulation**
2. Use TIA to **go online** / connect to your PLC instance



Exercise

Run the simulation

1. In TIA, open your tag list and **monitor** it
2. Test the connection by clicking on the **virtual green start button** inside CIROS. You should see the **value of %I1.0 change** in TIA



Common Issues

Can't download project to PLC instance anymore


Once CIROS has established a link to a PLCSIM instance, that instance is bound to the simulation. Only when the CIROS simulation is running, will the instance run as well.

Should TIA appear to be stuck when downloading to the instance that is likely because your CIROS simulation is paused. As soon as you start the simulation, the download will continue.

Remote Connection between CIROS and PLCSIM Advanced

If you're running CIROS and PLCSIM Advanced on different machines, you need a little bit of extra configuration.


1. PLCSIM Advanced must use the [Virtual Ethernet Adapter](#)
2. The [communication interface](#) must be set to the network interface through which you're connecting to CIROS
3. The [runtime manager port](#) must be enabled. Note the port number written here



Remote Connection between CIROS and PLCSIM Advanced

You also have to let CIROS know, where to find PLCSIM Advanced.

1. Go to the virtual PLC's properties
2. Open the [PLCSIM Advanced](#) page
3. Check [Activate remote connection](#)
4. Enter the [IP address](#) of the PC where PLCSIM Advanced is running
5. Enter the [runtime manager port number](#) that is configured in PLCSIM Advanced



Python

Python in Model Libraries

- Python 3.7 or higher is required for the support of CP Lab / Factory model library.
- Replication of CP Lab / Factory workpieces within CIROS is based on various Python scripts, compared to previous versions this change within the CIROS kernel simplifies the integration of user defined workpieces.
- If not already installed, CIROS installation wizard will install Python and add it to Windows path during the setup in silence mode.
- In case Python is removed...
 - Due to various reasons, like uninstallation of other applications in the same PC, Python can be uninstalled or removed from Windows path.
 - In this case, CIROS will throw an error, most commonly [cirospluginpython.dll not loaded](#).
 - When this happens, user should check whether the correct Python version is installed and if it is in the Windows path.

Python in Model Libraries

Adding python to Windows path (1)



- To define Python in System Environment Variable Path in Windows 10:

1. Open System Properties.

Menu → Settings → System → About → Advanced System Settings

2. Open Environment Variables.

Advanced → Environment Variables




Python in Model Libraries

Adding python to Windows path (2)


3. Edit Variable Path in System Variables.

System Variables → Path → Edit



4. Insert the path to Python and Python Scripts folder here.


For example: `C:\Program Files\Python 38\` and `C:\Program Files\Python 38\Scripts\`



5. Restart the computer.

Python Installed but Not Working

- When different python versions are installed in the same computer, CIROS always selects the version on top of the Windows environment path list.
- When the version on top of the list is not supported by CIROS, there will be an error.
- Typical error message is “cirosPluginPython.dll not loaded”.
- Steps to solve this problem
 1. Open Windows Environment Variable.
 2. Edit System variables.
 3. Move the python with correct version up to the top.



Python Scripts

- CIROS v7 and above works with Python scripts. The scripts can be called for following purposes
 - Creation and modification of model.
 - Controller for simulation or components.
 - Define user defined commands in context menu.
- There is an integrated python module for CIROS, “Ciros”
 - Overview of the functions in the module can be called from [Menu → Extras → Python → Show function list](#)
 - In CIROS 7.1, there are currently 19 classes and 275 commands
 - Example models can be found in [C:\Program Files\Festo Didactic\CIROS 7.0\CIROS Studio\Example Models\Help\Python](#)
- Requirements
 - Python 3 is installed
 - Supported versions are 3.6, 3.7, 3.8 and 3.9
 - The used version will be chosen automatically
 - First line in python function list states the version used.

Note:


- [Python must be defined in windows PATH-variable.](#)
- [The script cannot contain endless loop.](#)

Python Scripts

Python scripts can be executed by following methods


1. Manually

- With or without simulation
- Menu Extras → Python → Execute




2. By a trigger during simulation

- Parameters
 - **Element:** Specify the element that calls the script.
 - **Trigger:** Specify event that trigger the call.
 - **File:** The script to be called.
 - **Function call:** Function in the script to be called. Optional.
 - **Output:** Defines whether outputs should be written in message window or not.




3. Python controller

- Controller script to control the simulation.
- A controller object, e.g. simulation controller is required.



CP System Construction Helper

- A python library contains of four classes.



Class	Explanation
CPFactoryConstructionHelper	Constructs a single line of CP-Factory base modules from left to right.
CPLabConstructionHelper	Constructs a single island of CP-Lab modules from left to right, base modules and corners must be added in the correct order, build order is from left to right. 
CPRobotinoConstructionHelper	Construct Robotino and related modules
CPSystemConfigurationHelper	This can be used to change the configuration of certain modules. Please note that u need to give the correct object name as it appears in the model, for example CP-L-BRANCH_1 for the second added branch module.

- **Note:** This library does not come in default with the installation. It might be found in the CIROS project configured by Festo Didactic in folder [python](#). If it is not found, please contact us to request for it.

OPC UA Interface

CIROS as OPC UA Client

1. Change controller object type to **OPC UA client**.
 1. Select the object in **Model Explorer**.
 2. In **Properties window**, select **General** → **Object type**.
 3. First, change object type to **inactive object** to clear filter.
 4. Then, all the available object types will be shown, select **OPC UA client**.
2. Change controller control to **Simulation controller**.



CIROS as OPC UA Client

- In **Properties** → **OPC-UA-Client**, search for the endpoint of OPC UA server.
 - If endpoint did not change, you can type the URL directly in the field.
- Expand OPC-UA-Client and select **Items**.
- Click on **Connect**.
- Assign the OPC UA nodes in server to the internal IOs.
- Select **Apply**.

The screenshot shows the 'Properties' dialog box with the 'OPC-UA-Client' section expanded to the 'Items' tab. The 'Items' table lists internal IOs and their corresponding OPC UA nodes. The 'Connect' button is highlighted with a blue box labeled '3'. The 'Items' table is highlighted with a blue box labeled '4'.

Name	Item
_Z_Achse_oben	
_Z_Achse_unten	
_Rueckschale_bereits...	
Outputs	
App_DI0	
App_DI1	
App_DI2	
App_DI3	
App_DI4	
App_DI5	
App_DI6	
App_DI7	
_X_Achse_nach_links	xMB1
_X_Achse_nach_rechts	xMB2
_Bohrer_1_ein	xMA3
_Bohrer_2_ein	xMA4
_Z_Achse_nach_oben	xMB5
_Z_Achse_nach_unten	xMB6
_Z_Achse_Klemmung_...	xMB7
CIROS_App_ID	

The screenshot shows the 'Properties' dialog box with the 'Connection' tab selected. The 'Endpoint' field is highlighted with a blue box labeled '1.1'. The 'Security' and 'Message Security' dropdowns are set to 'None'. The 'Anonymous login' checkbox is checked.

The screenshot shows the 'Discover OPC-UA-servers' dialog box. The 'Discovery URL' field is highlighted with a blue box labeled '1'. The 'Search now!' button is also visible.

The screenshot shows the 'Apply' and 'Discard' buttons. The 'Apply' button is highlighted with a blue box labeled '5'.


Robot Programming

Mitsubishi

Mitsubishi Industrial Robot

Electric RV-4FL robotic arm

Type	Articulated robot
Number of axes	6
Ultimate load	4 kg
Maximum reach radius	649 mm
Movement range	480° / 240° / 164° / 400° / 240° / 720°
Maximum composite speed	9048 mm/s
Cycle time	0.36 s
Position repeatability	± 0.02 mm
Weight	41 kg
Tool wiring	8 I/O
Protection rating	IP67



Mitsubishi Industrial Robot

Robot controller CR750-D

Programming language	MELFA-BASIC-V
Number of programs	512
Positions / program	3900
Programming	Teach box / PC
Power supply	Single-phase 180 – 253 V AC
Interface	RS422 / ethernet / USB / digital I/O
Dimensions (H x W x D)	430 mm x 425 mm x 174 mm
Weight	16 kg
Protection rating	Ground position / IP20




Mitsubishi Industrial Robot

Teach box R56TB

Menu navigation (language)	German, English, French, Italian
Features	Operating, programming and monitoring all robot features
Programming and Monitoring	Reading out information even during the running system; Programming using a virtual keyboard; Display of up to 14 lines of programming code; I/O Monitoring of up to 256 inputs and 256 outputs; Maintenance display of service intervals; Trouble indication of the last 128 alarms
Display	Touchscreen with background lighting 6,5" TFT display (640 x 480 pixel), 65536 colours
Interface	USB, combined RS422 and ethernet interface
Connection	Direct connection to the robot controller, cable length 7m
Protection rating	IP65
Weight	1,25 kg



Layout and Windows



Model window


Programme window

Position list window

CP-F-RASS

Robot simulation

- RASS stands for **R**obot **A**Ssembly **S**tation.
- It is possible to simulate the Mitsubishi robot program in CIROS environment.
- The robot program requires several input parameters, which usually comes from MES4 or PLC. For standalone robot simulation in CIROS, user has to provide the input parameters manually.
- Following are the input parameters are required for standalone CIROS robot simulation:
 1. Program number.
 - Program 1 : Assemble PCB
 - Program 2 : Assemble PCB and front fuse
 - Program 3 : Assemble PCB and rear fuse
 - Program 4 : Assemble PCB and both fuses
 2. Position in box.



CP-F-RASS

General information

- The robot programs are written in Melfa Basic V (MBA5) with extension [.mb5](#), which is the programming language of Mitsubishi robot.
- Positions are stored in the position list with extension [.pos](#).
- There is a robot project in CP-F-RASS model, which have the same programs as in actual robot. However, the I/O channels and tool changing mechanism are modified to suit the modelling environment.
- In CIROS simulation, a main program [RobotSystemDriver.mb5](#) is used to simulate the slot allocation in actual robot controller.
- Generally, a program name can be any string characters. However, PLC only calls the program by integers. To allow the new program to be able to function in real robot, the program name should be numbers.

CP-F-RASS

Programs list

RobotSystemDriver.mb5	Main program. Assign subprograms to slot.
999.mb5	Reset robot
1.mb5	Assemble PCB to front cover
2.mb5	Assemble PCB and front fuse to front cover
3.mb5	Assemble PCB and rear fuse to front cover
4.mb5	Assemble PCB and both fuses to front cover
5.mb5	Demo program. Assemble and disassemble PCB in front cover.
123.mb5	Check all positions in PCB box. Assemble and disassemble all PCBs in box.
234.mb5	Camera test program. Pick front cover from stopper, place to vision field and run camera. Repeat four times.
255.mb5	Calculate positions in box based on four positions taught
ENERGSAVEVACU.mb5	Switch on vacuum gripper when workpiece is loose
GETCAMRESULT.mb5	Get camera result
GETCURTOOLNO.mb5	Get current tool number
GETFUSEMAGNO.mb5	Get fuse magazine number
GRPCLOSE.mb5	Close gripper
GRPLOCK.mb5	Lock the gripper to robot arm flange
GRPOPEN.mb5	Open gripper
GRPRELEASE.mb5	Release gripper from robot arm flange

GRPVACOFF.mb5	Switch off vacuum gripper
GRPVACON.mb5	Switch on vacuum gripper
INITIALIZE.mb5	Initialize input and output variables
MONITORHOME.mb5	Check if robot arm is at home position
MONITORPALWS.mb5	Check if robot arm is at PCB box position
MOUNTBOTFUSE.mb5	Mount rear fuse
MOUNTPCB.mb5	Mount PCB to front cover
MOUNTTOPFUSE.mb5	Mount front fuse
MOVHOME.mb5	Move robot arm to home position
PCBTRAYCNTRL.mb5	Check PCB box lock signal and PCB position count
PICKFRMSTOPR.mb5	Pick workpiece from stopper
PICKFRMVISION.mb5	Pick workpiece from vision field
PICKFUSFRMAG.mb5	Pick a fuse from fuse magazine
PICKNEWTOL.mb5	Pick a new gripper
PICKPCBFRPAL.mb5	Pick PCB from PCB box
PICKWPFROMASS.mb5	Pick workpiece from assembly position
PLACETOSTOPR.mb5	Place workpiece to stopper.
PLACETOVISION.mb5	Pick workpiece from stopper to vision field
SENSORCHECK.mb5	Check sensors at stopper, assembly position, fuse magazines and input parameter for PCB position in box.
SENSORCHECK1.mb5	Check sensors at stopper, assembly position and input parameter for PCB position in box.
SENSORCHECK6.mb5	Check sensors at stopper position
UBP.mb5	User base program. Global program contains all global variable, flags and positions.

CP-F-RASS

Controllers and I/Os

- Station CP-F-RASS has two controllers,
 - PLC controller
 - Robot controller
- In CIROS, the station has two controllers as well.
 - [SPS_Roboter](#) is the virtual representation of PLC controller
 - [Montage_RV-4FL](#) is the virtual representation of robot controller
- The I/Os are linked internally in CIROS model.

Montage_RV-4FL	Index	Type	SPS_Roboter	Index	Type	Description
I_Stop	100	DI	DOUT_100_x0	40	DO	Stop robot program
I_Start	101	DI	DOUT_100_x1	41	DO	Start a robot program
IDATA_(0-15)	116 – 131	16 Bit DI	AOUT_W102	002	AO	Program number in binary
DI_PCBPalletNo_(0-7)	172 – 179	8 Bit DI	AOUT_B109	004	AO	Position in PCB box
HOpen_1	900	DO				Open gripper
HClose_1	901	DO				Close gripper
HOpen_3	904	DO				Release gripper
HClose_3	905	DO				Lock gripper

CP-F-RASS


Grippers' tool number

- Each gripper has a tool number. It is important to select the right tool as different TCP is used for different tools.
 - Tool 1 : Vacuum gripper.
 - Z-offset relative to flange TCP 205 mm.
 - C-rotation relative to flange TCP 33.5°.
 - Tool 2 : Parallel gripper for front cover.
 - Z-offset relative to flange TCP 170 mm.
 - C-rotation relative to flange TCP 33.5°.
 - Tool 3 : Parallel gripper for fuse.
 - Z-offset relative to flange TCP 151.5 mm.
 - C-rotation relative to flange TCP 33.5°.
 - Tool 4 : No gripper.
 - Z-offset relative to flange TCP 0 mm.
 - C-rotation relative to flange TCP 0°.

CP-F-RASS

List of default positions in CIROS environment for reference

No	Definition	Position
1	P_AssemblePCB	(-140.03,-367.01,109.01,-179.73,0.09,89.95)(7,0)
2	P_PCBPalletOrigin	(93.00,276.00,213.00,-180.00,0.00,90.00)(7,0)
3	P_PCBPaletXDir	(-140.10,276.00,213.00,-180.00,0.00,90.00)(7,0)
4	P_PCBPaletYDir	(93.00,398.00,213.00,-180.00,0.00,90.00)(7,0)
5	P_PCBPaletXYDir	(-140.10,398.00,213.00,-180.00,0.00,90.00)(7,0)
6	P_CarrierStop1	(402.50,-267.00,171.50,179.73,-0.09,90.05)(7,0)
7	P_Vision	(30.00,-350.00,101.50,180.00,-0.00,90.00)(7,0)
8	P_AssembleWp	(-139.00,-362.00,114.00,-180.00,-0.00,90.00)(7,0)
9	P_AssembleFuse1	(-138.97,-401.18,127.13,-180.00,0.00,180.00)(7,0)
10	P_AssembleFuse2	(-138.97,-388.18,127.13,180.00,-0.00,180.00)(7,0)
11	P_FuseMagazine1	(-300.65,-430.30,160.30,177.86,-42.56,-177.96)(7,0)
12	P_FuseMagazine2	(-299.24,-360.21,159.46,177.87,-42.57,-177.96)(7,0)
13	P_FuseMagazine3	(-299.44,-290.40,159.99,177.87,-42.57,-177.96)(7,0)
14	P_GrpStorageVac	(-395.65,-125.00,484.90,-180.00,-0.00,-0.00)(7,1)
15	P_GrpStorageWp	(-395.65,0.00,484.90,-180.00,0.00,0.00)(7,1)
16	P_GrpStorageFuse	(-395.65,125.00,484.90,-180.00,-0.00,-0.00)(7,0)



Steps to configure CP-F-RASS for simulation

1. Create a new CIROS project.
2. Insert and snap following from [CP System model libraries](#).
 1. CP-F-RASS (Mitsubishi)
 2. CP-F-SOURCE
 3. CP-F-SINK
3. Optional: Hide safety glass.
 1. In [Model Explorer](#), choose [Objects](#) → [CP-F-RASS_Mitsubishi](#) → [Geometrie](#) → [Geometrie_Umhausung](#)
 2. In [Properties](#), select [Visualization](#).
 3. Click [Invisible](#).
4. Open robot program in project management.
 1. In [Project Management](#), right click on [Projects](#) and select [Open](#).
 2. Select `<project folder>\CF\Rob_Montage\RV-4FL\Montage_RV_4FL.prjx`.
 3. In [Project Management](#), select [Controllers](#) → [Montage_RV_4FL](#)
 4. Assign project [Montage_RV_4FL](#) to the controller.
5. Assign required I/Os to IO monitor.
 1. Open an [I/O monitor](#) window, it can be any I/O monitor.
 2. Drag the Outputs from [Model Explorer](#) to [I/O monitor](#) window.
 3. Required Outputs are in [Objects](#) → [CP-F-RASS_Mitsubishi](#) → [SPS_Roboter](#) → [Outputs](#)
 1. AOUT_W102 (analogue 002) : robot program
 2. AOUT_B109 (analogue 004) : position in PCB box
6. Change source part number to 210.
 1. In [Model Explorer](#), select [CP-F-SOURCE](#).
 2. In [Properties](#) → [CP System](#), change [Part Number](#) to 210.

Note: The configured model can be saved as a template which can be opened with CIROS Studio and Education in robot programming lessons.

Video tutorial: 51_ConfigureRASSForRobotProgramSimulation.mp4

Steps to simulate CP-F-RASS

1. Optional: To reduce computing power, close all windows except [model window](#) and [I/O monitor](#), e.g. Model Explorer, Properties, Project Management, etc.
2. Start simulation.
3. Give a robot program and position in box in I/O monitor and activate override.
 1. For example: robot program 1 and box position 3.
 - [AOUT_W102](#) = robot program → Value = 1
 - [AOUT_B109](#) = position in box → Value = 3
5. Press on green source button in model window.
6. Observe the program.
 - To run another robot program, repeat step 3 to 6.
 - To restart simulation, repeat step 2 to 6.

Video tutorial: [52_SimulateRASSRobotProgram.mp4](#)

Simulate Real Robot Program in CP-F-RASS Model

- It is possible to simulate real CP-F-RASS robot program in CIROS.
- However, the program has to be modified to suit the simulation environment, for example, the I/Os address and tool changing mechanism.
- Besides, the simulated program does not connect to a camera. Thus, the subprogram which connects with camera has to be commented out.
- The modified robot program can be saved as a template project and be used repeatably in robot programming classes as it is portable with both CIROS Studio and CIROS Education.

Simulate Real Robot Program in CP-F-RASS Model

Steps to modify robot program (1)

1. Create a new CIROS project.
2. Load and snap following models in place from CP System model libraries.
 1. CP-F-RASS (Mitsubishi)
 2. CP-F-SOURCE
 3. CP-F-SINK
3. Change Part Number of CP-F-SOURCE to 210.
4. Place all the real robot programs in a single folder and place the folder in CIROS project folder.
5. In the folder, delete following files.
 1. Files with type [.bak](#).
 2. Files with type [.prjx](#).
6. Copy following files from [<project folder>\CF\Rob_Montage\RV-4FL](#) to the robot program folder.
 1. RobotSystemDriver.mb5
 2. Montage_RV_4FL.prjx
 3. ENRGSAVEVACU.mb5, if not exist
 4. MonitorHome.mb5, if not exist
 5. MonitorPalWS.mb5, if not exist
 6. PCBTrayCntrl.mb5, if not exist
7. In CIROS, open Project Manager, open the copied project [Montage_RV_4FL.prjx](#) in robot program folder and assign it to controller Montage_RV-4FL.
8. In Project Manager, open [Projects](#) → [Montage_RV_4FL \(MBA5\)](#) → [Files](#) and delete the files which do not exist.

Simulate Real Robot Program in CP-F-RASS Model

Steps to modify robot program (2)

9. In CIROS, change the following in all files in the project.

1. Bits and bytes in I/O definitions

From	To	From	To	From	To
2032	132	2072	172	2148	248
2033	133	2144	244	2150	250
2040	140	2147	247	2151	251
2064	164				

2. Tool changing mechanism

From	To
M_Tool = m_GripperFuse	Tool P_tGripperFuse
M_Tool = m_GripperNone	Tool P_tGripperNone
M_Tool = m_GripperVac	Tool P_tGripperVac
M_Tool = m_GripperWP	Tool P_tGripperWP
HOpen 6	HOpen 3
HClose 6	HClose 3

3. Make following changes.

1. Add following lines in [999.mb5](#).

```
P_tGripperVac=(0,0,205,0,0,33.50)
P_tGripperWP=(0,0,170,0,0,33.50)
P_tGripperFuse=(0,0,151.5,0,0,33.50)
P_tGripperNone=(0,0,0,0,0,33.50)
```

2. Comment out or delete all position declarations in [UBP.mb5](#) and add following lines.

```
Def Pos P_tGripperVac
Def Pos P_tGripperWP
Def Pos P_tGripperFuse
Def Pos P_tGripperNone
```

3. Change following positions to reference positions in [UBP.pos](#). The location of tool magazine in CIROS model is different from actual robot. Thus, the offsets are too large to be ignored.

```
P_GrpStorageVac = (-395.65,-125.00,484.90,-180.00,-0.00,-0.00)(7,1)
P_GrpStorageWp = (-395.65,0.00,484.90,-180.00,0.00,0.00)(7,1)
P_GrpStorageFuse = (-395.65,125.00,484.90,-180.00,-0.00,-0.00)(7,0)
```

4. Comment out or remove all lines calling camera related subprograms, for example the line calling [GetCamResult](#) in program 1 to 5.mb5.

```
REM CallP "GetCamResult", CamPrgNumber%
```

10. Save all and compile the project.

CP-F-RASS Robot Programming

Robot programming example 'gripper test' (1)

- The program is independent of all the other robot programs, but uses positions in UBP.pos.
- It is written in MBA V and does the following.
 1. Move robot arm to home position.
 2. Move robot to parallel workpiece gripper magazine.
 3. Mount the gripper.
 4. Remove gripper from magazine.
 5. Open gripper.
 6. Close gripper.
 7. Store gripper back to magazine.
 8. Move robot arm back to home position.

Note: For more programming example, see tutorial video '50_RASS-Programming.mp4'.

CP-F-RASS Robot Programming

Robot programming example 'gripper test' (2)

1. Create a CIROS project and load CP-F-RASS from CP System model libraries.
2. Make sure a project is assigned to controller Montage_RV-4FL and UBP.pos is in the project.
3. In Project Management, right click on [Projects](#) → [⟨project name⟩](#) → [Files](#) and choose [new](#).
4. Create a Melfa Basic V program and name it [RASS-GripperTest.mb5](#).
5. With the programming window being the active window, select [Programming](#) → [Programming assistant](#).
6. Uncheck [Declare inputs and outputs](#) and click [OK](#).
7. In the programming window, add the lines shown in right.
8. Save the program.
9. In Project Management, right click on the program and select [Set main program](#).
10. Compile the project.
11. Run simulation.

```
' TODO add your code here
```

```
' Move to home position
MOV P_Home
DLY 1
```

```
' Mount parallel workpiece gripper
MOV P_PCBPalletHelp
MOV P_GrpStorageWp, -30
JOVRD 50
MVS P_GrpStorageWp
HClose 3
MVS P_GrpStorageWp + P_ToolX80
DLY 1
```

```
' Open and close gripper
HClose 1
HOpen 1
DLY 1
HOpen 1
HClose 1
DLY 1
```


```
' Store gripper back to magazine
MVS P_GrpStorageWP
HOpen 3
```

```
' Move back to home position
MVS P_GrpStorageWp, -30
JOVRD 100
MOV P_PCBPalletHelp
MOV P_Home
```

```
END
```

Move Robot Manually

- There are several ways to move robot manually in CIROS.
 1. Move the robot directly to a position on position list.
 - Double click on the position.






No	Position	Orientation	Comment
P1	249.9, -38.3, 192.2	179, 0, -122, R, A, N	
P3	311.9, 24.8, 180.0	180, -0, -180, R, A, N	
P4	449.7, 143.6, 176.3	180, -0, -90, R, A, N	
P50	311.0, 73.1, 194.8	180, 0, -135, R, A, N	
P51	397.5, 72.9, 194.7	180, 0, -45, R, A, N	
P52	311.4, 148.1, 195.2	180, -0, -135, R, A, N	
P53	397.9, 147.9, 195.1	180, 0, -45, R, A, N	
P6	132.0, 259.1, 323.0	180, 0, 90, 0.0, 0.0, R, A, N	

2. Double click on any location in model window.

Move Robot Manually

3. Move the robot with **Teach-In panel**.
 - Gripper can be controlled in section **Gripper output**.





Mount and Release a Gripper Manually

- In some system, for example, CP-F-RASS, TCP changes relative to the gripper.
- Steps to mount a gripper manually with example CP-F-RASS model.
 1. Move the robot arm to the tool position.
 2. In [Teach-In panel](#) → [Gripper output](#), close [HClose_3](#).
 3. Start simulation (F5).
 4. Stop simulation (F5).
 5. The gripper is mounted.
- Steps to release a gripper manually with example CP-F-RASS model.
 1. Move the robot arm to the desired position.
 2. In [Teach-In panel](#) → [Gripper output](#), open [HClose_3](#).
 3. Start simulation (F5).
 4. Stop simulation (F5).
 5. The gripper is released.


TCP Tracking

- TCP path of robot movement can be monitored.
- Active TCP tracking from **View** → **TCP tracking**.




View TCP Coordinate

- Joint coordinate and cartesian coordinate of the active TCP can be monitored.




Robot Workspace

- The room that TCP can reach.
- Activate at [View](#) → [Robot workspace](#).



Collision Detection

- Collision detection can be activated.
- In collision detection mode the movements are always incremental.
- It is useful in testing a new robot program to avoid collision.




Collision Detection

Configuration (1)


1. Assign group. Collision is only detected when elements in different groups cross each other.

1. Select **Settings** → **Collision detection**.




2. In Collision Detection window, select **Manage collision groups**.

3. Assign content to Roboter group.




4. Assign content to Rest group.



Collision Detection

Configuration (2)


2. Assign the collision group pair.
 1. Close Manage collision groups window.
 2. Select **Roboter** as group 1 and **Rest** as group 2.
 3. Move the pair to the right to activate it.
 4. Select OK.



Collision Detection

Activate simulation

1. Select [Simulation](#) → [Collision detection](#).




2. Move the robot against an object and observe the simulation.

Connect to Robot Controller

Communication interface

- Ethernet cable
- TCP/IP protocol
- IP-Address and Port



Check the Ethernet Cable

Please check the ethernet connection between robot controller and the computer.




Connect to Robot Controller

Find the IP-address from TB

1. The IP-address can be read from robot teach box (TB).




2. Exit everything until home page.




3. Press F1 to enter menu.



4. Select **3.PARAM.**




5. Search for parameter **NETIP**. Read the IP-address.



Connect to Robot Controller


Change the IP-address of the computer to the same network

1. Open network adapter properties.



2. Select Internet Protocol Version 4 (TCP/IPv4).


3. Select Properties.
4. Change the IP address to the same network as robot controller.



Connect to Robot Controller

RCI-Explorer


- RCI = Robot Control Interface
- Allow user to read information, program and control the robot controller in CIROS.
- Can create / load robot controller backup.
- Edit the program by uploading the robot program into local workspace.



Connect to Robot Controller

Open RCI-Explorer

- Select **Extras** > **Online management** > **RCI explorer...**





Connect to Robot Controller

Set connection in RCI Explorer

1. Right click **connection** and select **properties**.
2. In properties window, select **Communication**.
3. Select **TCP/IP** as connection type.


4. Expand Communication in properties window and select **TCP/IP**.
5. Enter the IP-address of the robot controller.
6. Port = 10001



Connect to Robot Controller


Build the connection

1. In RCI Explorer, right click on Connection and select **Connect**.




2. Please pay attention to the security advice and environment of real robot!

3. Select **OK** when the window pops up.




4. Connection is established.




Create Robot Controller Backup

1. Right click on the robot and select **Create backup** > **All**.




2. Create the backup in an empty folder.

3. Confirm the warning.



Load Backup

1. Right click on the robot and select **Load backup > All**.



1. Select backup folder.
2. Restart the controller after loading complete.



Online Teaching

- Once connected, it is possible to activate online teaching in Teach-In panel. (→)
 - Online teaching mode allows
 - Simulation of real time robot position in CIROS
 - Move the real robot in CIROS
 - Track the real robot coordinates in CIROS
1. Activate online teaching.
 2. Observe the change in model window.
 3. Move Roll coordinate of the robot incrementally 5°.
 4. Deactivate online teaching.
 5. Reset the model.

Teach-In

Joint coordinates Cartesian coordinates

Move

Waist ← →

Shoulder ← →

Elbow ← →

Twist ← →

Pitch ← →

Roll ← →

Hold TCP pose

Joint values

0.21 -240.00 to +240.00

0.38 -120.00 to +120.00

89.94 +0.00 to +160.00

-50.17 -200.00 to +200.00

74.93 -120.00 to +120.00

-0.76 -360.00 to +360.00

Apply

Speed override 10%

Gripper output HCLOSE1 Close


Move incrementally

25.00 mm 5.00

i Robot is connected. Activate online teaching

Upload Robot Programs

- Robot programs can be uploaded to the computer.
- Uploaded programs are listed in Workspace > Programs.
- The programs can then be edited.




The screenshot shows the RCI Explorer interface. On the left, a tree view shows the 'Workplace' folder expanded to 'Programs'. The main area displays a table of files with columns for File name, Size, Type, and Saved at.


File name	Size	Type	Saved at
RV-2F			
11.POS	3 KB	POS	22.09.2021 13:53
15.POS	2 KB	POS	22.09.2021 13:54
3.POS	3 KB	POS	22.09.2021 13:53
5.POS	1 KB	POS	22.09.2021 13:53
6.POS	1 KB	POS	22.09.2021 13:53
99.POS	1 KB	POS	22.09.2021 13:54
A1.POS	1 KB	POS	22.09.2021 13:54
A2.POS	1 KB	POS	22.09.2021 13:54
A3.POS	1 KB	POS	22.09.2021 13:54
A4.POS	1 KB	POS	22.09.2021 13:54
A5.POS	1 KB	POS	22.09.2021 13:54
APP1.POS	1 KB	POS	22.09.2021 13:54
T1.POS	0 KB	POS	22.09.2021 13:54
11.MB5	39 KB	MB5	22.09.2021 13:53
15.MB5	1 KB	MB5	22.09.2021 13:54
3.MB5	19 KB	MB5	22.09.2021 13:53
5.MB5	16 KB	MB5	22.09.2021 13:53
6.MB5	11 KB	MB5	22.09.2021 13:53
99.MB5	1 KB	MB5	22.09.2021 13:54
A1.MB5	2 KB	MB5	22.09.2021 13:54
A2.MB5	5 KB	MB5	22.09.2021 13:54
A3.MB5	5 KB	MB5	22.09.2021 13:54
A4.MB5	4 KB	MB5	22.09.2021 13:54
A5.MB5	4 KB	MB5	22.09.2021 13:54
APP1.MB5	1 KB	MB5	22.09.2021 13:54
T1.MB5	1 KB	MB5	22.09.2021 13:54

Upload Robot Programs

1. Right click on **RV-2F > Programs** and select **Upload all**.




2. Click **OK** everytime this window pops up.



Download Program

- Programs in Workspace can be downloaded into robot controller.

1. Select the MB5 program in workspace.
2. Right click and select Download.




Virtual Reality

Setting up VR Glasses

- CIROS can be directly connected to VR glasses like [HTC Vive](#) and [Oculus Rift](#).
- Typical procedure
 1. Install Steam / SteamVR and create a user account (<https://store.steampowered.com/>)
 2. Start Steam and switch to “offline mode” in case that Steam should be used without internet access
 3. Start SteamVR and run room setup
 4. Configure the VR mode of CIROS
 5. Activate VR mode of CIROS and start the simulation


Note: HTC Vive is the only officially supported VR glasses.

Switching between Steam’s online/offline mode




Setting up VR Glasses

Start SteamVR and run Room Setup



List of available HTC Vive components (from left to right):
Glasses, controller 1 & 2, left & right base station


Configuration of the (virtual) room



Setting up VR Glasses

Start SteamVR and run Room Setup


Choose “Room-Scale” to be able to go around in the real and virtual room



Setting up VR Glasses

Start SteamVR and run Room Setup


Calibrate real and virtual floor
(ground level wrt. to z-axis)



Setting up VR Glasses

Start SteamVR and run Room Setup


Configuration of the available physical space to be matched with the virtual room



Setting up VR Glasses

Start SteamVR and run Room Setup

Specify the available physical space (its outer perimeter) by holding the trigger button of one of the two controllers




Setting up VR Glasses

Start SteamVR and run Room Setup

If the available space defined before fits the “Play Area” it will be highlighted in green

Direction of the user perspective onto the SteamVR scene


“EDIT” allows for optimizing position, size, and user perspective manually



Setting up VR Glasses

Configure VR mode of CIROS

1. Select **File** → **Application options**.
2. Configure **VR devices**.




Enable VR glasses

“Standing” corresponds to SteamVR’s “Room Scale”

“Seated” should be used in cases in which “Standing Only” has been selected during SteamVR’s room setup




List of available/connected VR sets



Setting up VR Glasses

Configure VR mode of CIROS


3. Select **Settings** → **Model options**
4. Set the simulation increment to 0.011s, since the HTC Vive can perform 90fps
5. Let the simulation run as fast as possible
6. Switch the standard views to **default setting**



Setting up VR Glasses

Activate VR mode of CIROS and start the simulation


- Enable the connected VR device and start the simulation
- **Remark: It is highly recommended to disable all shadow calculations to have enough computational power for a “smooth” visualization!**



Advanced


Export as High-Resolution Images

- **File** → **Export** enables the user to save the content of the so-called “first” view window as a high-resolution PNG file.



Multiple View Windows


- CIROS is not restricted to a single view window but offers the possibility to show a couple of view windows concurrently.
- To open a new window, select **View** → **New window**.
- Each view might have a different perspective onto the scene.



First / main view window



Additional view windows



CIROS Starter

Calling CIROS model with URL

Possible action	Parameter	Explanation
Start simulation	StartSimulation	Starts the simulation.
Activate full screen	ActivateFullScreen	Runs CIROS in in full screen mode.
Use single instance	UseSingleInstance	CIROS uses an existing instance to open the new model. A new instance is only started if no instance of CIROS is running yet.

URL format:

“[StartCIROS](#): <path to model>?Parameter1&Parameter2”

Example:

"StartCIROS:Example Models\Small Demos for Learning\Robot Assembly with UR5\Robot Assembly with UR5.modx?ActivateFullScreen&UseSingleInstance"

Model Analysis

Extras → Model analysis → Whole model

- Help in problem diagnosis and finding a solution

Modellanalyse ✕

Beschreibung	Quelle
⚠ Objekt "Conveyor", Gruppe "CosTrans", Segment "Seg001": Die Gravitation ist aktiv und ein Antrieb ist zugewiesen.	Transportsimulation
⚠ Objekt "Conveyor_1", Gruppe "CosTrans", Segment "Seg001": Die Gravitation ist aktiv, aber nicht parametrisiert.	Transportsimulation
⚠ Objekt "Conveyor_2", Gruppe "CosTrans", Segment "Seg001": Die Gravitation ist aktiv und ein Antrieb ist zugewiesen.	Transportsimulation
⚠ Träger-Objekt "Carrier_1": Der Träger hat keine sichtbare Geometrie.	Transportsimulation
⚠ Träger-Objekt "Carrier_2": Der Träger hat keine sichtbare Geometrie.	Transportsimulation

Element auswählen

Hilfe F1

Note: Picture in German.

Create Own Part



Task: Add a MPS Part from CP-AM-MANUAL

- There are some parts supported from CP-System modell libraries. However, it is possible for the user to create their own part to work in CP environment in CIROS.
- User can import the CAD drawing of their parts and test it in virtual environment before implementing it on the real system.
- Steps to create own part will be explained with an example to add a Festo MPS red housing with RFIP and black MPS cap to the system via a manual work station.



Create Own Part

MPS part numbers according to FactoryViews

Part number	Part	Image
3001	Red MPS housing with RFID	
3002	Black MPS housing with RFID	
3003	Silver MPS housing with RFIC	

Part number	Part	Image
3020	Black cap	
3080	Cap with integrated micro-controller	

Create Own Part

Steps to create own part (1)

1. Group new parts and assign part numbers.
2. Load CAD file of the part in CIROS.
3. Optimise the geometry of CAD.

Troubleshoot in External Document

CIROS-CP_Troubleshoot_EN_v7.1_XXXXXX.pdf
