


Vision Sensor

SBSI/SBSC-EN

FESTO

Manual



8062650

1607b

Copyright (English)

No part of this document may be reproduced, published or stored in information retrieval systems or data bases in any manner whatsoever, nor may illustrations, drawings and the layout be copied without prior written permission from Festo Industriesensorik GmbH.

We accept no responsibility for printing errors and mistakes which occurred in drafting these document. Subject to delivery and technical alterations.


First publication February 2011

Festo AG & Co. KG

D-73726 Esslingen

Internet: <http://www.festo.com>

E-Mail: service_international@de.festo.com



Open Source Licences

The SBS Vision Sensor software makes use of a couple of third party software packages that come with various licenses. This section is meant to list all these packages and to give credit to those whos code helped in the creation of the SBS Vision Sensor software.

For components that reference the GNU General Public License (GPL) or the GNU Lesser General Public License (LGPL), please find these licenses and the written offer for source code in this software installation in \FESTO\SBS Vision Sensor\Eula\OpenSourceLicenses.

The SBS Vision Sensor firmware makes use of Linux Version 2.6.33 (Website: www.kernel.org), which is distributed under the GNU GPL version 2.

The SBS Vision Sensor firmware makes use of x-loader, an initial program loader for Embedded boards based on OMAP processors (Website: <http://arago-project.org/git/projects/?p=x-load-omap3.git;a=summary>) which is distributed under the GNU GPL version 2 or higher.

The SBS Vision Sensor firmware makes use of u-boot, an initial program loader for Embedded boards based on OMAP processors (Website: <http://arago-project.org/git/projects/?p=x-load-omap3.git;a=summary>) which is distributed under the GNU GPL version 2 or higher

The SBS Vision Sensor firmware makes use of spike Version 0.2,a SPI-driver (Website: <https://github.com/scottellis/spike/blob/master/spike.c>), which is distributed under the GNU GPL version 2 or higher.

The SBS Vision Sensor firmware makes use of Busy-Box Version 1.18.1 (Website: <http://www.busybox.net/>), which is distributed under the GNU GPL version 2 or higher

The SBS Vision Sensor firmware makes use of vsftpd Version 2.0.3 (Website: <https://security.appspot.com/vsftpd.html>), which is distributed under the GNU GPL version 2 or higher.

The SBS Vision Sensor firmware makes use of mtd-utils Version 1.5.0 (Website: <http://www.linux-mtd.infradead.org/doc/general.html>), which is distributed under the GNU GPL version 2 or higher.

The SBS Vision Sensor firmware makes use of Boa Webserver Version 0.94.13 (Website: <http://www.boa.org/>), which is distributed under the GNU GPL version 2 or higher.

The SBS Vision Sensor firmware makes use of Procps Version 3.2.8 (Website <http://procps.sourceforge.net/download.html>), which is distributed under the GNU GPL version 2 or higher and GNU LGPL version 2.1 or higher.

The SBS Vision Sensor firmware makes use of GnuPG Version 1.4.10 (Website: <https://www.gnupg.org/>), which is distributed under the GNU GPL version 3 or higher.

The SBS Vision Sensor firmware makes use of glibc, which is distributed under GNU LGPL version 2.1 or higher.

The SBS Vision Sensor firmware makes use of Dropbear - a SSH2 server Version 2012.55 (Website: <https://matt.ucc.asn.au/dropbear/dropbear.html>). The Dropbear SSH2 server is distributed under the terms of the Dropbear License which is a MIT/X Consortium style open source license. Please find this license in this software installation in \FESTO\SBS\Eula\OpenSourceLicenses

Vision Sensor Configuration Studio software is based in part on the work of the Qwt project (<http://qwt.sf.net>).

Table of Contents

I General Information and Safety	9
1.1 Safety notes	9
1.2 Components supplied	9
1.3 Requirements for use	9
2 Intended Use	10
2.1 Field of application	10
2.2 Functions overview	11
2.2.1 Functions overview: Color sensor, Universal	12
2.3 Sensor types	14
2.3.1 Object detection	14
2.3.2 Code Reader	15
2.3.3 Color Sensor	16
2.3.4 Universal	17
2.4 Field of view / Depth of view	18
3 Installation	23
3.1 Mechanical Installation	23
3.1.1 Arrangement for dark-field illumination	23
3.1.2 Arrangement for bright-field illumination	24
3.1.3 Alignment for a vertical illumination	25
3.1.4 Assembly SBS - Mounting bracket MK 45	26
3.2 Electrical installation	26
3.2.1 Connection possibilities	27
3.2.1.1 LED Display	27
3.2.1.2 Focussing screw	28
3.2.1.3 24 V DC Connection	28
3.2.1.4 LAN Connection	28
3.2.1.5 Data Connection	28
3.2.1.6 Plug connections	29
3.3 Network settings, Short reference	32
3.3.1 Basic settings for PC and SBS Vision Sensor	32
3.3.2 Direct Connection - Setting the IP Address of the PC	33
3.3.3 Network Connection - Setting the IP address of the SBS Vision Sensor	34
4 SBS – Operating- and configuration software	36
4.1 SBS – Operating- and configuration software - Overview	36
4.1.1 Structure of PC software	36
4.1.2 Context help	36
4.2 SBS – Operating- and configuration software – Short introduction	37
4.2.1 SBS, Short introduction, Starting the software	37
4.2.2 Vision Sensor Device Manager: Open sensors or sensor simulation / Passwords	37
4.2.3 Passwords	39
4.2.4 Password levels:	39
4.3 Vision Sensor Configuration Studio: Setting sensor, Job	41
4.3.1 Job Setup	42
4.3.2 Alignment settings	43
4.3.3 Detector settings	44
4.3.4 Output, I/O and data output	45

4.3.5 Result	47
4.3.6 Start sensor	48
4.4 Vision Sensor Visualisation Studio, display images and results	49
4.5 SBS – Operating- and configuration software – Vision Sensor Device Manager, all functions	50
4.5.1 Active sensors	50
4.5.2 Sensors for simulation mode	52
4.5.3 Find / Add active sensor	52
4.5.4 Configuring a connected sensor	53
4.5.5 Display images and result data	53
4.5.6 Sensor's network settings	53
4.5.7 Update / Firmware update	54
4.5.8 User administration / Passwords	54
4.6 SBS – Operating- and configuration software – Vision Sensor Configuration Studio, all functions	56
4.6.1 Jobs (Inspection tasks)	56
4.6.1.1 Creation, modification and administration of jobs	57
4.6.1.2 Loading and saving jobs and job sets	58
4.6.1.3 Parameters for image acquisition	59
4.6.1.4 Job, tab White balance	60
4.6.1.5 Preprocessing, Filter for image improvement.	61
4.6.1.6 Calibration	62
4.6.1.7 Parameters Cycle time	79
4.6.2 Alignment	80
4.6.2.1 Selection and configuration of an alignment detector	81
4.6.2.2 Alignment Pattern matching	82
4.6.2.3 Alignment Edge detector	84
4.6.2.4 Alignment Contour detection	86
4.6.3 Detectors	90
4.6.3.1 Creating and adjusting detectors	90
4.6.3.2 Selecting a suitable detector	92
4.6.3.3 Detector Pattern matching	92
4.6.3.4 Detector Contour	101
4.6.3.5 Contrast detector	109
4.6.3.6 Grey detector	113
4.6.3.7 Brightness detector	117
4.6.3.8 Detector BLOB, Introduction	120
4.6.3.9 Detector Caliper	133
4.6.3.10 Barcode detector.	136
4.6.3.11 2D Code detector	144
4.6.3.12 Detector OCR	152
4.6.3.13 Detector Color value	164
4.6.3.14 Detector Color area, Color select	166
4.6.3.15 Detector Color list	169
4.6.4 Output of inspection results	172
4.6.4.1 I/O mapping	172
4.6.4.2 Functions of the programmable, digital inputs:	175
4.6.4.3 Output signals (Digital outputs / Logic)	178
4.6.4.4 Interfaces	180
4.6.4.5 Timing, Digital outputs	184
4.6.4.6 Telegram, Data output	189

4.6.4.7 Parameters for image transmission	193
4.6.4.8 Parameters Archiving	195
4.6.5 Result	196
4.6.5.1 *) Score value with result of caliper detector.	198
4.6.6 Start sensor	198
4.6.7 Further topics of Vision Sensor Configuration Studio	199
4.6.7.1 Trigger settings	200
4.6.7.2 Switching between online and offline mode	200
4.6.7.3 Simulation of jobs (offline mode)	201
4.6.7.4 Creating filmstrips	201
4.6.7.5 Image recorder	203
4.6.7.6 Displays in image window	205
4.6.7.7 Search and parameter zones	205
4.6.7.8 Color models	207
4.6.7.9 Application Examples	209
4.7 SBS – Operating- and configuration software – Vision Sensor Visualisation Studio, all functions ..	210
4.7.1 Image display	210
4.7.2 Commands / Freeze image	211
4.7.2.1 Zoom	211
4.7.3 Image recorder	211
4.7.4 Archiving test results and images	213
4.7.5 Statistics	214
4.7.6 Result	215
4.7.7 Changing active job	216
4.7.8 Upload	217
5 Communication	219
5.1 Possibilities of image- / data transfer and archiving	219
5.1.1 Ethernet, Port 2005 / 2006	219
5.1.1.1 Ethernet example 1: Pure data output from SBS to PC / PLC	219
5.1.1.2 Ethernet example 2: commands (requests) from PC / PLC to SBS	224
5.1.2 RS422	228
5.1.2.1 RS422 example 1: Data output from SBS to PC / PLC, and commands (requests) to the SBS	228
5.1.2.2 Settings to connect the „I/O-Box“ for I/O- extension or ejector control to the SBS	237
5.1.3 PC- Archiving (Vision Sensor Visualisation Studio)	238
5.1.3.1 Start/end archiving:	240
5.1.4 Archiving via ftp or smb	240
5.1.4.1 Example: Archiving via ftp	241
5.1.4.2 Example: Archiving via smb	242
5.1.5 Ram disk (on the sensor)	249
5.2 Backup	251
5.2.1 Backup creation	251
5.2.2 Exchange SBS	251
5.3 Job switch	252
5.3.1 Job switch via digital inputs	252
5.3.1.1 Job 1 or Job 2	252
5.3.1.2 Job 1 ... 31 via binary bit pattern	252
5.3.1.3 Job 1..n via pulses	253
5.3.2 Job switch via Ethernet	253

5.3.3 Job switch via Serial	253
5.3.4 Job switch via Vision Sensor Visualisation Studio	253
5.4 Operation with PLC	254
5.4.1 Profibus plug adapter (RS422)	254
5.4.2 Example Siemens S7	255
5.4.3 Example Beckhoff CX 1020	255
5.5 Network connection	255
5.5.1 Installation of SBS into a network / gateway	255
5.5.2 Proceeding/Troubleshooting - Direct Connection	256
5.5.3 Proceeding/Troubleshooting - Network Connection	256
5.5.4 Used Ethernet- Ports	257
5.5.5 Access to SBS via network	258
5.5.6 Access to SBS via Internet / World Wide Web	259
5.6 Vision Sensor, PROFINET, Introduction	260
5.6.1 Electrical connection SBS in the Profinet network	261
5.6.2 Configuration of SBS via Festo Vision Sensor Configuration Studio for the use with PROFINET	261
5.6.2.1 Settings in Vision Sensor Device Manager	261
5.6.2.2 Setting of IP and name	262
5.6.2.3 Open Vision Sensor Configuration Studio	263
5.6.2.4 Select Interface “Profinet”	263
5.6.2.5 Definition of the telegram	264
5.6.2.6 Start sensor, data output	265
5.6.3 Profinet configuration of PLC, example Siemens S7-1200 TIA	265
5.6.3.1 Create a new project	265
5.6.3.2 Select GSD file	265
5.6.3.3 Adding SBS to Project	266
5.6.3.4 Connect SBS to PLC	267
5.6.3.5 Definition of I/O data	268
5.6.3.6 Set IP address of SBS in the project (Option 1)	268
5.6.3.7 Set IP Address with Vision Sensor Device Manager (Option 2)	269
5.6.3.8 Set the name with TIA interface	270
5.6.3.9 Write name into SBS	270
5.6.3.10 Translate project and write to PLC	271
5.6.4 Profinet- telegram description SBS	271
5.6.4.1 Module 1: „Control“ (From PLC to SBS)	271
5.6.4.2 Module 2: “Status” (From SBS to PLC)	273
5.6.4.3 Module 3: “Data” (From SBS to PLC)	276
5.6.4.4 Module 4: „Request“ (From PLC to SBS)	276
5.6.4.5 Module 5: „Response“ (From SBS to PLC)	277
5.6.4.6 Start- / End- criteria per each Profinet command	277
5.6.5 Timing diagrams to the SBS Profinet communication with a PLC	278
5.6.5.1 Case: Trigger ok	278
5.6.5.2 Case: Trigger not possible (not ready)	278
5.6.5.3 Case: Jobchange ok	279
5.6.5.4 Case: Jobchange delayed	279
5.6.5.5 Case: Jobchange not possible (e.g. wrong job number)	280
5.6.5.6 Case: Switch to run ok	280
5.6.5.7 Case: Switch to run not possible	280

5.6.5.8 Strong recommendations for PLC programmer	281
5.6.5.9 Request sequences	281
5.7 Vision Sensor, EtherNet/IP, Introduction	283
5.7.1 Electrical connection of the Vision Sensor in the EtherNet/IP network	283
5.7.2 Configuration of Vision Sensor for the use with EtherNet/IP	283
5.7.2.1 Settings in Vision Sensor Device Manager	284
5.7.2.2 Setting of IP and name	284
5.7.2.3 Open Vision Sensor Configuration Studio	284
5.7.2.4 Select Interface "EtherNet/IP"	285
5.7.2.5 Definition of the telegram	285
5.7.2.6 Start sensor, data output	286
5.7.3 EtherNet/IP protocol	286
5.7.3.1 Assembly request	287
5.7.3.2 Assembly response	289
5.7.4 EDS file	290
5.7.5 Implementation of Vision Sensor into RSLogix	291
5.7.5.1 Over Generic Profile	292
5.7.5.2 Over EDS-File	293
5.7.6 Result data: assembly response	294
5.7.7 EtherNet/IP Appendix	296
5.7.7.1 Assembly Request	296
5.7.7.2 Assembly Response	299
5.8 Rescue	304
6 Image settings and accessories	307
6.1 Good images	307
6.2 Environmental light, shrouding, IR- version	307
6.3 External illumination	308
6.4 The most important types of illumination are: Bright field, Dark field and Diffuse illumination.	310
6.4.1 Bright field illumination	310
6.4.2 Dark field illumination	311
6.4.3 Diffuse illumination (external only)	312
6.5 IO-Box as IO-Extension (RS422)	312
7 Technical Data	313
8 Addendum	316
8.1 Telegram, Data output	316
8.1.1 Serial Communication ASCII	316
8.1.2 Serial communication BINARY	338
8.2 Further explanations to Edge detector (alignment)	361
8.3 Starting Vision Sensor Visualisation Studio or Vision Sensor Configuration Studio via Autostart	365
8.4 Care and maintainance	365
8.4.1 Cleaning	365

I General Information and Safety

I.1 Safety notes

Before starting the SBS Vision Sensor, read these instructions carefully, ensure that you have understood them and comply with them at all times.

The SBS Vision Sensor should only be connected by a qualified electrician.

Do not tamper with or make alterations on the unit!

The SBS Vision Sensor is not a safety-critical component and its use is prohibited under conditions where the safety of persons may depend on its function.

The IP address set for the SBS Vision Sensor should be marked on the enclosed label. After installation, stick the label on the sensor in a clearly visible position.

The IP address of the SBS Vision Sensor must be used once only in any network.

For Use with any Listed (CYJV) cable assembly.

I.2 Components supplied

- SBS Vision Sensor including integrated illumination (or as version with C-Mount lens without illumination)
- CD-ROM with Computer software and Operating instructions
- Data sheet, mounting clamp, allen key, screwdriver and protective cap for Ethernet plug.

I.3 Requirements for use

Configuration of the SBS Vision Sensor requires a standard PC/Notebook (at least Pentium 4, 1GHz and 1 GB RAM, with Microsoft Windows 7 or Windows 10) with network connection or a network with TCP-IP protocol. We recommend a Pentium 4 Dual Core > 2GHz and 2GB RAM, for Windows 7 or Windows 10. We recommend a screen resolution of min. 1024 x 768 pixels. A basic knowledge of computers is also required. The SBS Vision Sensor is supplied with the IP address 192.168.100.100 and a subnet mask 255.255.255.0. The SBS Vision Sensor is operated independently of a PC or PLC. A PC/notebook is only necessary for configuration of the SBS Vision Sensor.

Attention must be paid to sufficient and constant object illumination to ensure reproducible results and avoid malfunction.

Reflections or varying incident light may affect detection results. If necessary, use an external light source and/or light-screening / shrouding devices to exclude incident light

2 Intended Use

2.1 Field of application

The SBS Vision Sensor is an optical sensor and uses several evaluation methods according to the version: pattern recognition, contrast detection, grey level, contour detection, barcode or Data Matrix code reading, Optical character reading as well as wafer detection. The product is designed for industrial use only. In residential areas possibly additional measures for noise suppression must be done.

Object:

The SBS Vision Sensor precisely detects faulty parts, parts in the wrong place, at the wrong angle or in the wrong order or a combination of all of these. Several detectors are available for inspection tasks and interpretation: e.g. pattern matching, contour detection, brightness, grey level, contrast detection, caliper or BLOB. The advanced version of the SBS Vision Sensor also offers alignment: it is thus now also possible to reliably detect those features which do not appear with repeated accuracy in the taught position. All interpretation is carried out relative to the actual position and angle of the part without having to define an independent characteristic for each possible position. This high capacity tool also enables you to solve demanding pick and place applications.

The advanced version offers also the calibration in world coordinates for measurement- and robot applications.

Code Reader:

Identification of products, components or packaging from printed or directly marked – punched or laser-etched – codes is common practice in many sectors of industry today. The Vision Code Reader from Festo immediately detects which part is in front of it: it can easily read numerous types of barcodes as well as printed and directly marked data matrix codes according to ECC 200 standard and read characters directly via Optical Character Reading (OCR), and this on any base (metal, plastic, paper, glass). The sensor can even routinely decipher askew or warped codes or codes on convex, reflective or transparent surfaces. The Vision Code Reader assesses the quality of your printed or directly marked data matrix codes using standardised ISO and AIM quality parameters. This enables you to introduce early correctional measures and thus avoid rejects due to illegible codes.

Color:

The SBS Color offers powerful object detection in combination with color detection. This leads to an increased stability in several object detection applications as well as the possibility to sort colored parts which would have a similar look in grey image. Beside this even active objects (like e.g. lighting LED's) or "non colors" like black and white can be detected.

Universal

In the SBS Universal all functions of SBS Object, Code Reader and Color are available in combination in one device. The Professional version offers also the Mutishot function to detect smallest surface defects.

The SBS Vision Sensor range is an economic alternative to conventional image processing systems.

2.2 Functions overview

Characteristics: Object / Code Reader / Solar

Function	Object Std.	Object Adv.	Code Reader Std.	Code Reader Adv.
Frames per second	50	50	50	50
Number of Jobs	8	255	8	255
Alignment	Contour only	X		X
Calibration in world coordinates		X		
Number of detectors	32	255	2	255
- Pattern matching (X-, Y- translation)	X	X		X
- Contour matching (X-, Y- translation and rotation)	X	X		
- Grey level	X	X		X
- Contrast	X	X		X
- Brightness	X	X		X
- Caliper		X		
- BLOB		X		
- Data code			X	X
- Barcode			X	X
- OCR				
4 digital outputs, 2 inputs, PNP or NPN	X	X	X	X
Free definable digital In- / Outputs, PNP or NPN	2	4	2	4
Free shape of ROI	contour only	X		X
Timeout, specified time response	X	X	X	X
Variable resolutions	X	X	X	X
Illumination quadrant controlled	X	X	X	X
Image recorder	X	X	X	X

Function	Object Std.	Object Adv.	Code Reader Std.	Code Reader Adv.
Encoder input		X		X
Ethernet interface	X	X	X	X
PROFINET	X	X	X	X
RS422 / RS232 interface		X	X	X
EtherNet/IP interface	X	X	X	X
Sensor monitoring by Viewer, Job-Upload	X	X	X	X
Sensor monitoring by SBSxWebViewer(Webviewer)	X	X	X	X
R3B integrated 6 / 12	X / X	X / X	X / X	X / X
R2B integrated 12 mm		X		X
Version with C-Mount		X		X

2.2.1 Functions overview: Color sensor, Universal

Characteristics SBS Color, Universal

Function	Color Standard	Color Advanced	Monochrome Universal Advanced
Frames per second	40	40	40
Number of Jobs	8	255	255
Alignment	Contour only	X	X
Calibration in world coordinates			X
Number of detectors	32	255	255
- Pattern matching (X-, Y- translation)		X	X
- Contour matching (X-, Y- translation and rotation)		X	X
- Grey level		X	X
- Contrast	X	X	X
- Brightness		X	X
- Caliper		X	X
- BLOB		X	X

Function	Color Standard	Color Advanced	Monochrome Universal Advanced
- Data code			X
- Barcode			X
- OCR			X
- Color value		X	
- Color area	X	X	
- Color List		X	
4 digital outputs, 2 inputs, PNP or NPN	X	X	X
Free definable digital In- / Outputs, PNP or NPN	2	4	4
Free shape of ROI	Contour only	X	X
Timeout, specified time response	X	X	X
Variable resolutions	X	X	X
Illumination quadrant controlled	X	X	X
Image recorder	X	X	X
Encoder input		X	X
Ethernet interface	X	X	X
PROFINET	X	X	X
RS422 / RS232 interface		X	X
EtherNet/IP interface	X	X	X
Sensor monitoring by Viewer, Job-Upload	X	X	X
Sensor monitoring by SBSxWebViewer (Webviewer)	X	X	X
R3B integrated 6 / 12	X / X	X / X	
R2B integrated 12 mm		X	
Version with C-Mount		X	X

2.3 Sensor types

2.3.1 Object detection

Part no.	Type	Optics	Depth of focus	Internal illumination	min. operating distance / mm ^{*1}	min. Field of view mm x mm
R3B Advanced White						
8058724	SBSI-Q-AF-R3B-F6-W	6	Normal	White	6	5 x 4
8058725	SBSI-Q-AF-R3B-F12-W	12	Normal	White	30	8 x 6
R3B Advanced IR						
8058726	SBSI-Q-AF-R3B-F6-NR ^{*3}	6	Normal	InfraRed	6	5 x 4
8058727	SBSI-Q-AF-R3B-F12-NR ^{*3}	12	Normal	InfraRed	30	8 x 6
R3B Advanced C-Mount						
8058728	SBSC-Q-AF-R3B ^{*2,3}	C-Mount		External	lens dependant	lens dependant
R3B Standard White						
2942261	SBSI-Q-R3B-F6-W	6	Normal	White	6	5 x 4
2942262	SBSI-Q-R3B-F12-W	12	Normal	White	30	8 x 6
R3B Standard IR						
2942265	SBSI-Q-R3B-F6-NR ^{*3}	6	Normal	InfraRed	6	5 x 4
2942266	SBSI-Q-R3B-F12-NR ^{*3}	12	Normal	InfraRed	30	8 x 6
R2B Advanced White						
8058730	SBSI-Q-AF-R2B-F12-W	12	Normal	White	30	16 x 13
R2B Advanced C-Mount						
8058729	SBSC-Q-AF-R2B ^{*2,3}	C-Mount		External	lens dependant	lens dependant

*1 For longer operating distances (from approx. 200 mm) external illumination may be necessary.

*2 When the C-Mount version of SBS is in use, a C-Mount lens with a 5 mm intermediate ring (delivered separately) or a C-Mount protective case is required.

*3 External IR illumination is only possible with IR sensors or C-Mount sensors.

2.3.2 Code Reader

Part no.	Type	Optics	Depth of focus	Internal illumination	min. operating distance / mm *1	min. Field of view mm x mm
R3B Advanced White						
8058715	SBSI-B-AF-R3B-F6-W	6	Normal	White	6	5 x 4
8058716	SBSI-B-AF-R3B-F12-W	12	Normal	White	30	8 x 6
R3B Advanced Red						
8058717	SBSI-B-AF-R3B-F6-R	6	Normal	Red	6	5 x 4
8058718	SBSI-B-AF-R3B-F12-R	12	Normal	Red	30	8 x 6
R3B Advanced IR						
8058719	SBSI-B-AF-R3B-F6-NR *3	6	Normal	InfraRed	6	5 x 4
8058720	SBSI-B-AF-R3B-F12-NR *3	12	Normal	InfraRed	30	8 x 6
R3B Advanced C-Mount						
8058721	SBSC-B-AF-R3B *2,3	C-Mount		External	lens dependant	lens dependant
R3B Standard White						
2930232	SBSI-B-R3B-F6-W	6	Normal	White	6	5 x 4
2930233	SBSI-B-R3B-F12-W	12	Normal	White	30	8 x 6
2930242	SBSI-B-R3B-F6-W-D	25	Normal	White	140	18 x 14
2930243	SBSI-B-R3B-F12-W-D	6	Enhanced	White	6	5 x 4
R3B Standard Red						
2930234	SBSI-B-R3B-F6-R	6	Normal	Red	6	5 x 4
2930235	SBSI-B-R3B-F12-R	12	Normal	Red	30	8 x 6
2930236	SBSI-B-R3B-F6-R-D	25	Normal	Red	140	18 x 14
2930237	SBSI-B-R3B-F12-R-D	6	Enhanced	Red	6	5 x 4
2930234	SBSI-B-R3B-F6-R	12	Enhanced	Red	30	8 x 6
R3B Standard IR						
2930238	SBSI-B-R3B-F6-NR *3	6	Normal	InfraRed	6	5 x 4
2930239	SBSI-B-R3B-F12-NR *3	12	Normal	InfraRed	30	8 x 6
2930240	SBSI-B-R3B-F6-NR-D *3	6	Enhanced	InfraRed	6	5 x 4

Part no.	Type	Optics	Depth of focus	Internal illumination	min. operating distance / mm ^{*1}	min. Field of view mm x mm
2930241	SBSI-B-R3B-F12-NR-D ^{*3}	12	Enhanced	InfraRed	30	8 x 6
R2B Advanced Red						
8058723	SBSI-B-AF-R2B-F12-R	12	Normal	Red	30	16 x 13
R2B Advanced C-Mount						
8058722	SBSC-B-AF-R2B ^{*2,3}	C-Mount		External	lens dependant	lens dependant

*1 For longer operating distances (from approx. 200 mm) external illumination may be necessary.

*2 When the C-Mount version of SBS is in use, a C-Mount lens with a 5 mm intermediate ring (delivered separately) or a C-Mount protective case is required.

*3 External IR illumination is only possible with IR sensors or C-Mount sensors.

2.3.3 Color Sensor

Part no.	Type	Optics	Depth of focus	Internal illumination	min. operating distance / mm ^{*1}	min. Field of view mm x mm
R3B Advanced White						
8058733	SBSI-F-AF-R3C-F6-W	6	Normal	White	6	5 x 4
8058734	SBSI-F-AF-R3C-F12-W	12	Normal	White	30	8 x 6
R3B Advanced C-Mount						
8058735	SBSC-F-AF-R3C ^{*2}	C-Mount		External	lens dependant	lens dependant
R3B Standard White						
8058731	SBSI-F-R3C-F6-W	6	Normal	White	6	5 x 4
8058732	SBSI-F-R3C-F12-W	12	Normal	White	30	8 x 6

*1 For longer operating distances (from approx. 200 mm) external illumination may be necessary.

*2 When the C-Mount version of SBS is in use, a C-Mount lens with a 5 mm intermediate ring (delivered separately) or a C-Mount protective case is required.

2.3.4 Universal

Part no.	Type	Optics	Depth of focus	Internal illumination	min. operating distance / mm ^{*1}	min. Field of view mm x mm
R2B Universal C-Mount						
8058736	SBSC-U-AF-R2B ^{*2,3}	C-Mount		External	lens dependant	lens dependant
R3B Universal C-Mount						
8058737	SBSC-U-AF-R3B ^{*2,3}	C-Mount		Extern	objektiv-abhängig	objektiv-abhängig

*1 For longer operating distances (from approx. 200 mm) external illumination may be necessary.

*2 When the C-Mount version of SBS is in use, a C-Mount lens with a 5 mm intermediate ring (delivered separately) or a C-Mount protective case is required.

*3 External IR illumination is only possible with IR sensors or C-Mount sensors.

2.4 Field of view / Depth of view

Field of view R3B 6mm lens, internal




Fig. 1: Field of view R3B 6mm lens, internal

Field of view R3B 12mm lens, internal




Fig. 2: Field of view R3B 12mm lens, internal

Field of view R2B I2mm lens, internal




Fig. 3: Field of view R2B I2mm lens, internal

Depth of view R3B 6mm lens internal, normal




Fig. 4: Depth of view R3B 6mm lens internal, normal

Depth of view R3B 6mm lens internal, enhanced




Fig. 5: Depth of view R3B 6mm lens internal, enhanced

Depth of view R3B 12mm lens internal, normal




Fig. 6: Depth of view R3B 12mm lens internal, normal

Depth of view R3B 12mm lens internal, enhanced




Fig. 7: Depth of view R3B 12mm lens internal, enhanced

Depth of view R2B 12mm lens internal, normal




Fig. 8: Depth of view R2B 12mm lens internal, normal

3 Installation

3.1 Mechanical Installation

To ensure maximum accuracy of detection, the SBS Vision Sensor should be protected from vibration. Secure the supply and I/O cables with cable binders to prevent crushing or slipping.

Select a position for the SBS Vision Sensor in which interfering factors such as slight differences in the position of the object or variations in illumination have little or no effect.

Screw the SBS Vision Sensor onto the mounting clamp (supplied with the unit) and then onto a suitable object. Use only the mounting clamp MK 45 (no. 543-11000) or the mounting hinge MG2A (no.543-11023).

3.1.1 Arrangement for dark-field illumination

For the prevention of direct reflections and accentuation of edges etc.




Fig. 9: Arrangement for dark-field illumination

3.1.2 Arrangement for bright-field illumination

For transmitted light/measuring tasks or for the accentuation of highly-reflective objects




Fig. 10: Arrangement for bright-field illumination

Observe the object clearance given in the table Field of View / Working Distance.

To avoid interfering reflection from the detection object, align the SBS Vision Sensor at an angle of approx. 10° - 15° with reference to the optical axis.

Fine adjustment

Important: Fine adjustment of the SBS Vision Sensor should not be carried out until after electrical connection and start-up (PC software installation).

3.1.3 Alignment for a vertical illumination

In order to assure the absolutely vertical alignment of the SBS to the object surface, put a piece of reflective foil or a mirror on top of the object and start the SBS operating software. For an image that is continually updated, select trigger mode „free run ? “ and image update: „continuous ?“. Then align the sensor to the reflective surface / the mirror as vertical as possible until the integrated illumination LEDs are directly dazzling in the image of the user interface ([Arrangement for bright-field illumination \(Page 24\)](#)).




Fig. 11: Alignment for a vertical illumination

3.1.4 Assembly SBS - Mounting bracket MK 45




Fig. 12: Assembly SBS - Mounting bracket MK 45

For fixing the SBS on a fixing system / machine housing, slide the provided dovetail mounting bracket MK45 on the dovetail guide at the bottom side of the SBS and fix it at the desired position with the hexagon socket in the cross hole of the mounting bracket. Then further Festo mounting accessories may be attached to the mounting bracket or any other attachments may be fixed by using the tapped holes in the MK45.

3.2 Electrical installation

The electrical installation of the SBS Vision Sensor must be carried out by a qualified person. When installing the SBS Vision Sensor, disconnect all electrical components from the power supply. When the unit is being used in a network, ensure that the network address (IP address) of the SBS Vision Sensor set by the manufacturer at 192.168.100.100 is free and is not in use for any other unit connected to the system.

If necessary, re-set the IP address of the SBS Vision Sensor as described in the section „Network settings“.

When the SBS Vision Sensor is in use, the protective caps supplied must be pushed onto the M12 sockets (data and LAN) which are not in use. For error free operation the length of the connecting cables must not be longer than 30 m. Failure to do this may cause malfunction.

3.2.1 Connection possibilities

For stand-alone operation (independent of PC /PLC) only connection 24 V DC is required after start-up.

For electrical installation, connect wires as follows:

- *A: LED display
- *B: Focussing screw
- *C: 24 VDC, I/O- M12 connection socket
- *D: Data (RS422) M12 socket
- *E: LAN M12 connection socket




Fig. 13: Connectors SBS




Fig. 14: Connection SBS

3.2.1.1 LED Display

Name	Colour	Meaning
Pwr.	green	Operating voltage
A	yellow	Result 1
B	yellow	Result 2
C	yellow	Result 3

All LED's are set without taking into account any timing function (e.g. Trigger delay)

3.2.1.2 Focussing screw

Focussing screw to adjust focus.

Focus: Clockwise = higher distance

Counter Clockwise = lower distance

3.2.1.3 24 V DC Connection

M12 Connection socket for 24 V DC voltage supply and digital I/O.

For the exact plug connection see [PIN assignment, connection 24 V DC](#)

3.2.1.4 LAN Connection

M12 Connection socket for Ethernet connection.

For the exact plug connection see [PIN assignment, connection LAN](#).

Use only the correct network cables.

3.2.1.4.1 Direct connection of the SBS Vision Sensor to a PC (recommended)




Fig. 15: Direct connection SBS <> PC

3.2.1.4.2 Connection of the SBS Vision Sensor to a PC via a network:




Fig. 16: Connection via a network

3.2.1.5 Data Connection

M12 Connection socket for DATA serial interface, RS422 / RS232.

s. [PIN assignment DATA *A](#)) (Page 30)

3.2.1.6 Plug connections

All pin assignments and signals are referring to the view from the sensor.

3.2.1.6.1 PIN assignment, connection 24 V DC

PIN	Colour	Use
1	BN	+ Ub (24V DC)
2	BU	GND
3	WH	IN (external trigger)
4	GN	READY *1
5 *2, *5	PK	IN/OUT (advanced: encoder B+)
6 *2, *5	YE	IN/OUT
7 *2	BK	IN/OUT, LED B*4
8 *2	GY	IN/OUT, LED C*4
9	RD	OUT (external illumination)
10	VT	IN (advanced: encoder A+)
11	GYPK	VALID *3
12	RDBU	OUT (ejector, max. 100mA), LED A*4

*1 Ready: Ready for next ext. trigger.

*2 Switchable input- output

*3 VALID: shows available results

*4 All LED´s are set without taking into account any timing function (e.g. Trigger delay)

*5 Not available with all Standard types

For shielded cables use shield, extensively connected.

3.2.1.6.2 PIN assignment, connection LAN

(M12) 4 pin	Signal
1	TxD+
2	RxD+
3	TxD-
4	RxD-

3.2.1.6.3 PIN assignment DATA *A)

PIN	Colour	Use RS422	use RS232
1	brown	RxD+	Rx
2	white	RxD-	NC
3	blue	TxD+	NC
4	black	TxD-	Tx
5	grey	GND	GND

*A) Not with Object-, Color-,Solar- Standard version

For shielded cables use shield.

3.2.1.6.4 Exemplary connection plan and software settings for the following setup:

- Power supply
- Trigger
- 1x digital output
- Encoder
- Ethernet to PC or PLC




Fig. 17: Exemplary connection plan

3.2.1.6.5 Electrical connection supply voltage and shield




Fig. 18: Electrical connection, supply voltage 24VDC in cabinet with shield

3.2.1.6.6 Electrical connection PNP / NPN




Fig. 19: Connection example SBS in PNP mode. In-/outputs switch to +24V




Fig. 20: Connection example SBS in NPN mode

As the inputs refer to ground, an additional pull-up resistor may be required in order to increase the input voltage to 24V when unswitched. The outputs switch to ground.

3.3 Network settings, Short reference

The following instructions indicate how to change the network configuration of the PC and the SBS Vision Sensor. If incorrect settings are used, the network connections in the computer may be lost. To be on the safe side, note the former settings for later use if required.

Following this procedure, it may be necessary to re-start the system. In order to determine which IP addresses are allowed in your network or locally in your PC, and to carry out the necessary settings on your PC, contact the system administrator beforehand.

The illustrations, dialogues and menus originate from the operating system Microsoft WindowsXP™. The illustrations are similar in other operating systems.

3.3.1 Basic settings for PC and SBS Vision Sensor

To configure the SBS Vision Sensor with a PC it is essential that a network board and the TCP/IP LAN-connection is installed on the PC (This also applies when the PC is not connected to a network). The SBS supports the automatic recognition of the Ethernet transmission rate, but 100 MBit at the most.

The internet protocol IPv4 must be activated.

There are two alternatives to configure and parameterize the SBS Vision Sensor.

See also chap. Network connection

1. Direct Connection

2. Network Connection

3.3.2 Direct Connection - Setting the IP Address of the PC

To connect the SBS Vision Sensor to a PC via Ethernet the IP addresses of both devices have to correspond. The default IP of the SBS is 192.168.100.100 with Subnet mask = 255.255.255.0. To establish a direct connection, the PC must be set to a corresponding, fixed IP address like follows.

1. Click on Start / Control Panel / Network Connection / LAN Connection / Properties, the window "Local Area Connection Properties" opens.
2. In the list „This connection requires following elements“ select the option „Internet Protocol (TCP/IP)“ and then click the button „Properties“.
3. In the following window (see fig. 7) set the desired IP address of the PC and the sub-network data.
4. Confirm entries with OK

Example:

The SBS Vision Sensor is pre-set to IP address 192.168.100.100 and subnet mask 255.255.255.0. In this case, the IP address may be set to any value between 192.168.100.1 and 192.168.100.254, with a subnet mask 255.255.255.0, with the exception of the sensor IP address (192.168.100.100). To alter the sensor's IP address, see chap. Please do also not use the addresses .0 and .255 as these addresses are reserved for network infrastructure devices such as servers, gateways, etc.




Fig. 21: PC IP Setup

3.3.3 Network Connection - Setting the IP address of the SBS Vision Sensor

Before connecting the sensor in the network, check with the network administrator whether the sensor's address has already been assigned (default: 192.168.100.100 with subnet mask 255.255.255.0). This can otherwise cause network failure. The set IP address is to be noted on the enclosed label. The label is then to be stuck on the sensor in a clearly visible place after installation.

Network connection speed:

The sensor must only be operated with 100MBit/full-duplex when using VGA resolution (or higher) and Vision Sensor Visualisation Studio.

Sensor's IP still free:

Connect sensor to network and then set the sensor's IP to match the PC according to the administrator's specifications, as follows, beginning with 2.

Sensor IP already assigned:

1. First connect sensor and PC directly and set an authorised IP address in the sensor.
2. Connection via the network can then be carried out. First ensure electrical connection and installation of PC software has been completed. To set the IP address on the SBS Vision Sensor, the following steps are to be carried out in the PC software:
 - a. Start Vision Sensor Device Manager software
 - b. Select the required SBS sensor from the active sensor list (single left mouse click)
 - c. Set sensor's new IP address with the "Set" button. Follow the on screen prompts. The IP address is assigned by your system administrator. The PC's IP address is shown in the status bar under the buttons. (Please note some pc's have more than one Ethernet connection i.e. wireless and wired LAN connections
 - d. When the new IP address has been set, Re-select the sensor and connect. Via Config or View




Fig. 22: Vision Sensor Device Manager

Modification of the standard gateway enables operation in different sub-networks. Only alter this setting after consultation with your network administrator. Automatic integration of a new computer or sensor in the existing network without manual configuration is possible through DHCP. Normally, automatic supply of IP address must only be set on the sensor, the client. When the sensor is started in the network, it can obtain the IP address, net mask and gateway from a DHCP server. Activation of DHCP mode is carried out via the “Set” button by activating the checkbox “DHCP”. As one and the same SBS can thus have different IP addresses at different times, a sensor name must be attributed when activating the DHCP. Should several SBS s be in one network, different names must be used.




Fig. 23: SBS IP Setup

If a SBS with DHCP is switched on in a network without a DHCP server, the SBS automatically sets the IP address to 0.0.0.0. This can be the case, e.g. in the case of power/server failure or the restart of the system after shutdown as the DHCP server may boot slower than the SBS . Make sure that the SBS is only switched on when the DHCP server is available.

4 SBS – Operating- and configuration software

4.1 SBS – Operating- and configuration software - Overview

4.1.1 Structure of PC software

The PC software is organised into the following three sections:

- Vision Sensor Device Manager:**
 This module is for selection of a SBS sensor, or a sensor simulation model, for configuration with the “Vision Sensor Configuration Studio” tool, or display (monitoring) with the “Vision Sensor Visualisation Studio” tool. Also system settings such as IP addresses, firmware updates can be modified with the “Set” tool.
- Vision Sensor Configuration Studio:**
 Complete set of functions to configure and test SBS vision sensor for one or several inspection tasks (jobs) in six simple logical operating steps.
- Vision Sensor Visualisation Studio:**
 For the display and monitoring of images and results from connected sensors, as well as job switch and job upload.




Fig. 24: Software structure

4.1.2 Context help

For all software functions a context sensitive help page is available and displayed as soon as a function is selected.

All available help pages can be viewed by pressing the Help- button („?“ symbol) or by double click to the online help window. There you also can do a keyword search. In comparison to the context help the size of this help window can be enlarged to view longer text more comfortable.

Used open source software: [Open Source Licences \(Page 3\)](#)

13/09/2016

4.2 SBS – Operating- and configuration software – Short introduction

(Example: Object sensor)

4.2.1 SBS, Short introduction, Starting the software

This short guide explains step by step the procedure for setting an example inspection task on the vision sensor

To start the SBS application click to the desktop icon "SBS Vision Sensor“.



Fig. 25: Icon SBS

4.2.2 Vision Sensor Device Manager: Open sensors or sensor simulation / Passwords

In this program, you can select a sensor or a sensor simulation for configuration or display (monitoring) and carry out different basic settings.

Next topic: [Vision Sensor Configuration Studio: Setting sensor, Job \(Page 41\)](#)

Configuring or displaying sensors

In order to open a sensor for configuration or display, select with a single left mouse click the required sensor in the "Active sensors“ list, then click on the button "Config“ to start the "Vision Sensor Configuration Studio“ software, or on the button "View“ for the "Vision Sensor Visualisation Studio“ software.

Sensor simulation

To open a sensor for offline simulation, select the required sensor in the "Sensors for simulation mode“ list, then click on the button "Config“ to start the module "Vision Sensor Configuration Studio“. Vision Sensor Visualisation Studio is not available for the simulation mode as there is no device to send the images for display.




Fig. 26: Vision Sensor Device Manager Overview

A) Active sensors

This list displays all the SBS vision sensors available on the network that can be controlled from the PC.

B) Sensors for simulation mode

All the sensors available for offline simulation are displayed here.

C) Add sensors via IP address

Sensors, which are not visible after starting the software or after clicking the "Find" button in Vision Sensor Device Manager, can be added manually with their IP address, if they are available in the network (e.g. after a gateway) and if the IP address is well-known. Via clicking the button "Add" such sensor can be found and added to the list of active sensors, in order to edit them.

D) Functions

- **Find**

Activates another search procedure on the network to locate SBS products

- **Config**

Configures a connected sensor or a sensor simulation

- **View**

Displays image or result data from a connected sensor

- **Set**

Edits network settings such as the sensor's IP address etc.

E) Context help

Context sensitive help

4.2.3 Passwords

When first started-up after installation, password entry is completely deactivated and auto login is preset to administrator.

If parameter settings are to be protected from unauthorised access, passwords should be given for the "Admin" and "User" password levels, see below. This can be called up via the menu bar File / User administration or via the button with the key symbol in the toolbar.



Fig. 27: Password button

4.2.4 Password levels:




Fig. 28: Password levels

Password level	Vision Sensor Device Manager	Vision Sensor Configuration Studio	Vision Sensor Visualisation Studio
Administrator password	all functions	all functions	all functions
Worker password	all functions except - Config. - Settings - Update	none	all functions, including Job Upload and Image Recorder
User (without any password)	all functions except - Config. - Settings - Update	none	only display of images, inspection results and statistics

In order to be able to use the function "Config" after the allocation of passwords, it is now necessary to login by clicking on the toolbar login button, and then entering the assigned password.



Fig. 29: Login button


A screenshot of a software dialog box for password input. The dialog has a title bar with a question mark and a close button. It is divided into two sections: "Administrator" and "Worker". Each section contains two text input fields: "Password" and "Retype password". At the bottom of the dialog are two buttons: "Set" and "Cancel".

Fig. 30: Password input

Allocating an empty password means the password can be confirmed without any further entry.

Activation of the "Deactivate password request" checkbox, permanently deactivates password request.

If passwords have been assigned and then forgotten, it is possible to reset passwords to delivery status by reinstalling the software on the local PC.

4.3 Vision Sensor Configuration Studio: Setting sensor, Job

With this program, you can configure your SBS vision sensor for one or several jobs in six simple logical operating steps.

Next topic: [Alignment settings \(Page 43\)](#)




Fig. 31: Vision Sensor Configuration Studio

The fields are:

A) Menu and tool bar

B) Setup Navigation / Operating steps

See next chapter for description

C) Image

Image output with graphically adjustable operating and search zones as well as zoom function also filmstrip navigation when in simulation mode

D) Context

Context-sensitive online help, automatically updated for each action.

E) Image acquisition mode

Switch-over between continuous (free run) and single image mode with trigger input (either from sensor or via onscreen button)

F) Connection mode

Switch-over between online and offline mode (sensor present or simulation without sensor)

G) Job selection

Changing variable content relating to action in set-up navigation, for setting of associated parameters.

H) Status bar

Different status information including Mode / Name of SBS / Active job. In Run Mode: Cycle time / cursor x/y location and pixel intensity / individual I/O on /off indication (like configured in "Output/Digital output").

4.3.1 Job Setup

Configuring a job

To configure a job, edit the job entry in the "Select job" (G) field or e.g. create a new job. Set global parameters here, such as shutter, exposure or the resolution which is valid for the entire job.

For Job- setup: in Setup/Job edit or generate a new job in field "Jobs" (G),




Fig. 32: Vision Sensor Configuration Studio Job

One job contains all settings and parameters necessary to perform a specific inspection task.

Jobs are created here, and several jobs can be stored in the SBS . All global settings, valid for each individual job, e.g. shutter, gain, illumination settings etc. are also carried out here.

- The following basic image settings should first be made to ensure a high-contrast and sharp image:
 - * Image brightness: Set shutter or amplification, see Job/General
 - * Image sharpness: Focus setting via the screw on the back of the SBS camera itself
- When delivered, the factory settings are trigger mode = "free run" (see Job/General) and image acquisition mode = "continuous" . A new image is continuously displayed for easier focus and brightness set up.
- The subsequent setting of alignment and detectors should preferably be carried out in single image mode, as all settings are then based on a master image and image collection is not continuously carried out.

- Alignment and multiple different detectors can subsequently be defined within one job to solve an inspection task.

4.3.2 Alignment settings

Alignment compensation can be necessary for objects whose position varies on the screen.

Next topic: [Detector settings \(Page 44\)](#)

Three different detection methods (alignment detectors) are available for this purpose, pattern matching, and edge detection and contour. alignment is optional.

After selection of the alignment method, set the working zones on the parameter to be used for alignment tracking by adjusting the graphic frame to the appropriate position and size on the image.

The associated parameters are displayed on the bottom right-hand side and can also be adjusted there.

Alignment, when used, affects the positions of all the detectors subsequently defined in this job.

In this example, the outside contour is used for alignment and the plug can be found either by contour or by pattern matching. If the angular rotation of the object can vary also, the contour method must be used.




Fig. 33: Alignment

4.3.3 Detector settings

Different detectors can be selected and adjusted to solve an inspection task. First the required detector is selected in the dialog box shown below.




Fig. 34: Detector list, Object sensor

Then the working and search zones are graphically set on the screen. If “teach zones” (red outline) exist, they are taught immediately after completion of the settings. All the detectors defined in this job are shown in the bottom left-hand corner. The parameters of the currently selected detector are shown in the bottom right-hand corner and can be adjusted there.

If other parameters are to be checked on the same part, many other detectors can be created as described above by clicking on "New".

In the example two brightness detectors are defined to check the presence of metal contacts in a plastic connector housing.

Detector 1: contact found (brightness value is in defined range as the shiny metal contact is mounted) result positive.

Detector 2: contact not found (brightness value out of defined range, as only weak reflection from the black plastic housing background) result negative.




Fig. 35: Detector settings

4.3.4 Output, I/O and data output

The output module enables different settings of digital inputs/outputs and data output.

Select and activate the interfaces in the different tabs. Logically connect detector results and assign to the available I/O's.

In order to enable the output of serial result data, select the required interface and compose data string.

Next topic: [Result \(Page 47\)](#)




Fig. 36: Output, digital and data

Setting possibilities in the different tabs:

- I/O mapping**
 Settings for the I/O Hardware configuration.
- Digital Output**
 Selection of digital signal outputs and definition and assignment of logical connection using the Boolean results of all detectors. Definition of complex logic connections via table or via input of a logical formula.
 A different logical connection can be assigned to each available digital output.
- Interfaces**
 Selection, setting and activation of the individual interfaces such as: programmable input IN2, RS422, I/O extension, Ethernet, Profinet, SBSxWebViewer and Ethernet/IP
- Timing**
 Setting of delay times: Trigger delay, result delay and duration of result
- Telegram**
 Setting and preview of data output string via RS422 or Ethernet.
 Selection of: binary or ASCII protocol, header and/or trailer, standard contents and/or flexible, combinable, special individual data from the individual detectors.
 Any number of individual results from all the defined detectors can be freely arranged in an output string.

4.3.5 Result

With this function, an inspection is carried out on the PC for control purposes, using all the settings made. All the results are produced and displayed just as on the sensor. However e.g. execution times will not be updated as these values are only informative when implemented on the sensor itself. See next step: „Start Sensor“.

Next topic: [Start sensor \(Page 48\)](#)




Fig. 37: Result display

4.3.6 Start sensor

When this function is activated, all settings are transferred to the sensor, stored in the flash memory and carried out in e.g. in free run or in triggered mode according to the settings made. All information in the list of detectors, result field or under „Statistics“ is updated here.

If using “triggered mode” then a trigger will be required from the external control system, alternatively a ‘software’ trigger can be sent using the Trigger button the left hand side of the image area.

Next topic: [Vision Sensor Visualisation Studio, display images and results \(Page 49\)](#)




Fig. 38: Start sensor

4.4 Vision Sensor Visualisation Studio, display images and results

This program enables the monitoring/inspection of the connected sensor and the analysis of inspection results.

Click to the **“View”** button in the Vision Sensor Device Manager software to start the Vision Sensor Visualisation Studio module. (You can open multiple copies of this software if you are using multiple cameras on the system, however only one ‘connection’ is allowed to each SBS sensor).

The current image is displayed with the drawings for alignment and the detectors (if „image transmission = active“ is activated in the configuration module under Job/General).

The tab **„Result“** shows the individual detectors with their results and the overall result.

The tab **„Statistics“** shows further statistical results.

The **“Freeze image”** button enables result-controlled images (e.g.: bad part) to be kept on the display.

“Zoom” enlarges images.

With **“Archive images”**, images and result data, as previously set under “File/Configure archiving”, can be archived on the hard disk of a connected PC, with or without numerical result data.

With **“Rec. images”** the last 10 images can be retrieved from the SBS sensor.

In the tab **„Job“**, it is possible to switch between jobs present on the sensor.

In the tab **„Upload“**, further, previously defined jobs or whole job sets can be loaded from the viewer on to the sensor.




Fig. 39: Vision Sensor Visualisation Studio

4.5 SBS – Operating- and configuration software – Vision Sensor Device Manager, all functions

In this program you can select a sensor or sensor simulation for configuration or display (monitoring) and carry out different basic settings:

- [Active sensors \(Page 50\)](#)
- [Sensors for simulation mode \(Page 52\)](#)
- [Find / Add active sensor \(Page 52\)](#) active sensor
- [Configuring a connected sensor \(Page 53\)](#) connected sensor
- [Display images and result data \(Page 53\)](#) image and result data
- [Sensor's network settings \(Page 53\)](#)
- [Update / Firmware update \(Page 54\)](#) / Firmware update
- [User administration / Passwords \(Page 54\)](#) / Passwords (button with Key- symbol)




Fig. 40: Vision Sensor Device Manager

If the "Configure" function is not accessible (button inactive), login (button with door- / arrow- symbol) with password entry is required. If you do not know the password, please contact the administrator.

4.5.1 Active sensors

All sensors available on the connected network are displayed in the selection list Active sensors.

[Configuring a connected sensor \(Page 53\)](#) (call up Vision Sensor Configuration Studio)

[Display images and result data \(Page 53\)](#) (call up Vision Sensor Visualisation Studio)

Significance of parameters displayed

Parameter	Significance
IP address	Sensor's IP address in the network

Hardware	Hardware (e.g. R3B,)
Sensor type	Sensor type (Object-, Code reader, Solar)
Variant	Sensor- sub variant (e.g. Standard / Advanced)
Version	Firmware version
Mode	Operating mode (Run, Config or Offline)
Sensor name	Name of sensor
Manufacturer	Name of manufacturer
Mac-Address	Sensor´s Mac address
Subnet mask	Sensor´s subnet mask
Gateway	Standard gateway
DHCP	DHCP active / inactive
Operating system	Type of operating system
Operating System Version	Version of operating system
Platform	z.B. SBS
Hardware version	Hardware version
RAM	RAM size
Flash	Flash size

If the "Configure" function is not accessible (button inactive, greyed out), login with password entry is required. If you do not know the password, please contact your site system administrator.

Information:

- If no entries are shown in the list, even though a sensor is connected, you can refresh the list with the "Find"-button or manually "Add" the IP address of the SBS product.
- If no sensor is connected, simulations of different sensor applications are available in the [Sensors for simulation mode \(Page 52\)](#) list such as 'Object' sensor.

Via the button "details" (at the right, upper corner of the parameter list of "Active Sensors") a detailed list of all SBS parameters is accessible.




Fig. 41: Sensor properties

4.5.2 Sensors for simulation mode

In order to access the simulation mode, select the required sensor type with a double click and press [Configuring a connected sensor \(Page 53\)](#) button (call up Vision Sensor Configuration Studio).

Significance of parameters displayed

Parameter	Significance
Type	Sensor type (e.g. Object , Code reader, Solar...)
Hardware	Hardware type (e.g. resolution, monochrome- or color version)
Version	Firmware version
Variant	Sensor- sub variant (e.g. Advanced ...)

If the function „Config” is not accessible (button inactive) a Login (button with door / arrow symbol) with password input is necessary. If you do not know the password please contact your administrator.

4.5.3 Find / Add active sensor

If no sensors are shown in the list Active sensors, even though a sensor is connected, please follow these steps:

Find / search sensor:

To search for sensors which are connected directly to the PC, or which are available in the network, click button "Find". Basic understanding of PC networking is required this is not covered within the scope of supply from Festo.

Add active sensor:

If you know the IP-address of a sensor, please enter it into the field IP-address and click button "Add".

Now the sensor appears in the list and can be accessed for e.g. Config or View.

If the function "Config" is not accessible (button not active / greyed out) a Login with password input is necessary. If you do not know the password please contact your site systems administrator.

4.5.4 Configuring a connected sensor

Mark a sensor (simulation) in the list and click on the "Config" button.

The configuration program Vision Sensor Configuration Studio is called up and the jobs currently stored on the sensor are shown in the selection list.

When Vision Sensor Configuration Studio is called up, you may be required to enter a password. See [User administration / Passwords \(Page 54\)](#) for defining passwords.

s. chap Vision Sensor Configuration Studio [SBS – Operating- and configuration software – Vision Sensor Configuration Studio, all functions](#)

4.5.5 Display images and result data

Mark a sensor in the list and click on the "View" button.

The Vision Sensor Visualisation Studio program is opened up and images and measurement results from the active jobs are displayed on screen.

Information:

Calling up Vision Sensor Visualisation Studio does not affect operation of the selected sensor.

s. chap. Vision Sensor Visualisation Studio [SBS – Operating- and configuration software – Vision Sensor Visualisation Studio, all functions](#)

4.5.6 Sensor's network settings

You can change the network settings of the selected sensor with the Set button.

The IP address, subnet mask, standard gateway, DHCP and sensor name can be set here.

The PC's IP address and subnet mask are displayed below in the Vision Sensor Device Manager status bar.

The address structure must be correct in order to be able to connect the sensor to the PC. The sensor's IP address etc. can therefore be modified accordingly here if necessary.

Please contact your site administrator for the definition of network parameters. Further information on this subject can be found in the printed manual.

If "DHCP = active" is selected, a unique name must be given for the sensor as the IP address is newly assigned each time the sensor starts up and can thus change.

You require administrator authorisation for these functions (see user administration).




Fig. 42: Vision Sensor Device Manager, IP- Setup

s. chap. Network settings / Ethernet connection [Network settings, Short reference](#) and [Network connection](#)

4.5.7 Update / Firmware update

You can update the firmware of the selected sensor through the menu item File/Update.

The appropriate firmware update file must first have been obtained via download from the Festo website or from Festo Support.

Select the appropriate firmware file in the file dialogue box that opens and follow the instructions.

Do not disconnect the power to the sensor during this process unless prompted by the onscreen instructions.




Fig. 43: Vision Sensor Device Manager, Firmware update

4.5.8 User administration / Passwords

The SBS configuration distinguishes between three user groups, which have different authorisations:




Fig. 44: Vision Sensor Device Manager, Password input

Password level	Vision Sensor Device Manager	Vision Sensor Configuration Studio	Vision Sensor Visualisation Studio
Administrator password	all functions	all functions	all functions
Worker password	all functions except - Config. - Settings - Update	none	all functions, including Job Upload and Image Recorder
User (without any password)	all functions except - Config. - Settings - Update	none	only display of images, inspection results and statistics

After software installation, login is automatically carried-out when the application is called-up, without password request. No passwords are assigned.

Define passwords:

Select file user administration in the File menu or click on in the toolbar to assign passwords for the administrator and user categories. Once a password has been entered, a logout is automatically carried out, i.e. input of the new password is now necessary. Assigning an "empty" password, enables entry by simply confirming with OK.



Fig. 45: Password button

Login

Once passwords have been assigned and automatic logout has taken place, a login is required e.g. for sensor configuration. Click on in the tool bar to login and / or (after password entry) to deactivate password entry for the next session for the selected user group.

If the "deactivate password request" box is ticked, the password will not be requested when the application is next started.



Fig. 46: Login- button

4.6 SBS – Operating- and configuration software – Vision Sensor Configuration Studio, all functions

With this programme, you can configure your SBS vision sensor for one or several jobs in six logical operating steps.

- [Jobs \(Inspection tasks\) \(Page 56\)](#)
- [Alignment \(Page 80\)](#)
- [Detectors \(Page 90\)](#)
- [Output of inspection results \(Page 172\)](#)
- [Result \(Page 196\)](#)
- [Start sensor \(Page 198\)](#)

Other program functions:

- [Trigger settings \(Page 200\)](#)
- [Switching between online and offline mode \(Page 200\)](#)
- [Simulation of jobs \(offline mode\) \(Page 201\)](#) using series of images.
- [Creating filmstrips \(Page 201\)](#) Image recording for analysis or simulation purposes. Use of Vision Sensor Configuration Studio may require password entry (administrator user group). See [User administration / Passwords \(Page 54\)](#)
- [Image recorder \(Page 211\)](#)

To obtain a continuously updated live image even without trigger, carry out the following (if necessary temporary) settings:

- Set to **free run** in "Job/Image acquisition"
- Set to **continuous** in "Trigger / collect image" User interface and operating procedure

4.6.1 Jobs (Inspection tasks)

A job contains all the settings and parameters required to carry out a certain inspection task.




Fig. 47: Vision Sensor Configuration Studio Job

4.6.1.1 Creation, modification and administration of jobs

A selected job (marked in the list) can be modified by entering parameters in both tabs of the configuration window:

If there is no job entry in the list, you must create a new job first.

Creating a new job:

1. Click on the button "New" underneath the job selection list. A new job entry appears in the list.
2. Edit the entry with a double click on the respective line (Name, Description, Author):

Further functions:

Function	Description
New	Defines a new job
Load	Loads a job from the PC
Save	Saves the selected job on the PC
Delete	Deletes the selected job from the list
Delete all	Deletes all the jobs in the list

All the functions described can also be carried out using the File menu.




Fig. 48: Vision Sensor Configuration Studio Joblist

If the sensor's memory capacity is exhausted and no further jobs can be loaded on to the sensor, the colour of the remaining memory display in the status bar changes to red.

4.6.1.2 Loading and saving jobs and job sets

Jobs can be loaded and stored individually or as a whole set of jobs in a job set. If several jobs are stored on the sensor, they form a job set, which you can store as an XML file on your PC or on an external storage medium just like an individual job.

Next topic: [Parameters for image acquisition \(Page 59\)](#)

Saving a job / job set:

1. Select Save job as ... from the File menu.
2. Select Save job set as ... from the File menu.

Loading a job / job set:

1. Select Load job ... from the File menu.
2. Select Load job set ... from the File menu.
3. Activate the button "Start Sensor" to transfer jobs to the sensor.
All the jobs stored on the sensor are deleted when a new job / job set is loaded !




Fig. 49: Vision Sensor Configuration Studio, Load / save job

4.6.1.3 Parameters for image acquisition

The basic parameters for image acquisition are determined in the tab Image acquisition.

Next topic: [Preprocessing, Filter for image improvement. \(Page 61\)](#)

Set image sharpness with the focus setting screw on the back of the SBS .

Parameters	Functions and setting possibilities
Resolution	Standard resolution is VGA (640x480), but a lower resolution (QVGA) can be selected with time-critical applications or for compatibility reasons. Available resolutions: R3B: WVGA (736x480), VGA (640x480), QVGA (320x240), QQVGA (160x120) R3BC: WVGA (736x480), VGA (640x480), QVGA (320x240) R2B: XGA (1280x1024), VGA (640x480), QVGA (320x240) R2BC: XGA (1280x1024), VGA (640x480) When the resolution is altered, all the detectors previously defined are deleted!
Zoom (R2B only)	Via the Zoom function different fields of view / image zones can be selected
Dynamic	Optimization of characteristics of image capturing: "Linear" means linear response curve (behaves like SBS -products with no dynamic image capturing), "High" means better graduation in bright areas of the image (avoids override).
Trigger mode	Select trigger mode (triggered or free run). In case of triggered mode trigger can be done by hardware-trigger (Pin 03 WH) or over one of the data interfaces. In free run the SBS continuously captures images and processes evaluations.
Shutter speed	Parameter for control of image brightness. Image brightness preferably should be set with "Shutter speed", only in case that it's not possible to achieve the required image brightness this way use the slider

Parameters	Functions and setting possibilities
	“Gain” (Default value of Gain = 1). With fast moving objects a high shutter value can cause blurring of the image. Exposure can be set automatically with the Auto-Shutter button. Maximum shutter value is 100ms. Maximum duration of internal illumination pulse is 8ms. Shutter timers longer than 8 ms just make sense, if internal and external illuminations are used.
Gain	Set image brightness preferably with shutter speed first, and only if necessary in a second step with gain. (Default value of Gain = 1).
Quadrants (illumination)	By click on the LED single quadrants of illumination can be switched off. This function may avoid reflections at low working distances.
Internal illumination	Switch internal illumination (on, off).
External illumination	Switch external illumination (on, off, permanent). External illumination is switched over Pin 09 RD.

To obtain a continuously updated live image even without trigger, carry out the following (if necessary temporary) settings:

- Set to **free run** under "Job/Image acquisition"
- Set to **continuous** under "Trigger / collect image"

4.6.1.4 Job, tab White balance

White balance is necessary for compensation of image colors.




Fig. 50: White balance

Parameter	Function
Red	Mean value of red channel in image
Green	Mean value of green channel in image
Blue	Mean value of blue channel in image

Teach	Execution of white balance, for white balance there has to be a homogeneous, white area below the camera.
Reset	Reset values

4.6.1.5 Preprocessing, Filter for image improvement.

In tab Pre-processing you can filter and re-arrange the images taken by the sensor before analysis. Up to 5 filters and one arrangement-filter can be used, which are processed in the selected sequence. All detectors (alignment and standard-detectors) will work with the pre-processed image (not with the original image)

Especially morphological operations (Dilation and Erosion) can lead to improvements by combining them. E.g. by processing Erosion and Dilation one after another – or in reverse order.

Next topic: [Calibration \(Page 62\)](#)

Example:- Black points in front of a bright background can be eliminated, if a sequence of dilation and erosion is processed.

The following arrangements are available for image improvement:

Arrangement type	Effect
Rotation 180°	Rotation of image for 180°
Mirror	Vertical mirroring
Flip	Horizontal mirroring

The following filters are available for image improvement:

Filter type	Effect
Gauss	Image is smoothed using a gaussian filter mask. This can be applied for reduction of disturbances, suppression of disturbing details and artefacts and smoothing the image.
Erosion	Extension of dark zones, elimination of light pixels in dark zones, elimination of artefacts, division of bright objects. Each grey value is replaced by the minimum grey level found inside the filter mask (e.g. 3x3).
Dilation	Extension of light zones, elimination of dark pixels in light zones, elimination of artefacts, division of dark objects. Each grey value is replaced by the maximum grey level found inside the filter mask (e.g. 3x3).
Median	Each grey value is replaced by the median value of the pixels found inside the filter mask (e.g. 3x3). Typical applications include noise reduction, especially for local bright or dark pixels ("salt-and-pepper"-noise).
Mean	Each grey value is replaced by the average grey value of the pixels found inside the filter mask (e.g. 3x3). This can be applied for reduction of disturbances, suppression of disturbing

	details and artefacts and smoothing the image.
Range	Each grey value is replaced by the range value (maximum gray level – minimum gray level) of the pixels found inside the filter mask (e.g. 3x3). Typical applications include the detection and enhancement of edges and the improvement of local image contrasts. (starting with firmware 1.5.x.x)
Standard deviation	Each grey value is replaced by the standard deviation of the pixels found inside the filter mask (e.g. 3x3). Typical applications include the highlighting of surface defects or edges.
Edge detection (Sobel)	Result image contains edges detected using the Sobel-algorithm (compare image processing literature also). Typical applications include the detection and enhancement of edges and the improvement of local image contrasts or the detection of surface defects.
Multiplication	The grey value of each pixel is multiplied by the choosen multiplier (2x, 4x, 8x, 16x). Values are clipped to 255.
Inversion	Inversion of image

The effect of an active filter is immediately visible in the image. The larger the filter core is selected, the stronger the effect of the filter. The filters are used in the order listed from top to bottom.

Configuring filters:

1. Select the filters in the required order, via the pop-up menus in the column Filter.
2. Enter the size of the filter kernel in the pop-up menu in the column Property. If the setting is Off, the respective filter is deactivated.




Fig. 51: Tab Job / Pre-processing

4.6.1.6 Calibration

The function "Calibration" transforms the image coordinates (pixel) into world coordinates (e.g. millimeter). When activated all position and distance data is calculated in the selected unit.

Next topic: [Parameters Cycle time \(Page 79\)](#)

Calibration method

Scaling (Measurement)	Relative calculation, limited accuracy (measurement/inspection, principal point = left, upper corner of field of view).
Point pair list (Robotics/ Pick and Place)	Absolute calculation, user defined reference system (robot calibration in robot coordinate system)
Calibration plate (Measurement)	Relative calculation, high accuracy (measurement/inspection, principal point = left, upper corner of field of view).
Unit	Desired unit of world coordinates
">" / "<"	Next / previous step

Note: All position values and measurement results are corrected. Not to cause longer cycle time the image data are not transformed / displayed rectified. This way a high execution speed, even with calibration active, is provided.

Next topic: [Calibration, Scaling \(Page 65\)](#)

Activation of Calibration is done in two steps:

1. Selection of calibration method:

Go to next / previous step with buttons [**<**], [**>**] on the right hand side of the calibration tab

2. Execution of selected calibration method

As soon as a calibration method is selected, on the left side in tab "Calibration" the status LED is shown. If calibration is active other functions like detectors can only be processed successfully, if calibration is valid.

Color significance of graphical points in image and lines in Point pair list:

Color	Significance
Green	Calibration valid, points accurately positioned
Yellow	Calibration valid, points not accurately positioned
Red	Calibration not valid

Color significance status LED for the different calibration methods

Calibration method	Significance
Scaling	Status-LED = green: Default- or input value result in scaling factor, no error determination possible.
Point pair list	Status-LED, graphical point in image and corresponding line in point pair list. - green: calibration valid, points accurately positioned - yellow: calibration valid, points not accurately positioned - red: calibration not valid With new job: - green: Default values(6 points) result in correct default calibration
Calibration plate	Status-LED: - green: calibration valid, points accurately positioned

	<p>- red: calibration not valid</p> <p>With new job:</p> <p>- red: as so far no calibration with calibration plate happened</p>
--	---




Fig. 52: Selection of calibration method

Detailed description

Method	Functions
None	Calibration not active, coordinate calculation, display and output in pixel (px)
Scaling (Measurement) (Relative calculation of distances in world coordinates)	<p>The calibration method "Scaling" serves relative calculation of distances in world coordinates (mm). This is realized with a simple factor. There is only one factor for both coordinate axis X and Y. The advantage is the very simple function, but accuracy is limited. Errors caused by tilt angle against perpendicular view to the measurement plane or by lens distortion are not corrected by this method. World coordinates are not absolute. The coordinate values refer to the principal point in left, upper corner or the field of view. Example: Determination of distances between two objects in mm. (Limited accuracy)</p>
Point pair list (Robotics / Pick and Place) (Absolute calculation in world coordinates, in a user defined reference system, e.g. robot coordinate system)	<p>The calibration method "Point pair list" serves absolute calculation of positions in world coordinates (e.g. mm). Errors caused by scaling, x- and y- axis separately, tilt angle against perpendicular view to the measurement plane or by lens distortion are all corrected by this method. Example: Determination of absolute positions of objects in world coordinates in millimeter (e.g. robot coordinate system) This is realized by the image capturing of a calibration part which is placed by the robot in the field of view. A point pair is set by: - Image coordinate by graphical input in the image, or by numerical input of a value - World coordinate by numerical input given from the robot controller</p>

Method	Functions
	This sequence is done till the desired number of point pairs is achieved in the list.
Calibration plate (Measurement) (Relative calculation of distances in world coordinates)	The calibration method "Calibration plate" serves relative calculations of distances in world coordinates (e.g. mm). This is done by image capturing of a calibration plate (s. www.Festo.de). By using a large number of points, the known, exact relative position of the points on the plate, this method provides a high accuracy. Errors caused by scaling, x- and y- axis separately, tilt angle against perpendicular view to the measurement plane or by lens distortion are all corrected by this method. World coordinates are not absolute. The coordinate values refer to the principal point in left, upper corner or the field of view. Beside coordinates, distances are also calculated in world frame. Example: Determination of distances between two object in mm.
Unit	Unit of world coordinates / distances - mm (millimeter) - cm (centimeter) - m (meter) - in (Inch)
">" / "<"	Go to next / previous step

Calibration effects the following detectors / alignment

Detector	Result value
Contour	Center coordinate x, y, angle
Pattern matching	Center coordinate x, y, angle
Caliper	Center coordinate x, y, distance
BLOB	Center of gravity-/ center coordinate x, y; width, height, angle
Alignment	Result value
Contour	Center coordinate x, y, angle
Pattern matching	Center coordinate x, y, angle
Edge detection	Center coordinate x, y

4.6.1.6.1 Calibration, Scaling

The calibration method "Scaling" serves relative calculations of distances in world coordinates (mm). This is realized with a simple factor. There is only one factor for both coordinate axis X and Y. The advantage is the very simple function of the scaling process, although accuracy is limited.

Errors caused by tilt angle against perpendicular view to the measurement plane or by lens distortion are not corrected using this method. World coordinates are not absolute. The coordinate values refer to the principal point in left, upper corner or the field of view.

Next topic: [Calibration, Point pair list \(Page 67\)](#)




Fig. 53: Calibration method, "Scaling"

Example: Determination of distance between two objects in mm.

Parameter Scaling

Parameter	Function
Distance image	Distance in image in pixel (px), by graphical or numerical input
Distance world	Corresponding distance in world by numerical input (in previously selected unit, e.g. mm)
Scaling factor	From above mentioned settings "Distance image" and "Distance world" resulting scaling factor e.g. [x] px/mm or. [y] mm/px
Punkt testen	Test point (graphically or values input) is for the user to check calibration of known points / dimensions around the image to confirm satisfactory setting of the scaling factor.
">" / "<"	Go to next / previous step

Note:

Please take care that the optical axis of the sensor is aligned perpendicularly to the measurement plane. This avoids different distortion in x and y axis. Errors caused by tilt angle against perpendicular view to the measurement plane or by lens distortion are not corrected using this method.

For setting up; place a object with known dimensions (e.g. gauge block) in the field of view.

Position the both graphical, green crosshairs in the image to the points of the object with a known dimension / distance. The distance in image pixels between the both centres of the crosshairs is displayed in the field "Distance image".

Now type the known distance in world in field "Distance world" (e.g. in mm).

The scaling factor is calculated and displayed.

From now on positions and distances are displayed and transferred in world coordinates. World coordinates are not absolute. The coordinate values refer to the principal point in left, upper corner or the field of view. Beside coordinates, distances are also calculated in world frame.

This kind of calibration is suitable for standard lenses, integrated or C-mount. However it's not suitable for telecentric lenses.

4.6.1.6.2 Calibration, Point pair list

The calibration method "Point pair list" serves absolute determination of positions in world coordinates (e.g. mm).

Next topic: [Calibration, Calibration plate \(Page 76\)](#)




Fig. 54: Calibration, Point pair list

Example: Determination of absolute positions, and orientation of objects in world coordinates in mm (e.g. robot coordinate system)

Motivation / Benefit

After calibration of the sensor via point pair list the position of the part to pick is available directly in the absolute coordinate system of the robot!

All errors like scaling, perspective and lens distortion are corrected. In robotics pick and place applications now the robot can pick the part with the sensor provided robot coordinate values.




Fig. 55: Position of part to pick directly in robot coordinate system!

Sequence calibration via point pair list

Previously the focus and the shutter of the sensor, and the desired unit must be selected.

1. Select calibration model (-with/without correction of lens distortion), and - if necessary - set z-offset..

2. Select line 1 in list box "point pair list".

3. Place calibration part (preferably flat, symmetric, e.g. similar plain washer) at exactly known world coordinate (e.g. with robot).

4. Place graphically the corresponding crosshair in the image (no. "n" corresponding to line "n" in point pair list) exactly in the center of the calibration object. (if necessary zoom image)

Alternatively: use "Snap- Function", that means: right click somewhere inside the calibration part. This way the center of gravity of the calibration part is automatically determined.

Preferably use point symmetric calibration parts, as then the center of gravity is independent from

orientation. With calibration parts which are not point symmetric please take care for always same orientation. (not available with color sensors)

Result: Values of image coordinates in pixel "Image X" and "Image Y" are automatically set in line "n".

5. Now type in the corresponding, known world coordinates in the field "World X" and "World Y" (with e.g. robot: the values displayed in the robot controller).

6. Repeat steps 2-5 as long as the desired number of point pairs is achieved. If more lines are necessary press "+", to delete lines press "-". (min. 6 points, recommended > 10 points)

Automated calibration, see also: [Calibration via interface commands \(Page 74\)](#)

Parameter Point pair list

Method	Functions
- Image X - Image Y Values in point list	Coordinate values in pixels (px) in the image, via exact graphical positioning of the crosshair to the center point of the calibration part which is placed exactly in world coordinates. Or: use "Snap- Function", that means: right click somewhere inside the calibration part. This way the center of gravity of the calibration part is automatically determined (recommended).
- World X - World Y Values in point list	Coordinate values in selected unit (e.g. mm), by direct numerical input of the values in the point pair list. In case of e.g. Robotics Pick&Place this values can be taken from the robot controller when placing the calibration part in the field of view.
Calibration parameter	Calibration model: With or without correction of lens distortion. Z- Offset: (if offset is given) Offset between calibration plane and measurement plane Different read only parameters of the regression calculation and error values. See also: Calibration, Calibration parameter (Page 70)
"+" / "-"	Add or delete one line / point. Delete affects the highlighted line.
Test point	A test point can be set in the image, whose world coordinate values for test and control purposes are displayed in the Test point window.
">" / "<"	Go to next / previous step

Note:

The sensor can be mounted in any alignment / pose referred to the measurement plane. Anyway a close to perpendicular alignment should be preferred, as this causes less distortion and this way less error correction is needed.

The accuracy of the calibration first depends on the quality / accuracy of the point position and secondly on the sufficient number of points. If the calibration is not accurate (yellow points) this can be improved by better precision of position input of the single points.

This kind of calibration is suitable for standard lenses, integrated or C-mount. It's not suitable for telecentric lenses.

Minimum required number of point pairs is "6" points.

The minimum necessary number of points for calibration via point pair list is 6 points. With minimum this number of points false inputs (like x and y interchanged) can be found by high error values in dialog "Calibraiton parameters" [Calibration, Calibration parameter \(Page 70\)](#), (if ≤ 5 points the error values are always = 0, as no errors can be calculated).

To show the quality of point position (how good point position matches with calculated position) the points are displayed in the following colors (only meaningful if minimum 6 points).

Color significance of graphical points in image and lines in Point pair list:

Color	Significance
Green	Calibration valid, points accurately positioned
Yellow	Calibration valid, points not accurately positioned
Red	Calibration not valid

In case of yellow point color a yellow line is visible starting in the center of the point. It's lenght and direction is a measure for the absolute value and orientation of the error in relation to the position accuracy of point input in world frame.

If there are big errors, potentially x- and y- coordinate are interchanged with one or some points, or some points are interchanged completely with others.

In the dialog [Calibration, Calibration parameter \(Page 70\)](#) the devaiton values / errors: "Mean", "Min"imum error and "Max"imum error are displayed. With this values the exact positon input of the existing points can be optimised.

This calibration method serves beside the absolute coordinate values the orientation of the part to pick also. (if Contour or Pattern matching is used as detector)

The result coordinate values of the part to pick are served from now on directly in the coordinate system e.g. of the robot!

4.6.1.6.2.1 Calibration, Calibration parameter

Here, if required , the Z-offset between calibration- and measurement level in Z-direction can be set and compensated . Also the calibration- and deviation parameters, for optimisation if desired, are displayed.

This kind of calibration is suitable for standard lenses, integrated or C-mount. However it does not work for telecentric lenses.

Next topic: [Calibration via interface commands \(Page 74\)](#)




Fig. 56: Calibration, Calibration parameter

Parameter	Function
Calibration model: Standard lens, with distortion	Correction of: - Scaling, x and y separately - Tilt angle against perpendicular view to the measurement plane - Lens distortion
Input parameter	
Offset calibration/measurement level in Z-direction	For Z=0 the calibration and the measurement plane are identical. For Z!=0 the calibration plane is shifted against the measurement plane. The two planes are always parallel.

Parameter	Function
	The sign of the deviation results from the right hand world system (thumb = x, index finger = y, middle finger = z, see below) Note: The depth of focus of the sensor must cover the calibration and the measurement plane. See also: Offset calibration/measurement level in Z-direction (Page 72)
Focus	Focus of the lens <ul style="list-style-type: none"> • With integrated lens: value of the built in lens • With C-Mount lens: Take value written on the used lens and type in. • Option: to check plausibility of e.g. z- value with below mentioned "Translation of calibration object" no malfunction if not used.
Read only parameter)	
Kappa	Calculated kappa (distortion) value of the lens.
Pixel pitch	Calculated pitch / axial distance from pixel to pixel on the sensor chip. Reduction of resolution in tab "Image acquisition" effects this value.
Origin of coordinates/ pixel	Point where the optical axis penetrates the measurement plane in the centre of the sensor chip, compared with the ideal centre point. This values refer to left , upper corner in pixel.
Image size	Image size in pixel
Translation of calibration object	All three calculated values of translation of the calibration object. I.e. in x-, y- and z-direction.
Rotation of calibration object	All three calculated values of rotation of the calibration object. I.e. the angles: alpha, beta and gamma.
Deviation	
Mean	Average error of calculated positions against input.
Min.	Maximum error of calculated positions against input.
Max.	Minimum error of calculated positions against input.

Offset calibration/measurement level in Z-direction

Sign of "Z" value depending on the world coordinate system / "right hand world system" (thumb = x, index finger = y, middle finger = z)




Fig. 57: Delta "D" / Z- Offset = negative! In case of: Z-to top, and calibration plane lower than measurement plane!




Fig. 58: Delta "D" / Z- Offset = positive! In case of: Z-to top, and calibration plane higher than measurement plane!




Fig. 59: Delta "D" / Z- Offset = positive! In case of: Z-to bottom, and calibration plane lower than measurement plane!




Fig. 60: Delta "D" / Z- Offset = negative! In case of: Z-to top, and calibration plane higher than measurement plane!

4.6.1.6.2.2 Calibration via interface commands

There are specific interface commands for automated creation of a point pair list, e.g. for recalibration with drift in production process or should the mounting of sensor or robot change.

In this case the calibration process can automatically be executed e.g. from the robot controller.

Example: In this example the used calibration object is a circular thin steel plate, which is detected by a BLOB detector. This detector determines the centre of gravity of the round calibration part.

PLEASE NOTE :- For the correct function of the commands on the sensor the interface to the robot controller (e.g. Ethernet) must be activated and the first two output values in the data string must be the x- and y- value.

Sequence for automated (re-) calibration with interface commands via Point pair list.

Scenario:

1. Separate Job to detect calibration part (here "Job 1")

A Contour detector determines the centre of gravity of a circular calibration part.

The first and the second value transmit via the Ethernet data output are the x- and y- value of the centre point of the round part.

Screenshot....?

2. Job which should be calibrated (here "Job2")

Currently the sensor is running Job 2. Job/Calibration/Point pair list is set in the HMI, and the sensor was started in this job.

Sequence / flow chart




Fig. 61: Automated sequence of calibration via Point pair list

For detailed telegram format see: [Serial Communication ASCII \(Page 316\)](#) ; [Serial communication BINARY \(Page 338\)](#)

Additionally to the used telegrams "Trigger / TRG", "Calibration Add Point / CAP" and "Calibration Calibrate / CCL" the following telegrams are available for calibration.

- "Calibration Clear Data / CCD": Reset of all values of the Point pair list.
- "Calibration Validate / CVL": Validation of calibration. Does not effect the current calibration.

4.6.1.6.3 Calibration, Calibration plate

The calibration method "Calibration plate" serves relative determination of e.g. distances in world coordinates (e.g. mm). This is done by image capturing of a calibration plate with one single click!

Next topic: [Parameters Cycle time \(Page 79\)](#)




Fig. 62: Calibration method, Calibration plate

Example: Determination of distances between two object in mm.

Sequence calibration via calibration plate

Previously the focus and the shutter of the sensor, and the desired unit must be selected.

1. Select calibration model (-with/without correction of lens distortion), and - if necessary - set z-offset..
2. Place the calibration plate that the field of view is completely covered (see also: [\(Page 77\)](#) [\(Page 77\)](#), and [\(Page 78\)](#))
3. Select the corresponding calibration plate (size and type) via the list box "Calibration plate".
4. With a click to the button "Start Calibration" all visible points of the calibration plate are determined, all detected are marked, and the calibration is calculated.

Parameter Calibration plate

Parameter	Function
Calibration plate	Here the used calibration plate (size and type / number of points) is selected. (see also: (Page 77) and (Page 78))
Calibration parameter	Calibration model: with or without correction of lens ditortion. If given, here the z-offset between calibration and measurement plane can

Parameter	Function
	be set. Also different read only parameters, as well as deviation parameters are shown in this dialog (see also: Calibration, Calibration parameter (Page 70))
Start Calibration	Calibration is started. All visible points of the calibration plate are determined, all detected are marked, and calibration is calculated.
Test point	A test point can be set in the image, whose world coordinate values for test and control purposes are displayed in the Test point window.
">" / "<"	Go to next / previous step

Note:

The sensor can be mounted in any alignment / pose referred to the measurement plane. Anyway a close to perpendicular alignment should be preferred, as this causes less distortion and this way less error correction is needed.

World coordinates are not absolute. The coordinate values refer to the principal point in left, upper corner or the field of view. Beside coordinates, distances are also calculated in world frame.

This kind of calibration is suitable for standard lenses, integrated or C-mount. It's not suitable for telecentric lenses.

Advices for the usage of calibration plates

- The calibration plate must be clean and plain.
- The plate must be illuminated homogeneously over the entire field of view and must not be overexposed. The bright regions should have a grey value of at least 100 and below 255. The contrast between bright and dark regions should be at least 100 grey values. That means, the image / any region must not be over- or underexposed.
- The entire field of view must be covered by the calibration plate. Anyway, for a successful, precise calibration it's not necessary that the whole plate / all points of the plate are visible. It is sufficient if approximately a quarter of the plate is visible like shown below (always including the center of the plate with the pattern of points with smaller black point in their center).
- Calibration does work correct only if focus and position of the sensor does not change in relation to the measurement plane.




Fig. 63: Calibration plate, red = minimum field of view, minimum two of the blue regions must be visible.




Fig. 64: Calibration plate, detail with smaller black points in the center (see above: blue regions).

- The diameter of a white circle should be minimum 20 pixel.

Types / sizes of calibration plates

Sizes of calibration plates	Number of points
50mm x 50mm	15 x 13
100mm x 100mm	15 x 13

200mm x 200mm	15 x 13
---------------	---------

In the installation folder: Festo/SBS Vision Sensor/Documentation/... the available calibration plates can be found as .pdf-file. This can be printed on paper or any other medium. Please consider the setting "actual size?", that print out is not scaled.

The length of the long edge of the plate must correspond exactly to the number in the name of the plate.

4.6.1.7 Parameters Cycle time

In tab Cycle time the timing conditions of the SBS can be defined.

Next topic: [Alignment \(Page 80\)](#)

Parameter	Function and possibilities
Max. cycle time	<p>Parameter to control the minimum and maximum time of a cycle. Inside a cycle some images can be evaluated (in case of "Number of images (max)" > 1) Maximum processing time per image interrupts a job after a defined time. The result of a cycle after a timeout is always "not o.k.". Maximum processing time should be selected higher than the time demand for one execution.</p> <p>The processing time is the time elapsed from trigger till the setting of the digital outputs. If this cycle time should be limited (e.g. if the machine cycle should not be exceeded) this function can be used. The result of all detectors which are not processed / finished after this processing time has elapsed are set to "failed". As the currently processed detector will still be finished, please consider that the adjusted job time may not be met a 100% exactly, and it may last a few milliseconds longer till the job is interrupted.</p> <p>It's recommended to test the real cycle time and to choose a value for this parameter which is a bit smaller / shorter.</p>
Max. processing time per image	Maximum duration of one evaluation inside a cycle including image capturing.
Min. processing time per image	Minimum duration of one evaluation inside cycle including image capturing. Minimum processing time blocks trigger signals which are coming before the minimum processing time was reached.
Number of images (max.)	Maximum number of image capturings, which are processed after one trigger, if the stop criteria is not fulfilled. The stop criteria is the "Overall job result" (access via Output/Digital output)
LED-Power	This value is calculated automatically. Standard Value is 100%. LED-power may be reduced, if shutter time is quite long and minimum job time is quite short, because the recovery time for the LEDs may be too short in this case. To obtain 100% LED power, minimum job time should be factor 10 bigger than shutter time.

Auto	If “Auto” is selected the minimum cycle time is automatically adjusted in the way that the LED-power is 100%
------	--




Fig. 65: Tab Job / Cycle time

4.6.2 Alignment

Alignment compensation can be necessary for objects or characteristics whose position varies in the image. Three different detection methods (alignment detectors) are available for this purpose.

Next topic: [Selection and configuration of an alignment detector \(Page 81\)](#)

Mode of function of an alignment detector

An alignment detector is a tracking coordinate system, which is anchored to one selected characteristic. All subsequently defined detectors are aligned in relation to this coordinate system. Maximum one alignment detector can be defined for each job.

For information to the meaning and adjustment of the different frames see chap.

[Search and parameter zones](#)

As alignment requires an extra calculation step, it should only be used if required by the application.

Application example:

Alignment of an entire part using two edge detectors, i.e. here the top left-hand corner of the part is detected. Now contrast detectors can find and check features in relation to the position of the part.




Fig. 66: Alignment

4.6.2.1 Selection and configuration of an alignment detector

Select alignment detector:

1. Click on the button "Alignment".
2. Select a detection method in the configuration window "Method":

Next topic: [Alignment detector Pattern matching \(Page 83\)](#)

The following three detectors are available for alignment:

Detection method	Description, Selection
None	Alignment deactivated
Pattern matching	<p>Detection of any pattern Pattern matching can be used preferably if:</p> <ul style="list-style-type: none"> • There are only marginal edges, parallel to axis or with strong contrast, but zones with grey pattern in the image. <p>Pattern matching cannot be used if there is an angular deviation / rotation of the part.</p>
Edge detection	<p>Detection of horizontal and/or vertical edges The detection of edge should be used if:</p> <ul style="list-style-type: none"> • a offset of the position occurs just in X- and / or Y- direction • there are edges with strong contrast , parallel to the axis <p>Edge detection is, if above mentioned criteria are fulfilled a very quick method of</p>

	alignment. Edge detection cannot be used if there is an angular deviation / rotation of the part.
Contour detection	Detection of contours and edges at any angle Contour detection must always be used if: <ul style="list-style-type: none"> • there can be a angular offset (rotation against teach in position) It can be used preferably if there are edges of any shape but with good contrast.

Configuration of alignment detector:

1. Adapt the position and size of the search and parameter zones displayed on the screen if necessary.
2. Configure the alignment detector in the tab Parameters.

4.6.2.2 Alignment Pattern matching

This alignment detector is suitable for the detection of any patterns, even without clear edges and contours.

[Color channel \(Page 133\)](#)

[Alignment detector Pattern matching \(Page 83\)](#)

4.6.2.2.1 Color channel

Selection of color model and color components for the grey image used by the detector.

The display of the image depends on the image chip and the selected detector.

A image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection with monochrome detectors also. By selection of the colour channels the composition of the grey image can be manipulated and so specific zones can be intensified or weakend.

- Monochrome chip: Display always greyscale
- Color chip + Color detector: Display always colored
- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel




Fig. 67: Color channel

Parameter	Function
Color model	Color models: RGB, Color model RGB (Page 207) HSV, Color model HSV (Page 208) LAB, Color model LAB (Page 209)
Color channel	Selection of a color filter. Non selected colors will not be used in the resulting grey image which is processed by the detector.

4.6.2.2.2 Alignment detector Pattern matching

Next topic: [Alignment detector Edge detector \(Page 85\)](#)

Settings in Parameters tab:

Parameters	Functions
Threshold	Zone for the required concordance of the found sample with the taught sample
Accurate - fast	Number of search levels / coarsening levels 0 = automatic selection Higher value: faster = riskier (overlook candidates) Smaller value: slower = less risky (all candidates)
Pattern	Shows the taught sample = red frame
Edit pattern	By edit ROI there can be masked out parts of the search area. The parts which are not relevant for this examination can be painted out like using an eraser. Masks can also be inverted, means that parts which are interesting can be marked.
Lock	Lock / Unlock Pattern: In locked status the taught pattern is protected against (unintentional / accidental) changing, by e.g. modification of the teach region. Unlock to modify taught pattern..




Fig. 68: Alignment detector, Pattern matching

4.6.2.2.3 Result offset

With the Result offset, the final position of a found object can be modified. This can be useful when working with robot coordinate systems and needing to define a 'pick point' for example

Settings in Result pose tab:

Parameters	Functions
None	Automatically determined centre of (<u>R</u> egion <u>O</u> f <u>I</u> nterest)
Offset	Free selectable position (graphically or by value input, e.g. for robot gripper use) <ul style="list-style-type: none"> • X: Offset in X- direction (ref. ROI centre) • Y: Offset in Y- direction (ref. ROI centre) • Angle: angle offset (ref. ROI orientation)




Fig. 69: Result pose

4.6.2.3 Alignment Edge detector

This alignment detector determines characteristics using edge detection (in X and Y axis). It is ideal for the detection of horizontal and vertical edges and thus for the resulting point of intersection.

To detect edges at any angle, it's recommended using the contour detector.

[Color channel \(Page 133\)](#)

[Alignment detector Edge detector \(Page 85\)](#)

4.6.2.3.1 Color channel

Selection of color model and color components for the grey image used by the detector.

The display of the image depends on the image chip and the selected detector.

A image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection with monochrome detectors also. By selection of the colour channels the composition of the grey image can be manipulated and so specific zones can be intensified or weekend.

- Monochrome chip: Display always greyscale
- Color chip + Color detector: Display always colored

- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel




Fig. 70: Color channel

Parameter	Function
Color model	Color models: RGB, Color model RGB (Page 207) HSV, Color model HSV (Page 208) LAB, Color model LAB (Page 209)
Color channel	Selection of a color filter. Non selected colors will not be used in the resulting grey image which is processed by the detector.

4.6.2.3.2 Alignment detector Edge detector

Next topic: [Detectors \(Page 90\)](#)

Settings in Parameters tab:

Parameters	Functions and setting possibilities
Detection	Here it is determined whether to use two detectors "horizontal and vertical", or just one i.e. "only horizontal" or "only vertical", i.e. the object is only sought in one direction.
Edge strength X/Y	Edge strength / contrast above which an edge should be detected as an edge
X/Y transition	Selection between light-dark or dark-light transition
Smoothing	Filter for smoothing rough edges or suppressing fine lines such as e.g. scratches. Blurred edges can be detected with a higher score using a higher sigma value. Scratches etc. can be masked through higher sigma values.
Search direction X/Y	Set search direction "left -> right" / "right -> left" or "down -> up" / "up -> down".
Number of search stripes X/Y	Number of parallel search stripes into which the width of the search zone is to be divided. Edge detection is carried out in each search stripe and the first edge is decisive. The greater the number of search stripes, the quicker the first edge will be found. (Finer detection - longer execution time).

Optimisation

Execution speed:

Search zone for position (yellow frame) only as large as required

Reduce search stripes

Reduce smoothing value

Reduce resolution to QQVGA, QVGA or VGA instead of WVGA (Attention: global parameter, affects all detectors!)

Robust detection:

If edges blurred: increase smoothing value

Interfering edges such as scratches are detected: increase switching threshold or / and smoothing value

Edge not vertical to search direction: increase search stripes

Effect of „Number search stripes”

Number search stripes represents in how many search stripes the width of the search area is divided. Edge detection is processed in each search stripe over the whole width. The first edge which is detected of all search stripes is the overall result of all search stripes. By increasing the number of search stripes it's assured that the first edge is found in the whole search area.

By increasing search stripes it may happen, that the found edge strength fluctuates. E.g. if only the half width of the search area is covered with an edge. The cause is that the first – not the strongest – edge is detected which is above the threshold.

Further informations to edge detection see chapter: [Further explanations to Edge detector \(alignment\)](#) (Page 361)




Fig. 71: Alignment, Edge detection

4.6.2.4 Alignment Contour detection

This alignment detector is ideal for the detection of contours with edges at any angle.

4.6.2.4.1 Color channel

Selection of color model and color components for the grey image used by the detector.

The display of the image depends on the image chip and the selected detector.

An image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection with monochrome detectors also. By selection of the colour channels the composition of the grey image can be manipulated and so specific zones can be intensified or weakened.

- Monochrome chip: Display always greyscale
- Color chip + Color detector: Display always colored
- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel




Fig. 72: Color channel

Parameter	Function
Color model	Color models: RGB, Color model RGB (Page 207) HSV, Color model HSV (Page 208) LAB, Color model LAB (Page 209)
Color channel	Selection of a color filter. Non selected colors will not be used in the resulting grey image which is processed by the detector.

4.6.2.4.2 Alignment detector Contour detection

Next Topic: [Detectors \(Page 90\)](#)

Settings in parameter tab:

Parameters	Functions and setting possibilities
Switching threshold	Zone for the required concordance of the found contour with the taught contour
Angular zone	Angular zone in which search is carried out
Increment (angle)	Increment in ° of the search across the selected angular zone (If the angular zone and increment are set to 0, the detector only searches for non-rotated objects)
Min. contrast	Minimum contrast required with taught model for an edge to be accepted as one.

pattern	
Min. contrast image	Minimum contrast required in current image for an edge to be accepted as one.
Edit contour	By edit ROI there can be masked out parts of the search area. The parts which are not relevant for this examination can be painted out like using an eraser. Masks can also be inverted, means that parts which are interesting can be marked.
Lock	Lock / Unlock Pattern: In locked status the taught pattern is protected against (unintentional / accidental) changing. by e.g. modification of the teach region. Unlock to modify taught pattern..




Fig. 73: Alignment detector, contour detector

4.6.2.4.3 Speed

Via the here adjustable parameters the execution time can be influenced. The search is processed either less detailed, that means stopped earlier = quicker, or it's processed more detailed, that means search lasts longer = slower.

Settings in tab Speed

Parameters	Functions
Accordance level	<p>Candidates with score less than indicated will already be rejected during search.</p> <ul style="list-style-type: none"> • High value: early rejection = quicker = riskier • Small value: late rejection = slower = less risky <p>In case of false results this value can be decreased.</p>
Search levels	<p>Number of search levels / Coarsening levels.</p> <ul style="list-style-type: none"> • Higher value: faster = riskier (overlook candidates) • Smaller value: slower = less risky (all candidates) • Auto = automatic selection




Fig. 74: Speed

4.6.2.4.4 Result offset

With the Result offset, the final position of a found object can be modified. This can be useful when working with robot coordinate systems and needing to define a 'pick point' for example

Settings in Result pose tab:

Parameters	Functions
None	Automatically determined centre of (<u>R</u> egion <u>O</u> f <u>I</u> nterest)
Offset	Free selectable position (graphically or by value input, e.g. for robot gripper use) <ul style="list-style-type: none"> • X: Offset in X- direction (ref. ROI centre) • Y: Offset in Y- direction (ref. ROI centre) • Angle: angle offset (ref. ROI orientation)




Fig. 75: Result pose

4.6.3 Detectors

Each job contains one or several inspection steps (detectors), which you can define here.

With the very first selection of the step "Detector" a window with a list of all available detectors opens.

Drawings in the image (yellow, red frames etc.) can be activated or deactivated for any detector or category in the menu item "View/all drawings". With "View/drawings of current detector only", all drawings on the screen can be deactivated with the exception of the detector currently being processed.

Next topic: [Creating and adjusting detectors \(Page 90\)](#)

For information to the meaning and adjustment of the different frames see chap. [Search and parameter zones](#)




Fig. 76: Detector list for selection (here Object sensor)

4.6.3.1 Creating and adjusting detectors

Types of detector:

- [Detector Pattern matching \(Page 92\)](#)
- [Detector Contour \(Page 101\)](#)
- [Contrast detector \(Page 109\)](#)
- [Brightness detector \(Page 117\)](#)
- [Grey detector \(Page 113\)](#)
- [Detector BLOB, Introduction \(Page 120\)](#)
- [Detector Caliper \(Page 133\)](#)
- [Barcode detector. \(Page 136\)](#)
- [2D Code detector \(Page 144\)](#)

- [Detector OCR \(Page 152\)](#)
- [Detector Color area, Color select \(Page 166\)](#)
- [Detector Color list \(Page 169\)](#)
- [Detector Color value \(Page 164\)](#)

Create new detector:

1. Click on “New” button under the selection list in the configuration window and select the type of detector required. A new detector entry appears in the selection list.
2. Edit the name of the detector with a double click on "Name"

Configure detector:

1. Activate the detector in the selection list.
2. Graphically define the appropriate search and parameter zone on the image.
3. Configure the detector by entering/adjusting the parameters in the Parameters /General and if necessary Advanced tabs in the configuration window. Which tabs are shown depends on the type of detector selected.

Functions for administration of detectors:

Control panel	Functions
New	Adds new detector > dialogue box with above-mentioned detector selection list appears
Copy	Copies all parameters from one detector to one or several others. The parameter zones are not copied. All detectors must be from the same type. Copy process: Create all desired destination detectors; they must be of the same type as the source detector. Mark source detector in the list Click to button „copy“ A list occurs, mark all desired destination detectors. (To select several press “Ctrl” key) Click “Copy” to confirm
Reset	Resets parameters and search and parameter zones of selected detector to standard values
Delete	Deletes the selected detector
Delete all	Deletes all the detectors in the list

Information:

"Flash x.x/yyyy.y kB" appears in the bottom corner of the screen, indicating first the memory used by the current configuration (x.x), and the memory available on the sensor (yyyy.y) in kB. Should the memory used exceed the available memory, this indicator switches to red as there is not enough space for the current settings on the sensor. In this case you can delete other jobs from the sensor before transfer.

Drawings in the image (yellow, red frames etc.) can be activated or deactivated for any detector or category in the menu item "View/all drawings". With "View/drawings of current detector only", all drawings on the screen can be deactivated with the exception of the detector currently being processed.

4.6.3.2 Selecting a suitable detector

Next topic: [Detector Pattern matching \(Page 92\)](#)

The following detectors are available in Vision Sensor Configuration Studio

Type of detectors	Description
Pattern matching	Part detection using pattern matching, X- and Y- translational
Contour detection	Part detection using object contour, up to 360° rotation
Contrast	Evaluation of contrast in selected search zone
Brightness	Evaluation of brightness in selected search zone
Grey level	Evaluation of grey values in selected search zone
BLOB	Count and evaluate objects
Caliper	Distance between edges
Barcode	Barcode reading ID Codes (Code reader)
2D- Code	Data code reading 2D Codes (Code reader)
Optical Character Reader (OCR)	Optical character reading (Code reader)
Color Area	Color verification inside area
Color List	Color verification inside list
Color Value	Output of color values
Wafer	Position check and control of wafers (Solar sensor)
Busbar	Position check and control of busbars (Solar sensor)

4.6.3.3 Detector Pattern matching

This detector is suitable for the detection of patterns of any shape, even without distinctive edges or contours.




Fig. 77: Detector Pattern matching

Next topic: [Detector Contour \(Page 101\)](#)

[Result offset \(Page 107\)](#)

[Creating and adjusting detectors \(Page 90\)](#)

[Pattern matching application \(Page 95\)](#)

4.6.3.3.1 Settings in tab Basic:

Parameters	Functions
Switching threshold min/max	Zone for the required concordance of the pattern found with the pattern taught.
Accurate - fast	Number of search levels / coarsening levels. 0 = automatic selection Higher value: faster = riskier (overlook candidates) Smaller value: slower = less risky (all candidates)
Position check	Checks whether the pattern found is in the right position. If position check is activated, the position frame is shown in blue (either rectangular or elliptic).
Pattern	Shows the taught pattern = contents of the red frame
Edit pattern	By the mask there can be masked out regions of the search area. The regions which are not relevant for this examination can be painted out like using an eraser. Masks can also be inverted, means that regions which are interesting can be marked.
Lock	Lock / Unlock Pattern: In locked status the taught pattern is protected against (unintentional / accidental) changing, by e.g. modification of the teach region. Unlock to

modify taught pattern..

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

Optimisation Pattern matching:

Execution speed:

- Search zone for position (yellow frame) only as large as necessary: Attention: The search area marks the area where the centre point of the pattern is searched!
- Reduce resolution to QVGA instead of VGA (Attention: Global parameter, affects all detectors!)
- Set “accurate – fast” to fast

Robust pattern detection:

- Search zone for position (yellow frame) sufficiently large?
- Reduce search levels
- Distinctive grey value pattern?, re-teach if necessary
- If found at wrong position: use distinct sample, re-teach if necessary

If, directly after teach, the found position (green frame) is not identical with teach area (red frame) the slider “Accurate – fast” should be set to “Accurate”

4.6.3.3.2 Color channel

Selection of color model and color components for the grey image used by the detector.

The display of the image depends on the image chip and the selected detector.

A image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection with monochrome detectors also. By selection of the colour channels the composition of the grey image can be manipulated and so specific zones can be intensified or weekend.

- Monochrome chip: Display always greyscale
- Color chip + Color detector: Display always colored
- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel




Fig. 78: Color channel

Parameter	Function
Color model	Color models: RGB, Color model RGB (Page 207) HSV, Color model HSV (Page 208) LAB, Color model LAB (Page 209)
Color channel	Selection of a color filter. Non selected colors will not be used in the resulting grey image which is processed by the detector.

4.6.3.3.3 Result offset

With the Result offset, the final position of a found object can be modified. This can be useful when working with robot coordinate systems and needing to define a 'pick point' for example

Settings in Result pose tab:

Parameters	Functions
None	Automatically determined centre of (<u>R</u> egion <u>O</u> f <u>I</u> nterest)
Offset	Free selectable position (graphically or by value input, e.g. for robot gripper use) <ul style="list-style-type: none"> • X: Offset in X- direction (ref. ROI centre) • Y: Offset in Y- direction (ref. ROI centre) • Angle: angle offset (ref. ROI orientation)




Fig. 79: Result pose

4.6.3.3.4 Pattern matching application

In this example a metal contact (left side) in a black plastic part is taught as pattern. It is detected with a high score value, as the metal contact is mounted. (Threshold near 100%)




Fig. 80: Pattern matching, application example, positive result.




Fig. 81: Pattern matching, application example, negative result.

If the same pattern matching is performed at a position, where the metal contact searched for is not mounted, the score value does not reach the threshold and the result gets negative. With the function pattern matching the detection is made by the grey values of the pixels at the corresponding position in the image. As here the inner, shiny and therefore bright region does not exist, and instead of this the grey

values of the pixels in the corresponding position do have lower (darker) values, the score value is significantly lower than with the contact mounted.

But, as also big regions of the search area are matching (the outer dark frame of the black plastic) the score value is not zero, but approx. 70%.

The settings in these examples are just made to illustrate the function of the detector pattern matching. In real operation these settings should be optimized further. (E.g. by smaller search and / or feature regions >> relevant pattern gets more significant, etc.)

By Teach the pattern inside the red frame gets stored in the sensor as reference pattern. Size and position of the reference pattern is defined by the red frame. In Run mode the SBS tries to find the best fit of the reference with any region in the image. Depending on the settings of the threshold the object / feature is detected or not. The function pattern matching does not work with rotated images; its tolerance is limited to an angle of approx. $\pm 5^\circ$. Patterns with higher angular deviation are not detected. This behaviour can be used to detect if a part is in correct orientation in feeding application.

Example:

The following pattern was taught:



Fig. 82: Pattern, reference

With the following three examples, the object is detected with 100% concordance, as the taught pattern is exactly the same, even though it is in another place on the image.

Only offset in X or Y direction and not rotated.




Fig. 83: Pattern, positive result

With the three now following examples in the second row, the object is also detected, but with less than 100% concordance, as it deviates from the taught pattern in some pixels. Good or bad results are supplied according to the setting of the threshold value (degree of concordance).




Fig. 84: Pattern, limit case

Pattern detection tolerates a ± 5 degree rotation. This means, the images in the bottom row were also detected, although the actual degree of concordance with the sample image is less than 100%, despite 100% pixel concordance.

Patterns with a larger degree of rotation are not detected.

This can be used as a function e.g. for detection of the correct alignment of parts on feeding units.




Fig. 85: Pattern, rotation

4.6.3.3.5 Function: Mask

With function „Mask“ the search region can be modified. Inside the search- and feature- areas of the different detectors, regions can be included or excluded.

Application example:

Outer and inner contour lines as well as holes shall not be considered, but all defects in the surface of the object are relevant. In this example only the not marked regions inside the ROI of the detector are relevant. The yellow masked regions are no longer relevant for the evaluation.




Fig. 86: Mask

Parameter	Function
Cursor (shape)	Changing shape (square, circle or line) of the cursor
Cursor size	Changing size of the cursor
Add pixels / Remove pixels	Select if the cursor adds or removes pixels
Add all	Adds all pixels
Remove all	Removes all pixels
Invert all	Inverts all pixels

Undo	Undo function – last action
Redo	Redo function – for last undo action
Display	Select a display mode (Zoom in / Zoom out)

By the flexible selection of cursor- shape and size, as well as if an action adds or removes pixels, complex geometric or free shaped search regions can be defined in a simple and quick manner. This regions are included = relevant, or excluded (yellow) in the search area.

To use the function „Mask” the following settings are necessary for the different detector types

Detector type	Necessary setting to use the function „Mask“
Pattern matching, Contour	Generally possible with „Edit pattern”
Contrast, Brightness, Grey, BLOB, Color value, Color area, Color list	Search region „Free shape“

Function „Mask” of search regions, examples

For the above mentioned detectors three different shapes of search regions: Circle, Rectangle and Free shape are available. If with shape Circle or Rectangle, which can be rotated also by picking and moving the tip of the arrow, the shape of the search area cannot be fit in a satisfying manner to the shape of the object the “Free shape” function can be used. With this any geometry can be designed for a search area. To design the search area the cursor can be set to a square, circle or line of any size.

In the following examples the creation of a masked search region is shown.

Example I,

Logo with relevant zones.




Fig. 87: Mask pattern 2

Created by one adding and one removing circle in front of the before reset mask.




Fig. 88: Mask pattern 3

Created by one adding and one removing circle in front of the before reset mask.

Example 2,

Only surface defects are relevant, object contour lines have to be masked.




Fig. 89: BLOB without function Mask, with a BLOB detector the surface defects and the outer and inner contour lines are detected.




Fig. 90: Function Mask: masking contour lines which shall not be considered




Fig. 91: BLOB with function Mask, only surface defects are detected, all contour lines are not relevant as they are masked now.

4.6.3.4 Detector Contour

This detector is suitable for detection of samples from edges at any angle.

Next Topic: [Contrast detector \(Page 109\)](#)

[Settings in Scaling tab: \(Page 106\)](#)

[Settings in Angle tab: \(Page 105\)](#)

[Speed \(Page 107\)](#)

[Result offset \(Page 107\)](#)

[Contour application: \(Page 108\)](#)

[Function: Mask \(Page 98\)](#)

The contours of an object in the search area are taught and stored in the sensor. In Run mode the sensor searches the position of the best fit with the taught contour. If the fit is higher than the selected threshold the result is positive. The function contour detection can work incomplete 360° angular detection mode. So the object can be rotated in any angle. The angular settings must be set accordingly.




Fig. 92: Detector contour, tab contour

The in the below, right corner in pale blue shown edges (high contrast changes in the image) have been identified and drawn because of the before made parameter settings. The found edges / contour can be influenced by changing these parameters, or by the function “Edit contour”. The SBS now searches this contour in the search area (yellow frame).

4.6.3.4.1 Settings in tab contour:

Parameters	Functions
Threshold Min/Max	Zone for required concordance of found contour with taught contour.
Min. contrast pattern	Minimum contrast required with taught model for an edge to be detected as one.
Min. contrast image	Minimum contrast required in current image for an edge to be accepted as one.

Position check	Checks whether the sample found is in the right position. If position check is activated, the authorised zone for the position of the found parameter is shown in a blue frame (either rectangular or elliptic). The centre (green cross) of the parameter found must be situated inside the blue frame.
Pattern	Taught sample with display of the edges found
Edit contour	By edit contour there can be masked out parts of the search area. The parts which are not relevant for this examination can be painted out like using an eraser. Masks can also be inverted, means that parts which are interesting can be marked. S. also chap.
Lock	Lock / Unlock Pattern: In locked status the taught pattern is protected against (unintentional / accidental) changing. by e.g. modification of the teach region. Unlock to modify taught pattern..

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

Optimisation:

Execution speed:

- Search zone for position (yellow frame) only as large as necessary. Please note: The contour is found as long as the centre point of the pattern is inside the search area!
- Search zone for angle only as large as necessary
- Search zone for scale only as large as necessary
- Reduce resolution to CGA instead of VGA (Attention: Global parameter, affects all detectors!)
- Set “accurate – fast” to fast
- Increase value “Min. contrast pattern”. Take care that the relevant contours are still visible in the display.
- Increase value “Min. contrast Image”.
- Especially in case of alignment: Use alternate reference pattern. E.g. with higher contrast, that “Min. contrast pattern” and “Min. contrast image” can be increased.

Robust detection:

- Search zone for position (yellow frame) sufficiently large?
- Search zone for angle sufficiently large?
- Search zone for scale sufficiently large?
- Contrasts for model and image suitably set? (for model visible in sample)
- Set “accurate – fast” to accurate
- Are there some and overlapping objects in the image?
- Distinctive edges available?, re-teach if necessary

- “Min. contrast pattern” set to a suitable value? If in the taught pattern the relevant contour lines are not shown completely: decrease “Min. contrast pattern”. If there are too many contour lines shown: increase “Min. contrast pattern”.
- “Min. contrast image” set to a suitable value for the current image? If the current image(s) do have a higher / lower contrast than the taught reference image /pattern please increase / decrease the value of “Min. contrast image” accordingly.
- In the taught pattern the relevant contour lines are not shown completely: decrease “Min. contrast pattern”. If there are too many contour lines shown: increase “Min. contrast pattern”.
- If found at wrong position: use distinct sample, re-teach if necessary
- If the result value is fluctuating strongly from image to image? Take care that there are no “false edges” taught (edges because of shadows, or fragments of contours, which are not desired in the contour model): This can be achieved by increasing “Min. contrast pattern” or by eliminating those false edges by function “Edit contour”.

4.6.3.4.2 Color channel

Selection of color model and color components for the grey image used by the detector.

The display of the image depends on the image chip and the selected detector.

A image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection with monochrome detectors also. By selection of the colour channels the composition of the grey image can be manipulated and so specific zones can be intensified or weakend.

- Monochrome chip: Display always greyscale
- Color chip + Color detector: Display always colored
- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel




Fig. 93: Color channel

Parameter	Function
Color model	Color models: RGB, Color model RGB (Page 207) HSV, Color model HSV (Page 208) LAB, Color model LAB (Page 209)

Color channel	Selection of a color filter. Non selected colors will not be used in the resulting grey image which is processed by the detector.
---------------	---

4.6.3.4.3 Function: Edit contour

s. chap.: Detector Pattern matching [Function: Mask](#)

4.6.3.4.4 Settings in Angle tab:

[Detector Contour \(Page 101\)](#)

[Settings in Scaling tab: \(Page 106\)](#)

[Speed \(Page 107\)](#)

[Result offset \(Page 107\)](#)

[Contour application: \(Page 108\)](#)

[Function: Mask \(Page 98\)](#)

Parameters	Functions
Angle range	Angle range in which search is carried out
Angle step	Step width / sensitivity of search throughout the selected angle rangein °




Fig. 94: Detector contour, tab angle

Angle, direction

The rotational direction of "Angle" is as follows:




Fig. 95: Rotational direction of Angle

4.6.3.4.5 Settings in Scaling tab:

[Detector Contour \(Page 101\)](#)

[Settings in Angle tab: \(Page 105\)](#)

[Speed \(Page 107\)](#)

[Result offset \(Page 107\)](#)

[Contour application: \(Page 108\)](#)

[Function: Mask \(Page 98\)](#)

Parameters	Functions
Scale min/max	Detection also of enlarged or reduced objects in a given scale range
Increment scale	Sensitivity of search throughout the selected scale range



Fig. 96: Detector contour, Scaling tab

4.6.3.4.6 Speed

Via the here adjustable parameters the execution time can be influenced. The search is processed either less detailed, that means stopped earlier = quicker, or it's processed more detailed, that means search lasts longer = slower.

Settings in tab Speed

Parameters	Functions
Accordance level	<p>Candidates with score less than indicated will already be rejected during search.</p> <ul style="list-style-type: none"> • High value: early rejection = quicker = riskier • Small value: late rejection = slower = less risky <p>In case of false results this value can be decreased.</p>
Search levels	<p>Number of search levels / Coarsening levels.</p> <ul style="list-style-type: none"> • Higher value: faster = riskier (overlook candidates) • Smaller value: slower = less risky (all candidates) • Auto = automatic selection




Fig. 97: Speed

4.6.3.4.7 Result offset

With the Result offset, the final position of a found object can be modified. This can be useful when working with robot coordinate systems and needing to define a 'pick point' for example

Settings in Result pose tab:

Parameters	Functions
None	Automatically determined centre of (Region Of Interest)
Offset	<p>Free selectable position (graphically or by value input, e.g. for robot gripper use)</p> <ul style="list-style-type: none"> • X: Offset in X- direction (ref. ROI centre)

- Y: Offset in Y- direction (ref. ROI centre)
- Angle: angle offset (ref. ROI orientation)




Fig. 98: Result pose

4.6.3.4.8 Contour application:

The visible edges / contour of metal contact mounted in a black plastic housing are taught as the reference contour. In this way the presence and the correct mounting of the contact is checked.




Fig. 99: Contour, application example, positive result

The found contour lines are displayed in the corner below right in pale blue. The contact is found reliably.




Fig. 100: Contour, application example, negative result

If now the same contour check is made at a position of the object where the metal contact is missing, the according edges / contour is not found. The detector gives a negative result.

4.6.3.5 Contrast detector

Next topic: [Grey detector \(Page 113\)](#)

[Contrast application \(Page 111\)](#)

This detector determines the contrast in the selected search area. Therefore all pixels inside the search area are evaluated with its grey value and the contrast value is calculated. If the contrast value is inside the limits set in parameter threshold the result is positive. The position of the single bright or dark pixels here is not relevant. The contrast is just depending on the bandwidth between darkest and brightest pixels and their quantity. Highest contrast value with 50% grey value “0” (= black) AND 50% grey value “255” (=white)




Fig. 101: Detector Contrast

Settings in tab Contrast:

Parameters	Functions
Threshold min/max	Range of contrast accepted.
Search region	Shape of search region can be set as Rectangle, Circle or Free shape. In mode Free shape "Edit search region" is active.
Edit search region	With Edit search region there can be masked out parts of the search area. The parts which are not relevant for this examination can be painted out like using an eraser. Masks can also be inverted, means that parts which are interesting can be marked. S. also chap. Function: Mask
Overlay search region	On- / Off of display of edited search region.

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

4.6.3.5.1 Color channel

Selection of color model and color components for the grey image used by the detector.

The display of the image depends on the image chip and the selected detector.

A image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection with monochrome detectors also. By selection of the colour channels the composition of the grey image can be manipulated and so specific zones can be intensified or weakend.

- Monochrome chip: Display always greyscale
- Color chip + Color detector: Display always colored
- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel




Fig. 102: Color channel

Parameter	Function
Color model	Color models: RGB, Color model RGB (Page 207) HSV, Color model HSV (Page 208) LAB, Color model LAB (Page 209)
Color channel	Selection of a color filter. Non selected colors will not be used in the resulting grey image which is processed by the detector.

4.6.3.5.2 Contrast application

[Contrast detector \(Page 109\)](#)

In the example the presence of a metal contact is checked with a contrast detector.




Fig. I03: Contrast, application example, positive result.

The presence of a shiny metal contact, in the middle of a surrounding black plastic housing, is checked with a contrast detector. As in this configuration contrast is pretty high the contrast detector delivers a high score, and in combination with alignment the whole job works reliably.




Fig. I04: Contrast, application example, negative result

If the same detector is placed now at a position where the metal contact is missing it leads to a negative result. As, between the black surrounding and the now visible black background of the contact, the contrast value here is low.

Function detector Contrast

The dark and the bright pixels are evaluated according to their amount and their intensity / brightness.

The position of the bright or dark pixels is not relevant.




Fig. 105: Contrast examples



Fig. 106: Contrast explanation

4.6.3.6 Grey detector

Next topic. [Brightness detector \(Page 117\)](#)

[Grey level application \(Page 115\)](#)

At this detector in the first step the range of accepted grey values is defined by setting the two limit sliders of parameter “Grey level”.

In the second step the share of the search area (in %) which must be covered by pixels with the grey value inside the definition made in step I, is defined with the parameter “Threshold” to achieve a positive result.

By the respective invert function all possible combinations can be defined, also those where the relevant grey values are only at the upper or lower border of the range of values. The position of the respective bright or dark pixels is not relevant.

With the parameter „Overlay“ pixels can be marked in a certain colour as an aid to select pixels / regions, which have a grey value inside (valid pixels), or outside (invalid pixels) the range set in „Grey level“. In this way pixels which are not covered with the settings / range of grey values can be detected very easily.

4.6.3.6.1 Settings in tab Grey:

Parameters	Functions
Grey level min/max	Range of grey values that are to be accepted
Threshold min/max	Percentage of the area, which must be in the selected grey value range
Search region	Shape of search region can be set as Rectangle, Circle or Free shape. In mode Free shape "Edit search region" is active.
Overlay	Selects which pixels are to be marked in colour on the screen as an adjustment aid. "None" = no marking, or "Valid pixels" or "Invalid pixels" are marked in the image.
Edit search region	With Edit search region there can be masked out parts of the search area. The parts which are not relevant for this examination can be painted out like using an eraser. Masks can also be inverted, means that parts which are interesting can be marked. S. also chap. Function: Mask
Overlay search region	On- / Off of display of edited search region.

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

4.6.3.6.2 Color channel

Selection of color model and color components for the grey image used by the detector.

The display of the image depends on the image chip and the selected detector.

A image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection with monochrome detectors also. By selection of the colour channels the composition of the grey image can be manipulated and so specific zones can be intensified or weakend.

- Monochrome chip: Display always greyscale
- Color chip + Color detector: Display always colored
- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel




Fig. 107: Color channel

Parameter	Function
Color model	Color models: RGB, Color model RGB (Page 207) HSV, Color model HSV (Page 208) LAB, Color model LAB (Page 209)
Color channel	Selection of a color filter. Non selected colors will not be used in the resulting grey image which is processed by the detector.

4.6.3.6.3 Grey level application

[Grey detector \(Page 113\)](#)




Fig. 108: Grey level, application example, positive result.

The contact is present in search area. Shiny metal contact shows grey values > 192, that means inside the limits of threshold = result positive.




Fig. 109: Grey level, application example, negative result

Shiny metal contact is not present in the search area. That means average value of grey values in the search area is not inside the defined threshold limits. (Not inside grey value 192-255, but rather in range < 50). Result: negative = contact not found.

Aid to determine grey values:

By placing the cursor somewhere in the image the according X- and Y- coordinate and the grey value (“I” = Intensity) are displayed in the status line on the screen below in the next to last field at the right.

Function detector Grey level.

The authorised grey value range is defined by the two limits on the grey level slider.

All pixels within this grey value range and within the defined working zone (yellow frame) are added together. The proportion of the number of all the pixels in the working zone (yellow frame) and of the number of pixels in the authorised grey value range represents the result of this detector.

If this result is within the limits set on the switching threshold slider, the result is positive. The position of the grey value pixels on the screen is of no importance.

Example: (when the grey level slider is set to very dark values):

Both images produce exactly the same result with the grey level detector, as in each case 9 of the 25 pixels are detected as dark.




Fig. 110: Grey level, example 1

If the threshold value was set to 10 in this example, the following images would produce a positive result.



Fig. 111: Grey level, example 2

4.6.3.7 Brightness detector

Next topic: [Barcode detector](#). (Page 136)

[Brightness application](#) (Page 118)

This detector determines the average value of the grey values in the search area. With the two limit sliders of the parameter „Threshold“ the valid range of the brightness mean value is defined.

As soon as the calculated average value is within these two limits the result is positive. The result value is standardized to %. The position of the bright or dark pixels is not relevant. If there are position deviations from check to check the alignment function must be used.

Settings in tab Brightness:

Parameters	Functions
Brightness min/max	Range of grey values that are to be accepted
Search region	Shape of search region can be set as Rectangle, Circle or Free shape. In mode Free shape “Edit search region” is active.
Edit search region	With Edit search region there can be masked out parts of the search area. The parts which are not relevant for this examination can be painted out like using an eraser. Masks can also be inverted, means that parts which are interesting can be marked. S. also chap. Function: Mask
Overlay search region	On- / Off of display of edited search region.

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

4.6.3.7.1 Color channel

Selection of color model and color components for the grey image used by the detector.

The display of the image depends on the image chip and the selected detector.

A image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection with monochrome detectors also. By selection of the colour channels the composition of the grey image can be manipulated and so specific zones can be intensified or weekend.

- Monochrome chip: Display always greyscale

- Color chip + Color detector: Display always colored
- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel



Fig. I 12: Color channel

Parameter	Function
Color model	Color models: RGB, Color model RGB (Page 207) HSV, Color model HSV (Page 208) LAB, Color model LAB (Page 209)
Color channel	Selection of a color filter. Non selected colors will not be used in the resulting grey image which is processed by the detector.

4.6.3.7.2 Brightness application

The detector Brightness calculates the average value of the grey values of all pixels within the search area.




Fig. I 13: Brightness, application example, positive result.

The contact is present within the position searched for; therefore the average value of the grey values in the search area has a high score (near 100%). That means the current value is within the requested threshold limits and the result is positive = contact present.




Fig. I 14: Brightness, application example, negative result.

The contact is not present within the position searched for; therefore the average value of the grey values in the search area delivers a low score (near 0%). That means the current value is not within the requested threshold limits and the result is negative = contact not present.

Examples: Brightness value as average value of the grey values.




Fig. I 15: Brightness, examples

4.6.3.8 Detector BLOB, Introduction

The BLOB detector is used to identify and count one or more objects with some common features like same grey value range, same area, same circumference, ...

[Color channel \(Page 133\)](#)

[Detector BLOB, tab Binarization, Absolute threshold \(Page 122\)](#)

[Detector BLOB, tab Binarization, Dynamic threshold \(Page 124\)](#)

[Detector BLOB, tab Features \(Page 127\)](#)

[Detector BLOB, tab Sorting \(Page 132\)](#)

BLOB, Introduction

"BLOB" abbreviation for "Binary Large Object" or "Binary Labeled Object".

Basic function of machine vision for evaluation of connected areas / objects in an image.

The single objects are distinguished by simple features like: area, width, height



Fig. 1.16: Screws 1. Binarization, 2. detected as BLOB / object

Typical applications

- Count objects
- Differentiation / classification of objects in the image by:
 - Size, area, contour
 - Form, geometry
 - Position, orientation
 - Face up/ down
 - Surface inspection





Fig. 117: Typical applications: count, classify / sort, orientation / face up / down

BLOB, simple configuration in 3 steps



1. Binarzation

Distinguish between relevant objects and background

[Detector BLOB, tab Binarization, Absolute threshold \(Page 122\)](#)

[Detector BLOB, tab Binarization, Dynamic threshold \(Page 124\)](#)

2. Filtering of detected BLOBs

Filtering by different features like: area, circumference, orientation, position, ...

[Detector BLOB, tab Features \(Page 127\)](#)

3. Data output

Definition of data output telegram and sorting of results

[Detector BLOB, tab Sorting \(Page 132\)](#)

[Telegram, Data output \(Page 189\)](#)

4.6.3.8.1 Color channel

Selection of color model and color components for the grey image used by the detector.

The display of the image depends on the image chip and the selected detector.

A image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection with monochrome detectors also. By selection of the colour channels the composition of the grey image can be manipulated and so specific zones can be intensified or weakend.

- Monochrome chip: Display always greyscale
- Color chip + Color detector: Display always colored
- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel




Fig. 118: Color channel

Parameter	Function
Color model	Color models: RGB, Color model RGB (Page 207) HSV, Color model HSV (Page 208) LAB, Color model LAB (Page 209)
Color channel	Selection of a color filter. Non selected colors will not be used in the resulting grey image which is processed by the detector.

4.6.3.8.2 Detector BLOB, tab Binarization, Absolute threshold

In this tab all parameters for binarization of a BLOB can be set.

[Detector BLOB, Introduction \(Page 120\)](#)

Binarization is the first step of BLOB processing. It is used to distinguish relevant objects from the background of the image, by converting the grey image into a pure black and white / binary image.

Binarization can be done by two different binarization methods.



Fig. 119: Detector BLOB, tab Binarization

In the first combobox the threshold method for binarization is selected.

Parameter	Function
Absolute threshold	Binarization threshold is set to an absolute grey value in range of 0 .. 255.
Dynamic threshold	Threshold is automatically set to a statistically optimised position in order to distinguish between fore- and background. Detector BLOB, tab Binarization, Dynamic threshold (Page 124)

Parameters with selection "Absolute Threshold"

Parameter	Function
Absolute threshold	Setting the upper and lower limit defines the range of valid grey values of pixels belonging to the BLOB.
Gray value range	Adjusting the upper and lower limit of grey values for binarization / valid for the BLOB.
Invert button	With the "Invert button" (default: red/green/red) the logic of detection can be inverted. This way the relevant range can be included or excluded.
Pipette button	With a click to the "Pipette button" the cursor changes into a pipette symbol. By moving the cursor and clicking to any position (pixel) inside the image the grey value of this pixel is taken and the limits of "Absolute threshold" are set to +/- 10 grey values of the grey value of this pixel (values clipped at 0 or 255).

Boundary BLOB's, Overlay and Histogram

Parameter	Function
Boundary BLOBs	Selected BLOBs (objects) are considered, if they are fulfilling the BLOB- / filter-criteria, even if they are not completely positioned within the yellow search region. Please note: BLOBs are also considered as Boundary BLOBs if they are touching a

	zone masked with the "Edit search region / Function: Mask" (even masked zones inside the image / search region) Detector BLOB, Boundary BLOBs (Page 125)
Search region	Search region can be set to: "Rectangle", "Circle" or "Free shape". In mode "Free shape" the function "Edit search region" is active.
Edit search region	Using the "Edit search region" button the dialog window to edit the search region can be opened. Function: Mask (Page 98)
Overlay BLOBs	"Valid BLOBs": all valid BLOBs which fulfill the filter criteria are marked in green. With this selection invalid BLOBs are marked in red. "BLOB contour": all valid BLOBs (all BLOBs fulfilling the filter criteria) are marked with a green contour line. With this selection invalid BLOBs are not marked.
Histogram	The Histogram button opens the Histogram window for the BLOB. Detector BLOB, tab Binarization, Histogram (Page 127)

4.6.3.8.3 Detector BLOB, tab Binarization, Dynamic threshold

In this tab all parameters for binarization with dynamic threshold can be set. The dynamic threshold can be used if BLOBs / objects and background do have clearly different grey value ranges, and illumination conditions are changing uniformly over the whole image.

If the brightness of the image changes uniformly, with the dynamic threshold limits are readjusted automatically. (With absolute threshold those limits must be readjusted manually.)

Please note:

The Dynamic threshold is newly calculated with each new image / evaluation.

Please consider that fluctuating illumination, surface- reflectivity, etc. may influence the result!




Fig. 120: Detector BLOB, tab Binarization, Dynamic threshold

Parameters with selection "Dynamic Threshold"

Parameter	Function
Dynamic threshold	Dynamic threshold is automatically set to an statistically optimised position in order to distinguish between fore- and background.
Brightness	Definition if BLOB is brighter or darker compared to the background

Gray value range	Adjusted limits of grey values for binarization.
Threshold correction factor	With the Threshold correction factor the above automatically calculated binarization threshold can be moved / manipulated either towards the foreground- or background- brightness.

For illustration of the dynamic threshold see also: [Detector BLOB, tab Binarization, Histogram \(Page 127\)](#)

4.6.3.8.3.1 Detector BLOB, Boundary BLOBs

If the checkbox "Boundary BLOBs" is active, the selected BLOBs (objects) are considered, even if they are not completely positioned within the yellow search region. (Of course they have to fulfill the BLOB- / filter- criteria anyway)

Please note: BLOBs are also considered as Boundary BLOBs if they are touching a zone masked with the "Edit search region / Function: Mask" (even if masked zones are inside the image / search region).

Example I: Boundary BLOBs, touching outer search region.




Fig. 121: Boundary BLOB example I/I: BLOB is touching outer yellow search region, it is not considered as valid BLOB as setting "Boundary BLOBs" is NOT active.




Fig. 122: Boundary BLOB example 1/2: BLOB is touching outer yellow search region, but it is considered as valid BLOB yet, as setting "Boundary BLOBs" is ACTIVE now!

Example 2, Boundary BLOBs, touching inner "Mask" region.




Fig. 123: Boundary BLOB example 2/1: BLOBs are touching inner yellow "Mask" regions, they are not considered as valid BLOBs, as setting "Boundary BLOBs" is NOT active.




Fig. 124: Boundary BLOB example 2/2: BLOBs are touching inner yellow "Mask" regions, but they are considered as valid BLOBs yet, as setting "Boundary BLOBs" is ACTIVE now!

4.6.3.8.3.2 Detector BLOB, tab Binarization, Histogram

In this window the Histogram of the grey values inside the yellow ROI, and the chosen thresholds are shown.

In the here shown example there are clear maxima for fore- and background. The binarization threshold is adjusted to approx. the center in between.




Fig. 125: Detector BLOB, tab Binarization, Histogram

4.6.3.8.4 Detector BLOB, tab Features

In this tab the features / filter criteria to distinguish between valid and invalid BLOBs/objects can be defined.

Processing sequence:

1. Step Binarization: List of BLOBs (all valid / green).
2. For each BLOB all selected features are calculated. Use "pipette" function to determine features.
3. For each criteria a range describing the valid BLOBs can be set.

4. Each BLOB is checked if it is fulfilling all above mentioned features/filter criteria.
5. Each BLOB fulfilling all features is a valid BLOB (green), all others are invalid (red).

Only the valid BLOBs are processed further, e.g. for data output.

Example: If the feature "Area" is set to a range of 100 ... 150 (pixel), only BLOBs with an area within this range are considered as valid (green).

Checkbox (Default: active)

active: feature is calculated, filtered (limits adjustable), and available for data output.

inactive: feature is calculated, but NOT filtered, but available for data output.




Fig. 126: Detector BLOB, tab Features

Slider "Number" in tab Features

Additionally to the features used for filtering the BLOBs, the number of existing and valid BLOBs can be checked.




Result positive: if number of valid (filtered) BLOBs is inside the range of "Number".

Result negative: if number of valid (filtered) BLOBs is outside the range of "Number".

If the detector counts more than 10.000 BLOBs (maximum) the detector result is negative and no further calculations are performed.

Feature	Function
Number	Lower and upper limit of number of BLOBs accepted. (max. 10.000). If the number of BLOBs is outside the defined limits, the detector result is negative, although valid BLOBs are marked in green.
Invert button	With the "Invert button" (default: red/green/red) the logic of detection can be inverted. This way the relevant range can be included or excluded.
Pipette- button (Number)	By clicking this symbol, the lower and upper limit of "Number", are set to exactly the found number of BLOBs in the image.
Checkbox (Number, default active)	active: feature is calculated, filtered (limits adjustable), and available for data output. inactive: feature is calculated, but NOT filtered, but anyway available for data output.

List of features / first level: Base parameter, and BLOB type

Feature	Function
Pipette- button (Feature)	With a click to the "Pipette button" the cursor changes into a pipette symbol. By moving the cursor and clicking to any position (pixel) inside a valid (green) BLOB, the limits of the selected feature are adjusted automatically to +/- 10% of the value of the BLOB clicked to. E.g.: with selected feature "Area" and clicking with Pipette active to any pixel inside the BLOB, the lower and upper limit of area is set to +/- 10%. of the found number of pixels of the selected BLOB.
Checkbox (Feature, default: active)	active: feature is calculated, filtered (limits adjustable), and available for data output. inactive: feature is calculated, but NOT filtered, but anyway available for data output.
- Area	Area of the BLOB, without holes, in pixels.
- Area (incl. holes)	Area of the BLOB, including holes, in pixels.
- Contour length	Number of pixels of outer contour of the BLOB.
- Compactness	Compactness of BLOB (Circle = 1, all other > 1) The stronger the shape of the BLOB deviates from an ideal circle the larger the value of compactness will be. Range of slider: 1 - 100 (clipped at 100, BLOBs with higher values are marked as invalid)
- Center of gravity X	X- coordinate of center of gravity of BLOB
- Center of gravity Y	Y- coordinate of center of gravity of BLOB
BLOB type / Geometric Model	Function
Some features are calculated based on a given geometric model, e.g. eccentricity is based on a ellipse fit to the object	
 - Rectangle, paraxial (R1)	Enclosing rectangle parallel to Y- axis and X- axis. Outliers are not eliminated.
 - Rectangle, min. area (R2)	Enclosing rectangle with smallest area. Outliers are not eliminated.
 - Ellipse, equivalent (E1)	Equivalent ellipse, based on moments of area.

List of features / second level: BLOB type parameter

Feature	Relevant for	Function
---------	--------------	----------

- Center X	R1, R2, EI	X- coordinate of the center of the fitted, geometric element (rectangle, ellipse)
- Center Y	R1, R2, EI	Y- coordinate of the center of the fitted, geometric element (rectangle, ellipse)
- Width	R1, R2, EI	Width of geometric element. Width ≥ 0 , width \geq height. The orientation is chosen in a way that width is always bigger than height. (Exception: R1, Rectangle, paraxial: Width always in horizontal orientation = parallel to X- axis)
- Height	R1, R2, EI	Height of geometric element. Height ≥ 0 , height \leq width. The orientation is chosen in a way that width is always bigger than height. (Exception: R1, Rectangle, paraxial: Height always in vertical orientation = parallel to Y- axis)
- Angle (180)	R2, EI	Orientation of width (long axis) of object in degree (range: $-90 \dots +90^\circ$, 0° = east, counterclockwise) see below *1)
- Angle (360)	R2, EI	Orientation of width of object in degree (range: $-180 \dots +180^\circ$, 0° = east, counterclockwise) see below *1)
- Axial ratio	EI	Ratio long / short axis (a/b)
- Face up/down, area	EI	Face up/down discrimination, based on area, indicated by sign. See also: Detector BLOB, tab Features, Face up / Face down (Page 131)

***1) Angle (180° / 360°), rotational direction**



Fig. 127: Rotational direction of "Angle 180"




Fig. 128: Rotational direction of "Angle 360"

4.6.3.8.4.1 Detector BLOB, tab Features, Face up / Face down

“Face up/down, area” and “Face up/down, contour” assess the symmetry of the blob with respect to an axis determined by the center and the orientation of the blob. If a blob is fully symmetric with respect to this line the result value will be 0 otherwise it will deviate from 0. The sign of the value indicates whether the side to the left or right is “stronger”.

“Face up/down, area” and “Face up/down, contour” can be used e.g. for discrimination of object pose as necessary in pick-and-place applications or with vibratory feeders.



Fig. 129: Face up / Face down, area or contour

The left image displays the demonstration object on one side. The thresholds are chosen in a way that this side is considered OK. The image displayed in the middle shows the same object flipped with its face down. It is considered not OK. The right image displays both objects in the image.

- “Face up/down, area” takes each pixel belonging to the blob into account for the calculation.
- “Face up/down, contour” only takes the pixels belonging to the blob’s contour into account.

This method can be used, if e.g. the object inside the contour varies or is subject to changes due to reflections or other environmental influences.

The axis used for the calculation is determined by the centre and the rotation angle (360°) of the blob. Thus these values are dependent of the geometric model for the blob that has been chosen (e.g. smallest enclosing rectangle (rectangle2) or equivalent ellipse (ellipse1)).

The geometric model has to be chosen in a way that its orientation (360°) returns a stable and unambiguous value. Thus highly objects (e.g. perfect rectangles, circles, squares or point-symmetric objects) cannot reliably be evaluated with this method. For objects where the smallest enclosing rectangle (rectangle2) returns an unambiguous orientation angle, e.g. “L”-shaped geometries or right-angled triangles, the ellipse model might return better results.

4.6.3.8.5 Detector BLOB, tab Sorting

The features that have been defined in the tab features [Detector BLOB, tab Features \(Page 127\)](#) are calculated for each individual BLOB. For each BLOB the results of these calculations will be sent to the PLC or computer, if this feature is defined as a telegram [Telegram, Data output \(Page 189\)](#). The sequence of these results is defined in the tab “Sorting”.

If e.g. the feature “Center of gravity Y” is calculated and there are 5 BLOBs in the image, the telegram comprises the results of all 5 BLOBs. If sorting criterium “Area” and order “Descending” are selected, the result (here: Center of gravity Y) of the BLOB with the largest area will be transmitted first.




Fig. 130: Detector BLOB, tab Sorting

Settings in tab Sorting

Parameter	Function
Sorting criteria	As a sorting criteria any feature explained in tab "Features" can be selected.
Order	Sorting order "Descending" or "Ascending".

4.6.3.9 Detector Caliper

With this detector you can control the dimensional accuracy of an object.

[Color channel \(Page 133\)](#)

[Detector Caliper, tab Probe \(Page 134\)](#)

[Detector Caliper, tab Distance \(Page 135\)](#)

[Caliper results / Histogram display \(Page 136\)](#)

4.6.3.9.1 Color channel

Selection of color model and color components for the grey image used by the detector.

The display of the image depends on the image chip and the selected detector.

A image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection with monochrome detectors also. By selection of the colour channels the composition of the grey image can be manipulated and so specific zones can be intensified or weakend.

- Monochrome chip: Display always greyscale
- Color chip + Color detector: Display always colored
- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel




Fig. 131: Color channel

Parameter	Function
Color model	Color models: RGB, Color model RGB (Page 207) HSV, Color model HSV (Page 208)

	LAB, Color model LAB (Page 209)
Color channel	Selection of a color filter. Non selected colors will not be used in the resulting grey image which is processed by the detector.

4.6.3.9.2 Detector Caliper, tab Probe

In this tab all parameters of the probe(s) can be set and the result / histogram display can be accessed.




Fig. I 32: Detector Caliper, tab Probe

Parameter	Function
Probe type	Selection of Probe type: - One probe, both sides - One probe, one side - Two probes, antiparallel (opposite direction) - Two probes, same direction
Edge strength	Edge strength / contrast above which an edge should be detected as an edge
Smoothing	Edges are smoothed in search direction. With higher values blurred or not to the search direction perpendicular edges are detected more reliably. Also tightly located bright-dark-bright or dark-bright- dark transitions can be eliminated. This way you can fade-out scratches or other disturbing edges. Via the Result button the effects for smoothing can be monitored in the histogram window.
Transition	Selection between light-dark or dark-light transition
No. of search stripes	Number of parallel search stripes into which the width of the search zone is to be divided. Edge detection is processed in each search stripe over the whole width. The bigger the number of search stripes, the more probable the very first edge will be found. (Finer detection - longer execution time).
Results	Opens result and histogram display

4.6.3.9.3 Detector Caliper, tab Distance

In this tab all parameters of the searched for distance can be set.




Fig. I 33: Detector Caliper, tab Distance

Parameter	Function
Distance	Distance in pixels, with two limits for tolerance band Blue bar: current distance value
Distance mode	For each search stripe one touching point is calculated. If the number of search stripes > 1 there are different possibilities how the final result is calculated. - Maximum: The touching point which represents the longest distance is selected. - Minimum: The touching point which represents the smallest distance is selected. - Mean (Average): All touching points are arithmetically averaged. If there are outliers these are also used for the calculation, and do influence the result. - Median: The values of the touching point are sorted ascending and the middle (central) value in the list is chosen. Outliers do not influence the result.

4.6.3.9.4 Caliper results / Histogram display




Fig. I 34: Caliper results / Histogram display

Parameter	Function
Probe (x)	Image of probe (x) with: - Green line: detected overall result edge - Green crosses: detected edge transition per search ray - Light blue zone: display of "Selected search ray"
Edge strength	Histogram with: - Blue line: contrast gradient in image, depending on "Selected search ray" - Red line: required contrast for edge detection (Threshold) - Light blue line: detected edge transition, depending on "Selected search ray"
Fit, "+", "-"	Fit or zoom of "edge strength" histogram
Selected search stripe	Selection of search stripe to be displayed in "Probe (x)" image - Winner: winner search stripe (depending on settings in "Distance/Distance mode") - "1, 2, ..." Number of search stripe

4.6.3.10 Barcode detector.

Next topic: [2D Code detector \(Page 144\)](#)

[Barcode detector, tab Reference string \(Page 138\)](#)




Fig. I35: Detector Barcode, tab Code

4.6.3.10.1 Barcode detector, tab Code

Settings in tab Code

Parameters	Functions
Bar code type	Select here the type of barcode to be read with the Code reader.
Decoded string length	Max. Length of a barcode. If contents of code are longer than this value, the rest will be cut off. If more than one code is read by this detector, this value has to be set for the longest code.
Check character	This setting activates the processing for a check character in case it is part of the code. Barcodes with check characters are e.g. Code 39, Codabar, 25 Industrial or 25 Interleaved. If this setting is not activated, the check character will be given out with the normal result string.
Min. number of codes	Minimum number of codes to be read inside the search area.
Max. number of codes	Maximum number of codes to be read inside the search area. If this value is set higher than necessary, the reading time may increase slightly.
Number of characters	Number of expected characters in the barcode. Codes with a different number of characters are ignored. If the number of characters of the code is known, this check increases the detection
No-read string	Specifies the text, which is given out over the interfaces in case of non successful reading.
Polarity	Specifies printing of code "black on white" or "white on black".

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

Optimisation:

Execution speed:

- Search zone for position (yellow frame) only as large as necessary

Robust detection:

- Search zone for position (yellow frame) sufficiently large?
- Contrasts for model and image suitably set? (for model visible in sample)
- Are thresholds set correctly?

4.6.3.10.2 Barcode detector, tab Reference string

Next topic: [Barcode detector. \(Page 136\)](#)

[Barcode detector, tab Quality \(Page 139\)](#)




Fig. 136: Detector Barcode, tab Reference string

Settings in tab Reference String

Parameters	Functions
Compare string	Activates verification of contents of the result information. The verification is done by using of regular expressions.
Ref. string	This text or regular expression is taken for verification. Here can be entered characters or regular expressions.
Add expression	Opens a list with examples for regular expressions.
Teach ref. string	Reads the code under the code reader and takes the contents of this code as a reference string. This text can be changed later.

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

Examples for reference strings specified by regular expressions:

Reference string	Hit	Example for hit
123	String containing 123	01234
\A123	String beginning with 123	1234
123\Z	String ending by 123	0123
\A123\Z	String matching exactly 123	123
[123]	String containing one of the characters	33
[123]{2}	String containing sequence of the characters of length 2	23
[12][34]	String containing a character of one of both groups	4

Most important elements of regular expressions:

^ or \AMatches start of string

\$ or \ZMatches end of string (a trailing newline is allowed)

.Matches any character except newline

[...]Matches any character listed in the brackets. If the first character is a '^', this matches any character except those in the list. You can use the '-' character as in '[A-Z0-9]' to select character ranges. Other characters lose their special meaning in brackets, except '\.'

*Allows 0 or more repetitions of preceding literal or group

+Allows 1 or more repetitions

?Allows 0 or 1 repetitions

{n,m}Allows n to m repetitions

{n}Allows exactly 'n' repetitions

|Separates alternative search expressions

4.6.3.10.3 Barcode detector, tab Quality

[Barcode detector, tab Reference string \(Page 138\)](#)

[Barcode detector, tab Lines \(Page 142\)](#)




Fig. 137: Detector Barcode, tab Quality

Settings in tab Quality

Parameters	Functions
Quality param.	<p>Evaluation of printing quality according to international standard ISO/IEC 15416. In order to achieve an evaluation according to the norm, there are defined minimum requirements for the size of the code inside the camera image (resolution) and mounting of camera and illumination. These requirements are specified inside the norm. For simple ID Barcodes, the rating of printing quality is combined in a total of eight elements:</p> <ul style="list-style-type: none"> Q1 Overall Q2 not used Q3 not used Q4 Minimal Reflectance Q5 Minimal Edge contrast Q6 Modulation Q7 Defects Q8 Decodability <p>"Overall" is rating the total quality, the further elements give information about possible reasons for a reduced quality. Inside ISO/IEC 15416 there is a list with common defects and their influence to the single grades. The single quality grades are defined as follows:</p> <ul style="list-style-type: none"> "Overall" is the minimum value of all other grades. "Decode" has value 4 when the code was read and value 0 when the code was not read. "Symbol contrast" is the difference between minimum and maximum reflexion value of greyscale, better contrast gives better grading. "Minimal reflectance" is set to 4 if the lowest reflectance value in the scan reflectance profile is lower or equal to 0.5 of the maximal reflectance value. Otherwise a value of 0 is assigned. "Edge contrast" is the contrast between any two adjacent elements, either bar-to-space or space-to-bar. The "minimal edge contrast" grades the minimum of the edge contrast values measured in the reflectance profile. "Modulation" indicates how strong the amplitudes of the bar code elements are. Big amplitudes make the assignment of the elements to bars or spaces more certain, resulting in a high modulation grade. "Defects" is a grading of reflectance irregularities found within elements and quiet zones. "Decodability" grade reflects deviations of the element widths from the nominal widths defined for the corresponding symbology. "Additional requirements" are bar code symbology specific requirements: mostly regarding the required quiet zones, but sometimes it can be also related to wide/narrow ratio, inter character gaps, guarding patterns or further symbology specific characteristics. <p>For composite codes, the rating has 24 grades:</p> <ul style="list-style-type: none"> OVERALL: Q1 Overall Q2 Overall Linear Q3 Overall Composite

	<p>LINEAR: Q4 Decode Q5 Symbol Contrast Q6 Minimal Reflectance Q7 Minimal Edge contrast Q8 Modulation Q9 Defects Q10 Decodability Q11 Additional Requirements</p> <p>COMPOSITE: Q12 Decode Q13 Rap Overall</p> <p>COMPOSITE RAP: Q14 Contrast Q15 Minimal Reflectance Q16 Minimal Edge Contrast Q17 Modulation Q18 Defects Q19 Decodability Q20 Codeword Yield Q21 Unused Error Correction Q22 Modulation Q23 Decodability Q24 Defects</p> <p>The "overall" grade in the group OVERALL is the final symbol grade to be reported. It is just the lower from the other two in the group: "overall linear" and "overall composite", which are the overall grades of the linear and the composite sub symbols, respectively. The other two groups, "LINEAR" and "COMPOSITE", contain the corresponding individual grades for both sub symbols, and give information for possible causes for poor quality of the symbol. The grades in the "LINEAR" group correspond to those for the simple ID bar code case, described above. The grades in the "COMPOSITE" group correspond to the grades for a PDF 417 data code symbol, where "rap overall" is called after the specific, so-called RAP, start/stop pattern of Composite symbols. Additionally, the sub group "COMPOSITE RAP" expands the individual grades for the reflectance profile of the RAP patterns. The RAP grades are consistent with the grades for the simple ID bar code case explained above.</p>
<p>Quality type</p>	<p>There are existing two possibilities, to display quality parameters. Both are according to the norm. The grades can be given in values from A to F or from 4 to 0. A and 4 are the best possible grades. This setting determines how the grades should be displayed. It affects the display on screen as well as the output over the interfaces.</p> <p>The assignment is the following: ABCDF 43210</p>

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

4.6.3.10.4 Barcode detector, tab Lines




Fig. I 38: Detector Barcode, tab Lines

Settings in tab Lines

Parameters	Functions
Minimum Size	Minimal size of bar code elements, i.e. the minimal width of bars and spaces. For small bar codes the value should be reduced to 1.5. In the case of huge bar codes the value should be increased, which results in a shorter execution time.
Maximum Size	Maximal size of bar code elements, i.e. the maximal width of bars and spaces. This value should be adequate low such that two neighbouring bar codes are not fused into a single one. On this other hand the value should be sufficiently high in order to find the complete bar code region.
Minimum height	Minimal bar code height. In the case of a bar code with a height of less than 16 pixels the respective height should be set by the user. Note, that the minimal value is 8 pixels. If the bar code is very high, i.e. 70 pixels and more, manually adjusting to the respective height can lead to a speed-up of the subsequent finding and reading operation.
Orientation	Expected bar code orientation. If the bar codes are expected to appear only in certain orientations in the processed images, one can reduce the orientation range adequately. This enables an early identification of false candidates and hence shorter execution times. This adjustment can be used for images with a lot of texture, which includes fragments tending to result in false bar code candidates.
Orientation tolerance	Orientation tolerance. See the explanation of 'orientation' parameter.
Measuring threshold	The bar-space-sequence of a bar code is determined with a scan line measuring the position of the edges. In the case of disturbances in the bar code region or a high noise level, this value should be increased.
Max. diff orientation	A potential bar code region contains bars, and hence edges, with a similar orientation. This value denotes the maximal difference in this orientation between adjacent pixels and is given in degree. If a bar code is of bad quality with jagged edges this parameter should be set to bigger values. If the bar code is of good it can be set to smaller values, thus reducing the number of potential but false bar code candidates.

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

4.6.3.10.4.1 Optimisation:

Execution speed:

- Search zone for position (yellow frame) only as large as necessary

Robust detection:

- Search zone for position (yellow frame) sufficiently large?
- Contrasts for model and image suitably set? (for model visible in sample)
- Are thresholds set correctly?
- Code size sufficient in the field of view?
- Width of barcode line sufficient?

4.6.3.10.5 Barcode detector, tab Structure




Fig. 139: Detector Barcode, tab Structure

Settings in tab Structure

Parameters	Functions
Edge contrast relative	Edge contrast relative Edges inside barcode are found by setting of a threshold. Parameter ' Edge contrast relative ' defines how this threshold in respect to the dynamic range of the scan line pixels is calculated. In the case of disturbances in the bar code region or a high noise level, the value of ' Edge contrast relative ' should be increased. Typical values: [0.05 ... 0.2]; Default: 0.05
Edge contrast absolute	Edge contrast absolute prevents misdetections of edges. For images with high noise levels this value should be higher. In noise-free images with very weak contrast, this parameter might disturb the detection of real edges. So it might be necessary to reduce it or even completely disable it by setting it to 0.0. Typical values: [0.0 ... 10.0]; Default: 5.0
Number scanlines	Number of scanlines used during the scanning of a code. Reducing the number of scanlines improves speed. Images with higher quality need less scanlines than images of lower quality. For an average image, a value between 2 and 5 should

	be good. If a code can not be detected any more after reducing the number of scanlines, the number has to be increased again. Typical values: [0, 5, 10, 20 ...]; Default: 0
Min. ident. scanlines	Minimal number of identical scanlines for a decoding of a code symbol to be accepted. If this parameter is not set (has a value of 0) a bar code is considered decoded with the first scanline, which was successfully decoded. Increasing this parameter to 2 or more is useful to avoid wrong readings. Typical values: [0, 2, 3, ...]; Default: 0
Start- / Stop pattern	Set searching criteria for a start or stop pattern to 'tolerant' or 'accurate'. 'Tolerant' will increase the detection chances of a bar code especially in images with low contrast. 'Accurate' increases the robustness against false detections. List of values: 'Tolerant', 'Accurate'; Default: 'Tolerant'
Slanted	If 'slanted' = 'On' improves readability of codes if single lines are orientated different from the others like when the code is not on a plain surface. If 'slanted' = 'Off' default setting when all lines of the barcode are parallel in image. If 'slanted' = 'Auto' the sensor tries first 'On' and then 'Auto', this setting can increase reading time. List of values: 'Off', 'Auto', 'On'; Default: 'Off'
Quiet zone	Enforces the detection of the quiet zones of a bar code. With 'Quiet zone' = 'on' the Quiet zones must be at least as wide as specified by the corresponding bar code standard. With 'Quiet zone' set to an integer value greater than or equal 1, the quiet zones must be at least as wide as 'Quiet zone' x X pixels. With 'Quiet zone' = 'tolerant' a limited number of edges are allowed in the quiet zone, but at most 1 per 4 module widths. The intent of this is to prevent detecting only part of a bar code, while still allowing to read bar codes with simple quiet zone violations. With 'Quiet zone' = 'off', the quiet zones detection is disabled. Detection of quiet zone prevents that simple bar code types are detected inside of a longer bar sequence. Usually, values between 2 and 4 achieve optimal results by effectively suppressing false bar codes, but still tolerating small disturbances, textures, label edges, etc. next to the symbol. Typical values: 'Off' 'On', 1, 2, 3, 4, 5; Default: 'Off'

4.6.3.11 2D Code detector

4.6.3.11.1 2D Code detector, tab Code

Next topic: [Detector OCR \(Page 152\)](#)

[2D Code detector, tab Ref. String \(Page 146\)](#)




Fig. 140: Detector 2D Code, tab Code

Settings in tab Code

Parameters	Functions
Symbol type	Select here the type of code to be read with the Code reader.
Code length	Max. Length of a barcode. If the contents of code are longer, the rest will be cut off. If more than one code is read by this detector, this value has to be set for the longest code.
Min. number of codes	Minimum number of codes to be read inside the search area.
Max. number of codes	Maximum number of codes to be read inside the search area. If this value is set higher than necessary, the reading time may increase slightly.
Reset	Reset parameters are for setting the code reading parameters back to the default state before teaching. There can be selected "standard", "enhanced" and "maximum". "Standard" is setting the default parameters in a way that most of the codes can be read. If your code can not be read, please use setting "Enhanced". If the code still cannot be read, use setting "Maximum". Settings "Enhanced" and "Maximum" may increase the reading time. This reset function is only for resetting the detector parameters, not for resetting of other settings outside the detector (i.e. general settings like illumination, in-outputs, serial settings etc.). After resetting the parameters, there can be made an initial teach, again
Initial teach / Additive	Teach: the region of interest is searched for codes. If a code was found the parameters are set for this code. After successful teaching, the code will be marked with a green frame. After teaching a code the code reader will search in "run"-mode only for this type of code.

teach	Once teaching was done at least one time successful, this button is named "Teach additive". "Teach additive" is for extending the parameters either in order to read several different codes in one detector or in order to cover differences in printing quality.
No-read string	Specifies the text, sent out over the interfaces in case of non successful reading.

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

Optimisation

Execution speed:

- Search zone for position (yellow frame) only as large as necessary

Robust detection:

- Search zone for position (yellow frame) sufficiently large?
- Contrasts for model and image suitably set? (for model visible in sample)
- Are thresholds set correctly?

4.6.3.11.2 2D Code detector, tab Ref. String

[2D Code detector \(Page 144\)](#)[Barcode detector. \(Page 136\)](#)

[Barcode detector, tab Quality \(Page 139\)](#)




Fig. 141: Detector 2D Code, tab Ref. String

Settings in tab Reference String

Parameters	Functions
Compare string	Activates verification of contents of the result information. The verification is done by using of regular expressions.
Ref. string	This text or regular expression is taken for verification. Here can be entered characters

	or regular expressions.
Add expression	Opens a list with examples for regular expressions
Teach ref. string	Reads the code under the code reader and takes the contents of this code as a reference string. This text can be changed later.

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

Reference string	Hit	Example for hit
123	String containing 123	01234
\A123	String beginning with 123	1234
123\Z	String ending by 123	0123
\A123\Z	String matching exactly 123	123
[123]	String containing one of the characters	33
[123]{2}	String containing sequence of the characters of length 2	23
[12][34]	String containing a character of one of both groups	4

Most important elements of regular expressions:

^ or \AMatches start of string

\$ or \ZMatches end of string (a trailing newline is allowed)

.Matches any character except newline

[...]Matches any character listed in the brackets. If the first character is a '^', this matches any character except those in the list. You can use the '-' character as in '[A-Z0-9]' to select character ranges. Other characters lose their special meaning in brackets, except '\.'

*Allows 0 or more repetitions of preceding literal or group

+Allows 1 or more repetitions

?Allows 0 or 1 repetitions

{n,m}Allows n to m repetitions

{n}Allows exactly n repetitions

|Separates alternative search expressions)

4.6.3.11.3 2D Code detector, tab Quality

[2D Code detector, tab Ref. String \(Page 146\)](#)

[2D Code detector, tab Advanced \(Page 149\)](#)




Fig. 142: Detector 2D Code, tab Quality

Settings in tab Quality

Parameters	Functions
Quality param.	<p>Quality parameters are additional information for rating the printing quality of the code. There are two different standards: AIM DPM- I-2006 and ISO/IEC 15415. Quality parameters are eight single parameters, the definition of the respective elements is as follows:</p> <ul style="list-style-type: none"> Q1 Overall quality Q2 Contrast Q3 Modulation Q4 Fixed pattern damage Q5 Decode Q6 Axial non-uniformity Q7 Grid non-uniformity Q8 Unused error correction Q9 Mean light <p>The overall quality is the minimum of all individual grades.</p> <p>The contrast is the range between the minimal and the maximal pixel intensity in the data code domain, and a strong contrast results in a good grading.</p> <p>The modulation indicates how strong the amplitudes of the data code modules are. Big amplitudes make the assignment of the modules to black or white more certain, resulting in a high modulation grade.</p> <p>The fixed pattern of both ECC200 and QR Code is of high importance for detecting and decoding the codes. Degradation or damage of the fixed pattern, or the respective quiet zones, is assessed with the fixed pattern damage quality.</p> <p>The decode quality always takes the grade 4, meaning that the code could be decoded. Naturally, codes which cannot be decoded cannot be assessed concerning print quality either.</p> <p>Originally, data codes have squared modules, i.e. the width and height of the modules are the same. Due to a potentially oblique view of the camera onto the data code or a defective fabrication of the data code itself, the width to height ratio can be distorted. This deterioration results in a degraded axial non-uniformity.</p> <p>If apart from an affine distortion the data code is subject to perspective or any other distortions too this degrades the grid non-uniformity.</p>

	<p>As data codes are redundant codes, errors in the modules or code words can be corrected. The amount of error correcting capacities which is not already used by the present data code symbol is expressed in the unused error correction quality. In a way, this grade reflects the reliability of the decoding process. Note, that even codes with an unused error correction grading of 0, which could possibly mean a false decoding result, can be decoded in a reliable way, because the implemented decoding functionality is more sophisticated and robust compared to the reference decode algorithm proposed by the standard.</p> <p>In order to achieve an evaluation according to the norm, there are defined minimum requirements for the size of the code inside the camera image (resolution) and mounting of camera and illumination. These requirements are specified inside the norm.</p> <p>Quality parameters according to AIM DPM- I-2006 are a extension to ISO/IEC 15415 Standard, which define the requirements of the grey value conditions of the image of the data code, and so improves the reproducibility of the quality evaluation of different manufacturers.</p> <p>Quality parameters according to AIM consist of one value more than quality parameters according to ISO/IEC 15415. This value is called „Mean Light“. „Mean light“ is not a quality value of the code, it shows the quality of the image by calculating the average grey value of the bright data code modules. „Mean light“ can vary from 0.0 to 1.0. A image has the required grey value conditions if the „mean light“ value is between 70% and 86% (0.70 to 0.86).</p>
<p>Quality type</p>	<p>There are existing two possibilities, to display quality parameters. Both are according to the norm. The grades can be given in values from A to F or from 4 to 0. A and 4 are the best possible grades. This setting determines how the grades should be displayed. It affects the display on screen as well as the output over the interfaces.</p> <p>The assignment is the following: A B C D F 4 3 2 1 0</p>

4.6.3.11.4 2D Code detector, tab Advanced

[2D Code detector, tab Quality \(Page 147\)](#)

[2D Code detector, tab Symbols \(Page 150\)](#)




Fig. 143: Detector 2D Code, tab Advanced

Settings in tab Advanced

Parameters	Function
Contrast min.	Minimum contrast in grey values between bright and dark parts of the code, range (1...100).
Polarity	Possible restrictions concerning the polarity of the modules, i.e., if they are printed dark on a light background or vice versa.
Slant max.	Slant of the L-shaped finder pattern in radians. This is the difference between the angle of the 'L' and the right angle.
Mirrored	Describes whether the symbol is or may be mirrored (which is equivalent to swapping the rows and columns of the symbol). The function helps, if codes should be read through transparent parts like glass.

4.6.3.11.5 2D Code detector, tab Symbols

[2D Code detector, tab Advanced \(Page 149\)](#)

[2D Code detector, tab Modules \(Page 150\)](#)




Fig. 144: Detector 2D Code, tab Symbols

Settings in tab Symbols

Parameters	Function
Symbol size	Only QR-Code: Size of symbol inside picture in pixel.
Row	Only ECC200 and PDF 417: Number of rows including finder pattern.
Column	Only ECC200 and PDF 417: Number of columns including finder pattern.

4.6.3.11.6 2D Code detector, tab Modules

[2D Code detector, tab Symbols \(Page 150\)](#)

[2D Code detector, tab Miscellaneous \(Page 151\)](#)




Fig. 145: Detector 2D Code, tab Modules

Settings in tab Modules

Parameters	Function
Module size	Size of modules in pixels.
Module width	Only PDF 417: width of modules inside picture in pixels.
Module aspect	Only PDF 417: minimum aspect of modules (rows compared to columns).
Module row gap	Only ECC200 and QR-Code: allowed gap between rows, i.e. at dot peened codes which have no full size modules.
Module column gap	Only ECC200 and QR-Code: allowed gap between columns.

4.6.3.11.7 2D Code detector, tab Miscellaneous

[2D Code detector, tab Modules \(Page 150\)](#)

[Detector OCR \(Page 152\)](#)




Fig. 146: Detector 2D Code, tab Miscellaneous

Settings in tab Miscellaneous

Parameters	Function
Version	Only QR-Code: Minimum symbol version to be read: [1 . . . 40]
Model type	Only QR-Code: Type of the QR Code model specification: 1, 2, 0
Shape	Only ECC200 and QR-Code: Possible restrictions concerning the module shape (rectangle and/or square).
Model robustness	Robustness of the decoding of data codes with very small module sizes. Setting the parameter to 'high' increases the likelihood of being able to decode data codes with very small module sizes. Additionally, in that case the minimum module size should also be adapted accordingly, thus should be set to the expected minimum module size and width, respectively.
Model grid	Only ECC200: Describes whether the size of the modules may vary (in a specific range) or not. Dependent on the parameter different algorithms are used for the calculation of the module's centre positions. If it is set to 'fixed', an equidistant grid is used. Allowing a variable module size ('variable'), the grid is aligned only to the alternating side of the finder pattern. With 'any' both approaches are tested one after the other. Please note that the value of 'module_grid' is ignored if 'finder_pattern_tolerance' is set to 'high'. In this case an equidistant grid is assumed.
Strict model	Specifies, if the code parameters have to be meet completely or not. If this parameter is set to "Yes", all codes outside the parameter range will be ignored.
Position pattern	Only QR-Code: Number of position detection patterns that have to be visible for reading a code (2 or 3).
Find pattern tolerance	Only ECC200: Tolerance of the search with respect to a disturbed or missing finder pattern. The finder pattern includes the L-shaped side as well as the opposite alternating side. In one case ('low'), it is assumed that the finder pattern is present to a high degree and shows almost no disturbances. In the other case ('high'), the finder pattern may be heavily disturbed or missing completely without influencing the recognition and the reading of the symbol. Note, however, that in this mode the run-time may significantly increase.

4.6.3.12 Detector OCR

4.6.3.12.1 Detector OCR, Procedure

To set up an OCR Detector please follow these steps. As some steps base on the results of the one which was processed before, for a correct processing the sequence of the steps must be as described.

[Detector OCR, tab Character \(flexible\) \(Page 156\)](#)




Fig. I47: Detector OCR

4.6.3.12.1.1 Basic sequence of setting parameters

- Segmentation by use of the tabs „Characters“ and „Segmentation“ as well as tab „Pre-Processing“ in step „Job“.
- Classification by use of tab „Classification“ by selection of a font and definition of a reference string.
- Removing of characters which not have been classified with sufficient quality in tab „Quality“.
- Using the OCR-Detector it is not sufficient to set the parameters with only one image. Stable reading results can only be achieved by using a large number of images. We recommend saving typically 20 to 30 images to cover all variations of the process, and optimising parameters in offline mode.

4.6.3.12.1.2 Segmentation

- Optimizing of segmentation by use of the tabs „Characters“ and „Segmentation“. Goal is to get a stable segmentation for all single characters. The result of classification "reading result" is not important in this step, this will be optimized later.
- Segmentation can be improved by use of image pre-processing in tab „Job“ – „Pre-Processing“, e.g. by use of „Gauss“, "Mean" or „Dilatation“/“Erosion“ or a combination of them. To achieve a stable segmentation it is recommended to use smoothing filters like "Gauss" or "Mean".
- Parameter „Groups of characters“ may support segmentation by specification of the number of characters per group.
- Parameter „Max. deviation from base line“ specifies, how much the vertical character position may be different from the base line of the font. Value is in percent of character height.
- Verify proper segmentation of all characters before going to step "Classification". Classification has no influence to segmentation. Faulty segmented characters will be classified wrong.

4.6.3.12.1.3 Segmentation Examples:



Fig. 148: Segmentation without any preset for parameter “Groups of characters”: All characters are found




Fig. 149: Figure 117: Segmentation with value „3“ for parameter “Groups of characters”: Only the both groups of 3 characters are found.




Fig. 150: Figure 118: Segmentation without preset for parameter “Groups of characters”: The segmentation for the first character „1“ failed, as it’s contrast to background is much lower than all others.




Fig. 151: Figure 119: Segmentation with value “3 3 2 1“ for parameter “Groups of characters”: Also the „lower contrast character“ get’s segmented.




Fig. I52: Figure I20: Segmentation with parameter “Text orientation” = „Font horizontal in image“: No characters are segmented as there are no characters with horizontal orientation in the image.




Fig. I53: Figure I21: Segmentation with parameter “Text orientation” = „Font horizontal in ROI“: Segmentation works as characters are horizontal relative to ROI (search area).




Fig. 154: Figure 122: Segmentation with value 15% for parameter: “Max deviation from base line”: Only the inner five characters are segmented.




Fig. 155: Figure 123: Segmentation with value 25% for parameter “Max deviation from base line”: All characters are segmented.

4.6.3.12.1.4 Classification

- In this step a suitable character set „font“ is selected. Each font is available with different character sets. Goal is to choose the font with the most stable results for the application.
- Naming of fonts by the example of group „Industrial“:
 - - „Industrial_0-9“: all numbers
 - - „Industrial_0-9+“: all numbers and special characters
 - - „Industrial_A-Z+“: all capital letters and special characters
 - - „Industrial_0-9A-Z“: all numbers and capital letters
 - - “Industrial.omc“: all characters
- Reference string has two functions:
 1. Manipulation of classification (of the recognized characters):
 For each segmented character a rating value (confidence), in relation to each in the whole set of characters (font) available character is calculated.
 If reference string is not used, the character with the highest rating value (confidence) is the winner. By use of reference string the "N" best alternatives will be considered (No. of alternatives). Maximum number of allowed character changes which did not have the maximum rating value (confidence) is specified in: “No. of corrections”.
 2. Manipulation of detector result:
 A minimum quality for complete string is specified (Threshold). If quality is below the threshold, detector result will be "false".

4.6.3.12.1.5 Quality

- If quality of one of the classified characters is below “Minimum confidence”, the detector result will be "false".
- Low confidence shows, that a character was not classified reliably. High confidence value however, is not a guarantee for reliable classification!

4.6.3.12.2 Detector OCR, tab Character (flexible)

[Detector OCR \(Page 152\)](#)

[Detector OCR, tab Segmentation \(Page 157\)](#)

Basic settings for characters to read.




Fig. 156: Detector OCR, tab Character

Parameters	Functions
Character height	Max. height of character in pixels.
Character width	Max. width of character in pixels.
Stroke width	Average width of lines of characters in pixels.
Polarity	Possibility to select between dark characters on bright background or vice versa.
Text orientation	„Font horizontal in Image“: text has to be horizontal in camera image. Rotated text will be not read or wrong read. „Font horizontal in ROI“: by rotation of ROI a rotation angle for reading of rotated text can be specified.
Max. number of lines	Max. number of lines to read.
Upper case only	Limitation to capital letters only.
Connect dots to characters	Connects single dots, e.g. of a dotted font or of a bad printed font for complete characters.
Overlay character size	Switch on and off overlay rectangle for size of letters.
Overlay segmentation	Switch on and off coloured overlay for segmentation of characters.

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

Optimisation:

Execution speed:

- Search zone for character (yellow frame) only as large as necessary

4.6.3.12.3 Detector OCR, tab Segmentation

Definition of basic settings of characters to read.

[Detector OCR, tab Character \(flexible\) \(Page 156\)](#)

Detector OCR, tab Classification (Page 158)



Fig. 157: Detector OCR, tab Segmentation

Parameters	Functions
Remove lines in background	This parameter can be used to remove disturbing lines in the background.
Connect fragments	Connects characters which may be divided e.g. by bad printing in two parts to one segment.
Imprinted	Enables reading of imprinted fonts e.g. if characters appear due to the illumination as white text with black outline (shadow) or vice versa.
Return Punctuation	Activates output of special characters such as full stops or comma.
Return separators	Activates output of special characters like dash.
Groups of characters	Enables possibility to specify the spacing of characters to read. E.G. if characters are always printed in two groups of four characters this can be specified by input of "4 4". This function should be used, if in several reading attempts in one and the same image, a different string length is read.
Max. deviation from base line	Maximum allowed difference of horizontal position characters on a straight line between first and last character. This function may be used if characters are not printed on a horizontal line.

4.6.3.12.4 Detector OCR, tab Classification

Definition of basic settings of characters to read.

[Detector OCR, tab Segmentation \(Page 157\)](#)

[Detector OCR, available fonts \(Page 160\)](#)

[Detector OCR, tab Quality \(Page 163\)](#)




Fig. 158: Detector OCR, tab Classification

Parameters	Functions
Font	For available fonts s. chap. Detector OCR, available fonts 0-9 => numbers only 0-9+ => numbers and special characters A-Z => only capital letters A-Z+ => capital letters and special characters No extension => all characters
Ref. String (Checkbox)	Activates verification of contents of the information read. Verification is done on base of regular expressions.
Ref. string	<p>This text or regular expression is used for verification. Here can be entered definite characters, which are compared directly, or with regular expressions to verify the structure of the result read. Characters which look very similar as number or as letter like "8" and "B" can be corrected automatically by use of regular expressions.</p> <p>In the case of the 'Reference string' the detector algorithm purely uses this as a simple check string, after it has 'segmented' and 'classified' the characters, and its only to confirm that the decoded string is as the per the 'Reference string'. and it doesn't influence the classification in any way.</p> <p>In the case of the 'Reference string' that is made up of a 'regular expression', then the 'expression' will try to use known characters to 'best fit' the expression. ie Day 3 letter (MON / TUE / WED / etc) is the segmentation and decode gives M0N rather than MON then the camera software will automatically 'correct' the (number) 0 to become a (letter) O .</p>
Add expression	Opens a list with regular expressions.
Teach ref. string	Reads the code below the Code Reader and copies the contents into Ref. string. Text can be edited afterwards.
No. of alternatives	This command controls how many 'other' near characters are to be considered ie if we are physically looking at a number '8', the near characters could be 6,9,0,B,R,D,O,S and only the closest matching 'x' number of near alternatives will be considered.
No. of corrections	This command controls how many characters with in the string can be changed when using a regular expression in the reference string ie Day 3 letter (MON / TUE / WED / etc) is the segmentation and decode gives the letters W6O rather than WED then with a setting of '2' in this field the camera software will automatically 'correct' the (number) 6 and (letter) O to become a (letter) E and D - If the setting in the field was 1 then the detector would fail.
Threshold	Threshold for good-bad decision: if number of corrections is higher than this threshold, the text will be marked as "not read" (detector result false).

Most important elements of regular expressions

Reference string	Hi	Example for hit
123	String containing 123	01234
\A123	String beginning with 123	1234
123\Z	String ending by 123	0123
\A123\Z	String matching exactly 123	123
[123]	String containing one of the characters	33
[123]{2}	String containing sequence of the characters of length 2	23
[12][34]	String containing a character of one of both groups	4

^ or \AMatches start of string

\$ or \ZMatches end of string (a trailing newline is allowed)

.Matches any character except newline

[...]Matches any character listed in the brackets. If the first character is a '^', this matches any character except those in the list. You can use the '-' character as in '[A-Z0-9]' to select character ranges. Other characters lose their special meaning in brackets, except '\.

*Allows 0 or more repetitions of preceding literal or group

+Allows 1 or more repetitions

?Allows 0 or 1 repetitions

{n,m}Allows n to m repetitions

{n}Allows exactly n repetitions

|Separates alternative search expressions)

4.6.3.12.4.1 Detector OCR, available fonts

[Detector OCR, tab Classification \(Page 158\)](#)

[Detector OCR, tab Quality \(Page 163\)](#)

Overview of fonts:

Semi

ABCDEFGHIJKLMNO
PQRSTUVWXYZ-
0123456789.

XB0225066244F5

7ICEM033MMD2

SI1658352110B3

Dot print

01.09.06 01.04.05 KA320:20
074104 07123 12040A
SK2/0311
040704

Handwritten

0123456789
0123456789
0123456789

Industrial

68-413 SN 108345 Machine Vision
97539 320 38 2 43-262
SN 100189 13 544/2 5377479

MICR

1 2 3 4 5 6 7 8 9 0
! , ' | " #


OCRA

0 1 2 3 4 5 6 7 8 9
A B C D E F G H I J K L M
N O P Q R S T U V W X Y Z
a b c d e f g h i j k l m
n o p q r t s u v w x y z
- ? ! / \ = + < > . # \$ % & () @ *

OCRB

0 1 2 3 4 5 6 7 8 9
A B C D E F G H I J K L M
N O P Q R S T U V W X Y Z
a b c d e f g h i j k l m
n o p q r t s u v w x y z
- ? ! / \ = + < > . # \$ % & () @ *

Pharma



4.6.3.12.5 Detector OCR, tab Quality

Definition of basic settings of characters to read.

[Detector OCR, tab Classification \(Page 158\)](#)

[Detector OCR \(Page 152\)](#)




Fig. 159: Detector OCR, tab Quality

Parameters	Functions
Quality	Quality of each character gets a value of 0 – 100 %. As higher the value, as higher is the confidence to the result. Small values are a sign for a bad reading quality.
Minimum confidence	If minimum confidence was not reached the character is considered to be not read and will be replaced by the replacement character.
Replacement character	Output character for the case that minimum confidence was not reached.

4.6.3.12.6 Result OCR

This function executes the job defined on the PC and the Result statistics window is displayed with Detector list and Evaluation results. Execution times are not updated in this mode, as they are not available from the sensor.

[Detector OCR, tab Quality \(Page 163\)](#)

Detailed inspection results from the detector marked in the selection list are displayed in run mode.

In the image window the search- and feature areas and the result bar graphs are displayed – if set up.




Fig. 160: Detector OCR, Result display

The parameters displayed vary according to the type of detector selected:

Parameters	Functions
String	Characters read
Confidence	Value from 0- 100%, shows how reliably a character has been read
String length	Length of string
Position X	Position X in pixels
Position Y	Position Y in pixels
Angle	Angle compared to horizontal line
Compare result	Is an indication for the quality of a result. If no characters had to be replaced according the reference string, this value is at 100%. The value decreases with rising number of corrections
Meets reference string	Indicates if string meets the reference string.
Compare result	Indicates if minimum quality was reached.
Truncated	Indicates if a part of the string was truncated.

4.6.3.13 Detector Color value

Output of average color values RGB / HSV / LAB over one of the interfaces.

[Color channel \(Page 169\)](#)

[Tab Color value \(Page 165\)](#)

4.6.3.13.1 Color channel

Selection of [Color models \(Page 207\)](#) or color channel on which the detector should work.

The display of the image depends on the image chip and the selected detector.

A image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection. By selection of single colour channels specific zones can be intensified or weakend.

- Monochrome chip: Display always black/ white
- Color chip + Color detector: Display always colored
- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel



Fig. 161: Color channel

Parameter	Function
Color model	Color model: RGB, Color model RGB (Page 207) , HSV, Color model HSV (Page 208) , LAB, Color model LAB (Page 209)
Color channel	One or more channels can be selected.

4.6.3.13.2 Tab Color value

Output of average color values RGB / HSV / LAB over one of the interfaces.

Next topic: [Detector Color area, Color select \(Page 166\)](#)

Function: [Mask \(Page 98\)](#)




Fig. 162: Color value

Parameter (Color channel dependent from setting of color model) detector	Function
Red (Hue / Lightness) I	Threshold for selected channel min. / max.
Green (Saturation / A)	Threshold for selected channel min. / max.
Blue (Value/ B)	Threshold for selected channel min. / max.
Search region	Sets search region as rectangle, as circle or as free shape. If free shape was selected, "Edit search region" gets active.
Edit search region	By edit ROI there can be masked out parts of the search area. The parts which are not relevant for this examination can be painted out like using an eraser. Masks can also be inverted, means that parts which are interesting can be

	marked.
Overlay search region	Activate overlays for free shape search regions.

Predestinated applications

- Output of calculated color parameters via one of the data interfaces for further processing.

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

4.6.3.14 Detector Color area, Color select

Determines percentage of area covered by a color or a range of colors. Depending from area there can be created a good / bad decision.

[Color channel \(Page 169\)](#)

[Detector Color area, Color select \(Page 167\)](#)

[Detector Color area, Thresholds \(Page 168\)](#)

4.6.3.14.1 Color channel

Selection of [Color models \(Page 207\)](#) or color channel on which the detector should work.

The display of the image depends on the image chip and the selected detector.

A image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection. By selection of single colour channels specific zones can be intensified or weakend.

- Monochrome chip: Display always black/ white
- Color chip + Color detector: Display always colored
- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel




Fig. 163: Color channel

Parameter	Function
Color model	Color model: RGB, Color model RGB (Page 207) , HSV, Color model HSV (Page 208) , LAB, Color model LAB (Page 209)
Color channel	One ore more channels can be selected.

4.6.3.14.2 Detector Color area, Color select

Function: [Function: Mask \(Page 98\)](#)

Determines percentage of area covered by a color or a range of colors. Depending from area there can be created a good / bad decision.




Fig. 164: Color area

Parameter (Color channel dependent from setting of color model)detector	Function
Red (Hue / Lightness) I	Threshold for selected channel min. / max.
Green (Saturation / A)	Threshold for selected channel min. / max.
Blue (Value/ B)	Threshold for selected channel min. / max.
Search region	Sets search region as rectangle, as circle or as free shape. If free shape was selected, "Edit search region" gets active.
Edit search region	By edit ROI there can be masked out parts of the search area. The parts which are not relevant for this examination can be painted out like using an erasor. Masks can also be inverted, means that parts which are interesting can be marked.
Overlay search region	Activate overlays for free shape search regions.
Overlay	Color marking of pixels inside or outside of specified color range. This is a help during setup to vizualise detector results and to set thresholds more accurate.
Color histogram	Offers possibility to enter the thresholds inside a color histogram.

Predestinated applications:

- Colored object with certain size and variable position in the ROI

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

4.6.3.14.2.1 Color histogram

Depending from selected color model there are displayed histograms for RGB, HSV or LAB. The histogram shows the distribution of colors in region of interest. By the buttons there can be switched on and off single channels. Limits for color detection can be set by moving small markings below the histogram. The selected range of colors is shown by colored areas. Crossing the limits results in inversion of the selection. If a color can be detected reliable by using only one channel, the other channels have to be set to max./min. limits to avoid disturbing influence to detection.




Fig. 165: Color histogram

4.6.3.14.3 Detector Color area, Thresholds

Determines percentage of area covered by a color or a range of colors. Setting of thresholds.

Next topic: [Detector Color list \(Page 169\)](#)



Fig. 166: Color area, thresholds

Parameter	Function
Threshold	Threshold for percentage of the area min. / max.
Object size	Min. / Max. object size (connected area)

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

4.6.3.15 Detector Color list

Compares a color with a list of known colors. Result: number or name of the color closest to a color in the list. This enables sorting of parts by color.

[Color channel \(Page 169\)](#)

[Detector Color list, Color select \(Page 169\)](#)

4.6.3.15.1 Color channel

Selection of [Color models \(Page 207\)](#) or color channel on which the detector should work.

The display of the image depends on the image chip and the selected detector.

A image, taken with a colour chip contains more information by the colour component than a monochrome image. This feature can be used with the colour channel selection. By selection of single colour channels specific zones can be intensified or weakend.

- Monochrome chip: Display always black/ white
- Color chip + Color detector: Display always colored
- Color chip + Object detector: Monochrome image, display depending on selected color model and color channel




Fig. 167: Color channel

Parameter	Function
Color model	Color model: RGB, Color model RGB (Page 207) , HSV, Color model HSV (Page 208) , LAB, Color model LAB (Page 209)
Color channel	One ore more channels can be selected.

4.6.3.15.2 Detector Color list, Color select

Next topic: [Output of inspection results \(Page 172\)](#)

Function: Mask (Page 98)

Compares a color with a list of known colors. Result: number or name of the color closest to a color in the list. This enables sorting of parts by color.




Fig. 168: Color list

Parameter	Function
Color distance	Distance of current color against taught color. The metric of the color distance depends on the the Color models (Page 207) used, only the selected color channels are considered. *1)
Name	Name of color, can be changed by doubleclick, e.g. red, green, blue...der Farbe, kann per Doppelklick auf den Namen geändert werden, z.B. Rot, Gelb, Blau
Sample color	Ouput of taught color as colored area and in numbers (RGB / HSV / LAB)
Teach	Teach color in active line, if more than one color has to be taught in one and the same image, a small ROI has to be moved to every color.
+	Add new line at end of list.
-	Delete active line.
Delete all	Delete complete list.
Up	Move marked line one line up.
Down	Move marked line one line down.
Search region	Sets search region as rectangle, as circle or as free shape. If free shape was selected, "Edit search region" gets active.
Edit search region	By edit ROI there can be masked out parts of the search area. The parts which are not relevant for this examination can be painted out like using an eraser. Masks can also be inverted, means that parts which are interesting can be marked.

Overlay search region	Activate overlays for free shape search regions.
Overlay	Color marking of pixels inside or outside of specified color range. This is a help during setup to visualize detector results and to set thresholds more accurate.
Color histogram	Offers possibility to enter the thresholds inside a color histogram.

!*) In the RGB- and LAB- color model the color distance is the euclidean distance.

In the color model LAB the distribution of colors is nearly homogenous over the entire model, that means that color distances of the same value lead to the very equal cognition of color difference over the entire model. That is why we can state that a distance of a value of ≥ 5 leads to a cognition of a different color in this color model.

Predestinated applicaitons:

- Sorting of colored object via the list index
- Simple control of homogenous colored areas (average of color value over ROI, teach, adjust small color distance (tolerance band) .. that´s it)

For newly generated detectors, all parameters are preset as standard values, suitable for many applications.

4.6.3.15.2.1 Color histogram

Depending from selected color model there are displayed histograms for RGB, HSV or LAB. The histogram shows the distribution of colors in region of interest. By the buttons there can be switched on and off single channels. Limits for color detection can by set by moving small markings below the histogram. The selected range of colors is shown by colored areas. Crossing the limits results in inversion of the selection. If a color can be detected reliable by using only one channel, the other channels have to be set to max./min. limits to avoid disturbing influence to detection.




Fig. 169: Color histogram

4.6.4 Output of inspection results

Here you define the assignment and logical connection of the digital signal outputs as well as the interfaces and output data of your SBS .

[I/O mapping \(Page 172\)](#)

[Output signals \(Digital outputs / Logic\) \(Page 178\)](#)

[Interfaces \(Page 180\)](#)

[Timing, Digital outputs \(Page 184\)](#)

[Telegram, Data output \(Page 189\)](#)

4.6.4.1 I/O mapping

Here the following settings can be made:

1. Definition, if I/O is used as an input or output (Pin 05 - 08, can be used as input or output)
2. Assignment of functionality to inputs and outputs. In the list-box there can be seen and selected all available functions for this input or output. Some functions can be assigned only to one special input or output (e.g. HW/Trigger).




Fig. 170: Output, I/O Mapping

4.6.4.1.1 Functions of inputs

Function	Description
H/W Trigger	Hardware Trigger (only on pin 03 WH available)
Encoder A+	Input for encoder, Track A+ (only on pin 10 VT available)
Encoder B+	Input for encoder, Track B+ (only on pin 05 PK available)
Enable Trigger	Enable or disable trigger signals (input needs a minimum signal length of 2ms before raising trigger signal).
Job 1 or 2	Job change between Job 1 and Job 2, depending on status of this input. Low = Job 1, High = Job 2.
Job 1 ... N	Job change by pulses on one input
Teach temporary /	Teaching of all detectors. Rising edge on this input <u>and</u> trigger start teaching.

permanent	Temporary: storage in RAM, void after reset. Permanent: storage in flash, still valid after reset.
Job switch (BitX), binary coded	Job change by binary bit pattern. Up to 5 inputs can be used to select up to 32 jobs. Bit 1 = LSB
Repeat mode enable	Images are captured and evaluated as long as: this input is on high level and none of the following stop criteria is fulfilled: - "Overall job result" = positive (access via Output/Digital output) - "Max. cycle time" is not elapsed (if active) If "Repeat mode enable" is used, this implicitly causes function "Trigger enable" at the same time. That means only if a high signal is at this input, triggers are accepted and executed. see below: Input, Repeat Mode Enable, with Trigger (Page 177)
Multishot trigger (only if Mutishot active)	Default setting if Mutishot is active, instead of above mentioned H/W Trigger
No function, undefined	no function, not used

Functions which are used already are displayed in grey, because they cannot be used any more. All inputs need a minimum signal length of 2ms.




Fig. 171: Output, Inputs

4.6.4.1.1.1 Encoder Connection

If both tracks A+ and B+ are used increasing or decreasing counting can be done / forward or backward movement of e.g. conveyor can be recognized.




Fig. 172: Encoder connection A+ / B+

4.6.4.1.2 Functions of outputs

Function	Description
Ejector	Dedicated ejector output, maximum load 100mA (all other outputs 50 mA), only on pin 12 RDBU available. (corresponds LED "A")
Result	Result output, every result output can be covered with a detector result or a logical expression.
Acknowledge job change	Can be used to get a confirmation after successful job change via digital I/O („Job I..n" or „Job Pin 'X', binary coded"). Rising edge indicates successful job change; high level is reset after 20ms. If job switch was not successful, signals remain low.
External illumination	If this setting is selected (via pin 09 RD available only), a external illumination can be connected / triggered
No function, undefined	no function, not used




Fig. 173: Outputs

There are 2 predefined outputs:

- Ready: indicates, that Sensor is ready to receive a trigger.
- Valid: indicated, that data on outputs are valid.

4.6.4.2 Functions of the programmable, digital inputs:

During operation with process control, the following cases can be carried out via the inputs:

- inactive
- enable/disable
- load Job (binary coded)
- load Job 1 ... n
- teach temporarily
- teach permanently

Description of different cases with a signal diagram.

All following signal diagrams are based on the setting "PNP".

4.6.4.2.1 Input: "Trigger enable"

For enable (high) or disable (low) of trigger input.




Fig. 174: Input timing, Trigger enable

4.6.4.2.2 Input: Job change binary or by function Job 1 or 2:

Job change binary over up to 5 inputs (Job 1- max. 31):

Possible only if Ready = high. As soon as the binary input signal change Ready is set to low.

Ready remains low until switch-over to the new job is done. If the option "Job change confirm" is used, this signal occurs after the job change, and hereafter "Ready" is set high again. During Job Change via binary inputs there must not be sent any trigger signal. The change of the logic levels of the according inputs must happen at the same time (during maximum 10ms all inputs must have a stable logic level)

Job change by function: Job 1 or 2:

Possible only if Ready = high. At the level change of the according input Ready is set low. Ready remains low till the job change is done. If the option "Job change confirm" is used, this signal occurs after the job change, and hereafter "Ready" is set high again. During Job Change over binary inputs there must not be sent any trigger signal. A high level causes evaluation according to job 2; a low level produces evaluation according to job 1.

Differences between binary switching and Job 1 or 2:

By usage of binary job switch the desired job number must be represented binary coded via the selected inputs. Therefore in this mode to switch between 2 jobs minimum 2 inputs are necessary.

In case of Job change Job 1 or 2 a high level cause's evaluation according to job 2, a low level produces evaluation according to job 1. In this way with only one input two the switching between two jobs can be done.




Fig. 175: Input timing, Job change via Binary / Job 1 or 2

4.6.4.2.3 Input: Job 1 ... n

For switching between jobs via impulses. Only possible when Ready = high. With the first impulse Ready is set to low. Impulses are counted until the first delay of $\geq 50\text{ms}$ and then switches to the appropriate job. Ready remains low until switch-over to the new job occurs. If the option "Job change confirm" is used, this signal occurs after the job change, and hereafter "Ready" is set high again. During Job Change over binary inputs there must not be sent any trigger signal. Pulse length for job change should be 5 ms pulse and 5 ms delay.

If possible job change should be made by binary coded signals like in fig. 2, this is the faster way.




Fig. 176: Input timing, Job 1 ... n

Attention!

At Job switch please take care of the following:

- All Jobs must have the same setting for job change

- All Jobs must be in triggered mode
- Ready signal must be high when trigger sequence starts

4.6.4.2.4 Input: Teach temp. / perm.

For re-teaching samples of all detectors of the current job. Only possible when Ready = high. A rising edge initiates teaching, during which a high level must exist at least until the next trigger, so that an image of an inspection part can be recorded in the correct position. Ready is set to low and remains low until teaching has been completed. Storage is either temporary (only in RAM), or permanent (in flash) according to the setting.




Fig. 177: Input timing, Teach

Attention!

The functions Job 1 or 2, Job 1 ... n or teach temp. /perm. can only be used in trigger mode

4.6.4.2.5 Input, Repeat Mode Enable, with Trigger

Images are captured and evaluated as long as, this input is on high level and none of the following stop criteria is fulfilled:

- "Overall job result" = positive (access via Output/Digital output)
- "Max. cycle time" is not elapsed (if active)

If "Repeat mode enable" is used, this implicitly causes function "Trigger enable" at the same time. That means only if a high signal is at this input, triggers are accepted and executed




Fig. 178: Input, Repeat Mode Enable, with Trigger

4.6.4.2.6 Input, Repeat Mode Enable, in Freerun




Fig. 179: Input, Repeat Mode Enable, with Trigger

4.6.4.3 Output signals (Digital outputs / Logic)

In this tab, you define the switching behaviour and logical connection of the digital outputs. Number of outputs depends from settings in tab IO mapping. Additionally an IO-extension can be connected over the serial interface.




Fig. 180: Output, tab digital output

Description of different cases with a signal diagram.

For each pin (output) there are the following possibilities:

Parameter	Function
Overall job result	No physical output, effects recorder, statistics and archiving functions
Invert	Invert total result for this pin (output)
Mode	Standard: combine several detectors by logical expressions like AND (&) / OR (!) / NOT (!) to one logical expression. Advanced: Free edit of logical expression.

NOT	Select: operator NOT (!)
Logic	Select: operator AND (&) / OR ()
DI - D...	All active detectors are shown in this list depending from number of detectors. These can be assigned to the listed output. Each detector can be set to on, off and invert.
Logical Expression	Here is shown either the logical expression that was build automatically by using of standard mode or the logical expression can be entered free by using the advanced mode.

Defining logical connection:

Define the logical connection between the inspection results of the individual detectors and the status of the selected output. You have two input possibilities:

4.6.4.3.1 Logical connection – Standard mode

In standard mode, connection of detector inspection results with the selected output must be carried out using the option buttons operator and the checkboxes in the detector selection list. The result is displayed in the logical formulas window (cannot be edited).

Connecting results:

1. Select the logical operator to be used for connecting the detectors in the selection list, from the operator window.
2. Activate the detector in the selection list which is to contribute to the result (tick in the Active column).

By activation the "Inverted" column, you can individually invert the respective detector result.

The entry in the "Result" column alters accordingly.

Examples:

The detector results can only be connected by one logical operation, e.g.:

- (D1&D2&D3) or
- !((!D1)|D2|D3) etc.

(For more complex connections, please select Formula mode)

4.6.4.3.2 Logical connection – Formula mode

In formula mode, connection of detector inspection results with the selected output is defined by the direct input of a logical formula. The operators AND, OR and NOT and round brackets are available for this purpose.

Please use the following characters for the logical operators when editing the formula:

- "&" for AND
- "|" for OR ("AltCtrl" key and "<>" key)
- "!" for NOT

Examples:

Logical expressions of any complexity can be created, e.g.:

- $(D1 \& D2) | (D3 \& D4)$
- $!((D1 | D2) \& (D3 | D4))$
- $(D1 | D2) \& (D3 | D4) \& (D5 | D6)$

etc.

4.6.4.4 Interfaces

In this tab you select and activate the digital inputs/outputs used and the interfaces for data output:




Fig. 181: Output, tab Interfaces

Parameter	Function
Internal I/O	Selection of I/O-type: PNP or NPN
RS 422 (baud rate)	RS422 for data output with choice of data transmission rate
Ext. (digital I/O)	External inputs and outputs (with I/O and encoder extension module)
Ethernet	Ethernet TCP/IP for data output. Sensor is a socket server. There are used two ports which can be defined by the user. Default is port 2006 (IN) for commands to sensor and port 2005 (OUT) for data transfer. Festo offer utilities for explanation of Ethernet communication. They are installed together with this software in utilities directory.
Ethernet/IP	Field bus Ethernet/IP for data output. Vision Sensor, EtherNet/IP, Introduction (Page 283)
Profinet	Field bus Profinet for data output, PLC communication. The Vision sensor starts the Profinet-Stack as soon as a job with Profinet is selected. Due to this the cycle time is slightly extended. Switching into a job without Profinet does not stop the Profinet- stack. To stop the stack the device must be turned off. Note: The sensor starts the Profinet stack as soon as a job with Profinet is selected. This causes a small slow down of the execution speed. Switching to another job without Profinet does not stop the stack. Only a new start / reset starts the sensor without execution of the stack. Vision Sensor, PROFINET, Introduction (Page 260)
SBSxWebViewer	Activates the webserver on the Vision Sensor. Similar like in the local installed module "Vision Sensor Visualisation Studio" now via "SBSxWebViewer" images and result data can be displayed via webbrowser.

	<p>Following browsers are supported: Microsoft Internet Explorer ab IE10, Google Chrome and Mozilla Firefox .</p> <p>To start SBSxWebViewer:</p> <ul style="list-style-type: none"> - Activate SBSxWebViewer, at Output/Interfaces/SBSxWebViewer - "Start sensor" (press button in Vision Sensor Configuration Studio) - Open Browser - Type the IP address of the sensor (see Vision Sensor Device Manager) into the address field of the browser. <p>Format: "http://Your Sensor IP", e.g.: "http://192.168.100.100" (default). See also: SBS – SBSxWebViewer (Page 181)</p>
--	---

For further informations see User manual, chapter "Communication"

Information

The outputs and interfaces can be separately activated or deactivated in the Active column.

Logical outputs:

By using the RS422, Ethernet and EtherNet/IP interface additional pure logic outputs can be defined, which just exist logically and can be communicated via one of these interfaces only.

Logical outputs can be assigned to an e.g. detector result or to a logic expression (formula).

4.6.4.4.1 SBS – SBSxWebViewer

With this software a connected sensor can be monitored, and results analysed.

From here no new settings on the sensor can be done, it´s a pure display tool to visualize images and results via a web browser.












Fig. 182: SBSxWebViewer in the Browser / Results

Functions

	<p>Switch off help window.</p>
	<p>Zoom of image. A click into the images brings back the original, smaller view.</p>
	<p>On / off of result bargraph.</p>
	<p>On / off of overlays.</p>
	<p>Store current image as a file.</p>
	<p>Switches between languages</p>
	<p>Switches between Result, Statistics and the list of Jobs available on the sensor.</p>



Commands for image control:
Possibility to "Freeze" an image. Only the image view is frozen, image capturing and execution is continued.




Fig. I83: SBSxWebViewer / Statistics




Fig. I84: SBSxWebViewer / Job

To start SBSxWebViewer:

- Activate SBSxWebViewer, at Output/Interfaces/SBSxWebViewer
- "Start sensor" (press button in Vision Sensor Configuration Studio)
- Open Browser
- Type the IP address of the sensor (see Vision Sensor Device Manager) into the address field of the browser.

Format: "http://Your Sensor IP", e.g.: "http://192.168.100.100" (default).

Note:

The following web browsers are supported: Microsoft Internet Explorer from IE10, Google Chrome and Mozilla Firefox .

With <http://192.168.100.100/zoom.html> (IP address of the sensor) a zoomed view is directly accessible.

Per one Vision Sensor only one browser connection is allowed.

4.6.4.5 Timing, Digital outputs

In this tab, you determine the time response of the selected signal output. If encoder was selected the delays are entered in encoder steps. Depending on the settings in the I/O configuration all following time delays are done in ms or in encoder steps.




Fig. 185: Output, tab Timing

Parameters	Functions
Trigger delay	Time between trigger and start of image capturing (in ms or encoder pulses). Max. time / no. of steps, is 3000 ms / encoder pulses. In case of use of: - H/W Trigger (digital input): this delay is effective. - Trigger (via Ethernet, Profinet): this delay is not effective (image is captured on trigger directly)
Digital outputs	All outputs can be delayed or only the ejector output.
Ejector / result delay	Time between trigger and appearance of result level at the signal outputs (in ms or encoder pulses). Between trigger and ejector maximum 20 parts are allowed (buffer size). Max. time / no. of steps, is 3000 ms / encoder pulses. In case of use of: - H/W Trigger (digital input): this delay is effective and starts with the trigger. - Trigger (via Ethernet, Profinet): this delay is effective, but starts only after image is processed (not with the trigger!)
Reset signal	Determines, how to reset outputs.
Duration of result	Duration of result signal in ms

Attention:

At Job Change and change from Run- to Config Mode outputs will get the following states: Buffer of delayed outputs will be deleted.

Digital outputs:

Will be reset to default at change from "Run" to "Config". Defaults are set by flag "Invert" in output tab. "Invert" inverts the default setting and also the result.

Reset of digital outputs:

The reset of the result outputs can happen depending on different settings 7 events. This are:

- "Change on result" (default).
The output changes its level according to the logical result when the next logical result is generated and valid. Typical use at controlling switch points e.g. in sorting applications.
- "Change on trigger"
The output is set to "inactive" (in operating mode PNP = low) with the next trigger. Typical use at operation with a PLC.
- "Valid duration"
The output changes back to inactive after the "Valid" duration time setting here in ms. typical use with e.g. pneumatic ejectors.

S. Vision Sensor Configuration Studio/Output/Timing/Signalling

READY AND VALID

- If Ready = high: Ready for next image / evaluation.
- If Valid = high: Results are valid at the outputs.

PNP or NPN operating mode.

All the described examples are in the operation mode „PNP“. If the setting „NPN“ is used, the examples are valid, but with inverted signal levels.

S. Vision Sensor Configuration Studio/Output/Interfaces/Internal I/O

4.6.4.5.1 The following cases for output timing are available:

4.6.4.5.1.1 Normal trigger, no delays:

Sequence: (Signalling here: Change in result)

- Rising edge at Trigger input (Pin03 WH)
- Consequence of Trigger = high: Ready = low, and Valid = low
- After the SBS has evaluated the image and the results are valid the defined outputs change to the according logical states. Ready and Valid are set to high again. (ready for next task, outputs valid)




Fig. 186: Output timing, standard sequence at normal trigger

4.6.4.5.1.2 Trigger delay active

(Trigger delay concerns hardware trigger only)

This setting is used to delay the image capturing / start of evaluation against the real physical trigger, which was e.g. caused by a light barrier or by the PLC. With this function the fine tuning of the trigger point in time can be done without any change in mechanics or PLC programming.

Sequence:

Image is taken after the trigger delay time is elapsed. The cycle time is trigger delay time + evaluation time.

s. Vision Sensor Configuration Studio/Output/Timing/Trigger/Delay

- Rising edge at Trigger input (Pin03 WH)
- Consequence of Trigger = high: Ready = low, Valid = low, all defined result outputs = low (Signalling = Change on trigger)
- Before the image for evaluation is taken, the adjusted Trigger delay time elapses.
- Now the evaluation starts. As soon as the results are valid the outputs change to the according logical levels. Ready and Valid are set to high again. (ready for next task, outputs valid)




Fig. 187: Output timing, and Trigger delay

4.6.4.5.1.3 Trigger delay + Result delay (here: Ejector only):

(Trigger delay concerns hardware trigger only)

The result delay (if for all outputs or ejector only) is used to fine tune the ejector point in time, independent from evaluation time, as especially the evaluation time can have slight variations.

Sequence:

Image is taken after the trigger delay time is elapsed. Furthermore the Result delay is active, but in this example just for the ejector output (pin 12 RDBU)

For all defined result outputs, except the ejector output the cycle time is: Trigger delay time + evaluation time.

For the ejector output the cycle time is: Result delay only! (Counted from trigger, only make sense if longer than summation of above mentioned times!) s. Vision Sensor Configuration Studio/Output/Timing/Output/Delay.

- Rising edge at Trigger input (Pin03 WH)
- Consequence of Trigger = high: Ready = low, Valid = low, all defined result outputs = low. Except Ejector, as for this a fix result delay is defined.
- Before the image for evaluation is taken, the adjusted Trigger delay time elapses.
- Now the evaluation starts. As soon as the results are valid the outputs change to the according logical levels. Ready and Valid are set to high again. (ready for next task, outputs valid)
- In this operation mode the Ejector output only is set after the Result delay is elapsed. In this example the Ejector output is also used with Result duration, therefore it's reset after the Result duration time is elapsed.




Fig. 188: Output timing, Result delay, ejector

4.6.4.5.1.4 Trigger delay + Result delay (here: all outputs):

(Trigger delay concerns hardware trigger only)

The result delay (if for all outputs or for ejector only) is used to fine tune the ejector point in time, independent from the evaluation time, as the evaluation time of the “job” can have slight variations.

Sequence:

Image is taken after the trigger delay time is elapsed. Furthermore the Result delay is active, in this example to ALL outputs.

For all defined outputs, the cycle time is: Result delay only! (Counted from trigger, only make sense if longer than summation of Trigger delay + Evaluation time) s. Vision Sensor Configuration Studio/Output/Timing/Output/Delay.

- Rising edge at Trigger input (Pin03 WH)
- Consequence of Trigger = high: Ready = low, Valid = low.
- Before the image for evaluation is taken, the adjusted Trigger delay time elapses.
- Now the evaluation starts. As soon as the results are valid, only the Ready signal is now directly set to high again (ready for next evaluation). Now the result delay time must elapse. After this has happened all defined outputs change to the according logical levels. Now also the Valid signal is reset to high level. (Valid = high: results / outputs valid. Signalling = Change on result)

In this operation mode the Ready signal only is reset to high level after Trigger delay + Evaluation time is elapsed. (Ready = high: Ready for next evaluation). This make sense as the SBS independent from the later setting of the other outputs, is now already available for the next evaluation task..




Fig. 189: Figure 142; Output timing, Result delay for all outputs.

4.6.4.5.1.5 Result duration active. (Here e.g. all outputs):

This timing setting is used to achieve a pulse at an output of defined length, for e.g. control of a pneumatic ejector in case of a bad part.

All defined result outputs are reset to low level (inactive in PNP operation) after the Result duration in ms is elapsed.




Fig. 190: Output timing, Result duration

4.6.4.5.1.6 Cycle time (Min, Max) active:

(Here: Signalling: Change on Trigger)

Parameter control for the minimum and maximum time for a job. Minimum job time blocks trigger signals which are coming in before the minimum job time was reached. (If during the Min Cycle time a further trigger is coming in it is ignored)

Maximum job time interrupts a job after a defined time. Job result after a timeout is "not o.k." Maximum job time should be selected higher than the time demand for one execution.

The Cycle time measures the time from Trigger till the setting of the outputs. If the cycle time should be limited, e.g. because of a machine cycle must not be exceeded, it should be set to an appropriate value. The result of all till this point of time not completely processed detectors is set to false. By selecting the Max. Cycle time please consider that this may not be 100% exact, as depending on the currently processed detector it's possible that there will elapse a few more milliseconds the function can be stopped. It's recommended to check this possible exceeding of the Cycle time in real operation and to decrease the value for the setting according to this offset.

Sequence:

All outputs and the signal „Valid“ (Outputs valid) are set directly after evaluation. But the signal „Ready“ (Ready for next evaluation) is set not until the Min Cycle time is elapsed. Therefore only from this point in time the next trigger will be accepted.




Fig. 191: Output timing, Cycle time

4.6.4.5.1.7 Multiple Result delay for Ejector

This mode of operation is used, if between trigger / evaluation for part A and it´s ejection is so much time / distance, that the SBS already has to check n (up to 20 parts possible) further parts which also has to be ejected later.

(Only available in mode: Vision Sensor Configuration Studio/Output/Timing/Delay: „Ejector only / Ejector- / result delay“)

Here: Signalling = Result duration (alternatively also „Change on result“)

This function is limited on 20 parts between trigger and ejector.




Fig. 192: Output timing, Multiple Result delay, ejector

Examples:

In operation with an I/O Box preferably use the timing functions of the I/O Box.

4.6.4.6 Telegram, Data output

[Serial Communication ASCII \(Page 316\)](#)

[Serial communication BINARY \(Page 338\)](#)

[EtherNet/IP Appendix \(Page 296\)](#)

Next topic: [Parameters for image transmission \(Page 193\)](#)

Configuration of data output via serial interfaces RS 422 and Ethernet as well as for archiving in .csv. files. Here all settings can be done, which result data of the SBS should be transferred via the before selected interface.




Fig. 193: Output, tab Telegram

Parameters	Functions
Binary / ASCII	Output data in Binary- (Hex) or ASCII- format.
Save to file	Exportation of file format with current results as .csv. Detailed file format of the free defined output string as .csv file with: Byte position (start position in string), Data type, Field name, Detector name, Value, Length (in Byte), Detector number and Detector type.
Reset	Reset of all parameters in this tab

Standard contents of protocol

Often required standard contents can be added to the output string by simply filling them in, or activation via the checkbox.

Start	Characters which are inserted at the beginning of the payload data sting (Binary or ASCII)
Trailer	Characters which are inserted at the end of the payload data sting (Binary or ASCII)
Separator	Characters which are inserted behind each payload value (ASCII only)
End of telegram	Characters which are sent at the end of a response to a PC or PLC (Reaction to a command, not with payload data, in ASCII mode only, output selectable in ANSI or Hexa Decimal)
Selected fields	Shows which of the following checkboxes are activated.
.... further standard content, like e.g. "Selected fields, Data length" ff.	to data string: „Payload“ Sequence: Selected fields, Data length, Status, Detector result, Digital outputs, Logical outputs, Execution time, Active job no., Checksum

Detector-specific individual results

First create a new entry by activating the "+" button.

Function of buttons

- "+": Insert new entry
- "-": Delete marked entry
- "Up", "Down": Displace marked entry

You can add detector-specific individual results to the data telegram in the required flexible order via the selection list: (adding new values via button “+”)




Fig. 194: Output, Detector specific payload

Column	Function
Active	Activates/deactivates the marked output value
Detector	Detector name (select from drop-down list)
Value	Available detector results (select from drop-down menu)
Min. length	Define the minimum length of the Value box; if the actual length is smaller than that specified, the box is filled with spaces (ASCII) or zeros (binary)
No. of results	BLOB only! Number of results of a BLOB detector which found several objects. Example: feature "area" was selected and 10 BLOBs have been found, here up to 10 of these area values can be transmitted. All available output data see: Serial Communication ASCII (Page 316) , Serial communication BINARY (Page 338) , chapter: Data Output in ASCII/Binary

4.6.4.6.1 Possibilities of data output of SBS (s. also User manual, chap. Communication)

4.6.4.6.1.1 (Ethernet-) port 2005 / RS422

Numerical data, which has been defined under Output/Telegram, now can be transferred in ASCII- or Binary- format.

Ethernet: The sensor here is the (socket-) “server” and serves the Data via a „server-socket” interface. This is basically a “programming interface”. To read or process the Data a “socket client” (PC, PLC, ...) must establish a (socket-) connection (active) to the sensor.

4.6.4.6.1.2 PC-Archiving (Vision Sensor Visualisation Studio)

Here images and numeric result data (in .csv. format) can be stored by “Vision Sensor Visualisation Studio” into a folder on the PC.

The configuration (folder, ...) of this archiving function is done via “Vision Sensor Visualisation Studio”. (Menu: File/Result archiving, this is a pure PC- function)

4.6.4.6.1.3 Sensor- archiving (ftp, smb)

With this function images and numeric result data (in .csv format) can be stored actively by the sensor via ftp/smb. This kind of archiving is configured under „Job/Archiving”, in this case:

- a) With „ftp“ used: the sensor is a „ftp client” and „writes“ the data to a „ftp server” folder on a drive which is available in the network. With Job/Start the sensor connects to the ftp-Server.
- b) With „smb“ used: the sensor „writes“ the data direct in a folder in a network. With Job/Start the sensor connects/mounts with this folder.

4.6.4.6.1.4 Ram disk (in the sensor)

In the sensor the last image as well as the numeric data of the last evaluation, which has been configured under Output/Telegram, are stored (in a .csv file) in a Ram disc- folder under. „/tmp/results/”.

This function is activated under „Job/Image transmission”. To access this data an ftp- connection must be established actively to the sensor. Therefore an ftp client is necessary.

Attention

- * The format of the .csv files is always the same (ftp, smb, ram-disk, Vision Sensor Visualisation Studio).
- * The data are stored readable (by default separated by comma) into the .csv file.
- * Only payload data which has been defined under (Output/Telegram) are transferred.

4.6.4.6.2 Communication settings

Communication	Ethernet	RS422
To Sensor, Command	Selectable in Tab: Protocol (Binary or ASCII)	
From Sensor, Data output	Selectable in Tab: Protocol (Binary or ASCII)	

Protocol settings

Parameters	Functions
Binary / ASCII	Output data in Binary- (Hex) or ASCII- format.
Save to file	Exportation of file format with current results as .csv
Reset	Reset of all parameters in this tab

Basics for establishing of a connection:

SBS is always tcp/ip (socket-) server.

SBS sensor opens always two (socket-) communication ports (default: 2005 + 2006).

- 2005 = Data port for sending of numerical results.
- 2006 = Command port for receiving of commands.

At a time only one (socket-) client (PC or PLC) can be connected to a port.

Recommendations:

Existing socket connections have only to be reconnected, if an error occurred (on ports 2005 + 2006)

(e.g.: PLC or client in stop mode or error mode, etc.). During normal operation there is no need to reconnect existing connections.

Ethernet data handling: Especially if several SBS are used Ethernet should be preferred.

Please see also installed help:

...:\Program files\Festo\SBS R3B Sensor\Utilities\Ethernet\SBS_Ethernet_communication.pdf

Commands to sensor in ASCII

4.6.4.7 Parameters for image transmission

Image transmission and/or the image recorder and the Ram disc can be activated in the Image transmission tab.

Next topic: [Parameters Archiving \(Page 195\)](#)

Set image sharpness with the focus setting screw on the back of the SBS .

The symbol “exclamation mark” inside life picture means, that image display / transfer on PC is slower than image processing on SBS . Not all images are transferred and displayed on the PC. This may cause lost images during archiving. If this symbol occurs often, PC-programs running in background should be closed in order to improve PC performance.

Parameters	Functions and setting possibilities
Vision Sensor Visualisation Studio	Transmission of images to Vision Sensor Visualisation Studio can be switch on and off (Off increases the speed of SBS). - Off: no images are transmitted to Vision Sensor Visualisation Studio - On: images are transmitted. Pre-processing filters do not effect the images. (But, if activated, Arrangement filters do effect the transmitted images!) - On (with Pre-processing): Images are transmitted, all activated Pre-processing and Arrangement filter do effect the image.
Image recorder	Storage of max. 10 images in the sensor's internal ring buffer. Setting possibilities via pop-up menu: Off, Any, Pass, Fail.
Ram disk	Storage of last image in ram memory, this image can be taken by a FTP-client. Ram disk Settings: Off, Any, Pass, Fail. The image is stored under name "image.bmp" in folder /tmp/results/. Parameters for FTP-client: user "user", password "user" Example Windows Console:

<pre> Microsoft Windows XP [Version 5.1.2600] (C) Copyright 1985-2001 Microsoft Corp. C:\>ftp 192.168.100.100 Verbindung mit 192.168.100.100 wurde hergestellt. 220 Welcome to SBS ftp-server! Benutzer (192.168.100.100:(none)): user 331 Please specify the password. Kennwort: user 230 Login successful. ftp> cd /tmp/results 250 Directory successfully changed. ftp> get image.bmp 200 PORT command successful. Consider using PASV. 150 Opening BINARY mode data connection for image.bmp (354358 bytes). 226 File send OK. FTP: 64d Bytes empfangen in 0,23Sekunden 1514,35KB/s ftp> Image is now in drive C of executing PC. If activated, results can be also received in the same way via the file "results.csv" (all defined data in "Output/Telegram", with divider ";". </pre>
--

Different types of archiving images

Access	Description	Max. number of images	Image filter	Drawings
Image recorder in SBS (Ram)	Images stored in run-mode on SBS can be transferred by Vision Sensor Configuration Studio or Vision Sensor Visualisation Studio to a PC.	10	like predefined in settings "Filter"	no
Vision Sensor Visualisation Studio archiving / Vision Sensor Configuration Studio save image	Images transferred to Vision Sensor Visualisation Studio can be stored on hard disc of PC.	unlimited (Limit is size of hard disc in PC)	like predefined in settings "Filter"	selectable yes / no
Saving of filmstrips in Vision Sensor Configuration Studio	Current images from filmstrip can be saved as filmstrip (*.flm) or as bitmap (*.bmp) on hard disc of PC.	50	without filtering	no
Last image in SBS (Ram Disk)	Last image is stored in ram disk of SBS and can be taken by FTP from directory /tamp/results.	1	without filtering	no
Archiving of images via FTP or SMB	Archiving of images via FTP or SMB	unlimited (Limit is size of hard disc)	selectable with / without filtering	no

		in PC)		
Get Image Request	Last image from SBS by using GetImage command in a program of a PLC or PC.	unlimited (Limit is size of hard disc in PC)	like predefined in settings "Filter"	no




Fig. 195: Tab Output / Image transmission

4.6.4.8 Parameters Archiving

In tab Archiving the archiving of data can be defined.

Next topic: [Preprocessing, Filter for image improvement. \(Page 61\)](#)

Parameters	Functions
Archive type	Off: no archiving, FTP: archiving to FTP server, SMB: archiving to a drive via SMB-service (Server Message Block) Attention: if archiving server is in different sub network set gateway first with Vision Sensor Device Manager.
IP Address	IP-Address of target server
Sharing name	Sharing name, specified in dialog "Advanced Sharing" in PC
Workgroup (Domainname)	Option ! , Workgoup / Domainname of server / client
User name	User name for FTP / SMB connection.
Password	Password for FTP / SMB connection.
Directory name (pass)	Directory for archiving of data of good parts (pass) (for C:\TESTPASS just enter TESTPASS)
Directory name (fail)	Directory for archiving of data of bad parts (fail) (for C:\TESTFAIL just enter TESTFAIL)
Filename	Filename for images and protocol file, this name is extended automatically by the image number (e.g. TESTFILE).
Image files	Activates archiving of images
Result files	If protocol file is active, there will be generated automatically a .csv file for each inspection (trigger). Contents of the file are specified in "Output / Telegram". Files will have increasing numbers.

Image contents	Possibility to select, whether images should be stored including the selected software filter or "raw" as taken from the camera.
Storage mode	Limit: after reaching maximum number of files transmission is stopped. Unlimited: files are stored, until target drive is full. Cyclic: after reaching maximum number of files the older files are replaced by the newer ones.
Max. number of files	Maximum number of file sets (image+protocol) which are allowed to be stored in the target directory.




Fig. 196: Tab Output / Archiving

4.6.5 Result

With this function the defined job is processed in the PC, and the “Results/statistics” window with the detector list and the evaluation results is displayed. The cycle times are not displayed in this mode as they are not available from the sensor.

In “Run” mode the results of the detector marked in the detector list are displayed. In the image window – if adjusted – the image, the search- and feature- frames, and the result- graphs are displayed




Fig. 197: Result

Param. results displayed	Detector type	Function
Result	all	Part / parameter detected (detected = green, not detected = red)
Score 1 ... n	all, exclusive of Caliper	Degree of concordance of pattern found with pattern taught
Score (1 ... n)	Caliper *1)	Score 1 / Score 2: Value of Edge strength in grey values, normalised to 100 (height of maximum in histogram). Score: smaller value of the both: Score 1 and Score 2
Execution time	all	Cycle time for an evaluation in ms
Distance	Caliper	Calculated distance
Position X 1 .. n, Position Y 1 .. n	Pattern match., Contour, Caliper	Coordinates of parameter found (centre point)
Delta X, Delta Y	Pattern match., Contour	Deviation of coordinates found in contrast to taught position / through alignment
Position check	Pattern match., Contour	Position found within the defined position frame
Angle	Pattern match., Contour	Orientation (absolute angle) of parameter found
Delta angle	Pattern match., Contour	Angle deviation between parameter taught and parameter found
Scale	Contour	Scale of contour found in contrast to taught contour.
Result index	Color list	Number in list
Color distance	Color list	Distance of measured color to taught color
Red (Color model RGB)	Color list, Color value	Mean value red
Green (Color model RGB)	Color list, Color value	Mean value green
Blue (Color model RGB)	Color list, Color value	Mean value blue
Hue (Color model HSV)	Color list, Color value	Hue value of color
Saturation (Color model HSV)	Color list, Color value	Saturation of color
Brightness (Color model HSV)	Color list, Color value	Brightness of color

Lightness (Color model LAB)	Color list, Color value	Lightness of color
A (Color model LAB)	Color list, Color value	A- value of color
B (Color model LAB)	Color list, Color value	B- value of color

The displayed parameters vary depending on the selected detector type. To see the results of another detector mark it in the detector list. In module Vision Sensor Visualisation Studio numeric results, statistics and images with or without the selected frames can be archived.

4.6.5.1 *1) Score value with result of caliper detector.

in case of Caliper- detector the result value "Score", "Score 1" and "Score 2" have the following meaning:

Score 1 / Score 2: value of Edge strength in grey values, normalised to 100 (height of maximum in histogram).

Score: smaller value of both: Score 1 or Score 2




Fig. 198: Score value Caliper detector

4.6.6 Start sensor

This function sets the sensor to run mode and executes the job.

[Image display \(Page 210\)](#)

[Result \(Page 196\)](#)

[Statistics \(Page 214\)](#)

Starting execution of a job:

Click on the "Start Sensor" button.

The active (= marked in the selection list) job is transmitted to the sensor, stored in the sensor's non-volatile memory and started (run mode).

The parameters found are shown in the display window; the inspection results from the first detector or the detector selected in the selection list are shown in the configuration window along with statistical parameters.

Changing detector display:

To display the inspection results for another detector, mark it in the selection list or click on its graphic representation in the display window.

Quitting job execution:

Click on the "Stop Sensor" button. You are now back in configuration mode and can edit your job.




Fig. 199: Start sensor

4.6.7 Further topics of Vision Sensor Configuration Studio

[Trigger settings \(Page 200\)](#)

[Switching between online and offline mode \(Page 200\)](#)

[Simulation of jobs \(offline mode\) \(Page 201\)](#)

[Creating filmstrips \(Page 201\)](#)

[Image recorder \(Page 211\)](#)

[Displays in image window \(Page 205\)](#)

[Search and parameter zones \(Page 205\)](#)

[Color models \(Page 207\)](#)

4.6.7.1 Trigger settings

Select the required trigger mode in the job settings in the "General" tab:

Parameters	Functions
Triggered	Operation with external trigger, or trigger button in the interface
Free run	Operation with automatically running self-trigger; the sensor supplies images with the maximum possible frequency

Select the form in which the images are to be supplied by the sensor using the option buttons in the zone Trigger/Collect image:

Parameters	Functions
Single image	Recording of a single image, image recording occurs once when: 1. Trigger mode = triggered: First external trigger signal or with the trigger button on the interface 2. Trigger mode = free run: First click on the "Single image" button
Continuous	Continuous supply of images, image recording occurs continuously when: 1. Trigger mode = triggered: Each external trigger or with each click on the trigger button on the interface 2. Trigger mode = free run: Continuously through internal self-triggering with maximum frequency

When exposure time, amplification, illumination or resolution parameters are modified in the Job settings, a new image is automatically requested from the sensor.

To obtain a continuously updated live image even without trigger, carry out the following (if necessary temporary) settings:

- Set to free run under "Job/General"
- Set to continuous under "Trigger / Collect image"

4.6.7.2 Switching between online and offline mode

Two operating modes are available for sensor configuration and test run, which you can select in the Connection window.

- Online mode: Configuration with connected sensor.
- Offline mode: Simulation of a sensor with the help of images stored in film strips.




Fig. 200: Connection mode

When the sensor is connected, both modes are available; it is possible to switch between the two. If no sensor is available, it is only possible to work in offline mode, i.e. with sensor simulation.

4.6.7.3 Simulation of jobs (offline mode)

You can create and test your configuration without a sensor being connected using stored film strips (= series of images). Simulation can be worthwhile to prepare a configuration or to improve a configuration carried out online.

[Displays in image window \(Page 205\)](#)

[Creating filmstrips \(Page 201\)](#)

Information:

- Several films are available in Vision Sensor Configuration Studio when delivered.
- Further methods for image acquisition: [Image recorder \(Page 211\)](#)

4.6.7.4 Creating filmstrips

In configuration mode, images from the sensor are continuously loaded into the PC's RAM. After switching from online to offline mode, max. 30 images are available and can be stored as a series of images in a filmstrip file. Alternatively or in addition to the images stored on the sensor, you can load series of archived images or individual images on your PC or an external storage medium and combine them into new films.

When you mark an image in the list, it is displayed in small format in the preview window on the right.

4.6.7.4.1 Storing images from the sensor as filmstrips:

1. First connect the PC to the sensor and fill the memory with images in free run and collect image / continuous. (Mode of connection = online)
2. Select option button "offline" in the window mode of connection.
3. Select configure filmstrips in the File menu or click on the icon filmstrips in the toolbar. The images loaded from the sensor appear in the selection list that appears below:




Fig. 201: Filmstrip

The images now can be examined; re-sorted or individual images can be deleted or added. The maximum number of images in a filmstrip is 30.

4. Click on Button "Save filmstrip" under the selection list.

All images in the list will be saved in a filmstrip file (extension .flm) in the order shown and are now available for future simulation.

4.6.7.4.2 Loading filmstrips and individual images from PC:

1. Select option button "Offline" in the window Mode of connection.
2. Select configure filmstrip in the File menu or click on the icon filmstrip in the tool bar.
3. Select a film file from the selection list and click on "Load filmstrip" button or load individual images from your PC or an external storage medium with the "Load image" button.

The loaded images are added to the selection list.

The type and memory location of the file is shown in the column source: filmstrips stored on the PC (Film), individual image stored on the PC (File), image in sensor memory (Sensor). After switching from online to offline mode all entries are Sensor.

4.6.7.4.3 Editing filmstrips:

You can create new films from the individual images in the selection list regardless of their source. The following functions are available for this purpose:

Button	Function
"<", "<<", ">", ">>"	Change order of images: The marked image is moved up/down one place or is moved to the end of the list.
Load image	Load further images from an external storage medium
Delete, Delete all	Delete image from the list/Delete all images from the list. (The images on the data carrier are not deleted here.)
Abort>	Quit the list without any modification
Import	Load all images into the film memory on the PC in the order shown. These are now available for display and analysis in offline mode.
Load / Save film strip	Load filmstrip from data carrier or save there

4.6.7.4.4 Displays in image window

4.6.7.4.4.1 Controlling image reproduction



Fig. 202: Image reproduction

You can control the selection and reproduction of stored images using the "<" (back), Start / Stop and ">" (next) buttons as well as the slide bar underneath the display window. The image counter indicates the number of the current image as well as the number of images in the active filmstrip.

4.6.7.4.4.2 Image section and enlargement:




Fig. 203: Zoom

You can select the required image section using the buttons or drop-down menu under the display window

4.6.7.4.4.3 Graphical display of results

You can active or deactivate the following graphics in the View menu:

- Bar graph result: Displays the inspection result as a bar graph
- Drawings: Displays search, parameter and position frames detectors and alignment detectors
- Focussing aid: Displays image sharpness (see also Job settings)
- Enlarged display: Insertion of a separate enlarged display window, which can be adapted to the required scale using the adjustment handles at the corners of the frame

The module Vision Sensor Visualisation Studio offers a limited selection of these functions.

4.6.7.5 Image recorder

An image recorder is available in the Vision Sensor Configuration Studio and Vision Sensor Visualisation Studio programmes. When the recorder is activated, either all images or just error images are continuously loaded into the internal memory. This covers 10 images, the oldest images are in turn replaced (FIFO buffer). The recorded images can then be called-up and displayed with a PC, or stored on a PC or on an external storage medium, and are then available for analysis or simulation purposes in offline mode.

In the Vision Sensor Visualisation Studio program, you may be required to enter a password (if activated) to call up recorder images (User user group, see user administration).

Activating recorder:

Activate the recording function in the job settings in the Vision Sensor Configuration Studio programme (tab Image transmission). You can select whether all images or only error images are to be recorded in the pop-up list of Recorder parameters.

Selecting and recording images:

Select "Get images from sensor" from the File menu or click on the button "Rec.images" (only in Vision Sensor Visualisation Studio).

A display window appears in which you can load images stored in the sensor's RAM on to the PC and then examine and save them:




Fig. 204: Image recorder

Parameter	Function
Back	Displays the previous image
Next	Displays the next image
Save	Saves the image displayed on the PC or an external storage medium
Save all	Saves all images

Information:

- The running number of the selected image and the total number of images recorded on the sensor (max. 10) are displayed in the counter under the display window.
- During storage, the images are deposited in bitmap format (extension .bmp) with a resolution of 640 x 480 pixels (VGA).
- The inspection results associated with the images (OK or error) and the date are stored in the file name (format YYYYMMDD_running no._Pass/Fail.bmp, e.g. 090225_123456_Pass.bmp).
- If you want to record detailed inspection results with the images, use the function Archive in Vision Sensor Visualisation Studio.
- If you only want to record a single image with or without overlay, you can use the function save current image in the file menu, instead of using the recorder.
- Images will get a time stamp when loading them from Vision Sensor.
- Loading images from the sensor on to the PC deletes data on the sensor. If the recorder window is closed without images having been saved, they will also be deleted from the PC.
- Images are lost from the buffer in the event of a loss of power.

4.6.7.6 Displays in image window

4.6.7.6.1 Controlling image reproduction




Fig. 205: Image reproduction

You can control the selection and reproduction of stored images using the "<" (back), Start / Stop and ">" (next) buttons as well as the slide bar underneath the display window. The image counter indicates the number of the current image as well as the number of images in the active filmstrip.

4.6.7.6.2 Image section and enlargement:




Fig. 206: Zoom

You can select the required image section using the buttons or drop-down menu under the display window

4.6.7.6.3 Graphical display of results

You can active or deactivate the following graphics in the View menu:

- Bar graph result: Displays the inspection result as a bar graph
- Drawings: Displays search, parameter and position frames detectors and alignment detectors
- Focussing aid: Displays image sharpness (see also Job settings)
- Enlarged display: Insertion of a separate enlarged display window, which can be adapted to the required scale using the adjustment handles at the corners of the frame

The module Vision Sensor Visualisation Studio offers a limited selection of these functions.

4.6.7.7 Search and parameter zones

You can define search and parameter zones in the configuration steps alignment and detectors. These are identified in the image window by different coloured frames.

Drawings in the screen (yellow, red frames etc.) can be activated or deactivated for any detector or category in the menu item "View/all drawings". With "View/drawings of current detector only", all drawings on the screen can be deactivated with the exception of the detector currently being processed.

4.6.7.7.1 Definition of search and parameter zones

When a new detector is created, a yellow frame is displayed, which defines the detector's search zone. The standard shape of the search zone is a rectangle; with contrast and grey level detectors, a circle can

also be selected. The defined parameters (red frame) are found (green frame) provided its centre is within the search zone (yellow frame).

With pattern matching and contour detection detectors, there is also a parameter zone within the search zone which is represented by a red or green frame:

- Red frame = teach parameters
- Green frame = parameters found

If position control / check is defined, a blue frame appears also (either a rectangle, circle or ellipse).

If an alignment detector is defined, it's frame is shown in dotted yellow lines.

At the according upper left corner of each frame the number of the detector is shown.

4.6.7.7.2 Adapting search and parameter zones

The zones initially displayed in standard size and position can be selected / marked in the image or in the detector list and altered in size and position. Eight adjustment handles on the frame enable you to adapt the shape and size of the frame. Its position can be displaced by clicking anywhere inside the frame. The arrow at the side of the frame pointing to the centre can be used to change the rotational position of the frame.

The taught sample is represented in original size in the General or Parameters tab in the bottom, right-hand corner of the screen. Only the frame of the currently active detector, selected in the image or detector list, is shown with thick lines and adjustment handles, all other frames which are not selected are shown with thin or dotted lines (alignment detector).




Fig. 207: Search- and feature frames

Information:

- For optimum detection, parameters must be distinct and not contain any variable parts, e.g. shadows.
- Significant contours, edges and contrast distinctions are of advantage.
- To reduce evaluation time, the search zone selected should not be unnecessarily large.

Result bar

On the right next to the search zone, the degree of concordance of the parameter searched for and found is displayed as a fixed result bar with a set threshold value:

- Green bar = The searched for parameter has been found and the pre-set threshold value of minimum concordance has been achieved.
- Red bar = The object could not be found with the required degree of concordance. The graphics displayed can be selected in the View menu.

4.6.7.8 Color models

For description of colors there are available color models.

SBS Color is able to work on different color models.

The following color models can be selected:

[Color model RGB \(Page 207\)](#)

[Color model HSV \(Page 208\)](#)

[Color model LAB \(Page 209\)](#)

Next topic: [SBS – Operating- and configuration software – Vision Sensor Configuration Studio, all functions \(Page 56\)](#)

4.6.7.8.1 Color model RGB

RGB color model is an additive color model, which describes colors by adding the components of the base color red, green and blue.

The RGB- color space is described as a linear color space, as a cube with the three axis Red, Green and Blue.




Fig. 208: Color model RGB

red, green, blue, 0-255

RGB color model is used from image capturing chip and from display to define the colors.

But image capturing chip and display have different sensitivities on each channel.

Because of this there has to be a compensation, means RGB is never the same as RGB.

Linear RGB

RGB values are calculated as linear RGB values, as the sensor chip delivers linear RGB values. Advantage of the linear RGB value is the linear relation between physical impact and RGB value.

Example: Doubling the shutter time leads to doubling of RGB values, if all other illumination conditions remain stable.

4.6.7.8.2 Color model HSV

HSV color model is the most similar to describe what the human eye sees.




Fig. 209: Color model HSV

H (hue) stands for the angle on the color circle (e. g. 0° = red, 120° = green, 240° = blue)

S (saturation) in percent (0 % = light grey, 50 % = low saturated color, 100 % = maximum saturated color)

V (value) in percent (0 % = dark, 100 % = full brightness)

4.6.7.8.3 Color model LAB

LAB or $L^*a^*b^*$ -color model is built from a three dimensional coordinate system:




Fig. 210: Color model LAB

a^* -axis describes the red and green components of a color, negative values stand for green and positive values stand for red. Range of values from -150 to +100.

b^* -axis describes the blue and yellow components of a color, negative values stand for blue and positive values stand for yellow. Range of values from -100 to +150.

L^* -axis describes the lightness of the color with values from 0 to 100.

One of the most important properties of the $L^*a^*b^*$ color model is the independency from the technology used for capturing and displaying the images.

LAB values are calculated from linear RGB values. This is based in a D65 illuminant and a 2° observer.

4.6.7.9 Application Examples

In Menu "File" "Examples" predefined examples can be loaded.

A filmstrip is loaded together with a job-file.

4.7 SBS – Operating- and configuration software – Vision Sensor Visualisation Studio, all functions

This program enables the monitoring of the image from the camera and the inspection results.

[Image display \(Page 210\)](#)

[Result \(Page 215\)](#)

[Statistics \(Page 214\)](#)

[Changing active job \(Page 216\)](#)

[Upload \(Page 217\)](#)

[Commands / Freeze image \(Page 211\)](#)

[Image recorder \(Page 211\)](#)

[Archiving test results and images \(Page 213\)](#)

From this software ONLY monitoring and job change (loading of already defined jobs) can be done. It can be password protected so that you can only view (worker level), or view and load predefined jobs (SuperSBS level)

4.7.1 Image display

The graphical display of an image and the inspection results in the display window depend on the setting of the parameter in tab "Image transmission" in job settings ("Parameters for image transmission" in Vision Sensor Configuration Studio) program:

- Image transmission active: The current image along with the frames for the defined search, parameter and position zones and parameters found are displayed.
- Image transmission inactive: Only the frames for the defined search, parameter and position zones and parameters found are displayed (current image is not displayed).

The degree of concordance between the parameter searched for and the parameter found appears to the right next to the search zone of the respective detector, in the form of a vertical result bar with a set threshold value:

- Green bar: The parameter searched for has been found and the pre-set threshold value for concordance has been reached.
- Red bar: The object could not be found with the required degree of concordance.

An exclamation mark in the top right hand corner of the live picture means, that image processing on PC is slower than image processing on SBS

. i.e. Not all images are transferred to PC.

This may cause lost images in images archiving. If this symbol occurs often, PC-programs running in background should be closed in order to improve PC performance.

You can configure the graphics of the inspection results in the View menu.




Fig. 21 I: Vision Sensor Visualisation Studio

Except the archiving all functions of Vision Sensor Visualisation Studio are available also in the module Vision Sensor Configuration Studio.

4.7.2 Commands / Freeze image

With the "Freeze image" button, you can request single images according to the type required (current image, next image, next failed image) and freeze them in the display window.

The required single image is displayed and the image counter stops at the corresponding image number.

Press "Continue" to end the frozen image state.

4.7.2.1 Zoom

With the button "Zoom" the image is opened in a new window with enlarged display.

4.7.3 Image recorder

An image recorder is available in the Vision Sensor Configuration Studio and Vision Sensor Visualisation Studio programmes. When the recorder is activated, either all images or just error images are continuously loaded into the internal memory. This covers 10 images, the oldest images are in turn replaced (FIFO buffer). The recorded images can then be called-up and displayed with a PC, or stored on a PC or on an external storage medium, and are then available for analysis or simulation purposes in offline mode.

In the Vision Sensor Visualisation Studio program, you may be required to enter a password (if activated) to call up recorder images (User user group, see user administration).

Activating recorder:

Activate the recording function in the job settings in the Vision Sensor Configuration Studio programme (tab Image transmission). You can select whether all images or only error images are to be recorded in the pop-up list of Recorder parameters.

Selecting and recording images:

Select "Get images from sensor" from the File menu or click on the button "Rec.images" (only in Vision Sensor Visualisation Studio).

A display window appears in which you can load images stored in the sensor's RAM on to the PC and then examine and save them:




Fig. 212: Image recorder

Parameter	Function
Back	Displays the previous image
Next	Displays the next image
Save	Saves the image displayed on the PC or an external storage medium
Save all	Saves all images

Information:

- The running number of the selected image and the total number of images recorded on the sensor (max. 10) are displayed in the counter under the display window.
- During storage, the images are deposited in bitmap format (extension .bmp) with a resolution of 640 x 480 pixels (VGA).

- The inspection results associated with the images (OK or error) and the date are stored in the file name (format YYYYMMDD_running no._Pass/Fail.bmp, e.g. 090225_123456_Pass.bmp).
- If you want to record detailed inspection results with the images, use the function Archive in Vision Sensor Visualisation Studio.
- If you only want to record a single image with or without overlay, you can use the function save current image in the file menu, instead of using the recorder.
- Images will get a time stamp when loading them from Vision Sensor.
- Loading images from the sensor on to the PC deletes data on the sensor. If the recorder window is closed without images having been saved, they will also be deleted from the PC.
- Images are lost from the buffer in the event of a loss of power.

4.7.4 Archiving test results and images

You can archive images with and without graphics, and inspection results on to your PC or an external storage medium for analysis or simulation purposes (see Offline mode).

Access to this function may require password entry (User user group, see user administration).

Configuring archiving:

1. Select Configure archiving ... from the File menu.
A dialogue box appears with the following options:




Fig. 213: Archiving configuration

Parameter	Function
Path for archiving	Directory in which archived file(s) are stored.
Settings, Automatic Start	Starts archiving automatically after start of Vision Sensor Visualisation Studio.
Settings, Archive image circularly	Activates cyclic overwriting of oldest images if limitation of storage is reached.
Settings, Limitation (max.)	In this drop-down menu it is possible to specify which images (all images or only good or bad images) are to be stored.
Type of images	Specifies, whether all, good or bad pictures have to be stored.
Graphics, Bar graph result	Choice of graphics to be archived in the image.
Numerical results	If "record with" is activated, numerical result data such as coordinate values etc. are archived in an additional .csv file. Setting "Legacy" / "Configured" determines the format of storage (.csv). With "Legacy" *1) the content is predefined, with "Configured" the content can be defined in "Output/Telegram". *1) The storage mode "Legacy" is obsolete and only provided for reasons of backward compatibility. It will be omitted with one of the next versions.

2. Select the required options and confirm your choice with OK.

Start/end archiving:

Click on the button "Archive images" in the "Commands" filed to start or end the archiving function with the above mentioned settings. The name of the image file currently to be stored appears in the status bar. Archiving is carried out for as long as the button "Archive images" is pressed.

4.7.5 Statistics

Statistical data from the inspection process is displayed in the Statistics tab in run mode. The statistical data displayed is identical for all types of detectors:

Parameter	Function
All evaluations	Total number of inspections
Good parts	Number of inspections with result "OK"

Bad parts	Number of inspections with result "Error"
Min./max./mean execution time	Min./max./mean execution time for evaluation in ms

All statistic values can be reset to zero with the "Reset" button.

You can archive inspection results and statistical evaluations including selected graphics in the Vision Sensor Visualisation Studio program.

4.7.6 Result

This function executes the job defined on the PC and the Result statistics window is displayed with Detector list and Evaluation results. Execution times are not updated in this mode, as they are not available from the sensor.

Detailed inspection results from the detector marked in the selection list are displayed in run mode.

The image, search and parameter zones and result graphs appear – when set – in the display window.

The parameters displayed vary according to the type of detector selected:




Fig. 214: Vision Sensor Visualisation Studio, Result

Param. results displayed	Detector type	Function
Result	all	Part / parameter detected (detected = green, not detected = red)
Score 1 .. n	all	Degree of concordance of pattern found with pattern taught
Distance	Caliper	Calculated distance
Execution time	all	Cycle time for an evaluation in ms
Position X 1 .. n, Position Y 1 .. n	Pattern match., Contour. Caliper	Coordinates of parameter found (centre point)
Delta X, Delta Y	Pattern match., Contour	Deviation of coordinates found in contrast to taught position / through alignment
Position check	Pattern match., Contour	Position found within the defined position frame
Angle	Pattern match., Contour	Orientation (absolute angle) of parameter found

Delta angle	Pattern match., Contour	Angle deviation between parameter taught and parameter found
Scale	Contour	Scale of contour found in contrast to taught contour.
Result index	Color list	Number in list
Color distance	Color list	Distance of measured color to taught color
Red (Color model RGB)	Color list, Color value	Mean value red
Green (Color model RGB)	Color list, Color value	Mean value green
Blue (Color model RGB)	Color list, Color value	Mean value blue
Hue (Color model HSV)	Color list, Color value	Hue value of color
Saturation (Color model HSV)	Color list, Color value	Saturation of color
Brightness (Color model HSV)	Color list, Color value	Brightness of color
Lightness (Color model LAB)	Color list, Color value	Lightness of color
A (Color model LAB)	Color list, Color value	A- value of color
B (Color model LAB)	Color list, Color value	B- value of color

To show inspection results for another detector, mark it in the selection list.

You can archive inspection results and statistics including selected graphics in Vision Sensor Visualisation Studio.

4.7.7 Changing active job

In the Job tab, the jobs available on the sensor are displayed in the selection list. Here you can switch between different jobs stored on the sensor.

The use of functions which stop an active sensor may require password entry (User group user, see user administration).

Password levels




Fig. 215: Password levels




Fig. 216: Vision Sensor Visualisation Studio, Job select

Select a job from the list and activate it with the "Activated" button.

The previous job is deactivated; the selected job is now active.

Attention:

At Job Change and change from Run- to Config Mode outputs will get the following states:

- Buffer of delayed outputs will be deleted.
- Digital outputs: will be reset to default at change from "Run" to "Config". Defaults are set by flag "Invert" in output tab. "Invert" inverts the default setting and also the result.
- Ready and Valid: Ready and Valid show at Job change and at change of operation mode from Run to Config, that the SBS is not ready and that results are not valid. (Low level)

4.7.8 Upload

You can load new jobs or entire job sets from the PC to the sensor memory in the Upload tab. The available jobs and job sets are displayed in the selection list.

Jobs and job sets can be created in the Vision Sensor Configuration Studio program and stored there under File / Save Job / Save Jobset as




Fig. 217: Vision Sensor Visualisation Studio, Job set upload

Information:

- A job set consists of one or several jobs which are simultaneously stored in the sensor or on the hard disk.
- Use of functions which can stop the active sensor may require password entry (User user group, see user administration).
- Select a job or job set from the list and load it on to the sensor with the "Upload" button.
- This action deletes all jobs previously stored on the sensor!

5 Communication

5.1 Possibilities of image- / data transfer and archiving

The SBS is able to communicate and exchange data via different communication channels with a PLC, I/O extension or a PC. It's possible to send data on request or cyclical from the SBS to a PLC/PC. But the PLC/PC can also actively communicate with the SBS, for e.g. only on demand / request to get result- or settings- data or to do a job switch.

The physically available communication interfaces are:

- Ethernet
- RS422

Via Ethernet also the fieldbus interface Ethernet/IP is supported. Via RS422 and the according interface converter the fieldbus Profibus is supported.

A complete overview about all available telegrams you find in chapter [Serial Communication ASCII \(Page 316\) ff.](#)

In the following pages the function and the according settings how to use the different possibilities to communicate with a SBS is illustrated in a few examples.

The following examples show how to work on the PC end with a Serial- and Ethernet- software- tool. Here the tool "Hercules" is used. This tool and the settings made here are examples for your PC- or PLC application, and all settings necessary you can see in these examples. If you also like to use the tool [Hercules SETUP utility](#) - produced by www.HWV-group.com, you can download as freeware.

5.1.1 Ethernet, Port 2005 / 2006

Numerical data, which has been defined under Output/Telegram, now can be transferred in ASCII- or Binary- format.

The sensor here is the (socket-) "server" and serves the Data via a „server-socket" interface. This is basically a "programming interface". To read or process the Data a "socket client" (PC, PLC, ...) must establish a (socket-) connection (active) to the sensor.

Handling, settings

5.1.1.1 Ethernet example I: Pure data output from SBS to PC / PLC

Step I:

After the job with all necessary detectors, if so alignment is set up, here the Ethernet interface get's activated and if necessary it's parameter are set also.




Fig. 218: Data output, Ethernet

In the example the Ethernet interface in the parameter field at the bottom in tab “interfaces” is activated by marking the checkbox. The default settings for input port (IN) = 2006 and output port (OUT) = 2005 remain as they are in this example. Of course here any other settings can be chosen to do a setup which fit to your network environment. If necessary please contact your network administrator.

Step 2:

In tab „Telegram“ the payload which should be transferred via Ethernet port 2005 are set up.

In this example it is:

- Start: „010“
- Overall result of detector I
- Trailer: „xxx“
- As format „ASCII“ is defined, that makes traceability easier. The function with other payload data or in binary format works analogue to this example and to the here made settings.




Fig. 219: Data output, configuration of output data

Step 3:

After starting the Ethernet tool „Hercules“ the tab „TCP-Client“ must be selected to communicate via Ethernet with the socket- server SBS .




Fig. 220: Data output, Ethernet tool / I

Here the IP address of the des SBS and the correct port number must be set up to receive data.

The IP address of the SBS you find in Vision Sensor Device Manager. Please look at the first line in the window „Active Sensors“ = 192.168.60.199




Fig. 221: Vision Sensor Device Manager, IP address ...

The port number for the output port was taken over from Step I with port 2005.

Step 4:

Therefore the following settings are made in Hercules: Module IP = 192.168.60.199, Port = 2005.

The rest of all settings remain on default. With a click to the button „Connect“ the connection to the SBS is established and shown in the main window in green letters.




Fig. 222: Figure 168 Data output, Ethernet Tool / 2

Step 5:

The SBSnow needs to be started from the PC application with „Start sensor“. (Later in autonomous operation the SBS directly starts after power on, and sends data, if configured this way).

In the example Trigger mode is “Continuous”, that means evaluation is done continuously and data is sent continuously too. All this data is visible in the main window of Hercules.



Fig. 223: Data output, Ethernet, Start sensor




Fig. 224: Data output, Ethernet, Tool / 3

Then here visible data are displayed (as set up in „Output“):

- Start: „010“
- Overall result of detector I („P“ for positive, as result of detector Brightness is = “Pass”)

- Trailer: „,xxx“

5.1.1.2 Ethernet example 2: commands (requests) from PC / PLC to SBS

With response / data output from SBS

Step 1

For better traceability in this example the triggered mode is used. That can be done as follows: Adjust Job/Image acquisition/Trigger mode = Trigger. All other settings remain the same like in example 1.




Fig. 225: Data output, Ethernet, Trigger

Step 2

To send commands / requests to the SBS , a second instance of Hercules is started. This time with Port 2006 as input port of the SBS , where it can receive commands. All telegrams (commands and response strings) to and from the SBS you find in chap. [Serial Communication ASCII](#) ff...




Fig. 226: Data output, Ethernet Tool / 4

In the window to the right the command “TRG” (for Trigger, command s. below, first line) was sent to the SBS , by a click to the according button “Send”. This command is shown as soon as it’s sent in the main window in red letters.

The SBS responds via port 2006 as a acknowledge to the command with „TRG“, and in this case with „P“ for a positive result for detector I, both in black letters, also in the right Hercules window.

In the left window the SBS sends via the output port 2005 the Output defined values „010Pxxx“, like in example Ethernet I. (Right window)




Fig. 227: Data output, Ethernet Tool / 5

In the example the command GIM0 (GetImage0) was sent to the SBS . It responds with the binary image data which are shown in the right window. That means, the data output of the manually under „Output“ defined payload data happened via port 2005. But the response to the request „GIM0“ was transferred via port 2006. This rule is valid for all payload- or response data.

Attention: to use the command GIMx the image recorder must be switched on.

5.1.1.2.1 Ethernet example 2.1 command job switch from PC/PLC to SBS With response / data output from SBS

Step 1

For better traceability in this example the triggered mode and ASCII format is used. That can be done as follows: Adjust Job/Image acquisition/Trigger mode = Trigger. All other settings remain the same like in example 1.

For this example Job 1 was set up with the below visible data output:

- Start: „010“
- Trailer: „xxx“




Fig. 228: Data output, Ethernet, Job switch Job 1

Job2 was set up with detector 1 and data output:

- Start: „020“
- Overall result of detector 1
- Trailer: „yyy“




Fig. 229: Data output, Ethernet, Job switch, Job 2

Step 2

Here the application Hercules is started two times again. First with port 2005 (to receive results like defined under „Output“) and port 2006 (commands and response), as the input port of the SBS to receive commands.

All telegrams (commands and response strings) to and from SBS you find in chap. [Serial Communication ASCII ff.](#)




Fig. 230: Data output, Ethernet, Job switch, tool / 1

In the window to the right (port 2006) the command TRG (Trigger, s. below, first line “Send”) was sent. This is displayed in the main window in red letters “TRG”. The SBS responds with the acknowledge „TRGP“ (repetition of the command „TRG“ and „P“ for positive)

In the window to the left (port 2005) the SBS, where currently Job2 is active, sends the according result string which was defined under “Output” in Job 2 with „020Pyyy“.




Fig. 231: Data output, Ethernet, Job switch, tool / 2

Now in the right window (port 2006) the command CJB001 (ChangeJob 001, 001 = Job Nr. 1, s. below, second line „Send“) was sent. This is displayed in the main window in red letters “CJB001“. The SBS responds with the acknowledge „CJBPT001“ (repetition of command „CJB“, „P“ for positive, „T“ = Triggered, “001” Job number to which was switched)




Fig. 232: Data output, Ethernet, Job switch, tool / 3

After the next Trigger command TRG (s. below third line „Send“) the command „TRG“ is displayed again in the main window in red letters. The SBS responds with „TRGP“ (repetition of command „TRG“ and „P“ for positive)

In the window left (port2005) the SBS, after switching to Job I!, now the according result sting which was defined under Output in Job I with „010xxx“!

Function of the both Ethernet- ports for in- and output:

*A: Port 2005, only one direction: Sensor >> PC, all payload data, defined in „Output“

*B: Port 2006, both directions: Sensor <> PC, commands / requests to the SBS, with acknowledge, + all response data to the request (no payload data !)




Fig. 233: Ethernet- ports

5.1.2 RS422

Numerical data that has been defined under Output/Telegram, now can be transferred in ASCII- or Binary- format.

Ethernet: The sensor here is the (socket-)“server” and serves the Data via a „server-socket” interface. This is basically a “program interface”. To read or process the Data a “socket client” (PC, PLC,) must establish a (socket-) connection (active) to the sensor.

Handling, settings

5.1.2.1 RS422 example I: Data output from SBS to PC / PLC, and commands (requests) to the SBS

With response / Data output from SBS

Step 1:

After the job with all necessary detectors, if so alignment is set up, here the RS422 interface get's activated and if necessary it's parameter are set also.




Fig. 234: Data output RS422

In the example the RS422 interface in the parameter area at the bottom in tab "Interfaces" get's activated by marking the checkbox.

The default settings for Baud rate = 19200 and Logical outputs = 0 remain as they are. Here of course any other settings can be done which must have its corresponding setting at the other side (at the PC or PLC, whatever used)

Step 2:

In tab „Output“ the payload data which shall be transferred via RS422 are defined.

In this example this is:

- Start: „010“
- Overall result of detector I
- Trailer: „xxx“
- As format „ASCII“ is defined, that makes traceability easier. The function with other payload data or in binary format works analogue to this example and to the here made settings.



Fig. 235: Data output RS422, configuration of output data

Step 3:

The SBSnow needs to be started from the PC application with „Start sensor“. (Later in autonomous operation the SBS directly starts after power on, and sends data, if configured this way).

In the example Trigger mode is continuous, that means evaluation is done continuously and data is sent continuously too. All this data is visible in the main window of Hercules.



Fig. 236: Start sensor

Step 4:

After start of Serial- tool Hercules, tab „Serial“ must be selected to communicate via RS422 with the socket server SBS .




Fig. 237: Data output, RS422 tool / I

Now the corresponding settings for baud rate like in SBS must be done. Also the correct serial port COMx must be set up her to receive data.

The baud rate you see in tab Output/Interfaces. The number of the serial COM port (COM x of the PC) you find out in Windows at: Start/Control Panel/Performance and Maintenance/System/Hardware/Device Manager, at Universal Serial Bus Controllers. (Here COM5).

The rest of the settings at the right are the default values of Hercules. „DTR“ and „RTS“ must be activated. With a click to the button „Connect“ the connection to the SBS is established and shown in the main window in green letters.




Fig. 238: Data output, RS422 COMx

Step 5:

With a click to button „Send“ the command „TRG“ is sent to the SBS . It responds with „,TRG“, followed by „,P“ for positive and the payload data „,010Pxxx“.




Fig. 239: Data output, RS422, tool / 2

Step 6:

In the following example the command „SST041000“ (SetShutterTemporary, 04 = number of letters of shutter value, 1000 = shutter value in microseconds) is sent and the SBS responds with SSTP (SetShutterTemporary, P = positive). All available telegrams you find in chap. [Serial Communication ASCII](#) ff. and are used in analogue way.




Fig. 240: Data output, RS422, tool / 3

5.1.2.1.1 RS422 example 1.1: command Job switch from PC / PLC to SBS

With response / data outputs from SBS

Step 1

Here the same setting for Job and Output are used as in „Ethernet Example 2.1“.

For better traceability in this example the triggered mode and ASCII format is used. That can be done as follows: Adjust Job/Image acquisition/Trigger mode = Trigger. All other settings remain the same like in example 1. In Output/Interfaces here the interface RS422 was activated.

For this example Job 1 was set up with the below visible data output:

- Start: „010“
- Trailer: „,xxx“




Fig. 241: Data output, RS422, Job switch, Job 1

Job2 was set up with detector 1 and data output:

- Start: „020“
- Overall result of detector 1
- Trailer: „yyy“




Fig. 242: Data output, RS422, Job switch, Job 2

Step 2

After start of Serial- tool Hercules, tab „Serial“ must be selected to communicate via RS422 with the socket server SBS .

Now the corresponding settings for baud rate like in SBS must be done. Also the correct serial port COMx must be set up here to receive data.

The baud rate you see in tab Output/Interfaces. The number of the serial COM port (COM x of the PC) you find out in Windows at: Start/Control Panel/Performance and Maintenance/System/Hardware/Device Manager, at Universal Serial Bus Controllers. (Here COM5).

The rest of the settings at the right are the default values of Hercules. „DTR“ and „RTS“ must be activated. With a click to the button „Connect“ the connection to the SBS is established and shown in the main window in green letters.

Step 3

With the command „TRG“ (Trigger, s. below, line 1, „Send“) an image acquisition and an evaluation was initiated. The SBS immediately responds with „TRGP“ („P“ for positive). Also, as in this moment Job 1 is active, the result data string „010xxx“ is sent.




Fig. 243: Data output, RS422, Job switch tool / I

Step 4

With the command „CJB002“ (ChangeJob, Job Nr. 002, s. below line2, “Send“) the SBS now switches to Job 2.

The response: „CJBPT002“ (repetition of command „CJB“, „P“ for positive, „T“ = Triggered, 002 Job number switched to) is sent and displayed in main window.




Fig. 244: Data output, RS422, Job switch tool / 2

Step 5

After the next Trigger command TRG (s. below line 1, „Send“) the command “TRG” the next evaluation is performed and the response „TRGP“ (repetition of command „TRG“ and „P“ for positive) is sent. Also, as now Job 2 is active, the result string „020Pyyy“ like in Job 2 defined is transmitted.




Fig. 245: Data output, RS422, Job switch tool / 3

5.1.2.2 Settings to connect the „I/O-Box“ for I/O- extension or ejector control to the SBS

To operate the I/O-Box with the SBS the following settings in Output/ Interfaces/External I/O extension must be done.

Setting I: 8Inputs_32Outputs

Enable: Mark checkbox in column „Enable“




Fig. 246: Data output, connection of I/O Box

5.1.3 PC- Archiving (Vision Sensor Visualisation Studio)

Via Vision Sensor Visualisation Studio images and numerical data (in .csv format) can be stored into a folder on the PC.

The setup (folder ...) is done via Vision Sensor Visualisation Studio in menu "File/Archiving". This function is available on PC only.

Step I:

Start Vision Sensor Visualisation Studio from Vision Sensor Device Manager, Click to button „View“




Fig. 247: Vision Sensor Device Manager

Vision Sensor Visualisation Studio is started

The conditions for a correct image display are the settings:

- Free run (set in Job/Image acquisition) or
- At least one trigger happened
- Image transmission active (set in Job/Image transmission)

Step 2

Select in menu: File/Archiving




Fig. 248: Vision Sensor Visualisation Studio, Archiving

Now the following dialog box occurs to set up parameter for archiving.

Parameter	Function
Path for archiving	Directory in which archived file(s) are stored.
Settings, Automatic Start	Starts archiving automatically after start of Vision Sensor Visualisation Studio.
Settings, Archive image circularly	Activates cyclic overwriting of oldest images if limitation of storage is reached.
Settings, Limitation (max.)	In this drop-down menu it is possible to specify which images (all images or only good or bad images) are to be stored.

Type of images	Specifies, whether all, good or bad pictures have to be stored.
Graphics, Bar graph result	Choice of graphics to be archived in the image.
Numerical results	The storage mode determines the format of the .csv file. "Legacy" means the contents of the .csv file is predefined, "Configured" means the file is freely configurable via "Output / Telegram"

Select the required options and confirm your choice with OK.

5.1.3.1 Start/end archiving:

Click on the button "Archive images" in the "Commands" filed to start or end the archiving function with the above mentioned settings. The name of the image file currently to be stored appears in the status bar. Archiving is carried out for as long as the button "Archive images" is pressed.




Fig. 249: Vision Sensor Visualisation Studio, Archiving configuration

5.1.4 Archiving via ftp or smb

With this function images and numeric result data (in .csv format) can be stored actively by the sensor via ftp/smb. This kind of archiving is configured under „Job/Archiving“, in this case:

- With „ftp“ used:** the sensor is a „ftp client" and „writes“ the data to a „ftp server" folder on a drive which is available in the network. With Job/Start the sensor connects to the ftp-Server.
- With „smb“ used:** the sensor „writes“ the data direct in a folder in a network. With Job/Start the sensor connects/mounts with this folder.

With this kind of data archiving in normal operation case no PC application like Vision Sensor Device Manager or Vision Sensor Configuration Studio is running, just a accordingly configured ftp- or smb-server.

5.1.4.1 Example: Archiving via ftp

In this example with the ftp- server freeware „Quick ´n Easy FTP Server“ a ftp communication was established and image- and result data are stored on the hard disc of the PC.

In the ftp server with the account wizard a user account with the name „SBS_ FTP" was created. A password and a path for data storage have been specified, and upload and download are activated.




Fig. 250: FTP Server

In Vision Sensor Configuration Studio now at: Job/Archiving the according settings for the ftp server on the SBS must be done. This are:

- Archive type = FTP
- IP address = IP of the PC where the ftp server is running (IP address of PC connected you find in status line in Vision Sensor Device Manager in the corner left, below)
- User name = Name of the user account in the ftp server
- Password = in the ftp account used Password (option)

With this the for ftp communication according settings are done.

Also other settings like: Filename, Max. number of files, Storage mode can be made here




Fig. 251: FTP Server, settings in Vision Sensor Configuration Studio

As soon as this settings are done and transferred to the SBS (with „Start Sensor“), the image and result data are transferred and stored into the specified folder on the PC, without any of the applications Vision Sensor Device Manager, Vision Sensor Configuration Studio or Vision Sensor Visualisation Studio active.




Fig. 252: Transferring files with FTP.

The function via smb works analogue via a smb server, which must be set up in the according kind.

5.1.4.2 Example: Archiving via smb

To archive data and / or images via SMB (Server message block), at the end of the PC a folder must be shared.

The following example shows the settings for archiving data via SMB exemplarily.

5.1.4.2.1 Settings for SMB on PC: Create folder and share it




Fig. 253: Create folder to write data and / or images.

Via right-click to the folder (here „Test_SMB“), select „properties“.

In the following dialog „Test_SMB Properties“ select tab „Sharing“ and open “Advanced Sharing”.




Fig. 254: Sharing of folder > Advanced sharing.

In the dialog „Advanced Sharing“ activate „Share this folder“. As “Share name” the name of the folder “Test_SMB” is suggested. Here any other name can be set. In this example the suggested folder name is used.

Important: This “Share name” must be set later in the SBS- SMB- Interface!

With a click to „Permissions“ the following dialog appears.




Fig. 255: Set Share name.

In the window „Permissions for Test_SMB”,

either

Select user group “Everyone”. With this choice everybody in the network has free access to the folder without any further login, and in the SBS- SMB – interface the fields: “User name” and “Password” remain empty.

or:

select a user (here „fsc“), (for which user name and password is known). User name and password are necessary later to be set in the SBS- SMB- Interface.

Activate „Full control“,

and close the dialog with „Apply“ and „OK“.




Fig. 256: Set permissions.

Now close the dialog „Advanced Sharing“ and „Test_SMB Properties“ with „Apply“ and „OK“ also.

The access for the here selected user to the selected folder on the PC now is set, and now the corresponding settings in the SBS- Interface „Vision Sensor Configuration Studio“ can be made.

5.1.4.2.2 Settings SMB SBS




Fig. 257: Settings in SBS- SMB- Interface

After starting Vision Sensor Configuration Studio, select Job/Archiving/Archive type: „SMB”.

Do the following settings

- IP address: IP address of PC (this can be found with command „ipconfig“ via Start/run/cmd, s. following screenshot). In this example: 192.168.60.14




Fig. 258: IP- Adresse des PC via Start/Ausführen/cmd/ipconfig

- Share name: Here enter Share name like set in PC- dialog „Advanced Sharing“, Fig.3.
- Workgroup: Option! Name of workgroup.
- User name and Password: Depending on the selection made in dialog „Test_SMB Permissions“:
 1. User group „Everyone“: User name and Password remain empty
 2. Enter corresponding User name and (here in example User name: „fsc“)
- Directory name (Pass), Directory name (Fail): Chose a name for the folders in which in case of Pass- or Fail- parts the data and images should be archived. (These folders are crated below the shared folder (here: „Test_SMB“).
- Filename: Enter any filename.
- Result files: If protocol file is active, there will be generated automatically a .csv file for each inspection (trigger). Contents of the file is like specified in "Output / Telegram". Filename with incremented counter.
- Image contents: Possibility to select, whether images should be stored including the selected software filter or "raw" as taken from the camera.
- Storage mode: Limit: after reaching maximum number of files transmission is stopped. Unlimited: files are stored, until target drive is full. Cyclic: after reaching maximum number of files the older files are replaced by the newer ones.
- Max. number of files: Maximum number of filesets (image+ data) which are allowed to be stored in the target directory.

5.1.4.2.3 Archiving via SMB, output data

After starting of the sensor the images and data (as .csv- file), which has been defined under: Vision Sensor Configuration Studio/Output/Telegram are stored in the corresponding subfolder of the shared folder.




Fig. 259: Successful processed data and image archiving via SMB.

5.1.5 Ram disk (on the sensor)

If Ram disk is active, always the according last image and the numeric result data, which have been specified in: „Output/Telegram" (in format .csv) are stored on the sensor in the ram disk folder /tmp/results/.

This function is activated in „Job/Image transmission".

To access these data an ftp client connection must be established to the sensor.

If:

- Vision Sensor Configuration Studio/Job/Image transmission/Ram Disk is activated in the SBS always the last image (any, pass, failed parts) are stored. File: image.bmp in folder /tmp/results/
- Vision Sensor Configuration Studio/Output/Telegram data has been specified this are also stored in format .csv, on the SBS in folder „/tmp/results".

Fig. 260: Ram Disk

To access this data an ftp client connection like follows e.g. with Windows Explorer is established via: ftp://IPAdr_SBS/tmp/results.




Fig. 26I: Ram Disk Sensor via Explorer

A further possibility to access the data on the sensor e.g. is:

Use Windows command „cmd“ in Start/Run to open a DOS- window. Process the following commands.

The password in factory setting is „user“.

- First change to the folder on the PC where the data should be stored.
- With ftp „IP_Adr_SBS“ a connection to SBS is established.
- User name: user
- Password: user
- Go to folder: /tmp/results on the SBS.
- There are the both files: image.bmp and results.csv (if in Output/Telegram a data string was defined), as image and result data of the latest evaluation.
- With command „get image.bmp“, or. „get results.csv“ the files are copied to the selected folder on the PC

```

C:\WINDOWS\system32\cmd.exe - ftp 192.168.60.199
Datenträger in Laufwerk C: ist WindowsXP
Volumeseriennummer: 60AC-955B

Verzeichnis von C:\Temp

01.03.2012  11:06    <DIR>          .
01.03.2012  11:06    <DIR>          ..
             0 Datei(en)               0 Bytes
             2 Verzeichnis(se), 16.556.417.024 Bytes frei

C:\Temp>ftp 192.168.60.199
Verbindung mit 192.168.60.199 wurde hergestellt.
220 Welcome to ftp-server!
Benutzer (192.168.60.199:(none)): user
331 Please specify the password.
Kennwort:
230 Login successful.
ftp> cd /tmp/results
250 Directory successfully changed.
ftp> dir
200 PORT command successful. Consider using PASU.
150 Here comes the directory listing.
226 Directory send OK.
ftp> dir
200 PORT command successful. Consider using PASU.
150 Here comes the directory listing.
-rw-rw-rw-   1 ftp      ftp      308278 Jan 03 00:26 image.bmp
-rw-rw-rw-   1 ftp      ftp         46 Jan 03 00:26 results.csv
226 Directory send OK.
FTP: 64d Bytes empfangen in 0,00Sekunden 136000,00KB/s
ftp> get image.bmp
200 PORT command successful. Consider using PASU.
150 Opening BINARY mode data connection for image.bmp (308278 bytes).
226 File send OK.
FTP: 64d Bytes empfangen in 0,06Sekunden 4893,30KB/s
ftp> _

```

Fig. 262: Ram Disk via DOS

Attention:

- * The format of all .csv files (ftp, smb, ram-disk, Vision Sensor Visualisation Studio) is always the same.
- * The data is readable (by default divided with semicolon comma) stored into the .csv file.
- * Only (payload) data, which have been defined under Output/Telegram are transmitted.

5.2 Backup

5.2.1 Backup creation

To save all setting of the sensor, which have been made to check one or some parts, please store all these settings with the command „Save job as ...“ or „Save job set ...“ in Vision Sensor Configuration Studio/File. With the commands „Load job ...“ or „Load job set ...“ these settings can be restored to the sensor later.

5.2.2 Exchange SBS

Before exchanging a sensor store all necessarily settings (as described in chap. [Backup creation](#).) By exchanging one SBS -Sensor against another please consider that the sensors are not calibrated optically or mechanically. That means the new sensor must be: installed mechanically and electrically like described in chap. [Installation](#) ff. And also must be optically focused and set up correctly to work in the network.

After this the in advance stored parameter settings can be restored from the PC to the sensor.

5.3 Job switch

5.3.1 Job switch via digital inputs

To switch between several jobs, which are already stored on the sensor, via digital inputs the following options are available:

S. also chap. ff., timing diagrams and comments

5.3.1.1 Job 1 or Job 2

To switch between Job 1 and Job 2 any input can be defined in Vision Sensor Configuration Studio/Output/I/O mapping with the function „Job 1 or 2“. After the according logical level is connected to this input Job 1 or Job 2 is processed Low = Job 1, High = Job 2). S. also chap. [I/O mapping \(Page 172\)](#) / Function of inputs ff.

5.3.1.2 Job 1... 31 via binary bit pattern

To switch between up to 31 jobs by binary input pattern via the up to 5 digital inputs, all needed inputs in Vision Sensor Configuration Studio/Output/I/O mapping are set to the according function “Job switch (Bitx)”.

The in the following graphics shown binary input pattern then switch directly to the according job number. S. also chap. [I/O mapping \(Page 172\)](#) / Function of inputs ff.

Attention:

- Job switch starts / happens immediately after the input pattern has changed.
- The display of the active job changes with the first following trigger.
- The mapping of the I/O's is not fixed. It's depending on the settings in Vision Sensor Configuration Studio/Output/I/O mapping.
- The change of the logical level of all related inputs must happen at the same time.




Fig. 263: Job- switch binary

5.3.1.3 Job I..n via pulses

To switch between job´s with function “Job I..n” any input can be set up with this function in Vision Sensor Configuration Studio/Output/I/O mapping. Only possible if Ready = High. After the last impulse (+50ms) Ready is set to low. Impulses are counted until the first delay of >= 50ms and then switches to the appropriate job. Ready remains low until switch-over to the new job occurs. If the option “Job change confirm” is used, this signal occurs after the job change, and hereafter Ready is set high again. During Job Change over binary inputs there must not be sent any trigger signal. Pulse length for job change should be 5 ms pulse and 5 ms delay. S. also chap. [I/O mapping \(Page 172\)](#) / Function of inputs ff.

If possible job change should be made by binary coded signals like in chap. [Job I... 3I via binary bit pattern](#), this is the faster way.

5.3.2 Job switch via Ethernet

s. chap. [Ethernet example 2.1 command job switch from PC/PLC to SBS](#)

5.3.3 Job switch via Serial

s. chap. [RS422 example 1.1: command Job switch from PC / PLC to SBS](#)

5.3.4 Job switch via Vision Sensor Visualisation Studio

In the application Vision Sensor Visualisation Studio a job switch can be made, or completely new job set´s can be uploaded.

In tab „Vision Sensor Visualisation Studio/Job“ on in the sensor stored jobs are displayed. If there is more than one job in the sensor memory, one of them can be marked in the job list, and activated with button “Set active”. S. also chap. [Changing active job \(Page 216\)](#)




Fig. 264: Vision Sensor Visualisation Studio, Job switch

- In tab „Vision Sensor Visualisation Studio/Job upload“ all on PC available job set are displayed. This can be marked in the job list and uploaded to the sensor via the button „Upload“.

Attention:

By uploading a new job set all jobs in the sensor memory are deleted.




Fig. 265: Vision Sensor Visualisation Studio, Job upload

5.4 Operation with PLC

5.4.1 Profibus plug adapter (RS422)

Via the Profibus plug adapter the communication between sensor and PLC can be established. This is realized with the RS422 / Profibus converter described in document: „Anybus Profibus operating instruction“ in: Startmenue/Festo/SBS Vision Sensor/Tools/Anybus Profibus/...

5.4.2 Example Siemens S7

The connection to a Siemens S7 PLC and it's parameter settings is described in document: „Siemens S7 operating instruction“ in: Startmenue/Festo/SBS Vision Sensor/Tools/SPS/PLC/...

5.4.3 Example Beckhoff CX 1020

The connection to a Beckhoff CX 1020 and it's parameter settings is described in document: „Beckhoff operating instruction“ in: Startmenue/Festo/SBS Vision Sensor/Tools/SPS/PLC/...

5.5 Network connection

5.5.1 Installation of SBS into a network / gateway

In Vision Sensor Device Manager/Active sensors, all SBS sensors, which are installed in the same network segment as the PC which runs Vision Sensor Device Manager are displayed as list. To update this list press the button „Find“, to see sensors which e.g. have been powered after Vision Sensor Device Manager was started.

For sensors, which are installed in the network, but are located in a different network segment via a gateway, please enter their IP address in the field „Add active sensor“ and press button „Add“. „

The according sensor now appears in the list „Active sensors“ and can be accessed now.

5.5.2 Proceeding/Troubleshooting - Direct Connection

Creating a functioning Ethernet connection between SBS Vision Sensor and PC




Fig. 266: Direct connection sensor / PC, proceeding / troubleshooting

5.5.3 Proceeding/Troubleshooting - Network Connection

Establishing an operational Ethernet connection between SBS Vision Sensor and PC




Fig. 267: Connection via network sensor / PC, proceeding / troubleshooting

5.5.4 Used Ethernet- Ports

If the SBS should be installed into a network, the following ports must be enabled, if so by the network administrator. This is necessary only in case that this specific ports have been locked e.g. in a company network by a firewall installed on a PC.

To communicate between a PC for configuration and the SBS the following ports are used:

- * Port 2000, TCP
- * Port 2001, UDP Broadcast (to find sensors via Vision Sensor Device Manager)
- * Port 2002, TCP

* Port 2003, TCP

* Port 2004, TCP

To communicate between PLC (PLC- PC also) and the SBS the following ports are used.

* Port 2005, TCP (Implicit results, that means, user configured result data)

* Port 2006, TCP (Explicit requests, e.g. trigger or job switch)

If the ports 2005 or 2006 are changed in Vision Sensor Configuration Studio, the according ports also must be enabled in the firewall by the administrator.

If the interface EtherNet/IP is used the following two ports must be enabled too.

* Port 2222, UDP (EtherNet/IP)

* Port 44818, TCP (EtherNet/IP)

5.5.5 Access to SBS via network

Exemplary values for IP etc.

Access to SBS 1 from PC 1, if in same subnet.

- Via Vision Sensor Device Manager (/find)

Access to SBS 2 from PC1, if in different subnet.

Only if:

- Gateway is set correct in sensor 2 (here to 192.168.30.1) - and
- in Vision Sensor Device Manager via Add- IP- the sensor IP of sensor 2 is set correct

> now the SBS 2 appears in the list „Active Sensors“ in Vision Sensor Device Manager !




Fig. 268: Access to SBS via network, same or different subnet

5.5.6 Access to SBS via Internet / World Wide Web

Exemplary values for IP etc.

Access from PC 1 (company network 1), via World Wide Web, into company network 2 to SBS 1

- Add the IP- WAN of router 2 (company network 2) in PC 1 (company network 1) in Vision Sensor Device Manager under „Add active sensor“ (here in example: 62.75.148.101)

In router 2 the ports which should be used by the sensor must be defined. (s. also chap. [Used Ethernet-Ports \(Page 257\)](#))




Fig. 269: Access to SBS via Internet / World Wide Web

5.6 Vision Sensor, PROFINET, Introduction

This chapter explains the use of Festo Vision sensor with Profinet. The Profinet interface is implemented starting with version I.12.x.x.

For data communication between Vision sensor and PLC via Profinet the following topics are explained: electrical connection, settings in Vision sensor and PLC (as example for Siemens S7), available telegrams formats and the telegram timing.

5.6.1 Electrical connection SBS in the Profinet network

The Vision Sensor SBS is connected via a Ethernet TCP/IP connection and a Profinet switch to the network, and so to the Profinet environment.




Fig. 270: Connection of SBS via Profinet switch

5.6.2 Configuration of SBS via Festo Vision Sensor Configuration Studio for the use with PROFINET

In this example the configuration of SBS R2B CR Advanced is described. For all other types the configuration works analogue.

5.6.2.1 Settings in Vision Sensor Device Manager




Fig. 271: SBS is displayed and selected in Vision Sensor Device Manager

At the start of Vision Sensor Device Manager or by click to the button “Find” the sensor is listed in window “Active sensors”. By click to the button “Set” the following dialog starts.

5.6.2.2 Setting of IP and name




Fig. 272: Setting of IP and name

Here the IP address of the SBS and it's name is set.

If here a name is set which shall be used permanently, the identical name must be used in the PLC as well.

Caution: these settings are active not before a reboot of the sensor.

Close this dialog with “Set”

Important conditions:

Independent from which possibility is used to do the settings, for a properly working Profinet communication it's necessary:

- The SBS name must be identical in PLC and sensor
- The IP address of SBS and PLC must correspond (same address range)

IP address and name of the SBS can be set in different ways:

- Either via SBS software Vision Sensor Device Manager, or
- Via PLC interface, here Siemens TIA.
-

The name must be DNS compatible. That means: .

- Hostnames may only consist of the characters 'a'-'z', '0'-'9', '-' and '!'. (lower case only)
- The Character '!' may just occur as divider between labels in domain names.

- The character '-' may not occur as first or last character

Setting a name via Vision Sensor Device Manager please take care to meet the above mentioned DNS conventions, as they are not checked. Via the input in the TIA PLC interface the names are converted automatically. S. chap. [Set the name with TIA interface \(Page 270\)](#)




Fig. 273: IP and name has been updated

5.6.2.3 Open Vision Sensor Configuration Studio

With click to “Config” in Vision Sensor Device Manager, and to “OK” in the following dialog Vision Sensor Configuration Studio starts.




Fig. 274: Open Vision Sensor Configuration Studio

5.6.2.4 Select Interface “Profinet”

In Output/Interface/Profinet via the checkbox the Profinet interface is selected. By this command the Profinet stack gets startet.




Fig. 275: Activation of Profinet in Vision Sensor Configuration Studio

5.6.2.5 Definition of the telegram

In the tab “Telegram” the data which should be transferred can be defined completely free. For the use with Profinet this must be done with format “Binary”.

5.6.2.5.1 Definition of the output data

The output data itself are configured identically as the data output via Ethernet TCP/IP or RS422 in: Vision Sensor Configuration Studio/Output/Telegram.

The description you find in the SBS User manual in chapter [Telegram, Data output \(Page 189\)](#) under: Vision Sensor Configuration Studio/Help/Manual.




Fig. 276: Data output, protocol: Binary

5.6.2.6 Start sensor, data output

With “Start sensor” the configuration data are transferred to the SBS . The sensor get´s started and now the output data are transferred as defined.





Fig. 277: Start sensor

5.6.3 Profinet configuration of PLC, example Siemens S7-1200 TIA

5.6.3.1 Create a new project

New project with: Project/Create new project



(Fig. 9) Create new project

5.6.3.2 Select GSD file

First a Profinet PLC must be added to the project.

To use the Profinet functions of the SBS, the GSD file for the SBS must be installed in it's latest version. This is done at: Options/Install general station description file.

The GSD file is available in the installation path of SBS: ..\Festo\SBS Vision Sensor\Tools\Profinet, and as download at www.Festo.com.




Fig. 278: Select and install GSD file

5.6.3.3 Adding SBS to Project

The SBS modules are added in the hardware catalog: Other field devices/ProfiNet IO/Sensors/ Festo Industriesensorik GmbH.




Fig. 279: Add SBS to the project

5.6.3.4 Connect SBS to PLC

With drag and drop a SBS module can be put into the Network view. Now connect the SBS via Profinet to the PLC (Tab. Network view).




Fig. 280: Connect SBS to PLC

5.6.3.5 Definition of I/O data

In the tab “Device view” as default the modules CTRL (Control) and STAT (Status) are active. As an option the module DATA (Data module) can be added with a certain size of payload.

In the example: 2 Byte + 16 Byte payload (1Byte: Image ID; 1Byte: Result data overrun (s. [Module 3: “Data” \(From SBS to PLC\) \(Page 276\)](#)), + 16 Byte payload data): If the data is longer than the defined range the payload is truncated (in this case: Result data overrun = 1), if it’s shorter the rest of the 16 byte are filled with 00h .




Fig. 281: Define I/O data

5.6.3.6 Set IP address of SBS in the project (Option 1)

The IP address of the SBS can be set via the project. Select option „Set IP address in the project“ and set IP address. Address from the field “IP address” is written into the SBS. The IP address of the PLC and of the SBS must not be the same, but must correspond, what means they have to be in the same address range.




Fig. 282: Set IP address in project

The SBS can be used without a started project also, and so can be configured via Vision Sensor Device Manager.

If the IP address of the SBS does not correspond to the one in the TIA project, the PLC is setting a IP address. In this case the IP address of the SBS is overwritten with 0.0.0.0. That means that the IP address is set correctly, but the IP configuration is deleted (this is important for a restart without a connected PLC).

5.6.3.7 Set IP Address with Vision Sensor Device Manager (Option 2)

The IP address of the SBS can be set also via Vision Sensor Device Manager. Select option „Set IP Address using a different method“ in the PLC / TIA Interface, and set IP address via Vision Sensor Device Manager (s. chap. [Setting of IP and name \(Page 262\)](#)).




Fig. 283: Set IP address via Vision Sensor Device Manager, settings therefor in the PLC/TIA interface

5.6.3.8 Set the name with TIA interface

To set the name of SBS from TIA interface there are two options.

5.6.3.8.1 Generate name automatically

The Profinet name of the SBS can be generated automatically from the PLC. Option: „Generate Profinet device name automatically“ takes the name from the project. This name originally comes from the GSD-file.

5.6.3.8.2 Set name manually

If the option „Set PROFINET device name using a different method“ is selected any name can be set.

Information: In the field „Converted name“ a different name may be shown than the one edited, as with Profinet not all characters can be used a conversion may be necessary and is done automatically. (names must be DNS compatible, s. also chap. 3.2)

If a name for the SBS is set via this option, in each case it must be written to the sensor with the „Assign PROFINET device name“- Tool (as described in chap. 4.9)

The Profinet name in the project and in the SBS must be the same.




Fig. 284: Set name in project

5.6.3.9 Write name into SBS

In case that the Profinet name in the SBS has to be updated, it's necessary to write the name into the sensor to establish a communication.

This is done with the tool: Online/Assign PROFINET device name. Select the device in the list (SBS) and with „Assign name“ the name is written into the sensor.




Fig. 285: Write name into SBS

5.6.3.10 Translate project and write to PLC

To finish the configuration and save changes of the project: 1. translate and 2. transfer / write to the PLC



Fig. 286: Translate project and write to PLC

5.6.4 Profinet- telegram description SBS

5.6.4.1 Module I: „Control“ (From PLC to SBS)

Name in PLC „CTRL (3 bytes)“

Byte-Position in Module	Size in Bytes	Member name	Data-Type	Bit number	Meaning
0	3	Reset error	I Bit	0	Reset Error clears 4bit Errorcode in Module: “Status”. Rising edge (low ==> high) clears error code.
		HW-Trigger Disable	I Bit	1	This bit is set to disable triggering via the hardware trigger. Valid for triggered and free-run mode. Low (0): Hardware trigger or free run enabled. High (1): Hardware trigger or free run disabled. If the HW-Pin "Trigger enable" is used, both (Digital input “Hardware- Trigger” and “HW Trigger Disable Bit”)

				be set on "Enable" to accept triggers.
	Trigger	1 Bit	2	Rising edge (low ==> high) Trigger is executed immediately. If Trigger was not executed, Trigger Ack-Bit stays low and Bitfield "Error" has error code "1: Failure trigger request". S. also Timing diagram, chap. Case: Trigger not possible (not ready) (Page 278) .
	Change job	1 Bit	3	Rising edge (low ==> high) indicates, to switch to the job with the number in byte "Jobnumber" in Control Module. This request can be executed delayed. After successful Jobchange, the byte "Jobnumber" in Status Module equals to that in Control Module. If Jobchange could not be executed due to error (e.g. wrong Jobnumber), Bitfield "Error" has error code "2: Failure change job" (and Ready stays low!). S. also Timing diagram, chap. Case: Jobchange not possible (e.g. wrong job number) (Page 280) .
	Switch to run	1 Bit	4	Rising edge (low ==> high) "Switch to Run" is executed. Success or failure of Switch to Run request is signaled with bitfield "Error" (error code "3: Failure Switch to run request") and Bit "Operation Mode". S. also Timing diagram, chap. Case: Switch to run not possible (Page 280) .
	Reserve	1 Bit	5	
	Reserve	1 Bit	6	
	Reserve	1 Bit	7	
1	Reserve	1 Byte		
2	Job number	U8		Number of job to be changed to, on rising edge of Change-job bit. Binary value 1-255 for "Jobnumber Change" 0 indicates no change, even if Change job bit toggles

Example I.1: Module I "Control": Trigger bit set

Must change from 0 to 1, and remain till Trigger ack. is received

Byte 0									Byte 1								Byte 2							
Bit 2: Trigger bit = 1 (rest not relevant in this case)									Reserve								Job number							
0.7	0.6	0.5	0.4	0.3	0.2	0.1	0.0	1.7	1.6	1.5	1.4	1.3	1.2	1.1	1.0	2.7	2.6	2.5	2.4	2.3	2.2	2.1	2.0	
x	x	x	x	x	1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	

Example I.2: Module I "Control": Change Job

Must change from 0 to 1, and remain till Change job ack. is received

Byte 0								Byte 1								Byte 2							
Bit 3: Change job = 1, (rest not relevant in this case)								Reserve								Job number: Binary value e.g. = 10101010 (=170dez)							
0.7	0.6	0.5	0.4	0.3	0.2	0.1	0.0	1.7	1.6	1.5	1.4	1.3	1.2	1.1	1.0	2.7	2.6	2.5	2.4	2.3	2.2	2.1	2.0
x	x	x	x	1	x	x	x	x	x	x	x	x	x	x	x	1	0	1	0	1	0	1	0

5.6.4.2 Module2: “Status” (From SBS to PLC)

Name in PLC „STAT (6 bytes)“

Byte-Position in Module	Size in Bytes	Member name	Data-Type	Bit number	Meaning
0	3	Ready	1 Bit	0	SBS is ready to receive trigger. Ready = 1. Caution: The Ready Bit is reserved to indicate that the SBS is ready for the next evaluation cycle. It is not suitable to indicate that an evaluation cycle is finished or the results are valid! (Rising edge of Ready is not equivalent with result valid! The Ready Bit is a replication of the digital Ready-signal and it follows this as fast as possible, but due to the cycle nature of the Profinet protocol this is not possible hundred per cent.)
		Reserve	1 Bit	1	
		Trigger acknowledge	1 Bit	2	Acknowledge for successful trigger request (via Trigger Bit in Control Module). Acknowledge is cleared as a response of clearing the Trigger bit. If trigger was not executed, Trigger Ack-Bit stays low.
		Change job acknowledge	1 Bit	3	Acknowledge for completion of Change job request (via Change Job Bit in Control Module) - independent of success. Acknowledge is cleared as soon as Change job Request bit is cleared. Success or failure of Change job request is signaled with bitfield "Error" (error code "2: Failure change job") and byte "Jobnumber" in Status Module . This Ack-Bit can be delayed due to delayed execution of Job Change.
		Switch to run acknowledge	1 Bit	4	Acknowledge for completion of Switch-to-run request (via Switch to run request Bit in Control Module). Acknowledge is cleared as soon as request bit is cleared. Success or failure of Switch to run request is signaled with bitfield "Error" (error code "3: Failure Switch to run request") and Bit "Operation Mode". Acknowledge

					is given after Vision Sensor Configuration Studio has been disconnected and job has been reloaded from flash, or a failure is detected.
		Reserve	1 Bit	5	
		Reserve	1 Bit	6	
		Reserve	1 Bit	7	
1		Reserve	1 Byte		
2		Digital results (same as in Ethernet Payload, without length)	1 Bit	0	12 RDBU
			1 Bit	1	09 RD
			1 Bit	2	05 PK
			1 Bit	3	06 YE
			1 Bit	4	07 BK
			1 Bit	5	08 GY
		Reserve	1 Bit	6	
		Reserve	1 Bit	7	
3		Job number	U8		Number of current job: Jobnumber: 1-255
4		Image ID	U8		Image ID (0-255) is incremented with each job execution, independent from trigger source.
5		Error	4 Bit	0	4 bit error code. Used to indicate failures on requests or system error via Control Module. Error is cleared by "Reset error", or overwritten with next error. 0: No error 1: Failure trigger request (sensor not ready) 2: Failure change job 3: Failure switch to run 15: System error
		Trigepr mode	1 Bit	4	1 = Free run 0 = Triggered
		Reserve	1 Bit	5	
		Operation	1 Bit	6	1 = Run

		mode			0 = Config
		Reserve	1 Bit	7	

Example 2.1: Module 2 “Status”: Trigger acknowledge is set

- Trigger ack. is set to 1 (Trigger received)
- Ready is set to 0 (Busy)

Byte 0								Byte 1								Byte 2							
Bit 0: Ready = 0 Bit 2: Trigger ack. = 1								Reserve								Digital results							
0.7	0.6	0.5	0.4	0.3	0.2	0.1	0.0	1.7	1.6	1.5	1.4	1.3	1.2	1.1	1.0	2.7	2.6	2.5	2.4	2.3	2.2	2.1	2.0
0	x	1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x

Byte 3								Byte 4								Byte 5							
Job number								Image ID								Error 4 bit, Trigger mode etc.							
3.7	3.6	3.5	3.4	3.3	3.2	3.1	3.0	4.7	4.6	4.5	4.4	4.3	4.2	4.1	4.0	5.7	5.6	5.5	5.4	5.3	5.2	5.1	5.0
x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x

Example 2.2: Module 2 “Status”: Change job acknowledge is set

- Change job ack. is set to 1 (Change job received)
- Ready is set to 0 (Busy)

Byte 0								Byte 1								Byte 2							
Bit 0: Ready = 0 Bit 2: Trigger ack. = 1								Reserve								Digital results							
0.7	0.6	0.5	0.4	0.3	0.2	0.1	0.0	1.7	1.6	1.5	1.4	1.3	1.2	1.1	1.0	2.7	2.6	2.5	2.4	2.3	2.2	2.1	2.0
0	x	x	1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x

Byte 3								Byte 4								Byte 5							
Job number								Image ID								Error 4 bit, Trigger mode etc.							
3.7	3.6	3.5	3.4	3.3	3.2	3.1	3.0	4.7	4.6	4.5	4.4	4.3	4.2	4.1	4.0	5.7	5.6	5.5	5.4	5.3	5.2	5.1	5.0
1	0	1	0	1	0	1	0	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x

5.6.4.3 Module 3: “Data” (From SBS to PLC)

Name in PLC „DATA (2 + 8/16/... bytes)

Byte-Position in Module	Size in Bytes	Member name	Data-Type	Bit number	Meaning
0	1	Image ID	U8		Image ID (0-255) is incremented with each job execution, independent from trigger source.
1	1	Result data overrun	1 Bit	0	Result data has been truncated. 1: Data overrun = truncated 0: No overrun
		Reserve	7 Bit	1-7	Reserve
2	One block of 8, 16, 32, 64, 128 or 256 Bytes	Result data	Byte-array		Data as defined in Vision Sensor Configuration Studio in "Output/Telegram/Payload". In case of Profinet in tab “Telegram” = “Binary” must be selected.

Example 3.1: Module 3 “Data”

- Eg.: No overrun
- Data Byte 2 ... n as defined in Vision Sensor Configuration Studio "Output/Telegram/Payload"

Byte 0									Byte 1									Byte 2 ... n							
Image ID									Result data overrun Reserve									Result data: as defined in Vision Sensor Configuration Studio "Output/Telegram/Payload" in binary format.							
0.7	0.6	0.5	0.4	0.3	0.2	0.1	0.0		1.7	1.6	1.5	1.4	1.3	1.2	1.1	1.0		2.7	2.6	2.5	2.4	2.3	2.2	2.1	2.0
x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x

5.6.4.4 Module 4: „Request“ (From PLC to SBS)

Name in PLC „REQU (4 + 8/16/... bytes)“

Byte-Position in Module	Size in Bytes	Member name	Data-Type	Bit number	Meaning
0	1	Key	1 Byte		Request key (Request counter)

1		Reserve	 Byte		Reserve
2		Reserve	 Byte		Reserve
3		Reserve	 Byte		Reserve
4	One block of 8, 16, 32, 64, 128 or 256 Bytes	Request data	Byte-array		Same data as for TCP requests, s. addendum: Serial communication BINARY (Page 338)

5.6.4.5 Module 5: „Response“ (From SBS to PLC)

Name in PLC „RESP (4 + 8/16/... bytes)“

Byte-Position in Module	Size in Bytes	Member name	Data-Type	Bit number	Meaning
0		Key	U8		Response key which is mirrored from request
1		Result data overrun	1 Bit	0	Response data has been truncated
		Reserve	7 Bit	1-7	Reserve
2		Reserve	 Byte		Reserve
3		Reserve	 Byte		Reserve
4	One block of 8, 16, 32, 64, 128 or 256 Bytes	Result data	Byte-array		Same data as for TCP responses s. addendum: ... Serial communication BINARY (Page 338)

5.6.4.6 Start- / End- criteria per each Profinet command

Command (Modul „Control“)	Start- condition (Modul „Status“)	Confirmation of acceptance (Modul „Status“)	Confirmation of execution (Modul „Status“)
Trigger	Ready = High	Trigger Ack = High	Image ID changed

Change Job	/	Job Change Ack = High	Job Nr. changed
Switch to run	Operation Mode = Low	Switch to run Ack = High	Operation Mode = High

5.6.5 Timing diagrams to the SBS Profinet communication with a PLC

5.6.5.1 Case: Trigger ok




Fig. 287: Timing Trigger ok

5.6.5.2 Case: Trigger not possible (not ready)




Fig. 288: Timing Trigger not ready

5.6.5.3 Case: Jobchange ok




Fig. 289: Timing Jobchange ok

5.6.5.4 Case: Jobchange delayed




Fig. 290: Timing Jobchange delayed

5.6.5.5 Case: Jobchange not possible (e.g. wrong job number)




Fig. 291: Timing Jobchange not possible

5.6.5.6 Case: Switch to run ok




Fig. 292: Timing Switch to run ok

5.6.5.7 Case: Switch to run not possible




Fig. 293: Switch to run not possible

5.6.5.8 Strong recommendations for PLC programmer

1. Follow the sequence for requests.
2. Wait for completion of an action before sending the next one. Completion of action is given by change in image ID for trigger request and reception of acknowledge bit for other requests.

Note that completion of action cannot be safely detected by low-high transition of READY because long exchange rates between PLC and SBS, e.g. 32ms, may result in READY not getting low.

3. READY should be high before sending trigger request.

5.6.5.9 Request sequences

5.6.5.9.1 Accepting / Discarding of Requests of Control Module

1. Request is accepted with rising Ack bit.
2. Request is discarded with error bit.
3. Request is discarded without error and Ack, if sensor is processing previous request and has not given Ack to that request. (Not obeying recommended "Handshake").

5.6.5.9.2 TRIGGER Request Sequence

1. Check Ready Bit high in Status module.
2. Set Trigger Request Bit high in Control Module.
3. Check Trigger Ack Bit high and Error Bitfield in status Module.
 - a) if Trigger Ack Bit high (Trigger successful), set Trigger Request Bit low. (continue with step 4)
 - b) if Trigger Ack Bit low and Error Bitfield has Errorcode "I: Failure trigger request", then set Trigger Request Bit low and set Reset Error Bit high. (continue with step 6)
4. (Case Trigger successful) check Trigger Ack Bit low.
5. (Case Trigger successful) then check ImageID Byte incremented.
Trigger Request is finished.
6. (Case Trigger not successful) Check Error Bitfield going 0, then set Reset Error Bit low.

5.6.5.9.3 ChangeJob Request Sequence

1. Set Byte Jobnumber in Control module to desired value.

2. Check Ready Bit in Status module (in case of previous jobchange failure, ignore Ready).
3. Set ChangeJob Request Bit high in Control Module.
4. Wait and Check for ChangeJob Ack Bit high.
5. Check Error Bitfield in status Module.
 - a) if Error Bitfield has not Errorcode "2: Failure change job", then set ChangeJob Request Bit low. (continue with step 6)
 - b) if Error Bitfield has Errorcode "2: Failure change job", then set ChangeJob Request Bit low and set Reset Error Bit high. (continue with step 8)
6. (Case ChangeJob successful) Check ChangeJob Ack Bit low.
7. (Case ChangeJob successful) then check Jobnumber Byte in Status module. If Jobnumber is correct. Jobchange is finished.
8. (Case ChangeJob not successful) Check Error Bitfield going 0, then set Reset Error Bit low. Check the correct jobnumber and repeat the request with Step 3 (Ready bit stays low).

5.6.5.9.4 Switch-To-Run Request Sequence

1. Check Ready Bit high and Operation Mode Bit low (Config mode) in Status module.
2. Set Switch-to-Run Request Bit high in Control Module.
3. Wait and Check Switch-to-Run Ack Bit high.
4. Check Error Bitfield in Status Module.
 - a) if Error Bitfield has not Errorcode "3: Failure switch to run request", then set Switch-to-Run Request Bit low. (continue with step 5)
 - b) if Error Bitfield has Errorcode "3: Failure switch to run request", then set Switch-to-Run Request Bit low and set Reset Error Bit high. (continue with step 6)
5. (Case Switch-to-Run successful) Check Switch-to-Run Ack Bit low and Operation Mode Bit high (Run mode).
Switch-to-Run is finished.
6. (Case Switch-to-Run not successful) Check Switch-to-Run Ack Bit low and Error Bitfield going 0, then set Reset Error Bit low.

5.6.5.9.5 Sequence for requests via request/response module:

1. Request ID and request data is set.
2. Request key is incremented.

3. PLC waits for until request key is mirrored in response key.
4. PLC reads results including error included in results. See TCP payload.

5.6.5.9.6 Error Reset (depicted in UseCase "Jobchange not possible")

- 1) Reset by "Reset Error Bit"
- 2) Error bits are overwritten by new error bits.

5.7 Vision Sensor, EtherNet/IP, Introduction

This chapter explains the use of the Vision Sensor with EtherNet/IP.

For data communication between Vision Sensor and PLC via EtherNet/IP the following topics are explained: electrical connection, settings in Vision Sensor and PLC (as example for Rockwell RSLogix), available telegrams formats and the telegram timing.

5.7.1 Electrical connection of the Vision Sensor in the EtherNet/IP network

The Vision Sensor is connected via an Ethernet TCP/IP and a EtherNet/IP switch to the network.




Fig. 294: Connection of Vision Sensor via EtherNet/IP switch

5.7.2 Configuration of Vision Sensor for the use with EtherNet/IP

In this example the configuration of the Vision Sensor is described.

5.7.2.1 Settings in Vision Sensor Device Manager




Fig. 295: Vision Sensor is displayed and selected in Vision Sensor Device Manager.

When Vision Sensor Device Manager launches or by clicking the “Find” button, all active Vision sensors are listed in the upper window called “Active sensors”. You can change the IP address, subnet mask and other parameters on the Vision sensor by clicking the “Set” button. This displays the following dialog box.

5.7.2.2 Setting of IP and name




Fig. 296: Setting of IP and name

5.7.2.3 Open Vision Sensor Configuration Studio

With click to “Config” in Vision Sensor Device Manager, and to “OK” in the following dialog Vision Sensor Configuration Studio starts. With the desired Vision sensor is selected in Vision Sensor Device Manager, click “Config.” When the following dialog box is displayed, click “OK” to stop the Vision sensor and begin configuring it.




Fig. 297: Open Vision Sensor Configuration Studio

5.7.2.4 Select Interface “EtherNet/IP”

In the setup menu click "Output".

On the "Interface" tab, check the box to select EtherNet/IP.




Fig. 298: Activation of EtherNet/IP in Vision Sensor Configuration Studio

5.7.2.5 Definition of the telegram

In the tab “Telegram” the data which should be transferred can be defined completely free. For the use with EtherNet/IP this must be done with format “Binary”.

5.7.2.5.1 Definition of the output data

The output data itself are configured identically as the data output via Ethernet TCP/IP or RS422 in: Vision Sensor Configuration Studio/Output/Telegram.

The description you find in the Vision Sensor User manual in chapter [Telegram, Data output \(Page 189\)](#) under: Vision Sensor Configuration Studio/Help/Manual.




Fig. 299: Data output, protocol: Binary

5.7.2.6 Start sensor, data output

With “Start sensor” the configuration data are transferred to the Vision Sensor. The sensor get´s started and now the output data are transferred as defined.




Fig. 300: Start sensor

5.7.3 EtherNet/IP protocol

EtherNet/IP has a predefined protocol, consisting of two assemblies.

- Assembly request (PLC to Sensor, 344 bytes long) and
- Assembly response (Sensor to PLC, 444 bytes long)

5.7.3.1 Assembly request

Request key

Position 0 (Byte 0 and 1) are the request key. Every change in the request key indicates to the sensor that there are new data inside the assembly request available. Changing the request key triggers a command like trigger, job change...

Command configuration

The command configuration starts on position 2 and has a size of 2 bytes (byte 2 and 3).

It is possible with selected code, to choose between: Trigger, Change job and Set reference string.

- **Trigger:** To make a trigger (to take a new picture), the code is: 0x01

- **Change job:** to send the command to change a job, the code is: 0x02

Commands which need further arguments like “change job” need to get the arguments on the correct byte positions : the job number is an integer value to be placed on “pnValueInt” (byte 264), the length of this information is 1 byte long, following Parameter “unNumInt” (byte 6) has to be set to “1”.

Examples

Trigger

Request structure	Key	ID
Storage	unKey	unId
Byte position	0	2
Request pattern	Count	0x01

Change Job

Request structure	Key	ID	NumInt	Job number
Storage	unKey	unId	NumInt	ValueInt[0]
Byte position	0	2	6	264
Request pattern	Count	0x02	0x01	Job no.

Set reference string permanent

Request structure	Key	ID	Length of string	NumInt	Ref. String	Detector number	Parameter number	Parameter type
Storage	unKey	unId	NumChar	NumInt	Char	Int[0]	Int[1]	Int[2]
Byte position	0	2	4	6	8	264	268	272
Request pattern	Count	0x05	0x01	0x03	0x43	0x01	0x65	0x0A
Explanation			Example 1 character	Constant value	Example string f. “C”	Example for detector 1	Command set ref. string	Example param. type

								string
--	--	--	--	--	--	--	--	--------

Set reference string temporary

Request structure	Key	ID	Length of string	NumInt	Ref. String	Detector number	Parameter number	Parameter type
Storage	unKey	unId	NumChar	NumInt	Char	Int[0]	Int[1]	Int[2]
Byte position	0	2	4	6	8	264	268	272
Request pattern	Count	0x06	0x02	0x03	0x41 0x42	0x01	0x65	0x0A
Explanation			Example 2 character	Constant value	Example string f. "AB"	Example for detector 1	Command set ref. string	Example param. type string

5.7.3.1.1 Sensor Ready information / signaling and handshake

Over hardware IO the Vision Sensor offers a "Ready" signal. Sending a Trigger is allowed only if "Ready" signal is high.

When hardware ready signal is not connected to the PLC it is very easy to find out the ready status just over EtherNet/IP.

After first connection of PLC to SBS the SBS must in be "ready"-state, otherwise there would have been no connection.

Following chart shows the hardware ready signal in relation to the commands over EtherNet/IP at the example of a typical trigger sequence:




Fig. 301: EtherNet/IP, Sensor ready

5.7.3.2 Assembly response

User defined data output to be configured in the result telegram specification:




Fig. 302: User defined data output

Depending from kind of output data they can be found in the assembly response at

- Boolean: byte 92 (pucBool)
- String: byte 116 (pcString)
- Integer: byte 244 (pnInt)

Example Trigger Handshake




Fig. 303: EtherNet/IP, Trigger handshake

Response and request bytes



Fig. 304: EtherNet/IP, Response and request bytes

A complete documentation of the assemblies can be found in the end of this chapter.

5.7.4 EDS file

Festo provides an EDS file for easy implementation into controllers which support EDS files.

Concerning installation and use of EDS files please use the documentation of the controller.

Example: Installation of EDS file in RSLogix:

1.) Use dialog for installation of EDS files:




Fig. 305: Installation of EDS files

2.) Follow the instructions of the Wizard:



Fig. 306: Wizard, EDS file installation

5.7.5 Implementation of Vision Sensor into RSLogix

Establish a network-connection between RSLogix and each sensor by adding a Generic Ethernet Module in the Ethernet I/O network for each sensor.




Fig. 307: EtherNet/IP, Ethernet Module

You will also need to set up the suitable network adapter which is mounted in side the PLC.

The Ethernet Card will need to setup as a module on the Ethernet I/O network within the same subnet as the camera(s) you will be communicating with.

In this example the IP adress of RSLogix is 192.168.100.84, this can be configured by click with right mouse button on „EtherNet/IP Eth1“ → “New Module”:




Fig. 308: EtherNet/IP, New EtherNet/IP Module




Fig. 309:

5.7.5.1 Over Generic Profile

Each sensor is added as a “Generic Ethernet Module” as shown in the following two screenshots: enter IP address of sensor (as set before with Vision Sensor Device Manager software) and the number of input and output bytes like shown in screenshot:




Fig. 310: EtherNet/IP, select Generic Module

Add one Ethernet module for each sensor




Fig. 311: EtherNet/IP, number of input and output byte

Duplicate this step with different name and IP-address for each sensor, rest of settings the same.

5.7.5.2 Over EDS-File

If an EDS file has been installed before „Festo SBS” can be selected directly inside the list of available modules.

Assembly size and Assembly instance is set automatically in this case. Only IP address of SBS has to be entered.




Fig. 312: EtherNet/IP, select Generic Module




Fig. 313: EtherNet/IP, set IP address, EDS- file

5.7.6 Result data: assembly response

User defined data output to be configured in the result telegram specification:




Fig. 314: EtherNet/IP, Result data specification

Depending on the kind of output data they can be found in the assembly response at

- Boolean: byte 92 (pucBool)

Name	Value	Force Mask	Style	Data Type	Description
Eth21 Data[87]	0	0	Decimal	SINT	
Eth21 Data[88]	0	0	Decimal	SINT	
Eth21 Data[89]	0	0	Decimal	SINT	
Eth21 Data[90]	0	0	Decimal	SINT	
Eth21 Data[91]	0	0	Decimal	SINT	
Eth21 Data[92]	1	0	Decimal	SINT	
Eth21 Data[93]	0	0	Decimal	SINT	
Eth21 Data[94]	0	0	Decimal	SINT	
Eth21 Data[95]	0	0	Decimal	SINT	
Eth21 Data[96]	0	0	Decimal	SINT	
Eth21 Data[97]	0	0	Decimal	SINT	
Eth21 Data[98]	0	0	Decimal	SINT	

Fig. 315: EtherNet/IP, Output data, Bool

- String: byte 116 (pcString)

Name	Value	Force Mask	Style	Data Type	Description
Eth21 Data[108]	0	0	Decimal	SINT	
Eth21 Data[109]	0	0	Decimal	SINT	
Eth21 Data[110]	0	0	Decimal	SINT	
Eth21 Data[111]	0	0	Decimal	SINT	
Eth21 Data[112]	0	0	Decimal	SINT	
Eth21 Data[113]	0	0	Decimal	SINT	
Eth21 Data[114]	0	0	Decimal	SINT	
Eth21 Data[115]	0	0	Decimal	SINT	
Eth21 Data[116]	'D'	0	ASCII	SINT	
Eth21 Data[117]	'E'	0	ASCII	SINT	
Eth21 Data[118]	'T'	0	ASCII	SINT	
Eth21 Data[119]	'1'	0	ASCII	SINT	
Eth21 Data[120]	'4'	0	ASCII	SINT	
Eth21 Data[121]	0	0	Decimal	SINT	
Eth21 Data[122]	0	0	Decimal	SINT	
Eth21 Data[123]	0	0	Decimal	SINT	
Eth21 Data[124]	0	0	Decimal	SINT	
Eth21 Data[125]	0	0	Decimal	SINT	
Eth21 Data[126]	0	0	Decimal	SINT	

Fig. 316: EtherNet/IP, Output data, String

- Integer: byte 244 (pnInt)




Fig. 317: EtherNet/IP, Output data, Int

To see boolean results of Q1 to Q3 you have to activate the transmission in Vision Sensor Configuration Studio-Software:

=> Output => Telegram => Digital Outputs

If this setting is correct, you get them on Q1 = Eth2:I.Data[60].01, Q2 = Eth2:I.Data[60].02, Q3 = Eth2:I.Data[60].03

5.7.7 EtherNet/IP Appendix

5.7.7.1 Assembly Request

Communication settings

Description:	Request posted from PLC to Vision Sensor
Class:	Class I
nAssemblyInstance:	100
nType:	AssemblyConsuming
nLength (bytes):	344
szAssemblyName:	AssemblyRequest

Assembly request

Vision Sensor receives a data frame of 344 bytes.

To release commands to the sensor, proceed as follow:

Each byte corresponds to values which are sent from the PLC to the sensor. The position defines the byte to use and the size defines the length of this command.

Position	Size (bytes)	Member	Data type	Description
----------	--------------	--------	-----------	-------------

0	2	unKey	UI6	request key, eg. a request counter
2	2	unId	UI6	request ID, eg. for requests "trigger", "change job"
4	2	unNumChar	UI6	no. of valid char parameters
6	2	unNumInt	UI6	no. of valid int parameters
8	256	pcValueChar[RQST_NUM_CHAR]	I8	char parameters for request, member may only hold one string
264	80	16 int parameters for request	I16	int parameters for request

The request key:

The position 0 (Byte 0) with a size of 2 bytes, corresponds to the request key. It valid the modification of parameters sent. For that, you need to increment the request key bytes with a value of your choice to release a command.

Example:

I want to make a trigger on the Vision Sensor. The default code of the request key is 0x0 0x0. After Trigger configuration (description follows), I increment the request key to engage the trigger. The request key code is now: 0x0 0x2.

Position 0:

Byte 1	Byte 0
Always 0	0000 0010

Command configuration:

The request key has a size of 2 bytes (at position 0 and 1), the command configuration will start on position 2 and has a size of 2 bytes. It is possible to choose a command called **Request ID** between: Trigger, Change job, statistics reset, auto shutter, permanent or temporary teach.

Position 2:

Byte 3	Byte 2
Always 0	0000 0001

Change job: to send the the change job command, the code is: 0x0 0x2 in position 2. You have to set the LSB of position 6 to "1". (Standard version: job 1 or job 2; Advanced versions: 255 jobs available). For that, write the job number 4 bytes to position / byte 264 .

To validate your request, you have to increment the request key. After that you need to make a trigger to change the job (don't forget to set the LSB of position 6 to "0").

Position 2:

Byte 3	Byte 2
Always 0	0000 0010

Position 6:

Byte 7	Byte 6
Always 0	0000 0001

Position 264:

Byte 265	Byte 264
Always 0	0000 0010

Byte 3	Byte 2
Always 0	0000 0100

Auto Shutter: For function auto shutter you have to write the code: 0x0 0x7 on position 2.

Position 2:

Byte 3	Byte 2
Always 0	0000 0111

Permanent teach: The permanent teach allows to teach a new reference pattern / contour etc. with same tools and same settings. These teach is permanent, it means the new reference pattern / contour etc. is stored permanently in the sensor memory, even if the sensor is reset. The code is: 0x0 0x8 on position 2. To activate this command, you have to launch a new trigger to catch a new picture and you have to increment the request key.

Position 2:

Byte 3	Byte 2
Always 0	0000 1000

Temporary teach: The temporary teach allows a new reference pattern / contour etc. with same tools and same setting. These teach is temporary, it means the reference pattern / contour etc. is not available after a reset of the sensor. The code is: 0x0 0x9 on position 2. To active this command, you have to launch two trigger to catch a new picture and you have to increment the request key.

Position 2:

Byte 3	Byte 2
Always on 0	0000 1001

Summary of available commands:

Commands	Position	Size	Code
Trigger	2	2	0x0 0x1
Change job	2	2	0x0 0x2
Job number	264	4	Job number
Statistics reset	2	2	0x0 0x4
Auto shutter	2	2	0x0 0x7
Permanent teach	2	2	0x0 0x8
Temporary teach	2	2	0x0 0x9

Example: I want to make a trigger, I write the code: 0x0 0x1 on position 2, I modify the request key on position 0: 0x0 0x2 => 0x0 0x4. The Vision Sensor take a new picture.

Attention: Don't forget to increment the request key to valid the commands.

5.7.7.2 Assembly Response

Communication settings

Description:	Response returned from Vision Sensor to PLC
Class:	Class 1
nAssemblyInstance:	101
nType:	AssemblyProducing
nLength (bytes):	444
szAssemblyName:	AssemblyResponse

Assembly response

Assembly responses are data sent by the sensor after made some commands by the PLC or by the software.

For the commands by PLC, please see Ethernet / IP request file.

To set commands by the software with the Vision SensorConfig, proceed as follow:

After PLC configuration and Vision SensorConfig configuration, the size of the frame assembly response is of 444 Bytes. Each of them corresponds to some values describe as follow:

Position	Size (bytes)	Member	Data type	Description				
0	4	unFault	U32	member is standard in Rockwell RSLogix				
4	2	unKey	U16	Request key is returned in response				
6	2	unId	U16	Request ID is returned in response. (Trigger, Change job, Statistics reset...)				
8	2	unError	U16	Error code of response				
10	4	unNumChar	U32	Responses values for requests like job change, teach ...				
					Byte 13	Byte 12	Byte 11	Byte 10
				Trigger	Always 0	Always 0	Always 0	0000 0001
				Change job	Always 0	Always 0	Always 0	0000 0010
Permanent teach	Always 0	Always 0	Always 0	0000 1000				
14	2			RESERVED				
16	16	pcValueChar [RPNS_NUM_CHAR]	18	char parameters for response, member may only hold one string				
32	16	pnValueInt[RPNS_NUM_INT]	U32	int parameters for response				
48	4	unImageCount	U32	Number of images taken by the Vision Sensor sensor.				
52	4	unExecutionTime	U32	Average execution time of last processed image. (To active this data, select in Vision SensorConfig : Execution time)				
56	4	pucStatus[RPNS_IMPL_NUM_BYTE_STATUS]	U32	Status : Vision Sensor mode (To active this data, select in Vision SensorConfig : Status) Freerun : The sensor takes a new picture when the processing is finished. Trigger : The sensor wait an external signal to take a new picture. Example Byte 56, bit "0" and "1":				

				<table border="1"> <thead> <tr> <th></th> <th>Byte 59</th> <th>Byte 58</th> <th>Byte 57</th> <th>Byte 56</th> </tr> </thead> <tbody> <tr> <td>Freerun</td> <td>Always 0</td> <td>Always 0</td> <td>0000 000X</td> <td>0000 0X01</td> </tr> <tr> <td>Trigger mode</td> <td>Always 0</td> <td>Always 0</td> <td>0000 000X</td> <td>0000 0X10</td> </tr> </tbody> </table> <p>Additional data for I.7.10.1 version or more Configuration : The sensor is connected to a PC for configuration</p> <p>Example Byte 56, bit "2":</p> <table border="1"> <thead> <tr> <th></th> <th>Byte 59</th> <th>Byte 58</th> <th>Byte 57</th> <th>Byte 56</th> </tr> </thead> <tbody> <tr> <td>Configuration</td> <td>Always 0</td> <td>Always 0</td> <td>0000 000X</td> <td>0 0000 00XX</td> </tr> <tr> <td>Run</td> <td>Always 0</td> <td>Always 0</td> <td>0000 000X</td> <td>0000 01XX</td> </tr> </tbody> </table> <p>Run : The job is downloaded in the Vision Sensor memory. The sensor works stand alone.</p> <p>Byte "57", bit "0" shows the sensor ready status</p> <table border="1"> <thead> <tr> <th></th> <th>Byte 59</th> <th>Byte 58</th> <th>Byte 57</th> <th>Byte 56</th> </tr> </thead> <tbody> <tr> <td>Sensor ready</td> <td>Always 0</td> <td>Always 0</td> <td>0000 0001</td> <td>0000 0XXX</td> </tr> <tr> <td>Sensor not ready</td> <td>Always 0</td> <td>Always 0</td> <td>0000 0000</td> <td>0000 0XXX</td> </tr> </tbody> </table>		Byte 59	Byte 58	Byte 57	Byte 56	Freerun	Always 0	Always 0	0000 000X	0000 0X01	Trigger mode	Always 0	Always 0	0000 000X	0000 0X10		Byte 59	Byte 58	Byte 57	Byte 56	Configuration	Always 0	Always 0	0000 000X	0 0000 00XX	Run	Always 0	Always 0	0000 000X	0000 01XX		Byte 59	Byte 58	Byte 57	Byte 56	Sensor ready	Always 0	Always 0	0000 0001	0000 0XXX	Sensor not ready	Always 0	Always 0	0000 0000	0000 0XXX
	Byte 59	Byte 58	Byte 57	Byte 56																																													
Freerun	Always 0	Always 0	0000 000X	0000 0X01																																													
Trigger mode	Always 0	Always 0	0000 000X	0000 0X10																																													
	Byte 59	Byte 58	Byte 57	Byte 56																																													
Configuration	Always 0	Always 0	0000 000X	0 0000 00XX																																													
Run	Always 0	Always 0	0000 000X	0000 01XX																																													
	Byte 59	Byte 58	Byte 57	Byte 56																																													
Sensor ready	Always 0	Always 0	0000 0001	0000 0XXX																																													
Sensor not ready	Always 0	Always 0	0000 0000	0000 0XXX																																													
60	2	unActiveJob	U16	Active job : Value of job number																																													
62	2			RESERVED																																													
64	2	unNumDigital	U16	Number of active digital outputs (assigned to one tool) (To active this data, select in Vision SensorConfig : Digital outputs) According to: Byte 1 and 2, of "Digital outputs", in "Serial communication / Data output Binary"																																													
66	2	unNumLogic	U16	Number of active logical outputs (assigned to one tool) (To active this data, select in Vision																																													

				SensorConfig : Logical outputs) According to: Byte 1 and 2, of "Logical outputs", in "Serial communication / Data output Binary"										
68	2	unNumDetector	U16	Number of selected tools (It is a default value) According to: Byte 2 and 3, of "Detector result", in "Serial communication / Data output Binary"										
70	2	unNumBool	U16	no. of valid boolean parameters										
72	2	unNumString	U16	no. of strings included in pcValueChar										
74	2	unNumInt	U16	Number of received payload (To active this data, select a data in Vision SensorConfig : Payload)										
76	2	pucDigital[RPNS_IMPL_NUM_BYTE_DIGITAL]	U8	<p>Digital outputs results: result according to the order of the outputs. LSB => first output. MSB => Last output. Example: 4 active outputs (12, 09, 05, 06). Status of outputs : 12 = OK; 09 = NOK; 05 = OK; 06 = OK. The code will be :</p> <table border="1"> <thead> <tr> <th></th> <th>Byte 79</th> <th>Byte 78</th> <th>Byte 77</th> <th>Byte 76</th> </tr> </thead> <tbody> <tr> <td>Result</td> <td>0000 0000</td> <td>0000 0000</td> <td>0000 0000</td> <td>0000 1101</td> </tr> </tbody> </table> <p>(To active this data, select in Vision SensorConfig : Digital outputs)</p> <p>According to: Byte 3 ... n, of "Digitaloutputs", in "Serial communication / Data output Binary"</p>		Byte 79	Byte 78	Byte 77	Byte 76	Result	0000 0000	0000 0000	0000 0000	0000 1101
	Byte 79	Byte 78	Byte 77	Byte 76										
Result	0000 0000	0000 0000	0000 0000	0000 1101										
80	8	pucLogic[RPNS_IMPL_NUM_BYTE_LOGIC]	U8	<p>Logical outputs results: result according to the order of the outputs. LSB => first output. MSB => Last output. Example: 4 active outputs (12, 09, 05, 06). Status of outputs : 12 = OK; 09 = NOK; 05 = OK; 06 = OK. The code will be : 1011</p> <table border="1"> <thead> <tr> <th></th> <th>Byte 83..87</th> <th>Byte 82</th> <th>Byte 81</th> <th>Byte 80</th> </tr> </thead> <tbody> <tr> <td>Result</td> <td>0000 0000</td> <td>0000 0000</td> <td>0000 0000</td> <td>0000 1011</td> </tr> </tbody> </table> <p>(To active this data, select in Vision SensorConfig : Logical outputs)</p> <p>According to: Byte 3 ... n, of "Logical outputs", in "Serial communication / Data output Binary"</p>		Byte 83..87	Byte 82	Byte 81	Byte 80	Result	0000 0000	0000 0000	0000 0000	0000 1011
	Byte 83..87	Byte 82	Byte 81	Byte 80										
Result	0000 0000	0000 0000	0000 0000	0000 1011										

88	1	pucDetector [RPNS_IMPL_NUM_BYTE_DETECTOR]	U8	<p>Global result (Only available on Vision SensorConfig and Vision SensorViewer): Only coded on the third LSB bits. Bit0 = Global result status (0 : OK ; 1 : NOK) Bit1 = Status of the case « Detector result » in Optional field during the data configuration. Bit2 = Indicate if one of tools is NOK even if result global is OK => 0 Example 1: We select Detector result case; Tool1 OK; Tool2 OK; Global result on tool1 and on tool2 => OK, the bit2 will be on 1.</p> <table border="1" data-bbox="783 645 1394 759"> <tr> <td></td> <td>Byte 88</td> </tr> <tr> <td>Result</td> <td>0000 0111</td> </tr> </table> <p>Example 2: We select Detector result case; Tool1 OK; Tool2 NOK; Global result on tool1 => OK, the bit2 will be on 0.</p> <p>According to: Byte 1, of "Detector result", in "Serial communication / Data output Binary"</p> <table border="1" data-bbox="783 983 1394 1097"> <tr> <td></td> <td>Byte 88</td> </tr> <tr> <td>Result</td> <td>0000 0011</td> </tr> </table> <p>Other bits always on 0. (To active this data, select in Vision SensorConfig : Detector results)</p>		Byte 88	Result	0000 0111		Byte 88	Result	0000 0011
	Byte 88											
Result	0000 0111											
	Byte 88											
Result	0000 0011											
89	3	pucDetector [RPNS_IMPL_NUM_BYTE_DETECTOR]	U8	<p>Detector result: Each bit corresponds to a tool. Only on 1Byte: Bit1 = tool1; bit2 = tool2; bit3 = tool3... until 8 bits. Other bytes, always on 0. Future Applications, coded on 3 bytes. (To active this data, select in Vision SensorConfig : Detector results)</p>								
92	4	pucBool[RPNS_IMPL_NUM_BYTE_BOOL]	U8	<p>boolean results (bitwise) as configured in HMI (listbox)</p>								
96	16	punStringLength [RPNS_IMPL_NUM_STRING]	U16	<p>lengths of strings included in pcValueChar</p>								
112	2	pucStringTruncated [RPNS_IMPL_NUM_BYTE_STRING_TRUNCATED]	U8	<p>indicates for each string whether it has been truncated (bitwise)</p>								

114	2			RESERVED
116	128	pcString[RPNS_IMPL_NUM_BYTE_STRING]	18	char result as configured in HMI (listbox), member may hold multiple strings
244	200	pnInt[RPNS_IMPL_NUM_INT]	U32	Results of payload configured on Vision Sensor Config in tab « frame ». All data on payload are describe as follow :

5.8 Rescue

The utility „Rescue“ is used to reset SBS sensors, which no longer can be found by Vision Sensor Device Manager, to a default status to be able to be accessed via Vision Sensor Device Manager and Vision Sensor Configuration Studio again.

- Start Rescue (leave empty field „Mac address of Sensor“)
- Reset SBS , Power off/on or Vision Sensor Device Manager/File/Sensor soft reset (SBS must be connected via Ethernet and be located in the same network as the PC)
- In the field below „Received Data“ now all settings of the SBS are displayed.




Fig. 318: Rescue / I

- Now the below shown Mac address can be entered into the field „Mac address of Sensor“.
- Into the lines below, all the network settings like, IP address, Subnet Mask etc., which the SBS should have after the next Restart (Power off/on), can be entered.
- Restart SBS .

Attention:

The after the next restart displayed data are the old ones as they are not refreshed by sensor restart.




Fig. 319: Rescue / 2

6 Image settings and accessories

6.1 Good images

To achieve good images follow these steps:

- Align the sensor to the desired field of view. Take care for stable mounting.
- For high contrast images adjust angles and illumination like described in chap. [The most important types of illumination are: Bright field, Dark field and Diffuse illumination..](#)
- Adjust a sharp image with the focus screw at the backside of the sensor housing.
- Adjust the brightness of the image with the parameter "Shutter speed" in Vision Sensor Configuration Studio/Job/Image acquisition. (Do not use parameter "Gain", not until you are not able to achieve desired brightness via "Shutter speed")

6.2 Environmental light, shrouding, IR- version

Mechanical shrouding

In most cases it's much simpler and highly cost effective to protect the scene against disturbing light or sun beams, which e.g. shine temporary at a certain time of day or season from windows or roof lights, by mechanical shrouding like metal plates, than to create illumination conditions, e.g. by additional illumination which is strong enough not to be disturbed in any situation.

Version with Infrared illumination

A further elegant way to get independent from the environmental light is to use the according SBS version with Infrared illumination. Here the scene get's illuminated with the built in powerful IR-illumination. The receiver is equipped with the according filter. That means the sensor works in a narrow range of this specific wavelength, and for that as far as possible with its own light only.

Another advantage of the infrared light is, that the light flashes are not visible and do not disturb any human workers which are near the plant.

6.3 External illumination

For the SBS a large range of accessories is available, which also covers a big range of external illuminations, which can be used additionally or instead of the internal illumination.

Further information on vision accessory: <http://www.Festo.com/de/download>.

The both types LF45 xxx and LFR I 15 xxx can be connected directly to the sensor.





Fig. 320: Connection of external illumination LF45 xxx and LFR45 xxxAll other listed types are connected to the SBS as follows.






Fig. 321: Connection of external illumination, all types except LF45 xxx and LFR115 xxx.

6.4 The most important types of illumination are: Bright field, Dark field and Diffuse illumination.

6.4.1 Bright field illumination

Bright field internal / Bright field external




Fig. 322: Bright field illumination

With bright field lighting, the lighting, sensor and object are arranged so that the object's surface reflects the light directly into the sensor. The smooth surface of the object appears as a bright area and each indentation, bump or defect, such as e.g. scratches, are a dark edge.

Attention: With bright field lighting, the angle of alignment between the lighting, object and sensor and the object's surface is critical as direct reflection by the object's surface only works when the angle and surface characteristics (shiny, mat, oily) are constant!

With Bright field / With Dark field




Fig. 323: Example Bright field illumination

By the direct reflection of the highly reflective (shiny) metal part, even before a white background, this is possible to be distinguished and recognized with Bright field illumination! With Dark field illumination it's not possible to distinguish between shiny metal part and white background!

6.4.2 Dark field illumination

Dark field internal / Dark field external




Fig. 324: Dark field illumination

With dark field illumination, the lighting, sensor and object are arranged so that the smooth surface of the object does not reflect the light directly into the sensor. Object edges (indentations and bumps) appear as bright areas, smooth object surfaces however are dark. This type of illumination functions with wide angle ranges and depends little on the object's surface.

With Bright field / With Dark field




Fig. 325: Example, Dark field

Edges are clearly accentuated with Dark field illumination.

6.4.3 Diffuse illumination (external only)

Diffuse external




Fig. 326: Diffuse illumination

Diffuse lighting is used everywhere where highly-reflective, curved and above all irregularly-shaped object surfaces are concerned (e.g. aluminium foil on blister packs etc.). Such objects cannot be illuminated with spot-shaped lighting, but only with diffuse lighting (i.e. even lighting from all directions). Diffuse lighting is also known as “cloudy day“ illumination, i.e. uniform light from behind the cover of clouds rather than from direct sunlight.

Spot illumination / Diffuse illumination




Fig. 327: Figure 218. Diffuse illumination

That means; clear homogeneous image with diffuse illumination! With any spot illumination the reflections of the aluminium foil from one part to another are always different.

6.5 IO-Box as IO-Extension (RS422)

Via the IO-Box the digital in- and outputs can be extended (8 inputs, 32 outputs), or an encoder controlled ejector can be realized. The connection and parameter setting of the I/O-Box is described in document:

„IO-Mounting and operating instructions“ in:

Startmenue/Festo/SBS Vision Sensor/Documentation/...

7 Technical Data

Electrical data			
Operating voltage	U _B 24 V DC, -25% / +10%		
Residual ripple	< 5 V _{ss}		
Current consumption (no I/O)	≤ 200 mA		
All inputs	PNP / NPN High > U _B - 1 V, Low < 3 V		
Input resistance	> 20 kOhm		
Encoder input	High > 4 V		
Outputs	PNP / NPN		
Maximum output current (per output)	50 mA, Ejector (Pin I2 / RDBU) 100 mA		
Short-circuit protection (all outputs)	yes		
Inductive load	typ.: Relays 17K / 2H, pneumatic valve 1.4K / 190mH		
Protection against inverse polarity	yes		
Interfaces SBS -XX-Standard	Ethernet (LAN)		
Interfaces SBS -XX-Advanced	Ethernet (LAN), RS422/RS232		
Readiness delay	Typ. 13 s after power on		
Optical data			
Number of pixels, chip size, pixel size	SBS - R3B...: 736 (H) x 480 (V), 1/3", 6,0 um square SBS - R2B...: 1280 (H) x 1024 (V), 1/1.8", 5,5 um square		
Technology	CMOS (mono / color)		
Integrated scan illumination	8 LEDs (except C-Mount)		
Integrated lens, focal length	6, 12 or 25 mm, adjustable focus		
	R3B	R3B	R2B
Lens (adjustable to infinity)	6	12	12
Min. scan distance	6	30	30
Min. field of view X x Y	5 x 4	8 x 6	16 x 13
Mechanical data			
Length x width x height	65 x 45 x 45 mm (without plug)		
Weight	approx. 160 g		
Vibration / shock	EN 60947-5-2		

Ambient operating temperature	0° C 50° C (80% humidity, non-condensing)
Storage temperature	-20° C ... 60° C (80% humidity, non-condensing)
Protective system	IP 65/67
Plug connection	24V DC and I/O M12 12-pin, LAN M12 4-pin, Data M12 5-pin
Housing material	aluminium, plastic
Function and characteristics	
Object detection	
Number of jobs / detectors	SBS -XX-Standard: 8 / 32 SBS -XX-Advanced: max. 255 / max. 255
Evaluation modes	<ul style="list-style-type: none"> • alignment • contour match with/without position detection • pattern match with/without position detection • area test grey level • area test contrast • area test brightness • direction info, or coordinates for position detection SBS -XX-Advanced: <ul style="list-style-type: none"> • Caliper, distances between edges • BLOB, object evaluation and counting
Typical cycle time	typ. 20 ms pattern matching typ. 30 ms contour typ. 2 ms area test
Code Reader	
Number of jobs / detectors	SBS -XX-Standard: 8 / 2 SBS -XX-Advanced / Professional: max. 255 / max. 255
Evaluation modes	<ul style="list-style-type: none"> • DataMatrix Code acc. ECC200 in any rotational position, square and Rectangular. • QR-Code, Model 1 and Model 2, Version 1 . . . 40 • Barcode Interleaved 2 of 5, Code 39, EAN13-Gruppe (EAN8, EAN13, UPC-A, UPC-E), EAN128 (Codes A, B, C) • OCR Optical character recognition (Professional) • position and size of field of view freely adjustable • logic operation of single configuration (AND, OR = sorting) • verify
Typical cycle time	40 ms one evaluation Coder reading, 10 ms per character OCR
Typical cycle time	100 ms for one evaluation
Color	
Number of jobs / detectors	SBS -XX-Standard: 8 / 32 SBS -XX-Advanced: max. 255 / max. 255
Evaluation modes	<ul style="list-style-type: none"> • alignment (Advanced) • contour match with/without position detection

	<ul style="list-style-type: none"> • pattern match with/without position detection • area test grey level • area test contrast • area test brightness • direction info, or coordinates for position detection • color value • color area • color list
Typical cycle time	<p>typ. 30 ms pattern match typ. 60 ms contour typ. 2 ms brightness typ. 2 ms contrast typ. 2 ms grey threshold typ. 2 ms colour value typ. 30 ms colour area typ. 2 ms colour list</p>
Universal	
Number of jobs / detectors	SBS R2B-ALL ... : max. 255 / max. 255
Evaluation modes / Typical cycle time	<p>All function as</p> <ul style="list-style-type: none"> • Object • Code Reader • Color

8 Addendum

8.1 Telegram, Data output

The following telegrams are available

[Serial Communication ASCII \(Page 316\)](#)

[Serial communication BINARY \(Page 338\)](#)

[EtherNet/IP Appendix \(Page 296\)](#)

8.1.1 Serial Communication ASCII

Data format of commands and data output

Communication settings

Communication	Ethernet	RS422
To Sensor, Command	Selectable in Tab: Protocol (Binary or ASCII)	
From Sensor, Data output	Selectable in Tab: Protocol (Binary or ASCII)	

Commands to sensor in ASCII

Trigger (ASCII) Request string to Sensor		
Byte no.	ASCII contents	Significance
1	T	Trigger, (simple trigger without index, via port 2006)
2	R	
3	G	
Trigger (ASCII) Response string from sensor		
Byte no.	Contents	Significance
1	T	Trigger, (response to trigger without index, via port 2006. If defined: result date without index via port 2005)
2	R	
3	G	
4	P F	Pass Fail
Additional information		
Accepted in run mode:		Yes
Accepted in configuration mode:		Yes
Accepted when Ready Low:		No
Status of Ready signal during processing:		Low
End of telegram		max. 4 byte (option)

Extended Trigger (ASCII) Request string to Sensor		
Byte no.	ASCII contents	Significance
1	T	Extended Trigger, (trigger with index, for correlation of trigger to the corresponding result data, via port 2006)
2	R	
3	X	
4	x	Length of following data (n)
5	x	
6...n	x	Data
Extended Trigger (ASCII) Response string from sensor		
Byte no.	ASCII contents	Significance
1	T	Extended Trigger, (reponse to trigger with index and result data, via port 2006, for correlation of trigger to the corresponding result. Result data without index via port 2005 also)
2	R	
3	X	
4	P F	Pass Fail
5	x	Length of following data (n)
6	x	
7...n	x	Data of request command
n+1	x	C = Config R = Run
n+2	x	Length of following result data (m)
n+3	x	
n+4	x	
n+5	x	
n+6	x	
n+7	x	
n+8	x	
n+9	x	Result data
n+9...m	x	

m+1	x	End of telegram (option, max 4 byte)
m+2	x	
m+3	x	
m+4	x	
Additional information		
Accepted in run mode:		Yes
Accepted in configuration mode:		Yes
Accepted when Ready Low:		No
Status of Ready signal during processing:		Low
End of telegram		max. 4 byte (option)

Job change-over (ASCII) Request String to Sensor		
Byte no.	ASCII contents	Significance
1	C	Change Job
2	J	
3	B	
4	x	Job number
5	x	
6	x	
Job change-over (ASCII) Response String from Sensor		
Byte no.	Contents	Significance
1	C	Change Job
2	J	
3	B	
4	P F	Pass Fail
5	T F	Triggered Free-run
6	x	Job number
7	x	
8	x	
Additional information:		

Accepted in run mode:	Yes
Accepted in configuration mode:	No
Accepted when Ready Low:	Yes
Status of Ready signal during processing:	Low
End of telegram	max. 4 byte (option)

Set parameter (ASCII)		
Byte No.	Contents	Significance
1	S	Set parameter
2	P	
3	P T	P Permanent T Temporary
4	X	Detector No.
5	X	
6	X	
7	X	Command: Set reference string / value *I), see below !
8	X	
9	X	
10	X	Length of reference string / value in Bytes (n)
11	X	
12	X	
13	X	
14	X	
15...n	X	Reference string / value
Set parameter (ASCII) Response string from Sensor		
Byte No.	Contents ASCII	Significance
1	S	Set parameter
2	P	
3	P T	P Permanent T Temporary
4	P F	P Pass F Fail

5	S	Parameter of type STRG (String) was set
6	T	
7	R	
8	G	
Additional information		
Accepted in run mode:		Yes
Accepted in configuration mode:		No
Accepted when Ready Low:		Yes
Status of Ready signal during processing:		Low
End of telegram		max. 4 byte (option)

***1) Byte No. 7: Command: set reference string / value:**

Detector	Function	Command
Alignment Pattern matching	Threshold Min	001
	Threshold Max	002
Alignment Contour	Threshold Min	001
	Threshold Max	002
Alignment Edge	Threshold Min	001
	Threshold Max	002
	Transition_Horizontal	101
	Transition_Vertical	102
Pattern matching	Threshold Min	001
	Threshold Max	002
Contour	Threshold Min	001
	Threshold Max	002
Grey Level	Threshold Min	001
	Threshold Max	002
	GreyMin	101
	GreyMax	102
Contrast	Threshold Min	001
	Threshold Max	002
Barcode	Reference String	101
Datocode	Reference String	101
OCR	Reference String	101
Color Value	ColorMinChannel I	101
	ColorMaxChannel I	102

	ColorInvertChannel1 ColorMinChannel2 ColorMaxChannel2 ColorInvertChannel2 ColorMinChannel3 ColorMaxChannel3 ColorInvertChannel3	103 104 105 106 107 108 109
ColorArea	ColorMinChannel1 ColorMaxChannel1 ColorInvertChannel1 ColorMinChannel2 ColorMaxChannel2 ColorInvertChannel2 ColorMinChannel3 ColorMaxChannel3 ColorInvertChannel3	101 102 103 104 105 106 107 108 109
BLOB	GreyAbsoluteMin GreyAbsoluteMax GreyAbsolutelInvert	101 102 103

Get parameter (ASCII)		
Byte No.	Contents	Significance
1	G	Get parameter
2	P	
3	A	
4	X	Detector No. e.g. 001
5	X	
6	X	
7	X	Command: Set reference string / value *1), see below !
8	X	
9	X	
Get parameter (ASCII) Response String from Sensor		
Byte No.	Contents	Significance
1	G	Get parameter
2	P	
3	A	
4	P F	P Pass F Fail
5	S	Parameter of type STRG (String) was read

6	T	
7	R	
8	G	
9	X	Length of Reference strings / value (n) z.B. 00005
10	X	
11	X	
12	X	
13	X	
14...n	X	Reference string / value
Additional information		
Accepted in run mode:		Yes
Accepted in configuration mode:		No
Accepted when Ready Low:		Yes
Status of Ready signal during processing:		no change
End of telegram		max. 4 byte (option)

***1) Byte No. 7: Command: Get reference string / value:**

Detector	Function	Command
Alignment Pattern matching	Threshold Min	001
	Threshold Max	002
Alignment Contour	Threshold Min	001
	Threshold Max	002
Alignment Edge	Threshold Min	001
	Threshold Max	002
	Transition_Horizontal	101
	Transition_Vertical	102
Pattern matching	Threshold Min	001
	Threshold Max	002
Contour	Threshold Min	001
	Threshold Max	002
Grey Level	Threshold Min	001
	Threshold Max	002
	GreyMin	101
	GreyMax	102
Contrast	Threshold Min	001
	Threshold Max	002

Barcode	Reference String	101
Datocode	Reference String	101
OCR	Reference String	101
Color Value	ColorMinChannel1	101
	ColorMaxChannel1	102
	ColorInvertChannel1	103
	ColorMinChannel2	104
	ColorMaxChannel2	105
	ColorInvertChannel2	106
	ColorMinChannel3	107
	ColorMaxChannel3	108
	ColorInvertChannel3	109
ColorArea	ColorMinChannel1	101
	ColorMaxChannel1	102
	ColorInvertChannel1	103
	ColorMinChannel2	104
	ColorMaxChannel2	105
	ColorInvertChannel2	106
	ColorMinChannel3	107
	ColorMaxChannel3	108
	ColorInvertChannel3	109
BLOB	GreyAbsoluteMin	101
	GreyAbsoluteMax	102
	GreyAbsoluteInvert	103

Get image (ASCII), not available for RS232/422		
Byte No.	Contents	Significance
1	G	Get image
2	I	
3	M	
4	X	0 – Last Image 1 – Last Failed Image 2 – Last Good Image
Get image (ASCII) Response String from Sensor		
Byte No.	Contents	Significance
1	G	Get image
2	I	
3	M	
4	P F	P Pass F Fail
5	X	Error type

		0 – Success, 1 – Recorder Off 2 – No Matching Image of requested type
6	X	Image type 0 - greyscale 1 – COLOR_BAYER_GB 2 – COLOR_BAYER_GR 3 – COLOR_BAYER_BG 4 – COLOR_BAYER_RG At conversion of the image from Bayer into RGB, the appropriate image type must be considered.
7	X	Image result 1 - good image 0 - failed image
8	X	No of rows e.g. 0480 / 0200
9	X	
10	X	
11	X	
12	X	No of columns e.g. 0640 / 0320
13	X	
14	X	
15	X	
16...n	X	Binary image data (rows * columns)
Additional information		
Accepted in run mode:	Yes	
Accepted in configuration mode:	No	
Accepted when Ready Low:	Yes	
Status of Ready signal during processing:	pulled low	
End of telegram	max. 4 byte (option)	

Set Shutter (ASCII)		
Byte No.	Contents	Significance
1	S	Set Shutter in active Job
2	S	
3	P	Permanent

	T	Temporary
4	X	Number of chars of shutter value, e.g. 04
5	X	
6	X	New shutter value in microseconds, e.g. 8000 = 8 ms
7	X	
8	X	
9	X	
Set Shutter (ASCII) Response String from Sensor		
Byte No.	Contents	Significance
1	S	Set Shutter
2	S	
3	P T	Permanent Temporary
4	P F	P Pass F Fail
Additional information		
Accepted in run mode:		Yes
Accepted in configuration mode:		No
Accepted when Ready Low:		Yes
Status of Ready signal during processing:		pulled low
End of telegram		max. 4 byte (option)

Get Shutter (ASCII, since version 1.6.5.3)		
Byte No.	Contents	Significance
1	G	Get shutter from active job
2	S	
3	H	
Get Shutter (ASCII) Response String from Sensor		
Byte No.	Contents	Significance
1	G	Get shutter
2	S	
3	H	
4	P F	P Pass

		F Fail
5	X	Shutter value length
6 .. n	X	Shutter value
Additional information		
Accepted in run mode:		Yes
Accepted in configuration mode:		No
Accepted when Ready Low:		Yes
Status of Ready signal during processing:		Not altered
End of telegram		max. 4 byte (option)

Set ROI (ASCII), not available for RS232/422		
Byte No.	Contents	Significance
1	S	Set ROI SRP0000005500100020016000000120000000800000004000000180000
2	R	Length55, Detector=1,yellow ROI, rectangle, centre X=160, centre Y=120, half width= 80, half height=40
3	P T	Permanent Temporary
4-11	X	ROI Info length in bytes from Byte 4 to end e.g. 00000055
12	X	Detector No. e.g. 001
13	X	
14	X	
15	X	ROI Index = 00 for yellow ROI
16	X	= 01 for red ROI
17	X	ROI shape 01=circle / 02=rectangle / 03=ellipse e.g. 02 for rectangle
18	X	
19-26	X	centre X (in pixels * 1000), e.g. 160 pixels = 00160000
27-34	X	centre Y (in pixels * 1000), e.g. 120 pixels = 00120000
35-42	X	half width / X-radius (in pixels * 1000), e.g. 80 Pixel = 0008000
43-50	X	half height / Y-radius (in pixels * 1000), e.g. 40 Pixel = 0004000
51-58	X	Angle (not at circle / ellipse) (in ° * 1000), e.g. 180° = 0018000

Set ROI (ASCII) Response String from Sensor		
Byte No.	Contents	Significance
1	S	Set ROI
2	R	
3	P T	Permanent Temporary
4	P F	P Pass F Fail
Additional information		
Accepted in run mode:	Yes	
Accepted in configuration mode:	No	
Accepted when Ready Low:	Yes	
Status of Ready signal during processing:	pulled low	
End of telegram	max. 4 byte (option)	

Get ROI (ASCII), not available for RS232/422		
Byte No.	Contents	Significance
1	G	Get ROI e.g. GRI00100
2	R	
3	I	
4	X	Detector No. e.g. 001
5	X	
6	X	
7	X	ROI Index = 00 for yellow ROI = 01 for red ROI
8	X	
Get ROI (ASCII) Response String from Sensor		
Byte No.	Contents	Significance
1	G	Get ROI
2	R	
3	I	
4	P F	P Pass

		F Fail
5-12	X	ROI Info length in bytes, from Byte 5 to end of string
13	X	Detector No.
14	X	
15	X	
16	X	ROI Index = 00 for yellow ROI
17	X	= 01 for red ROI
18	X	ROI shape 01=circle / 02=rectangle / 03=ellipse
19	X	
20-27	X	centre X (in pixels * 1000)
28-35	X	centre Y (in pixels * 1000)
36-43	X	X-radius (in pixels * 1000)
44-51	X	Y-radius (in pixels * 1000)
52-59	X	Angle (not at circle / ellipse) (in ° * 1000)
Additional information		
Accepted in run mode:		Yes
Accepted in configuration mode:		No
Accepted when Ready Low:		Yes
Status of Ready signal during processing:		pulled low
End of telegram		max. 4 byte (option)

Teach detector(ASCII)		
Byte No.	Content	Significance
1	T	Teach detector
2	E	
3	D	
4	X	Detector number 0 = Alignment >= 1 Detectors
5	X	
6	X	
7	X	Permanency 0 = Temporary 1 = Permanent
8	X	Trigger

		0 = no Trigger 1 = Trigger
Teach detector (ASCII) Response String from sensor		
Byte No.	Content	Significance
1	T	Teach detector
2	E	
3	D	
4	P F	P = Pass F = Fail
Additional information		
Accepted in run mode:		Yes
Accepted in configuration mode:		No
Accepted when Ready Low:		Yes
Status of Ready signal during processing:		pulled low
End of telegram		max. 4 byte (option)

Calibration Add Point (ASCII), request string (from PLC)		
Byte No.	Content	Significance
1	C	Calibration Add Point
2	A	
3	P	
4-8	X	List index of calibration point pair 0: attach new point at end of list >0: overwrite point at existing index position 1: first point in list
9-16	X	World X
17-24	X	World Y
Example	CAP123451234567812345678	
Calibration Add Point (ASCII) response String (from sensor)		
Byte No.	Content	Significance
1	C	Calibration Add Point
2	A	
3	P	
4	P	P: Pass

	F	F: Fail
5-12	X	Image X
13-20	X	Image Y
Example	CAPPI23451234567812345678	
Additional information		
Accepted in Run mode	Yes	
Accepted in Config mode	No	
Accepted when Ready is Low	Yes	
Status of Ready signal during processing	Not altered	
Supported Interfaces	UserApp	
End of telegram	max. 4 byte (option)	
Necessary settings in requesting job	In "Output/Telegram/Payload" as first and second value the X- and Y-value of the finding position must be set.	

Calibration Calibrate (ASCII), request string (from PLC)		
Byte No.	Content	Significance
1	C	Calibration Calibrate
2	C	
3	L	
4	X	Permanency 0 = Temporary 1 = Permanent
Example	CCLI	
Calibration Calibrate (ASCII) response String (from sensor)		
Byte No.	Content	Significance
1	C	Calibration Calibrate
2	C	
3	L	
4	P F	P: Pass F: Fail
5-9	X	Current highest point pair index
10-17	X	RMSE (Root Mean Square Error)
18-25	X	Mean

26-33	X	Max
34-41	X	Min
Example	CCLP0001012345678123456781234567812345678	
Additional information		
Accepted in Run mode	Yes	
Accepted in Config mode	No	
Accepted when Ready is Low	Yes	
Status of Ready signal during processing	Not altered	
Supported Interfaces	UserApp	
End of telegram	max. 4 byte (option)	

Calibration Clear (ASCII), request string (from PLC)		
Byte No.	Content	Significance
1	C	Calibration Clear
2	C	
3	D	
Example	CCD	
Calibration Clear (ASCII) response String (from sensor)		
Byte No.	Content	Significance
1	C	Calibration Clear
2	C	
3	D	
4	P F	P: Pass F: Fail
Example	CCDP	
Additional information		
Accepted in Run mode	Yes	
Accepted in Config mode	No	
Accepted when Ready is Low	Yes	
Status of Ready signal during processing	Not altered	
Supported Interfaces	UserApp	
End of telegram	max. 4 byte (option)	

Calibration Validate (ASCII), request string (from PLC)		
Byte No.	Content	Significance
1	C	Calibration Validate
2	V	
3	L	
Example	CVL	
Calibration Validate (ASCII) response String (from sensor)		
Byte No.	Content	Significance
1	C	Calibration Validate
2	V	
3	L	
4	P F	P: Pass F: Fail
5-9	X	Current highest point pair index
10-17	X	RMSE (Root Mean Square Error)
18-25	X	Mean
26-33	X	Max
34-41	X	Min
Example	CVLP0001012345678123456781234567812345678	
Additional information		
Accepted in Run mode		Yes
Accepted in Config mode		No
Accepted when Ready is Low		Yes
Status of Ready signal during processing		Not altered
Supported Interfaces		UserApp
End of telegram		max. 4 byte (option)

Set Gain (ASCII), request string (from PLC)		
Byte No.	Content	Significance
1	S	Set Shutter in active Job
2	S	
3	P	Permanent

	T	Temporary
4	X	Number of chars of shutter value, e.g. 04
5	X	
6	X	New shutter value in microseconds, e.g. 8000 = 8 ms
7	X	
8	X	
9	X	
Set Shutter (ASCII) Response String from Sensor		
Byte No.	Contents	Significance
1	S	Set Shutter
2	S	
3	P	Permanent
	T	Temporary
4	P	P Pass
	F	F Fail
Additional information		
Accepted in run mode:		Yes
Accepted in configuration mode:		No
Accepted when Ready Low:		Yes
Status of Ready signal during processing:		pulled low
End of telegram		max. 4 byte (option)

Set Gain (ASCII), request string from PLC		
Byte No.	Content	Significance
1	S	Set Gain
2	G	
3	A	
4	1	1 = Permanent
	0	0 = Temporary

5	X	New Gain Value
6	X	
7	X	
8	X	
9	X	
Set Gain (ASCII), response string from sensor		
Byte No.	Content	Significance
1	S	Set Gain
2	G	
3	A	
4	P F	P = Pass F = Fail
5-9	X	Current Gain value
Additional information		
Accepted in run mode:		Yes
Accepted in configuration mode:		No
Accepted when Ready Low:		Yes
Status of Ready signal during processing:		not altered
End of telegram		max. 4 byte (option)

Data output in ASCII

Dynamically composed from user settings in the software

For detailed informations to the file format see also: [Telegram, Data output \(Page 189\)](#)

<START> (((<OPTIONAL FIELDS> <SEPARATOR> <PAYLOAD>))) <CHKSUM> <TRAILER>

Output data (ASCII), dynamically composed from user settings in the software

Name	Number of bytes	ASCII contents / example	Significance /Comments
Header	1 - max. 8	User defined, max. 8 characters	Start string (Header)
Separator	1 - 5	User defined, max. 5 characters (per separator)	Separator from: "after first optional field", or „after first detector spec. date“
Selected Fields	16	1 Byte per field	by this field output of all active checkboxes "byte-wise" can be activated - Output order is from left to right and from top to down.

			<p>- For each checkbox there is one byte beginning with LSB = low significant bit.</p> <p>- Checkbox "Selected fields" is not part of the output!</p> <p>P = logical output set</p> <p>F = logical output not set</p> <p>0 = logical output not active</p>
Data length	n	<p>One byte per figure of decimal number</p> <p>e.g. 102 „1“; „0“; „2“</p>	Length of telegram in bytes
Status	3	<p>“110” triggered mode</p> <p>or</p> <p>“101” free-run mode</p>	
Detector result	n	<p>Byte 1 = AND conjunction of all detectors</p> <p>Byte 2 = Boolean result of alignment</p> <p>Byte 3 = global result of the active job</p> <p>Following Bytes: number of detectors</p> <p>Following Bytes: Detector results, "P" = Pass, "F" = Fail, last byte is first detector</p> <p>Length: 4 Byte + 1 Byte per each used detector</p>	
Digital outputs	n	<p>First Bytes: number of active outputs</p> <p>Following Bytes: digital outputs</p>	<p>P = logical output set</p> <p>F = logical output not set</p> <p>0 = logical output not active</p>
Logical outputs	n	<p>First Bytes: number of active logical outputs</p> <p>Following Bytes: logical</p>	<p>Example: 18 logical outputs are configured, but only output 1, 2 and 9 are linked to functions (are active):</p> <p>3PP000000P</p>

		outputs	2 bytes number of active outputs, all results bit-coded ... In this example there are needed 2 bytes because of output 9.... P = logical output set F = logical output not set 0 = logical output not active
Total exec. time	n		Current (job) cycle time in [ms]
Active job no.	1-3		Active job no. (1..255)
<<Detector specific>>			
Detector result	1	P = Pass F = Fail	Boolean detector result
Score value 1 .. n	1-3		Score (0..100%)
Execution time	n		Execution time of individual detector in [msec].
Distance	n		Calculated distance, [1/1000]*1)
Position X 1 .. n	n	e.g.: X = 180 (pix) = (in ASCII) "180000" = 6 Byte	Position found X (x-coordinate). [1/1000]*1)
Position Y 1 .. n	n		Position found Y (y-coordinate). [1/1000]*1)
DeltaPos X	n		Delta position X between object taught and object found [1/1000]*1)
DeltaPos Y	n		Delta position X between object taught and object found [1/1000]*1)
Angle	n		Orientation of object found (0°..360°) [1/1000]*1)
Delta Angle	n		Angle between object taught and object found (0°..360°) [1/1000]*1)
Scaling	n		Only with contour (0.5..2) [1/1000]*1)
Result horizontal	1	P = Pass F = Fail	Boolean result of horizontal edge detection of alignment
Result vertical	1	P = Pass F = Fail	Boolean result of horizontal edge detection of alignment
Score horizontal	1-3		Score 0..100% (alignment only using edge detection)
Score vertical	1-3		Score 0..100% (alignment using edge detection)

R(ed)	n		Value for color parameter
G(reen)	n		Value for color parameter
B(lue)	n		Value for color parameter
H(ue)	n		Value for color parameter
S(aturation)	n		Value for color parameter
V(alue)	n		Value for color parameter
L(uminanz)	n		Value for color parameter
A	n		Value for color parameter
B	n		Value for color parameter
Result index	n		Index in list
Color distance	n		Distance between taught and current color
Area	n		Area of the BLOB, without holes, in pixels
Area (incl. holes)	n		Area of the BLOB, including holes, in pixels
Contour length	n		Number of pixels of outer contour
Compactness	n		Compactness of BLOB (Circle = 1, all other > 1) The stronger the shape of the BLOB deviates from circle the larger the value of compactness will be.
Center of gravity X	n		X- coordinate of center of gravity of BLOB
Center of gravity Y	n		Y- coordinate of center of gravity of BLOB
Center X	n		X- coordinate of fitted, geometric element (rectangle, ellipse)
Center Y	n		Y- coordinate of fitted, geometric element (rectangle, ellipse)
Width	n		Width of geometric element. Width >= 0, width >= height, negative value indicates failure
Height	n		Height of geometric element. Height >= 0, height <= width, negative value indicates failure
Angle (360)	n		Orientation of width of object in degree (range: -180 ... +180°, 0° = east, counterclockwise)
Eccentricity	n		Eccentricity numerical (range 0,0 ... 1,0)
Face up/down, area	n		Face up/down discrimination, based on area, indicated by sign
String	1...n	Maximum length 127!!	Contents of Code, depending from code string length may change, if a fix string length is needed, parameters minimum string length (detector specific data output) and maximum string length (detector parameters) have to be used.
String length	n		Length of Code in Bytes

Truncated	1	F = Code complete, P = Code truncated	Code truncated
Checksum	3		XOR checksum of all bytes in telegram
Trailer	1 - max. 8	User defined, max. 8 characters	End of string (Trailer)

*1) All detector-specific data with decimal places are transmitted as whole numbers (multiplied by 1000) and must therefore be divided by 1000 after receipt of data.

8.1.2 Serial communication BINARY

Data format of commands and data output

Communication settings

Communication	Ethernet	RS422
To Sensor, Command	Selectable in Tab: Protocol (Binary or ASCII)	
From Sensor, Data output	Selectable in Tab: Protocol (Binary or ASCII)	

Commands to sensor in BINARY

Trigger (Binary) Request string to sensor			
Byte no.	Data type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x05	
5	Unsigned Char	0x01	Trigger command, (simple trigger without index, via port 2006)
Trigger (Binary) Answer string from sensor			
Byte no.	Data type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x07	
5	Unsigned Char	0x01	Trigger command, (response to trigger without index, via port 2006. If defined: result data without index via port 2005)
6	Unsigned	0x00	Error code, 0 = Pass, 1 = Fail

	Short		
7		0xXX	
Additional information			
Accepted in run mode:		Yes	
Accepted in configuration mode:		Yes	
Accepted when Ready Low:		No	
Status of Ready signal during processing:		Low	

Extended Trigger (Binary) Request string to sensor			
Byte no.	Data type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x05	
5	Unsigned Char	0x013	Extended Trigger command, (trigger with index for correlation of trigger to the corresponding result data, via port 2006)
6	Unsigned Char	0xXX	Length of following data (n)
7...n	Unsigned Char	0xXX	Data
Extended Trigger (Binary) Answer string from sensor			
Byte no.	Data type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x07	
5	Unsigned Char	0x013	Extended Trigger command, (response to trigger with index and result data, via port 2006, for correlation of trigger to corresponding result, Result data without index, via port 2005 also)
6	Unsigned Short	0x00	Error code 0 = Pass
7		0xXX	1 = Fail

8	Unsigned Char	0xXX	Length of following data (n)
9...n	Unsigned Char	0xXX	Data of request command
n+1	Unsigned Char □	0xXX	Operating mode 0 = Config Mode 1 = Run Mode
n+2	Unsigned Int	0xXX	Length of following result data (m)
n+3		0xXX	
n+4		0xXX	
n+5		0xXX	
n+6	Unsigned Int □	0xXX	Result data
n+7		0xXX	
n+8		0xXX	
n+9...m		0xXX	
Additional information			
Accepted in run mode:		Yes	
Accepted in configuration mode:		Yes	
Accepted when Ready Low:		No	
Status of Ready signal during processing:		Low	
Job change-over (Binary) Request string to sensor			
Byte no.	Data type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x06	
5	Unsigned Char	0x02	Job change-over command
6	Unsigned Char	0xXX	Job no, XX = 1 - n
Job change-over (binary) Answer string from sensor			
Byte no.	Data type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram

2		0x00	
3		0x00	
4		0x09	
5	Unsigned Char	0x02	
6	Unsigned Short	0x00	Error code, 0 = Pass, 1 = Fail
7		0xXX	
8	Unsigned Char	0xXX	Trigger mode 0 = triggered 1 = free-run
9	Unsigned Char	0xXX	Job no, XX = 1 - n
Additional information			
Accepted in run mode:		Yes	
Accepted in configuration mode:		No	
Accepted when Ready Low:		Yes	
Status of Ready signal during processing:		Low	

Set parameter (Binary) Request string to Sensor			
Byte no.	Data type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram = 9 Bytes + length of string (n)
2		0x00	
3		0x00	
4		0xn	
5	Unsigned Char	0x05 0x06	Command set parameter permanent Command set parameter temporary
6	Unsigned Char	0xXX	Detector no., XX = 1 - n
7	Unsigned Char	0x65	Command: Set reference string 7 value *1), see below !
8	Unsigned Short	0x00	Length new reference string / value (n)
9		0x0n	
10..n	Unsigned Char	0xn	Reference string / value
Set parameter (Binary) Response string from Sensor (may be 4-5 seconds delayed)			

Byte no.	Data type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x08	
5	Unsigned Char	0x05 0x06	ID set reference string permanent ID set reference string temporary
6	Unsigned Short	0xXX	Error Code 00 00 = Pass Error Code 00 01 = Fail
7		0xXX	
8	Unsigned Char	0x0A	Parameter type string
Additional information			
Accepted in run mode:			Yes
Accepted in configuration mode:			No
Accepted when Ready Low:			Yes
Status of Ready signal during processing:			Low

***1) Byte No. 7: Command: set reference string / value:**

Detector	Function	Command	Length of following data
Alignment Pattern matching	Threshold Min	1	4
	Threshold Max	2	4
Alignment Contour	Threshold Min	1	4
	Threshold Max	2	4
Alignment Edge	Threshold Min	1	4
	Threshold Max	2	4
	Transition_Horizontal	101	4
	Transition_Vertical	102	4
Pattern matching	Threshold Min	1	4
	Threshold Max	2	4
Contour	Threshold Min	1	4
	Threshold Max	2	4
Grey Level	Threshold Min	1	4
	Threshold Max	2	4
	GreyMin	101	4
	GreyMax	102	4

Contrast	Threshold Min	1	4
	Threshold Max	2	4
Barcode	Reference String	101	n
Datacode	Reference String	101	n
OCR	Reference String	101	n
ColorValue	ColorMinChannel1	101	4
	ColorMaxChannel1	102	4
	ColorInvertChannel1	103	4
	ColorMinChannel2	104	4
	ColorMaxChannel2	105	4
	ColorInvertChannel2	106	4
	ColorMinChannel3	107	4
	ColorMaxChannel3	108	4
	ColorInvertChannel3	109	4
ColorArea	ColorMinChannel1	101	4
	ColorMaxChannel1	102	4
	ColorInvertChannel1	103	4
	ColorMinChannel2	104	4
	ColorMaxChannel2	105	4
	ColorInvertChannel2	106	4
	ColorMinChannel3	107	4
	ColorMaxChannel3	108	4
	ColorInvertChannel3	109	4
BLOB	GreyAbsoluteMin	101	4
	GreyAbsoluteMax	102	4
	GreyAbsoluteInvert	103	1

Get parameter (Binary) Request string to Sensor			
Byte no.	Data type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x07	
5	Unsigned Char	0x0A	Command get parameter
6	Unsigned Char	0xn	Detector no., XX = 1 - n
7	Unsigned Char	0x65	Command: Set reference string / value *1), see below !
Get Parameter (Binary) Response string from Sensor (may be 4-5 Seconds delayed)			
Byte no.	Data type	Contents	Significance

1	Unsigned Int	0x00	Length of telegram = 10 Bytes + Length of string (n)
2		0x00	
3		0x00	
4		0x0n	
5	Unsigned Char	0x0A	ID get parameter
6	Unsigned Short	0xXX	Error Code 00 00 = Pass Error Code 00 01 = Fail
7		0xXX	
8	Unsigned Char	0x0A	Parameter type string
9	Unsigned Short	0x00	Length of parameter (n)
10		0x0n	
11..n	Unsigned Char	0xn	Reference string / value
Additional information			
Accepted in run mode:			Yes
Accepted in configuration mode:			No
Accepted when Ready Low:			Yes
Status of Ready signal during processing:			No change

***1) Byte No. 7: Command: Get reference string / value:**

Detector	Function	Command	Length of following data
Alignment Pattern matching	Threshold Min	1	4
	Threshold Max	2	4
Alignment Contour	Threshold Min	1	4
	Threshold Max	2	4
Alignment Edge	Threshold Min	1	4
	Threshold Max	2	4
	Transition_Horizontal	101	4
	Transition_Vertical	102	4
Pattern matching	Threshold Min	1	4
	Threshold Max	2	4
Contour	Threshold Min	1	4
	Threshold Max	2	4
Grey Level	Threshold Min	1	4
	Threshold Max	2	4
	GreyMin	101	4

	GreyMax	102	4
Contrast	Threshold Min	1	4
	Threshold Max	2	4
Barcode	Reference String	101	n
Datacode	Reference String	101	n
OCR	Reference String	101	n
ColorValue	ColorMinChannel1	101	4
	ColorMaxChannel1	102	4
	ColorInvertChannel1	103	4
	ColorMinChannel2	104	4
	ColorMaxChannel2	105	4
	ColorInvertChannel2	106	4
	ColorMinChannel3	107	4
	ColorMaxChannel3	108	4
	ColorInvertChannel3	109	4
ColorArea	ColorMinChannel1	101	4
	ColorMaxChannel1	102	4
	ColorInvertChannel1	103	4
	ColorMinChannel2	104	4
	ColorMaxChannel2	105	4
	ColorInvertChannel2	106	4
	ColorMinChannel3	107	4
	ColorMaxChannel3	108	4
	ColorInvertChannel3	109	4
BLOB	GreyAbsoluteMin	101	4
	GreyAbsoluteMax	102	4
	GreyAbsoluteInvert	103	1

Get image (Binary) Request string to Sensor, not available with RS232/RS422			
Byte No.	Data type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x06	
5	Unsigned Char	0x03	Get image
6	Unsigned Char	0xXX	0 – Last Image 1 – Last Failed Image 2 – Last Good Image
Get image (Binary) Response String from Sensor			
Byte No.	Data type	Contents	Significance

1	Unsigned Int	0xXX	Length of telegram e.g. 00 04 B0 0D
2		0xXX	
3		0xXX	
4		0xXX	
5	Unsigned Char	0x03	Response ID Get image
6	Unsigned short	0xXX	Error code 00 00 – Success, 00 01 – Recorder Off 00 02 – No Matching Image of requested type
7		0xXX	
8	Unsigned Char	0xXX	Image type 0 - greyscale 1 – COLOR_BAYER_GB 2 – COLOR_BAYER_GR 3 – COLOR_BAYER_BG 4 – COLOR_BAYER_RG At conversion of the image from Bayer into RGB, the appropriate image type must be considered. Pre- processing filters of category "Arrangement" do influence the Bayer- type.
9	Unsigned Char	0xXX	Image result 01 - good image 00 - failed image
10	Unsigned short	0xXX	No of rows e.g. 01 E0
11		0xXX	
12	Unsigned short	0xXX	No of columns e.g. 02 80
13		0xXX	
14...n	Unsigned Char	0xXX	Binary image data (rows * columns)
Additional information			
Accepted in run mode:			Yes
Accepted in configuration mode:			No
Accepted when Ready Low:			Yes
Status of Ready signal during processing:			Pulled low

Set Shutter (Binary) Request string to Sensor			
Byte No.	Data Type	Contents	Significance

1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x09	
5	Unsigned Char	0x0E 0x0F	Command set shutter temporary Command set shutter permanent
6	Unsigned Int	0xXX	Shutter value (in microseconds)
7		0xXX	
8		0xXX	
9		0xXX	

Set Shutter (Binary) Response String from Sensor

Byte No.	Data Type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x07	
5	Unsigned Char	0x0E 0x0F	ID set shutter temporary ID set shutter permanent
6	Unsigned Short	0x00	Error Code 00 00 = Pass
7	0xXX		Error Code 00 01 = Fail

Additional information

Accepted in run mode:	Yes
Accepted in configuration mode:	No
Accepted when Ready Low:	Yes
Status of Ready signal during processing:	Pulled Low

Get Shutter (Binary), Request string to Sensor (since version 1.6.5.3)

Byte No.	Data type	Contents	Significance
1	Unsigned int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x05	
5	Unsigned Char	0x17	Request ID, Get shutter

Get Shutter (Binary) Response String from Sensor			
1	Unsigned int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x0B	
5	Unsigned Char	0x17	Request ID, Get shutter
6	Unsigned short	0xXX	0 - Pass 1 - Fail 2 - Unused 3 - Insufficient parameter data 4 - Command rejected, simultaneous module requests received
7		0xXX	
8	Unsigned int	0xXX	Shutter value
9		0xXX	
10		0xXX	
11		0xXX	
Additional information			
Accepted in run mode:			Yes
Accepted in configuration mode:			No
Accepted when Ready Low:			Yes
Status of Ready signal during processing:			Not altered

Set ROI (Binary) Request string to Sensor, not available with RS232/RS422			
Byte No.	Data Type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x20	
5	Unsigned Char	0x10	Command set ROI temporary
		0x11	Command set ROI permanent
6	Unsigned Int	0xXX	ROI Info Length in Bytes from Byte 6 to end
7		0xXX	
8		0xXX	
9		0xXX	
10	Unsigned Char	0xXX	Detector No.

11	Unsigned Char	0x00	ROI Index = 00 = yellow ROI
12	Unsigned Char	0xXX	ROI shape 01=circle / 02=rectangle / 03=ellipse
13	Unsigned Int	0xXX	ROI Parameter: centre X (in Pixels * 1000)
14		0xXX	
15		0xXX	
16		0xXX	
17	Unsigned Int	0xXX	ROI Parameter: centre Y (in Pixels * 1000)
18		0xXX	
19		0xXX	
20		0xXX	
21	Unsigned Int	0xXX	ROI Parameter: width / radius X (in Pixels* 1000)
22		0xXX	
23		0xXX	
24		0xXX	
25	Unsigned Int	0xXX	Only ellipse / rectangle: ROI Parameter: width / radius Y (in Pixels* 1000)
26		0xXX	
27		0xXX	
28		0xXX	
29	Unsigned Int	0xXX	Only ellipse / rectangle: ROI Parameter: Angle in ° (in ° * 1000)
30		0xXX	
31		0xXX	
32		0xXX	
Set ROI (Binary) Response String from Sensor			
Byte No.	Data Type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x07	
5	Unsigned Char	0x10 0x11	ID set ROI temporary ID set ROI permanent
6	Unsigned Short	0x00	Error Code 00 00 = Pass
7		0xXX	Error Code 00 01 = Fail
Additional information			

Accepted in run mode:	Yes
Accepted in configuration mode:	No
Accepted when Ready Low:	Yes
Status of Ready signal during processing:	Pulled Low

Get ROI (Binary) Request string to Sensor, not available with RS232/RS422			
Byte No.	Data Type	Content	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x07	
5	Unsigned Char	0x12	Command get ROI
6	Unsigned Char	0xXX	Detector No.
7	Unsigned Char	0xXX	ROI Index = 00 = yellow ROI
Get ROI (Binary) Response String from Sensor			
Byte No.	Data Type	Contents	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x34	
5	Unsigned Char	0x12	ID get ROI
6	Unsigned Short	0x00	Error Code 00 00 = Pass
7		0xXX	Error Code 00 01 = Fail
8	Unsigned Int	0xXX	ROI Info Length in Bytes from Byte 8 to end
9		0xXX	
10		0xXX	
11		0xXX	
12	Unsigned Char	0xXX	Detector No.
13	Unsigned Char	0x00	ROI Index = 00 = yellow ROI
14	Unsigned Char	0xXX	ROI shape 01=circle / 02=rectangle / 03=ellipse

15	Unsigned Int	0xXX	ROI Parameter: centre X (in Pixels * 1000)
16		0xXX	
17		0xXX	
18		0xXX	
19	Unsigned Int	0xXX	ROI Parameter: centre Y (in Pixels * 1000)
20		0xXX	
21		0xXX	
22		0xXX	
23	Unsigned Int	0xXX	ROI Parameter: width / radius X (in Pixels* 1000)
24		0xXX	
25		0xXX	
26		0xXX	
27	Unsigned Int	0xXX	Only ellipse / rectangle: ROI Parameter: width / radius Y (in Pixels* 1000)
28		0xXX	
29		0xXX	
30		0xXX	
31	Unsigned Int	0xXX	Only ellipse / rectangle: ROI Parameter: Angle in ° (in ° * 1000)
32		0xXX	
33		0xXX	
34		0xXX	
Additional information			
Accepted in run mode:			Yes
Accepted in configuration mode:			No
Accepted when Ready Low:			Yes
Status of Ready signal during processing:			Pulled Low

Teach Detektor (Binary) Request string to Sensor			
Byte No.	Data Type	Content	Significance

1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x07	
5	Unsigned Char	0x18	Command Teach Detektor
6	Unsigned Char	0xXX	Detector number 0 = Alignment >= 1 Detectors
7	Unsigned Char	0xXX	Permanency 0 = Temporary 1 = Permanent
8	Unsigned Char	0xXX	Trigger 0 = no Trigger 1 = Trigger

Teach Detector (Binary) Response- String from sensor

Byte No.	Data Type	Content	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x07	
5	Unsigned Char	0x18	Command Teach Detector
6	Unsigned Short	0xXX	Error Code 0 = Pass 1 = Fail 2 = Unused
7		0xXX	3 = Insufficient parameter data 4 = Command rejected, simultaneous module requests received

Additional information

Accepted in run mode:	Yes
Accepted in configuration mode:	No
Accepted when Ready Low:	Yes
Status of Ready signal during processing:	Not altered

Calibration Add Point (Binary) Request string to Sensor

Byte No.	Data Type	Content	Significance
----------	-----------	---------	--------------

1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x10	
5	Unsigned Char	0x1D	Command Calibration Add Point
6	Unsigned Short	0xXX	List index of calibration point pair 0: attach new point at end of list >0: overwrite point at existing index position 1: first point in list
7		0xXX	
8-11	Unsigned Int	0xXX	World X
12-15	Unsigned Int	0xXX	World Y

Calibration Add Point (Binary) Response string from Sensor

1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x0F	
5	Unsigned Char	0x1D	Command Calibration Add Point
6	Unsigned Short	0xXX	Error Code 0: Pass 1: Fail 2: Unused 3: Unsufficient parameter data 4: Command rejected, simultaneous module request received
7		0xXX	
8-11	Unsigned Int	0xXX	Image X
12-15	Unsigned Int	0xXX	Image Y

Additional information

Accepted in run mode:	Yes
Accepted in configuration mode:	No
Accepted when Ready Low:	Yes
Status of Ready signal during processing:	Not altered
Supported interfaces	UserApp, Profinet
Necessary settings in requesting job	In "Output/Telegram/Payload" as first and second value the X- and Y- value of the finding position must be set.

Calibration Calibrate (Binary) Request string to Sensor

Byte No.	DataType	Content	Significance
----------	----------	---------	--------------

1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x05	
5	Unsigned Char	0x1E	Command Calibration Calibrate
6	Unsigned Char	0xXX	Permanency 0 = Temporary 1 = Permanent
Calibration Calibrate (Binary) Response string from Sensor			
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x17	
5	Unsigned Char	0x1E	Command Calibration Calibrate
6	Unsigned Short	0xXX	Error Code 0: Pass 1: Fail 2: Unused 3: Unsufficient parameter data 4: Command rejected, simultaneous module request received
7			
8-9	Unsigned Short	0xXX	Current highest point pair index
10-13	Unsigned Int	0xXX	RMSE (Root Mean Square Error)
14-17	Unsigned Int	0xXX	Mean
18-21	Unsigned Int	0xXX	Max
22-25	Unsigned Int	0xXX	Min
Additional information			
Accepted in run mode:			Yes
Accepted in configuration mode:			No
Accepted when Ready Low:			Yes
Status of Ready signal during processing:			Not altered
Supported interfaces			UserApp, Profinet

Calibration Clear (Binary) Request string to Sensor			
Byte No.	Data Type	Content	Significance

1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x05	
5	Unsigned Char	0x1F	Command Calibration Clear
Calibration Clear (Binary) Response string from Sensor			
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x07	
5	Unsigned Char	0x1F	Command Calibration Clear
6	Unsigned Short	0xXX	Error Code 0: Pass 1: Fail 2: Unused 3: Unsufficient parameter data 4: Command rejected, simultaneous module request received
7		0xXX	
Additional information			
Accepted in run mode:			Yes
Accepted in configuration mode:			No
Accepted when Ready Low:			Yes
Status of Ready signal during processing:			Not altered
Supported interfaces			UserApp, Profinet

Calibration Validate (Binary) Request string to Sensor			
Byte No.	Data Type	Content	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x05	
5	Unsigned Char	0x20	Command Calibration Validate
Calibration Validate (Binary) Response string from Sensor			

1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x17	
5	Unsigned Char	0x20	Command Calibration Validate
6	Unsigned Short	0xXX	Error Code 0: Pass 1: Fail 2: Unused 3: Unsufficient parameter data 4: Command rejected, simultaneous module request received
7		0xXX	
8-9	Unsigned Short	0xXX	Current highest point pair index
10-13	Unsigned Int	0xXX	RMSE (Root Mean Square Error)
14-17	Unsigned Int	0xXX	Mean
18-21	Unsigned Int	0xXX	Max
22-25	Unsigned Int	0xXX	Min
Additional information			
Accepted in run mode:			Yes
Accepted in configuration mode:			No
Accepted when Ready Low:			Yes
Status of Ready signal during processing:			Not altered
Supported interfaces			UserApp, Profinet

Set Gain (Binary) Request string to Sensor			
Byte No.	Data Type	Content	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x0A	
5	Unsigned Char	0x1B	Set Gain
6	Unsigned Char	0xXX	1 = Permanent 0 = Temporary

7	Unsigned Int	0xXX	Gain value
8		0xXX	
9		0xX	
10		0xXX	
Set Gain (Binary) Response string from Sensor			
Byte No.	Data Type	Content	Significance
1	Unsigned Int	0x00	Length of telegram
2		0x00	
3		0x00	
4		0x0B	
5	Unsigned Char	0x1B	Set Gain
6	Unsigned Short		Error Code 0: Pass 1: Fail 2: Unused 3: Unsufficient parameter data 4: Command rejected, simultaneous module request received
7		0xXX	
8	Unsigned Int	0xXX	Current Gain value
9		0xXX	
10		0xXX	
11		0xXX	
Additional information			
Accepted in run mode:			Yes
Accepted in configuration mode:			No
Accepted when Ready Low:			Yes
Status of Ready signal during processing:			Not altered

Data output from sensor in BINARY

dynamically composed from user settings in the software

For detailed informations to the file format see also: [Telegram, Data output \(Page 189\)](#)

Main string structure:<START> <OPTIONAL FIELDS> <PAYLOAD> <CHKSUM> <TRAILER>

Output data (BINARY), dynamically composed from user settings in the software			
Name	Number of bytes	Binary contents / Example	Significance /Comments
Start	1 - max. 8	User defined,	Start string (Header)

		max. 8 Bytes	
Selected fields	2 (Word)	1 Bit per field	By this field output of all active checkboxes "bit-wise" (in 2Bytes!) can be activated - Output order is from left to right and from top to down. - For each checkbox there is one bit (high/low) beginning with LSB = low significant bit. - Checkbox "Selected fields" is not part of the output!
Data length	2 (Word)	e.g. 0x00, 0x02 = length = 2 Byte	Length of telegram in Bytes
Status	2 (Word)	e.g. 0x00, 0x06 (triggered) e.g. 0x00, 0x05 (free-run)	Byte1: 0000xxx Bit0 = 1 = <Free-run> Bit1 = 1 = <triggered> Bit2 = <Op.mode> (1=run/0=config) Byte2 (reserved), always 0x00
Detector result	4..n	e.g.. 0x05 (Bit1+3=5) 0x00 (two bytes number of detectors) 0x01 0x01 (Detector result D1)	Byte 1 Bit1 (LSB) = global job result (1 = Pass, 0 = Fail) Bit2 = Boolean result, alignment only, alignment inactive = true Bit3 = AND conjunction of all detectors of the active job Byte 2 and 3 two bytes for the number of detectors inside job (without alignment) Byte 4 - n 1 Byte per each block of 8 used detectors e.g.: Bit1 (LSB) = Detector 1, Bit2 = Det. 2,
Digital outputs	n	Byte 1 and 2: number of active outputs Bytes 3 ... n: outputs, bit-coded	Results of all digital outputs (bit-coded)
Logical outputs	n	Byte 1 ... 2 number of active logical outputs Byte 3 ... n all active logical outputs, bit-coded	Example: 18 logical outputs are configured, but only output1,2 and 9 are linked to functions (are active): 000, 003, 003, 001 2 bytes number of active outputs, all results bit-coded ... In this example there are needed 2 bytes because of output

			9.... 1. result byte = 00000011 (log. output 1+2) 2. result byte = 00000001 (log. output 9)
Total exec. time	4 (Integer)		Current (job) cycle time in [ms]
Active job no.	1		Active Job no. (1..255)
<<Detector specific>>			
Detector result	1	(1 = Pass, 0 = Fail)	Boolean detector result
Score value 1 .. n	4		Score (0..100%)
Execution time	4		Execution time of individual detector in [msec].
Distance	4		Calculated distance, signed integer, [1/1000]*1)
Position X1 .. n	4		Position found X (x-coordinate). [1/1000]*1)
Position Y1 .. n	4		Position found Y (y-coordinate). [1/1000]*1)
DeltaPos X	4		Delta Position X between object taught and object found [1/1000]*1)
DeltaPos Y	4		Delta Position X between object taught and object found [1/1000]*1)
Angle	4		Orientation of object found (0°..360°) [1/1000]*1)
Delta Angle	4		Angle between object taught and object found (0°..360°) [1/1000]*1)
Scaling	4		Only with contour (0.5..2) [1/1000]*1)
Result horizontal	1	0x01 = True, 0x00 = fail	Boolean result of horizontal edge detection of alignment
Result vertical	1	0x01 = True, 0x00 = fail	Boolean result of horizontal edge detection of alignment
Score horizontal	2		Score 0..100% (alignment only using edge detection)
Score vertical	2		Score 0..100% (alignment only using edge detection)
R(ed)	4		Value for color parameter, signed integer, [1/1000]*1)
G(reen)	4		Value for color parameter, signed integer, [1/1000]*1)
B(lue)	4		Value for color parameter, signed integer, [1/1000]*1)
H(ue)	4		Value for color parameter, signed integer, [1/1000]*1)
S(aturation)	4		Value for color parameter, signed integer, [1/1000]*1)
V(alue)	4		Value for color parameter, signed integer, [1/1000]*1)

L(uminanz)	4		Value for color parameter, signed integer, $[1/1000]*1$)
A	4		Value for color parameter, signed integer, $[1/1000]*1$)
B	4		Value for color parameter, signed integer, $[1/1000]*1$)
Result index	4		Index in list, signed integer
Color distance	4		Distance between taught and current color, signed integer, $[1/1000]*1$)
Area	4		Area of the BLOB, without holes, in pixels
Area (incl. holes)	4		Area of the BLOB, including holes, in pixels
Contour length	4		Number of pixels of outer contour
Compactness	4		Compactness of BLOB (Circle = 1, all other >1) The stronger the shape of the BLOB deviates from circle the larger the value of compactness will be.
Center of gravity X	4		X- coordinate of center of gravity of BLOB
Center of gravity Y	4		Y- coordinate of center of gravity of BLOB
Center X	4		X- coordinate of fitted, geometric element (rectangle, ellipse)
Center Y	4		Y- coordinate of fitted, geometric element (rectangle, ellipse)
Width	4		Width of geometric element. Width ≥ 0 , width \geq height, negative value indicates failure
Height	4		Height of geometric element. Height ≥ 0 , height \leq width, negative value indicates failure
Angle (360)	4		Orientation of width of object in degree (range: -180 ... +180°, 0° = east, counterclockwise)
Eccentricity	4		Eccentricity numerical (range 0,0 ... 1,0)
Face up/down, area	4		Face up/down discrimination, based on area, indicated by sign
String	1...n	Maximum length 127!!	Contents of Code, depending from code string length may change, if a fix string length is needed, parameters minimum string length (detector specific data output) and maximum string length (detector parameters) have to be used.
String length	4		Length of Code in Bytes
Truncated	1	0x00 = Code complete, 0x01 = Code truncated	Code truncated
Checksum	1		XOR-checksum of all bytes in telegram
Trailer	1 - max. 8		End of string (Trailer)

*1) All detector-specific data with decimal places are transmitted as whole numbers (multiplied by 1000) and must therefore be divided by 1000 after receipt of data. Values are transferred in format "Big-endian". (there are two different architectures for handling memory storage. They are called Big Endian and Little Endian and refer to the order in which the bytes are stored in memory, in the case of the Vision Sensor architecture the data is stored Big End In first)

Example: "Score" Value (Binary protocol)

In Configuration Studio/Visualisation Studio "Score" = 35 is displayed.

Over Ethernet there will be received the following four bytes: 000,000,139,115

Formula for recalculating: $(\text{HiWordByte} * 256 + \text{HiLowByte}) * 65536 + \text{HiByte} * 256 + \text{LoByte} = \text{Value}$

Because Big-endian (from Sensor) is sent calculation goes as following:

000 = HiWordByte, 000 = HiLowByte, 139 = HiByte, 115 = LoByte

$(0 * 256 + 0) * 65536 + (139 * 256) + 115 = 35699 / 1000 = 35,699$ (real score value)

Angles or other negative values are transferred in two's complement.

8.2 Further explanations to Edge detector (alignment)

Function of „Number search rays“

„Number search rays“ parameter which defines in how many parallel sub- search regions the search area is divided. The edge detector searches in each sub region for the first edge separately.

Increasing the value of „Number search rays“, increases the chance to find the very first edge in the search area..

By increasing “Number search rays” it may happen, that the threshold value fluctuates strongly, e.g. if just the half of the search area is covered by the edge. The reason therefore is, that the first, not the strongest, edge is detected, which is above the threshold limit in search direction.




Fig. 328: Edge detection with „Number search rays“ = 1. The dominating edge, perpendicular to the search direction is found.




Fig. 329: Edge detection with „Number search rays“ >> 1. The first edge perpendicular to the search direction is found.

Function of Sigma (smoothing) to sharp or blurred edges

The edge strength represents the assumption of edge steps over a certain area in search direction, which is quantified in „Sigma“ (smoothing). With sharp edges the edge strength is not increased with increasing sigma. But with blurred edges the edge strength is increased by increasing sigma value.




Fig. 330: Edge detection of sharp edge. High edge strength with low sigma value (smoothing).




Fig. 331: Edge detection of blurred edge. Low edge strength with low sigma value.




Fig. 332: Edge detection of blurred edge. High edge strength with high sigma value.

Function of Sigma (Smoothing) to residual edges

Like mentioned above, the edge strength represents the assumption of edge steps over a certain area in search direction, which is quantified in „Sigma“ (smoothing).

If in this area edges are found with different polarity (dark- bright: positive polarity, bright-dark: negative polarity) it's edges steps can neutralize each other. This can be used to eliminate residual edges, by choosing a sigma value which is high enough.




Fig. 333: Edge detection with sigma value = 1. Residual edge is not eliminated.




Fig. 334: Edge detection with sigma value >> 1. Residual edge is eliminated.

8.3 Starting Vision Sensor Visualisation Studio or Vision Sensor Configuration Studio via Autostart

To start Vision Sensor Visualisation Studio or Vision Sensor Configuration Studio via Autostart please select in: Vision Sensor Device Manager/File/Auto start file, the module to autostart and save it.

After selecting the module to start and the user level, with "Save" store the Autostart- file in folder ..\Windows\Start Menu\Programs (exact path depends on Windows installation)

8.4 Care and maintainance

8.4.1 Cleaning

The SBS Vision Sensor is to be cleaned with a clean, dry cloth.

Dirt on the front panel is to be cleaned with a soft cloth and a small amount of plastic cleaner if necessary.

Attention

Never use aggressive detergents such as solvents or benzine.

Never use sharp objects. Do not scratch!