

FluidDraw P6 is an application for creating electro-pneumatic circuit drawings.

It contains a wide range of standard circuit diagram symbols as well as all components from the Festo product catalog with their part numbers and technical details. If you have set up a user account for the Festo Online Shop, your shopping baskets are also available in FluidDraw. FluidDraw also supports DXF files and circuit drawings created with older FluidDraw versions and the FluidSIM pneumatic simulator, in addition to its own file format.

Contents

1.	Installation and licensing	12
1.1	FluidDraw installation program	12
1.1.1	Installing FluidDraw	13
1.1.2	Installing the CodeMeter license server	19
1.2	License management	21
1.2.1	Activating licenses	25
1.2.2	Deactivating licenses	30
1.2.3	Relocating single licenses (license borrowing)	34
1.3	Licenses / troubleshooting	38
1.3.1	CodeMeter Control Center	39
1.3.2	WebAdmin	41
2.	Getting started	46
2.1	Ribbon	46
2.2	Creating a new project	46
2.3	Organizing projects, symbols and libraries	51
2.4	Inserting a symbol from the menu	52
2.5	Symbol libraries	54
2.5.1	Creating your own library	56
2.5.2	Creating new symbols	57
2.6	Project files	58
3.	Library, project window and object browser	59
3.1	Changing the window position	59
3.2	Automatic hiding and displaying	59
4.	Editing circuits	61
4.1	Inserting and arranging symbols	61
4.2	Using the Festo product catalog with FluidDraw	61
4.3	Using the Festo shopping basket with FluidDraw	63
4.4	Inserting valve terminals via order code	66

4.4.1	Distributing valve terminals to several pages	67
4.5	Connecting connectors	69
4.6	Automatically connect connectors.	70
4.7	Inserting T-distributors	72
4.8	Moving lines	74
4.9	Defining the properties of the lines	77
4.10	Deleting a line	79
4.11	Defining the properties of the connectors	79
4.12	Defining a component connector / setting a T-distributor	81
4.13	Deleting a component connector	82
4.14	Configuring directional control valves	82
4.15	Configuring cylinders	84
4.16	Grouping symbols	86
4.17	Creating macro objects	86
4.18	Deleting symbol groups and macro objects	87
4.19	Aligning symbols	87
4.20	Mirroring symbols	87
4.21	Rotating symbols	88
4.22	Scaling symbols	89
5.	Drawing frame	91
5.1	Using the drawing frame	91
5.2	Drawing frame editor	94
5.2.1	The structure of a drawing frame	94
5.2.2	Drawing Size	96
5.2.3	Page border	97
5.2.4	Page Dividers	98
5.2.5	Title block customizing	100
5.2.6	Title block location	107
5.3	Adding fixed elements to drawing frames	108
5.4	Page dividers	113
6.	Additional tools for creating drawings	117
6.1	Drawing aids	117
6.1.1	Grid	117

6.1.2	Alignment lines	117
6.1.3	Object snap	118
6.1.4	Rulers	119
6.2	Drawing layers	119
6.3	Displaying line jumps	121
6.4	Selection filter	122
6.5	Cross-references	124
6.5.1	Creating cross-references from symbols	126
6.5.2	Cross-reference representation	127
6.5.3	Managing cross-references	129
6.6	Drawing functions and graphical elements	130
6.6.1	Hatching	131
6.6.2	Text	133
6.6.3	Image	133
6.6.4	Line	135
6.6.5	Rectangle	137
6.6.6	Circle	139
6.6.7	Ellipse	141
6.6.8	Polyline (traverse line)	143
6.6.9	Connecting cable	145
6.6.10	Interruption/potential	147
6.7	Checking the drawing	150
7.	The object browser	152
7.1	Navigating in the object browser	152
7.2	Filter criteria for the object browser	154
8.	Manage Product Database	157
9.	Manage Translation Tables	164
10.	Dimensioning	172
10.1	Drawing dimensions	172
10.2	Settings for dimensioning	173

11. Equipment identifications and designation conventions 175

11.1	Renumber Designations	177
------	-----------------------	-----

12. Component attributes 181

12.1	Component attributes in the <i>Properties</i> dialog window	182
12.2	Identification	184
12.3	Catalog Properties	186
12.4	User Defined Properties	187
12.5	Drawing Properties	188
12.6	Main and secondary elements	189
12.7	Linking main and secondary elements	189
12.8	Linking solenoid valves and solenoid coils	193
12.9	Attributes of the text components	196
12.10	Linking text components with attributes	199
12.10.1	Text constants	202
12.11	Text components with predefined links	203
12.12	Changing the properties of several objects simultaneously	205

13. Managing projects 207

13.1	Creating a new project	207
13.2	Project node	208
13.3	page node	208
13.4	Global objects	210
13.5	Unplaced objects	213

14. Page and project properties 216

14.1	Attributes	217
14.1.1	Predefined placeholders	219
14.2	Page Dividers	220
14.3	Basic Unit Length	220
14.4	Language	221
14.5	Encryption	222
14.6	Designation Conventions	224

14.7	Cross Reference Representation	225
14.8	Representation	226
14.9	Display Attributes	227
15.	Position numbers	229
15.1	Dialog Manage position numbers	229
15.2	Assignment of the position numbers	232
15.2.1	Change in the numbering scheme	234
15.2.2	Manual adjustment of the position numbers	238
15.2.3	Display of the position number in the parts list	240
16.	Tables	241
16.1	Using tables	241
16.1.1	Editing contents	242
16.1.2	Formatting	243
17.	Reports	244
17.1	Using reports	244
17.2	Parts lists	245
17.2.1	Inserting a new parts list	245
17.2.2	Adapting a parts list	246
17.2.3	Adding user defined attributes to the parts list	251
17.2.4	Editing the parts list contents	253
17.2.5	Exporting a parts list	254
17.2.6	Sending it to the Festo Online Shop	256
17.2.7	Differences between parts lists in version 5 and 6	256
17.3	Table of contents	257
17.3.1	Inserting a new table of contents	257
17.3.2	Adapting the table of contents	258
17.4	Connector lists / terminal diagrams	258
17.5	Reports in detail	258
17.5.1	Object selection	260
17.5.2	Column selection	268
17.5.3	Appearance	272

18.	Functional diagram	277
18.1	Edit modes	277
18.1.1	Edit Mode	278
18.1.2	Drawing a diagram curve	280
18.1.3	Insert text boxes	281
18.1.4	Insert signal elements	281
18.1.5	Draw signal lines and insert signal connections	282
18.1.6	“Format” mode	285
18.2	Properties dialogs	286
18.2.1	Diagram properties dialog	287
18.2.2	Text box properties dialog	288
18.2.3	Diagram columns properties dialog	289
18.2.4	Signaling element properties dialog	291
18.2.5	Signal lines properties dialog	292
18.2.6	Signal link properties dialog	293
18.2.7	“Format” dialog	294
18.3	Rows	296
18.3.1	Add row	296
18.3.2	Insert row	296
18.3.3	Copy row	296
18.3.4	Moving rows	297
18.3.5	Delete row	297
18.4	Scrolling and zooming in and out	297
19.	Special functions for electric circuits	299
19.1	Potentials and conduction lines	299
19.2	Cables and wiring	301
19.2.1	Managing cables	306
19.2.2	Inserting a cable map	307
19.2.3	Inserting a cable list	308
19.3	Terminals and terminal strips	308
19.3.1	Setting terminals	308
19.3.2	Setting multiple terminals	311
19.3.3	Creating terminal strips	314
19.3.4	Managing terminal strips	316

19.4	Terminal diagram	317
19.4.1	Setting links	318
19.5	Contact image	322
20.	Circuit input and output	325
20.1	Printing circuits and parts lists	325
20.2	Importing DXF files	326
20.3	Exporting circuits	328
21.	Template management	331
21.1	Template management dialog	331
21.2	Adjustment of the folder structure	332
22.	Options	334
22.1	General	335
22.1.1	Language	335
22.1.2	Menu bar	336
22.1.3	Dialog boxes	336
22.1.4	Project	336
22.1.5	Check for updates at startup	337
22.2	Save	338
22.3	Product Catalog	339
22.4	Folder Locations	341
22.5	Translation Table	342
22.6	Connector Links	343
22.6.1	Connect Automatically	343
22.7	Warnings	345
22.7.1	Warnings	345
22.7.2	Show Warnings	346
22.8	Appearance	347
22.8.1	Override Default Settings	347
22.8.2	View	347
22.8.3	Zoom	348
22.8.4	Grid	348

22.9	Designation Conventions	348
22.9.1	Default Settings	349
22.9.2	User Defined	350
22.10	Cross Reference Representation	350
22.10.1	Default Settings	351
22.11	Text Sizes	352
22.12	Dimension	353
22.12.1	Default Settings	354
22.12.2	Preview	354
22.13	Drawing Layers	354
22.14	Display Attributes	355

23. Ribbon overview 357

23.1	Quick access toolbar	357
23.2	File	357
23.3	Home	359
23.4	Insert	363
23.5	Select	366
23.6	Edit	369
23.7	View	371
23.8	Page	374
23.9	Project	376
23.10	Library	377
23.11	Manage	379
23.12	Help	380

24. Adjust Ribbon 382

24.1	The Ribbon	384
24.2	Tree view and Command view	385
24.3	Adding Elements	386
24.4	Removing Elements	389
24.5	Moving Elements	390
24.6	Creating new Elements	390
24.7	Renaming Elements	391
24.8	Large / Small Symbol	394

24.9	Reset to default settings	395
24.10	Import / Export	395
24.11	Assign shortcuts	396
24.11.1	Assign new Shortcut	397
24.11.2	Remove Shortcut	400
24.11.3	Restore shortcuts	401

Index	402
--------------	------------

Installation and licensing

Chapter 1

FluidDraw uses the CodeMeter technology from Wibu-Systems for software protection. The CodeMeter Runtime must be installed for this. If the Runtime is not installed or if it is too old, then a current Runtime version of FluidDraw setup will be installed.

1.1 FluidDraw installation program

You can select the language to be used during the installation on the start page of the installation program. **Install FluidDraw** is used to start the installation. The **Install License Server** selection is described further below.

1.1.1 Installing FluidDraw




Figure 1/1: FluidDraw setup: start page




Figure 1/2: FluidDraw-Setup: *End-User License Agreement*

Please confirm the license conditions for a new installation. For an update installation no further settings have to be made and the installation can be started immediately.

FluidDraw requires the CodeMeter Runtime from Wibu-Systems for licensing. If no suitable version of the installation program is found on your system, the Runtime will be installed in the next steps.



You require administrator rights to install the CodeMeter Runtime.

If you would like to install FluidDraw under a user with limited rights, exit the installation program after the CodeMeter Runtime has been installed and start it again.




Figure 1/3: FluidDraw setup: installation of the CodeMeter Runtime

In the next step, you can select whether to perform a complete installation or a network access installation (client installation). For a client installation, FluidDraw must already be installed. In this case, the installation program does not perform an installation but only creates a link to the program already installed.




Figure 1/4: FluidDraw setup: type of installation

If your CodeMeter licenses are provided by a license server in your network and if this license server is in a different subnet, you can use the following dialog to specify the IP address of the license server. If you are using a local license or if the license server is in the same subnet, you can simply continue with **Next**.




Figure 1/5: FluidDraw setup: *Specify license server (optional)*

Then you can select whether FluidDraw is to be installed for all users or only for the currently logged on user.



You require administrator rights to select “*For all users*”.




Figure 1/6: FluidDraw setup: *Select User Group*

Then you can select the target folder and start the installation.




Figure 1/7: FluidDraw setup: selecting the target folder

1.1.2 Installing the CodeMeter license server

You can use any PC in your network as the license server. The following conditions must be met for this:

- The CodeMeter Runtime from Wibu-Systems must be installed on the server PC and the *Server Access* option must have been activated in the Runtime.
- The client PCs must have access to the server PC via the LAN.
- Valid licenses must have been activated on the server PC or a CodeMeter USB plug with valid licenses must be inserted.

The activation of licenses is described in the [“License management”](#) chapter.




Figure 1/8: FluidDraw setup: start page

If you started the FluidDraw installation program on a PC that you want to use as the server, then you can select the **Install License Server** to install the CodeMeter Runtime from Wibu-Systems. The “*Server Access*” option is automatically activated in the Runtime. If there already is a suitable version of the CodeMeter Runtime on the PC, the Runtime will not be installed and only the “*Server Access*” option will be activated. The “*Server Access*” option can also be activated and deactivated using the tools from Wibu-Systems. For details, see “*CodeMeter Control Center and WebAdmin*” chapter.




Figure 1/9: FluidDraw setup: installing the license server

1.2 License management

FluidDraw licenses are mainly output and managed via a ticket system. In this case, you will have received a ticket from your licensor that you can use to import (activate) and manage your licenses via the Internet. The ticket number consists of 5 alphanumeric strings of 5 characters each that are separated by a minus sign, e.g. “8A7T4-6P7GW-5YQLN-4WDWL-KR3M7”. The licenses can be managed using the “*Online License Activation Wizard*”. This wizard is available as a separate program “CodemeterActivation-Wizard.exe” in the “bin” folder of your FluidDraw installation or can be accessed directly from FluidDraw via the [Manage Licenses...](#) menu item.

The following conditions must be met to be able to use the activation wizard.

- The activation wizard must be able to establish an Internet connection. If the PC is behind a proxy, a dialog is opened in which you can enter the required proxy data.
 - The CodeMeter Runtime from Wibu-Systems must be installed on the PC used to open the activation wizard. If that is not the case, you can use the wizard to open the corresponding download page of Wibu-Systems in the standard browser.
 - The CodeMeter Runtime from Wibu-Systems must be installed on the PC to which the licenses are to be imported.
 - The activation wizard must be able to access the PC to which the licenses are to be imported via LAN.
-> Enter your ticket number on the start page of the activation wizard.

You can also copy the complete ticket number in the first input field via the clipboard. The ticket number is then automatically distributed to the five input fields.




Figure 1/10: Online License Activation Wizard



If the activation wizard has no access to the PC to which the licenses are to be imported, various files need to be exchanged between this PC and the licensor. Only select the **Transfer files manually** button in this case. An Internet site opens that guides you through the file exchange process.

→ Select **Next** to access the license information for your ticket via the Internet.




Figure 1/11: Activation wizard: *Select license*

The table lists all licenses for your ticket number. Free licenses that can be activated are displayed on a green background. If no free licenses are available, you will be informed. Every line contains a number of licenses of a product that can be activated or deactivated together.


Name	Contains the name of the licensed product.
Number of licenses	Specifies the maximum number of licenses that can be activated or deactivated.
CmContainer	Contains the serial number of the CodeMeter container in which the licenses were activated. The container can be a hardware plug (CmDongle) or a software-based license (CmAct).
Found server	

Contains the name of the server with the corresponding CodeMeter container. If the CodeMeter container cannot be found in the LAN, this field is empty and the license cannot be deactivated.

.....> Select “*Activate*” if you want to import (activate) licenses or “*Deactivate/Re-host*” if you want to deactivate or relocate licenses.

1.2.1 Activating licenses

After selecting “*Activate*”, you can select the number of licenses you want to activate. This dialog is skipped if only one license is available.



Online-Lizenzen Aktivierungsassistent

Lizenzanzahl wählen FESTO

Sie können alle Lizenzen in einen Container spielen oder die Lizenzen auf mehrere Container verteilen.
Die Aktivierungsschritte müssen für jeden Container individuell durchgeführt werden.

Name	FluidDraw P6 Permanent
Verfügbare Lizenzanzahl	2
Zu aktivierende Lizenzanzahl	<input type="text" value="1"/>

Figure 1/12: Activation wizard: *Specify number of licenses*

You can select whether to import the licenses locally or to a PC in the network (if available).



The CodeMeter Runtime from Wibu-Systems must be installed on the PC in the network.




Figure 1/13: Activation wizard: *Select location of license*

Then, you can define the CodeMeter container type. It can be a hardware plug (CmDongle) or a software-based container (CmAct). To use a hardware plug, you need to own one. The software-based container is automatically created by the activation wizard.




Figure 1/14: Activation wizard: *Select license type*

Before the actual activation, a summary of the licenses to be activated is displayed to you again.

.....> Start the activation with “*Activate*”.




Figure 1/15: Activation wizard: *Executing activation*

The individual activation steps are carried out via the Internet and highlighted in color.




Figure 1/16: Activation wizard: activation successful

Finally, you can close the activation wizard or have the current license information displayed for your ticket via [Back to license overview](#).

1.2.2 Deactivating licenses

After selecting “*Deactivate/Re-host*” in the license overview, you can select whether you want to deactivate licenses or [relocate an individual license](#).




Figure 1/17: Activation wizard: *Deactivate/Borrow licenses*

.....> Select “*Deactivate licenses*”.

You can now select the number of licenses you want to deactivate.
This dialog is skipped if only one license is available.

Online-Lizenzen Aktivierungsassistent

Lizenzanzahl wählen FESTO

Wählen Sie, wie viele Lizenzen Sie deaktivieren möchten.

Deaktivierte Lizenzen können anschließend wieder auf anderen Rechner aktiviert werden.

Name	FluidDraw P6 Permanent
Verfügbare Lizenzanzahl	2
Zu deaktivierende Lizenzanzahl	<input type="text" value="2"/>

Figure 1/18: Activation wizard: *Specify number of licenses*

Before the actual deactivation, a summary of the licenses to be deactivated is displayed to you again.

.....> Start the activation with “*Deactivate/Re-host*”.




Figure 1/19: Activation wizard: *Executing deactivation*

The individual deactivation steps are carried out via the Internet and highlighted in color.




Figure 1/20: Activation wizard: deactivation successful

Finally, you can close the activation wizard or have the current license information displayed for your ticket via [Back to license overview](#).

1.2.3 Relocating single licenses (license borrowing)

The activation wizard supports the simple conversion of a single license into a software license. That is a practical function e.g. if you have multiple licenses on a server and want to use an individual license for a foreseeable time locally on a laptop (license borrowing). You can also carry out the necessary steps manually using the activation wizard. The necessary steps for license borrowing are automated, however. The steps are deactivation of a license and

subsequent activation of a single software license on the local computer.

→ Select “ *Deactivate/Re-host*” from the license overview.




Figure 1/21: Activation wizard: license overview

→ Finally, select “ *Re-host a single license to the local machine.*”.




Figure 1/22: Activation wizard: license borrowing

The subsequent steps are carried out automatically.




Figure 1/23: Activation wizard: step 1: deactivation




Figure 1/24: Activation wizard: step 2: activation

Finally, you can close the activation wizard or have the current license information displayed for your ticket via [Back to license overview](#).



If you want to give back your license, you must deactivate it.

1.3 Licenses / troubleshooting

To be able to start FluidDraw, it must find a valid and available CodeMeter license. The CodeMeter Runtime from Wibu_systems is used to install various tools that you can use to query license information and make settings.

License server refers to the computer that can directly access the CodeMeter container (CmContainer) with licenses. A container can be a connected hardware plug (CmDongle) or an imported software-based CodeMeter-Act license (CmAct).

Client computer refers to the computer on which FluidDraw is started and on which it requests a license from the license server. If the CodeMeter containers are on the local computer, then license server and client computer are identical. Various requirements must be complied with for successful access to the license. How you can check these requirements using the tools of Wibu-Systems is described afterwards.

1. A current CodeMeter Runtime must be installed on the license server and on the client computer.
2. The license server must have direct access to the CodeMeter container with the corresponding licenses.
3. If the license server is not also the local computer, then the “*Server Access*” option must be selected on the license server.
4. The client computer must be able to access the license server via the network and its license information. If the license server is in a different subnet, then the IP address of the license server must be specified on the client computer (*Server Search List*).

1.3.1 CodeMeter Control Center

The *CodeMeter Control Center* is installed, along with the CodeMeter Runtime. The connected CodeMeter containers of the computer are displayed via the *CodeMeter Control Center*. No CodeMeter containers are listed that are on other license servers in the network. The *CodeMeter Control Center* can be started via the start menu under “CodeMeter”-“CodeMeter Control Center” or by clicking the corresponding symbol on the task bar.




Figure 1/25: *CodeMeter Control Centers* symbol on the task bar

Next to the list of connected CodeMeter containers, you can use the “WebAdmin” button to have detailed license information displayed in the Internet browser and you can make various settings. The WebAdmin is described in the next section.

On the license server, you can use the *CodeMeter Control Center* to check if your CodeMeter containers really are available or connected. More information on the *CodeMeter Control Center* can be found in the Help for the program.




Figure 1/26: CodeMeter Control Center

1.3.2 WebAdmin

The CodeMeter Runtime is also used to install the WebAdmin that you can use to access detailed license information and make runtime settings. The WebAdmin can be opened via the *CodeMeter Control Center*, which was described in the previous chapter. All WebAdmin functions are described in this Help. Only the main functions important for starting FluidDraw are explained below. The WebAdmin always shows a view of the licenses and settings of a selected license server. You can therefore also have information of a different license server in the network displayed.



Figure 1/27: WebAdmin: selecting the server

First check if the new licenses are available on the license server. Start the WebAdmin directly on the license server and check on the “Containers” tab if your CodeMeter container is available with the corresponding licenses.




Figure 1/28: WebAdmin, tab: Containers

If the license server is not the local computer and if the licenses are to be available to other client computers, then the “*Server Access*” option must be selected. You can configure this on the “*Configura-*

tion”-“ *Server*”-“ *Server Access*” tab. Select “ *Enable*” in the “ *Network Server*” group.




Figure 1/29: WebAdmin, tab: *Server Access*

Next, check if the licenses of the license server can be accessed by the client computer. Start the WebAdmin directly on the client server for this purpose. Then, you must select the license server in the WebAdmin at the bottom left.




Figure 1/30: WebAdmin: servers found

If your license server is not listed, there may be one of two reasons for this.

1. On the license server, the “*Server Access*” option is not activated (see previous section).
2. The license server is in a different subnet and this server is not entered in the server search list.

You can enter the license server on the tab: “*Configuration*”-“*Basic*”-“*Server Search List*”.




Figure 1/31: WebAdmin, tab: *Server Search List*

You should now be able to select the license server at the bottom left in the WebAdmin and you can then check on the “*Container*” tab if your CodeMeter container is available with the corresponding licenses on the license server.




Figure 1/32: WebAdmin: licenses on license server

If you still have any licensing problems, please contact Support.

Getting started

Chapter 2

2.1 Ribbon

For clearer and easier operation with fewer mouse clicks, in FluidDraw 6 a ribbon is used instead of the classic menu bars. The classic menu bars are still available, however and can be activated via the [Options](#).




Figure 2/1: Ribbon

The operating instructions in this manual refer to the ribbon. Every entry in the ribbon can also be found on the classic menu bar. If the general term “menu” is used in the manual, you can find the corresponding function in the ribbon and also on the classic menu bar.

You can customize the ribbon as well as the keyboard shortcuts to your own liking. For details, see [Adjust ribbons](#).

2.2 Creating a new project

A project in FluidDraw consists of pages that can be organized hierarchically in a tree structure. The main node of the tree structure is the project itself. Sub-nodes can be created under the project node for structuring. Pages can include circuit diagrams and reports, such as parts lists.

A sub-node automatically adopts all properties (attributes) of the parent node, such as the drawing frame. The properties can be overwritten in subordinate nodes and on the pages or deleted.



Please note that in FluidDraw, version 6, circuit diagrams are always managed in projects. However, individual pages of older FluidDraw versions that are not part of a project can still be opened, edited and saved.

→ On the ribbon, select **File** **New** **Project...**.

First specify the project file to which the new project is to be saved. A dialog box appears. The file extension that belongs to a project file is “fdprj”. Then, the dialog with the project properties automatically opens.

On the *Drawing Frame* tab, you can select a drawing frame that is to be used by default for all pages. Further information on the drawing frame can be found in the section: [Drawing frame](#).




Figure 2/2: **Project** dialog window, *Drawing Frame* tab: selecting a drawing frame

After closing the properties dialog of the project with **OK**, a new empty page is automatically created to which all project properties are transferred.




Figure 2/3: New project with a page

Via [Page Properties...](#), you can change the properties of a page, such as the description.



If you select [File New Page](#) to add a new page to the project, the properties dialog for the new page automatically opens.

You can insert symbols in the new page and connect them with lines. If you have selected a drawing frame in the project or on the page, the size of the drawing is automatically set. If you want to manually define the drawing size then deselect the “*Adopt from drawing frame*” option on the “*Drawing Size*” tab and select the drawing’s desired dimensions and orientation. If the drawing’s dimensions are larger than your printer’s printing area then you can distribute your drawing across several pages ([tiles](#))




Figure 2/4: [Page](#) dialog window, *Drawing Size* tab: setting the drawing size

For a better overview you can create attributes for every circuit drawing.

⇒ Click the “*Attributes*” tab to do this.




Figure 2/5: [Page](#) dialog window, *Attributes* tab: creating attributes

The attribute table allows you to save any desired data in the form of attribute value pairs. The associated placeholders (attributes with the same name) in the drawing frame are replaced by the values entered.

2.3 Organizing projects, symbols and libraries

To support the organization of the different document types in FluidDraw, they are classified into one of three groups:

Projects	The default location for projects is in the FluidDraw folder contained in the My Documents folder defined by the operating system. These have the fdprj file extension.
Symbols	Symbols are formal, abstract models, which graphically represent the function of a component or component group. These can be simple circuit symbols or also complete circuits. Symbols can be inserted in their own circuits and connected between the connector points. They are inserted either using the Insert menu or by dragging them (“drag and drop”) out of a library window . Symbols can be combined to libraries.
Libraries	Libraries are hierarchically organized collections of symbols. In addition to the standard library that cannot be changed by the user, you can compile your own libraries as desired. You can find functions for organizing the libraries in the Library menu and in the context menu of the active library. The library is switched over using the tab at the top edge of the library window. Library files have the file extension: lib .

2.4 Inserting a symbol from the menu

To find a specific symbol, you can enter characteristic key words in the *Find Symbol* dialog window or navigate through the hierarchical structure.

→ Open a new window, if necessary, and select the **Find Symbol Description...** menu item in the **Insert** menu.

The *Find Symbol* dialog window opens. You can enter search terms in the “*Search*” input line. The individual search terms are separated by commas or blanks. The order of the entries and (upper or lower) case are irrelevant.




Figure 2/6: *Find Symbol* dialog window


The symbols found are displayed in the two result lists. The library hierarchy is displayed on the left side. Only those branches appear that have the fitting symbols. An alphabetically sorted list with the search hits is displayed on the right side. The symbol of the highlighted entry is displayed in the preview. When you have found the desired symbol, you can select it using the **OK** button or by double-clicking the corresponding line in the result list. The symbol is then attached to the mouse pointer and is positioned on the drawing area by a left-click.

You can use the *Fuzzy Search* option to activate a tolerance to also get results in the event of input errors or spelling variants.

In addition to the option of inserting a specific symbol using the *Find Symbol* dialog window you can also insert a real component

along with its part number and technical details from the Festo product catalog. You can find details of how to use the Festo product catalog with FluidDraw under [Using the Festo product catalog with FluidDraw](#).

2.5 Symbol libraries

FluidDraw can manage several libraries, of which each individual one is displayed on a tab of the library window. Libraries that cannot be changed in FluidDraw are marked by a lock symbol  on the tab. That applies to the standard library and to FluidDraw symbol folders that you do not manage yourself or for which the logged-on user does not have any write access.

Every library is displayed hierarchically. Every hierarchy level can be displayed or hidden by clicking the group name. Right-click a library to open a context menu that provides the following menu items for editing the library:

View

Defines the size of the symbols displayed. **Small**, **Normal** and **Large** are available.

Show All Symbols

By default, the library contains the symbols and components normally used that are included in the Festo product catalog. All symbols can be displayed with the **Show All Symbols** option. These also include those that FluidDraw uses internally e.g. to [assemble valve terminals](#).

Show default designation

Reference letters that comply with the standard are already stored for typical components. They are displayed by default in the symbol at the top right. You can deactivate the display with this option if you do not want it.

Assign reference designation...

If a symbol does not have a default identification in the library or if you want to change it, you can assign an individual identification to every symbol. A free number is automatically attached to this identification when it is inserted on a page.





Figure 2/7: **Assign reference designation...** dialog window

Enter a standard identification for this symbol. The **Manage reference designations...** button opens an overview of all user IDs.

Copy to Other Library

Copies the marked symbols to another library. The available libraries are listed in a submenu. Only those libraries that are currently open (i.e. that appear as tabs in the library window) and that are not write-protected (indicated by the fact that no lock symbol  is displayed) appear here.

Expand All

Opens all hierarchy levels.

Collapse All

Closes all hierarchy levels.

There are three types of libraries:

The standard library

This library is supplied with FluidDraw and cannot be changed.

Symbol folder

Circuit and symbol files stored on the data storage medium can be used like libraries in FluidDraw. The files of the selected folder are added as a library via the **Library** menu and the **Add Existing Symbol Folder...** menu item. The library hierarchy exactly matches the folder hierarchy. These libraries cannot be changed in FluidDraw. Changes must be made directly on the data storage medium.


Own libraries

You can create and subsequently edit new libraries via the **Library** menu and the **Create New Library...** menu item (see section **Creating your own library**). Using “drag and drop” you can move the symbols and groups within the library as desired.

2.5.1 Creating your own library

To be able to access frequently used symbols (or circuits) more quickly, several symbols can be combined to libraries. Libraries are stored in files with the file extension **.lib**. You can create new libraries via the **Library** menu and the **Create New Library...** menu item. Right-click the new library to open a context menu that you can use to edit the library.

The following menu items are available::

Copy	Copies the selected symbols to the clipboard.
Paste	Inserts the symbols from the clipboard in the library. These symbols can also be sub-circuits.
Delete	Removes the marked symbols from the library.
Rename...	Changes the text which libraries display below the symbol.
Add Existing Symbols...	Opens a dialog window for selecting symbol files, which are to be copied as new symbols into the library.
Copy to Other Library	Copies the marked symbols to another library. The available libraries are listed in a submenu. Only those libraries that are currently open (i.e. that appear as tabs in the library window) and that are not write-protected (indicated by the fact that no lock symbol  is displayed) appear here.
New Sub-Folder...	Creates a new hierarchy level below the active group. The active group is the one that belongs to the area under the mouse pointer. It is indicated by a dark blue color.
Remove Sub-Folder	Removes the hierarchy level at which the mouse pointer is.
Rename Sub-Folder...	Allows the name of the hierarchy level to be changed at which the mouse pointer is.

2.5.2 Creating new symbols

Existing symbols from the standard library cannot be changed, but you can create your own symbols in FluidDraw. To do this, proceed as follows:

1. Draw symbol

You can easily create a new symbol using the line, polyline, rectangle, circle, ellipse, etc. drawing functions. Use these drawing elements to draw your desired symbol in an empty page. In order to achieve this precisely, you can activate additional snap functions such as [Snap to End Point](#), [Snap to Center](#) or [Snap to Intersection](#) using items on the ribbon page [Edit](#). The [Show Grid](#) option in the [View](#) page displays a grid in the background. This has a grid width of 2 M by default. Grid width and style can be adjusted in program options on the *Appearance* page.

2. Create macro object

After you have drawn the symbol, select all elements of the symbol and select [Create Macro Object](#) from the context menu in the circuit or from the menu on page [Home](#). The individual drawing elements are then combined to form a single new symbol with its own properties.

3. Define connectors

Via the [Define Connector](#) item in the [Insert](#) menu, you can now add pneumatic, hydraulic or electrical connectors to the symbol. For the line routing of conduction lines it is optimal if these connectors are placed in such a way that they are located at intersections with the grid.

4. Save symbol in own symbol library

Via the main menu item [Create New Library...](#) on the ribbon page [Library](#) you can create your own symbol library for your user symbols. If you use this menu item and specify a file name, a new empty symbol library is created. You can then drag and drop the newly created symbol into the new library. When storing the symbol in the library, you can assign your own symbol name and a description for the symbol.

Now you can use the new symbol from your user library just like a symbol from the standard library in your projects.

As an alternative to creating your own macro object in steps 1 and 2, you can also import a completely drawn symbol in DXF format. To do this, use the main menu item **DXF Import...** in the **File** menu.

2.6 Project files

FluidDraw project files have the file extension **fdprj** and are saved as compressed XML files. An option in the **Manage** ribbon under the **Options...** menu item in the *General Save* sub-menu allows you to deactivate this compression so that the circuit files can be viewed as plain text. This can be useful for version management software, for example.



Before version 6 of FluidDraw, individual pages could be saved as circuit diagram files with the file extension **circ**. These are also (compressed) XML files. They can still be opened, edited and saved using the current version of FluidDraw. Please bear in mind however, that the use of some new functions of FluidDraw requires a conversion into the current project format. In this case, FluidDraw displays a message prior to saving the data and offers to create a backup of the original file.

Library, project window and object browser

Chapter 3

3.1 Changing the window position

The library window is firmly attached on the left side by default and the project window and the object browser (if a project is open) are on the right side.

To release the window from its position: connect the mouse pointer to the upper edge of the window. Click and hold the left mouse button. Move the window a small distance towards the center of the screen. Now release the left mouse button. Now you need to move the library window to the bottom right and the project window to the bottom left. Once a window has been released from its fixed position it can be moved freely.

To move the window back into its fixed position: connect the mouse pointer to the upper edge of the window. Click and hold the left mouse button. Move the window as far as possible to the right or the left. Now release the left mouse button. This window snaps into place. This enables you to fasten the library window in place on the right and the project window on the left, for example. You can also fasten both windows on the same side. In this case you can move the desired window into the foreground by clicking the associated tab.

3.2 Automatic hiding and displaying

The tabs provide another practical function: the automatic hiding and display of the library, the project window or the object browser. Click the corresponding vertical “*Library*”, “*Project*” or “*Object browser*” tab at the edge of the window with the mouse pointer. That hides the window in order that a larger space is provided for the drawing. To have the window displayed again, it is sufficient to move the mouse pointer over the tab, which opens the window. As



soon as you have carried out your operation in this window and move the mouse to a circuit window again, the corresponding window is automatically hidden. To deactivate the function, click the corresponding tab again (which then appears in pressed-down form).

Editing circuits

Chapter 4

4.1 Inserting and arranging symbols

Using the *Find Symbol* dialog window and the [libraries](#), you can insert symbols in the circuit window to be edited. You can also apply objects from any other window however, by marking them and dragging them into the desired window. Alternatively, you can also use the clipboard by selecting the [Copy](#) menu item after highlighting the objects in the [Home](#) menu, moving the target window to the foreground and selecting the [Paste](#) menu item in the [Home](#) menu.

If you “drag” objects from one window to another using the mouse pointer, they are copied. If you drag the objects within a window from one position to another, they are moved. To copy objects within a window, you must keep the [Shift](#) key pressed when you move the mouse pointer. The corresponding operation is indicated by the shape of the mouse pointer: during a shift operation a cross with arrows appears  and for copying there is also a plus symbol  in the bottom right corner of the cross.

4.2 Using the Festo product catalog with FluidDraw

The FluidDraw standard installation already contains all products from Festo. For this, an excerpt from the Festo product catalog is also installed in several languages.



In order to remain up-to-date, we recommend to always install the latest update. FluidDraw updates always also include the data of the current Festo product catalog.

There are two basic options for inserting symbols with part numbers and technical details in the circuit.

Via the symbol search ([Insert](#) menu and [Find Symbol Description...](#)) menu item or from the Fluid-Draw library window)

About the Festo product catalog

If you wish to insert a symbol from the FluidDraw symbol library, simply select a graphical image that represents the function of a component or component group. For the majority of the symbols there is a large number of different products with different part numbers and technical details (attributes and parameters). To select a product open the *Properties* dialog window by right-clicking the symbol and click the [Find...](#) button.

The product catalog represents a complete database of the available Festo products. If you wish to insert the associated symbols with part numbers and technical details for certain products then select the [Insert](#) menu item from the [From Festo Catalog...](#) menu. The *Insert from catalog* dialog window appears. Enter your key words in the “ *Search* ” input line. The upper table contains the search result. Highlighting a row there displays the associated symbol in the preview. Select a product by double-clicking a table row or using the [Add to Selection](#) button. Selected products are collected in the lower table. When exiting the dialog window the symbols of the selected products are inserted into the circuit window. The symbols contain the part numbers and technical details of the previously selected products in the form of attribute value pairs.

If you are using a custom product database you can select it in the *Product Database* list box. You can use the selected database in the same way as the Festo product catalog.




Figure 4/1: *Insert from catalog* dialog window



There are different symbol representations for some products. If necessary, select a suitable symbol from the preview at the top left.

4.3 Using the Festo shopping basket with FluidDraw

If you want to insert one or more symbols from an existing shopping basket, select the [From Festo Shopping Basket](#) menu item in the [Insert](#) menu.

FluidDraw supports shopping baskets that you created with an installed product catalog (offline) and also shopping baskets created via the Online Shop (online).

If you want to insert shopping baskets from the Festo Online Shop, you must log on with the corresponding user account at Festo.




Figure 4/2: *Login to Festo Online Shop* dialog window



On request, FluidDraw can memorize your login data for the Festo Online Shop. This data is stored in encrypted form in the registration database for the currently logged-on Windows user. Use this convenient option only if you are sure that no unauthorized person uses the PC with your Windows login.

If a proxy is used in your environment for access to the Internet for which login data needs to be entered, a dialog automatically appears in which you can enter this login data for access to the Internet. Use the same data here that you also use e.g. for your Internet browser.

After successful login to the Online Shop, the stored shopping baskets are downloaded and displayed. All shopping baskets are displayed by default. You can modify the period, if necessary. A [default period](#) can also be defined in the program settings.

Insert Shopping Basket

Search parameters

Basket name:

Creator:

☐ Time span

Start date: 9 Dec 2018

End date: 8 Jan 2019

☐ Show shared baskets

Refresh

Shopping Basket: Valve Terminals

Date: 21 Oct 2015

Creator:

Select All **Invert Selection**

	Quantity	Part number	Customer part no.	Type	Item name	Unit	x stroke	Order code 1	Order code 2	Selection
▶	1	18200		CPV10-VI	Valve termi...	PCS		10P-10-8A...		<input checked="" type="checkbox"/>
	1	539217		VTSA-FB	Valve termi...	PCS		51E-F06GC...	44P-N-Y-K...	<input checked="" type="checkbox"/>
	1	546279		MPA-ASI-VI	Valve termi...	PCS		52E-AE4-X	32P-SGL-N...	<input checked="" type="checkbox"/>
	1	531029		MSB4	Wartungsg...	STK		MSB4-AGB...		<input checked="" type="checkbox"/>
	1	575265		VUVS-L20-...	Magnetventil	STK		VUVS-L20-...		<input checked="" type="checkbox"/>
	1	1247978		VABM-C8-1...	Anschlussl...	STK		VABM-C8-1...		<input checked="" type="checkbox"/>

OK **Cancel**

Figure 4/3: *Insert Shopping Basket* dialog window

Search options are available for further limiting the number of shopping baskets displayed. Press the **Refresh** button after any change to the search parameters to refresh the shopping baskets displayed.

To insert a specific shopping basket, select it from the list of baskets. You also have the option of deselecting individual items from the shopping basket.

If you have selected a product without any graphical representation, a text appears on the circuit drawing that includes the component attributes, instead of the symbol. This text also appears in the [parts list](#) just like the ID of the symbols.

You can make the settings that influence the creation of the symbol designations and accessories using the **Tools** tab under the **Manage** menu item in the *Product Catalog* menu. If desired FluidDraw can automatically generate text elements derived from the type attribute of the associated symbol.

4.4 Inserting valve terminals via order code

FluidDraw can insert the corresponding symbols from many Festo order codes. That does not only work via the [Festo shopping basket](#) but also by directly inserting an order code text from the clipboard.

→ Copy the following order code to the clipboard: 10P-10-8A-IC-V-Z-MMQMGFPCYEVF+MA and then insert the text via [Home](#) / [Paste](#) in FluidDraw.

FluidDraw uses it to create the following symbol:




Figure 4/4: valve terminal 10P-10-8A-IC-V-Z-MMQMGFPCYEVF+MA

You can get a more compact, but outdated view for some products by selecting the *Insert legacy valve terminal symbols* option under [Manage](#) / *Product Catalog*:




Figure 4/5: valve terminal 10P-10-8A-IC-V-Z-MMQMGFPCYEVF+MA, old representation

4.4.1 Distributing valve terminals to several pages

A complete valve terminal is generally too big for a single page. It is therefore practical to distribute symbols to several pages. As a valve terminal consists of a group of individual symbols, FluidDraw can break up this group to distribute the individual elements to different pages.

- Highlight the valve terminal and select the **Distribute to multiple pages...** menu item from the context menu (right mouse button)





Figure 4/6: **Distribute to multiple pages...** dialog window

The preview window represents the separation points of the valve terminal. The black vertical lines show possible separation points, and the blue ones show those currently selected. You can move the blue separators with the mouse to change the desired separating position.

Number of pages	Defines how many pages the valve terminal is to be distributed to.
Distance between blocks	Defines the space between two blocks on a page.
Draw connection lines	If there are several separate blocks on a page, you can connect them using lines.
Accumulate interruptions	The connectors are on the left and right sides of the deleted symbols that are connected via interruptions to the previous or following pages. FluidDraw can summarize these connectors for a better overview and only create a single interruption.
After closing the dialog with OK , FluidDraw automatically creates several new project pages according to the distribution and distributes the individual blocks to the new pages.	

4.5 Connecting connectors

To connect two component connectors to a line, move the mouse pointer over a component connector. A connector is indicated by the small circle at the end of a connector line of the symbol. As soon as you “hit” a connector, the mouse pointer is converted into a crosshair .






Figure 4/7: Mouse pointer as crosshair over a component connector

➞ Now, press the left mouse button and move the mouse pointer to the connector you want to connect to the first one.

The shape of the mouse pointer  shows you when you are over the connector. If the mouse pointer is over a connector to which a line is already connected, the prohibited sign  appears and no line can be created.

➞ Let go of the mouse button once you have hit the second connector.

FluidDraw automatically inserts a line between the two connectors.




Figure 4/8: Line between two connectors



Vertices can be set when dragging lines. To do so simply release the mouse button while dragging the line and click the desired points. The line is completed as soon as you click a second connector or the same point twice. You can cancel the action by pressing the **ESC** key or the right mouse button.

4.6 Automatically connect connectors.

FluidDraw supports two methods of automatically connecting connectors. The first is to drop a symbol on an existing line. To be able to use this method, the symbol must have at least two connectors that precisely fit onto one or more existing lines and the lines that are created must not cross the symbol. The following two figures show this function.




Figure 4/9: Circuit before the connectors are automatically connected




Figure 4/10: Circuit after the connectors are automatically connected

Another method of automatically connecting connectors is to position symbols so that their connectors can be horizontally or vertically connected with free connectors from other symbols. After the symbol has been dropped the corresponding lines are automatically drawn if they do not cross any symbols. The free connectors can also be T-distributors.

You can define how the connectors of different objects are automatically connected in the *General Connector Links* tab under the **Options...** menu item in the **Manage** menu. The following two figures show this function.




Figure 4/11: Circuit before the connectors are automatically connected





Figure 4/12: Circuit after the connectors are automatically connected

4.7 Inserting T-distributors

To insert a T-distributor you do not need to use any special symbol. FluidDraw automatically inserts a T-distributor if you drag a component connector to a line or a line segment to a connector. If you want to connect two lines, you can also drag one line segment to another one. FluidDraw then inserts two T-distributors and connects them with a new line.

→ Move the mouse pointer to a connector and press the left mouse button.

If you are over a line segment, the mouse pointer is converted into a crosshair .

→ Let go of the mouse button once you have hit the desired point of the line.

FluidDraw inserts a T-distributor and automatically inserts a line.





Figure 4/13: Line connection with T-distributor inserted

Every T-distributor can be used to connect up to 4 lines.

The default representation of the T-distributor can be selected via the corresponding  drop-down list on the **Edit** ribbon page.

You can customize the representation of the T-distributor by double-clicking the T-distributor or highlighting the T-distributor and selecting the **Home** menu item in the **Properties...** menu. The “*Properties*” dialog window opens. Select the “*Representation*” tab.




Figure 4/14: T-distributor dialog window. Tab: *Representation*

T distributor

Defines the representation of the basic T-distributor. Here you can select whether the distributor should be represented as a filled circle or a simple intersection.


Cross-Link

Defines that the T-distributor should be represented as an electrical link. This representation has an effect on the connected lines, which are automatically marked as [links](#).

Junction

Defines that the T-distributor should be represented as an electric junction. This representation has an effect on the [terminal destination search](#). With a junction, the target in the direction of a straight line or right angle is found first and then the target via an angled branch.

4.8 Moving lines

After connecting two connectors, you can adapt the position of the lines. You can move the line segments parallel by moving the mouse pointer on the relevant line segment. The “line start” form  of the mouse pointer shows you when you have hit the line.

→ Press the left mouse button and move the line segment in orthogonal direction to the desired position.




Figure 4/15: Moving a line segment

→ If you let go of the mouse button, FluidDraw will adjust the adjacent line segments in such a way that the complete line is retained.

If you move a line segment that is connected directly to a component connector, FluidDraw will insert any additional line segments to avoid gaps.

If you move a line segment that is horizontally or vertically connected with other line segments via T-distributors then these line segments are moved together with the T-distributors.




Figure 4/16: Moving multiple line segments




Figure 4/17: Moving multiple line segments

If you only want to move the individual line segment in the case described above then release the mouse button after highlighting the line segment. Click the segment again and move it while keeping the mouse button pressed.




Figure 4/18: Moving an individual line segment

4.9 Defining the properties of the lines

Lines, like other symbols, can be assigned an identification, catalog properties and user-defined properties. You can find more information on this under [Component attributes in the Properties dialog window](#).

You can also define the style, color and [drawing layer](#) of the lines by double-clicking a line segment or highlighting the line segment and selecting the [Home](#) menu item in the [Properties...](#) menu. The *Line Properties* dialog window opens. Select the *Drawing Properties* tab in this window. The settings are applied to the entire line section as far as the next connector or T-distributor.




Figure 4/19: *Line Properties* dialog window: defining the properties of a pneumatic or electric line

Layer	Defines the drawing layer for the line.
Color	Defines the color of the line.
Line Style	Defines the line style of the line.
Line Width	Defines the line width of the line.
Start Cap	Defines how the start of the line is displayed.

End Cap

Defines how the end of the line is displayed.

Straight connection line

By default, FluidDraw automatically creates all lines orthogonally. However, in some cases it may be desirable to create a straight connection between two connectors.

Note: Working lines are typically displayed as continuous lines and control lines are displayed as dashed lines.

4.10 Deleting a line

To delete a [line](#) you can either highlight an associated line segment and press the [Del](#) key or select the [Home](#) menu item in the [Delete](#) menu or highlight a component connector and press the [Del](#) key. In these cases it is the line rather than the connector itself that is deleted.

If you delete a T-distributor to which three or four lines are connected, all lines are deleted. However, if only two lines are connected, only the T-distributor is deleted and the two lines are joined to form one line.

4.11 Defining the properties of the connectors

You can give a component connector an identification and a blanking plug or a silencer by double-clicking the connector or by highlighting the connector and selecting the [Properties...](#) menu item in the [Home](#) menu. The *Connector* dialog window opens.




Figure 4/20: *Connector* dialog window: defining the properties of a connector

Identification

You can enter a text for identifying this connector at the input line. The identification is shown in the circuit drawing if the *Display* option is selected.



Whether or not the identification is actually displayed depends on the option selected under [View](#) [Show Connector Descriptions](#).

Terminator


Open the symbol list containing connector terminators by clicking the button using the arrow. Select a suitable silencer or a blanking plug.

Note: Please note that this symbol list is only available if a [line](#) is not connected to the connector in question. If you wish to connect a line to a sealed connector you first have to remove the blanking plug or silencer. To do this select the empty field in the symbol list with the connector terminators. The alignment of the connector terminator can be set via the radio buttons.

4.12 Defining a component connector / setting a T-distributor

You can set T-distributors on existing lines or define a new component connector by selecting the **Insert** menu item in the **Define Connector...** menu. FluidDraw then switches to a special mode in which the next mouse click sets a T-distributor or defines the new connector. You can cancel the action by pressing the **Esc** key or the right mouse button.

Connectors in symbols can be placed at any positions.

Note: To place the connector as exactly as possible at the desired position, it is recommended to increase the size of the image section of the corresponding symbol significantly. As soon as the mouse pointer is over a symbol, it is converted into a crosshair . You define the new connection with a left-click.




Figure 4/21: **Define Connector...** dialog window

Type of connector

Selects the connector type. The following are available: “*Pneumatic*”, “*Hydraulic*”, “*Electric*” and “*Electric (Label)*”.

Define multiple connectors

Multiple connectors can be set one after the other if this option is active. You can cancel the action by pressing the **Esc** key.

4.13 Deleting a component connector

To delete a component connector, select it and select the **Delete Connector** menu item in the **Home** menu.

Note: Bear in mind that the **Delete** menu item or the **DEL** key does not delete the connector, only any connected **line**.

4.14 Configuring directional control valves

If you require a specific valve that you cannot find in the FluidDraw standard library, you can use the valve editor to create your own valve symbols.

➞ Insert a 5/n directional control valve into a circuit window from the “*Pneumatic symbols - ISO 1219-1 | Configurable symbols*” library.

To determine the valve bodies and actuation types of directional control valves, double-click the valve. The **Properties** dialog window opens. Click the “*Configure Valve*” tab. That opens the valve editor.




Figure 4/22: *Properties* dialog window: *Configure Valve* tab

Left Actuation – Right Actuation

You can select the actuation types of the valve from the “*Manually*”, “*Mechanically*” and “*Pneumatically/ Electrically*” categories for both sides of the valve. Click the button with the mouse pointer and select a symbol element. A valve can have multiple actuation types at the same time. If you do not want an actuation from a category then select the empty field in the list. You can also define whether each side should have a spring return, pilot control, pneumatic spring or external supply.

Valve Body

A configurable valve can have a maximum of four switching positions. A valve body can be selected for every switching position.

Click the corresponding button with the arrow to open the list of symbol elements. Select a symbol element for every switching position. If you require less than four switching positions, select the empty field for the positions not required in the list.

Initial Position	This is for defining which switching position the valve should assume in the normal position. Note: When making the definition, make sure that it does not contradict any spring return.
Dominant Signal	This is for indicating graphically whether the right-hand signal or the left-hand signal is to dominate if two equally strong signals are applied.
Spring-returned	This is for defining whether the corresponding side is to be equipped with a spring return.
Piloted	This is for defining whether the corresponding side is to be equipped with a pilot control.
Pneumatic Spring	This is for defining whether a pneumatic spring is to ensure the return on the corresponding side.
External Supply	This creates another connector via which the external supply of the controller is connected.
Pilot air exhaust	Creates a symbol for releasing the pilot exhaust air into the environment.
Pilot air exhaust (ducted)	This creates a further connector via which the pilot exhaust air is released.

4.15 Configuring cylinders

If you require a specific cylinder that you cannot find in the FluidDraw standard library, you can use the cylinder editor to create your own cylinder symbols.

→ Insert a double-acting cylinder into a circuit window from the “*Pneumatic symbols - ISO 1219-1 | Configurable symbols*” library.

Double-click the cylinder to configure it. The **Properties** dialog window opens. Click the “*Configure Cylinder*” tab. That opens the cylinder editor.




Figure 4/23: *Properties* dialog window: *Configure Cylinder* tab

Cylinder Type

Click the button with the arrow to open the list of the symbol elements. Select a cylinder type. Defines whether the cylinder is to be single-acting or double-acting.

Return Spring	Specifies whether a spring is to be inserted for the return in the right or left cylinder chamber.
Piston	Click the button with the arrow and select a symbol element for the piston. Define whether the cylinder is to have end-position cushioning and whether it can be adjusted.
Piston Rod	Click the button with the mouse pointer and select a symbol element for the piston rod.
Piston Position	You can use the slide ruler to specify the relative piston position in increments of 25 %. 0 % stands for a completely retracted piston and 100 % stands for a completely extended piston.

4.16 Grouping symbols

If you wish to combine multiple symbols to a group, then highlight them and select the [Home](#) menu item from the [Group](#) menu. Groups can also be nested, i.e. grouped objects can be grouped again.

A group is primarily a drawing aid and does not represent a new component. Every group element is added to a [parts list](#) in exactly the same way as without grouping. Double-click a group element to open the *Properties* dialog window of the clicked group element.

If you want to combine multiple symbols to a new component with its own attributes then create a [macro object](#).

4.17 Creating macro objects

If you wish to combine multiple symbols into a new component with its own attributes then highlight these and select the [Home](#) menu item from the [Create Macro Object](#) menu. This creates a new macro object. Macro objects are included in the [parts lists](#) as independent components. The original symbols are removed from

the parts lists. It is no longer possible to edit their component attributes.

4.18 Deleting symbol groups and macro objects

To delete a group or a macro object, highlight the group or the macro object and select the **Ungroup/Break Off** menu item in the **Home** menu. Always only the very outer group is deleted first. To delete nested groups, you must carry out the operation several times.

4.19 Aligning symbols


To mutually align objects, highlight them and select the desired alignment in the **Home** menu under the **Align** menu item or click



the corresponding button on the toolbar.

4.20 Mirroring symbols

The symbols can be mirrored horizontally and vertically. To do this, select the desired mirror axis in the **Home** menu under the



Mirror menu item or click the corresponding button on the toolbar. If you have highlighted several objects simultaneously, each object is mirrored on its own. If you want the operation to apply to a common mirror axis, group the objects prior to the operation.

You can also enter the drawing properties as component attributes under the “*Drawing Properties*” tab. Enter a negative sign in front of the scaling factor to mirror the symbol.

4.21 Rotating symbols

The symbols can be rotated in increments of 90 degrees or using the mouse pointer. For a rotation in 90 degree increments, select the desired angle in the **Home** menu under the **Rotate** menu



item or click the corresponding button **Rotate** on the toolbar. If you have highlighted several objects simultaneously, each object is rotated on its own. If you want the operation to apply to a common axis of rotation, group the objects prior to the operation.

You can also rotate symbols using the mouse pointer by dragging the edge of the symbol. In order to do this FluidDraw must be in **Enable Rotate** mode. This mode can be activated or deactivated on the **Edit** ribbon page with the **Enable Rotate** menu item.

Note: Activating **Enable Scale** mode deactivates **Enable Rotate** mode and vice versa.

→ In **Enable Rotate** mode, click the edge of a symbol and keep the mouse button pressed.




Figure 4/24: Rotating a symbol

The current angle of rotation and auxiliary lines are displayed.

→ Keep the mouse button pressed and move the mouse pointer until the desired angle of rotation is established. The angle changes in 15 degree steps.

Note: If you also press the **Shift** key then you can rotate the symbol continuously.




Figure 4/25: Rotating a symbol

The angle of rotation can also be entered directly in the properties dialog window on the **Drawing Properties** tab.

4.22 Scaling symbols

The component symbols can be scaled using the mouse pointer. In order to do this FluidDraw must be in **Enable Scale** mode. This mode can be activated or deactivated on the **Edit** ribbon page with the **Enable Scale** menu item.

Note: Activating **Enable Scale** mode deactivates **Enable Rotate** mode and vice versa.

→ In **Enable Scale** mode, click the edge or a corner of a symbol and keep the mouse button pressed.




Figure 4/26: Scaling a symbol

The current scaling relationship to the current original size is displayed.

→ Move the mouse pointer, keeping the mouse button pressed, until the desired size is established. The scaling relationship is

changed in increments of 0.25. If you also press the **Shift** key then you can scale the symbol continuously.




Figure 4/27: Scaling a symbol

You can simultaneously mirror the symbol by moving the mouse pointer over the middle of the symbol to the opposite side.




Figure 4/28: Mirroring a symbol

The scaling factors can also be entered directly in the *Properties* dialog window on the [Drawing Properties](#) tab.

Drawing frame

Chapter 5

FluidDraw provides some drawing frames that can be embedded at the project or page level. FluidDraw provides a special [editor](#) for adjustments or user-specific drawing frames. It can be used to flexibly adapt the header and the frame with the distribution of fields.

5.1 Using the drawing frame

To select a drawing frame that is to be used for all pages of the entire project, open the project's properties dialog. You can then overwrite this setting e.g. for a page with a parts list or for a complete project node and define a different drawing frame.

⇒ Open the properties of a page and activate the *Drawing Frame* tab. Remove the *Inherit From Project* option, if necessary.




Figure 5/1: *Page* dialog window: inserting a drawing frame

Inherit From Project

If this option is activated then the drawing frame specified in the project is copied into the circuit. The path and the file used are displayed in the “*Frame File*” line.

Pick...

This button is used to open a dialog that can be used to select a frame provided. These frame files are to be found in the **frm** directory.

Reload File

Reloads the frame from the specified file. That can be practical if the drawing frame was changed in the meantime.

Edit...

Opens the frame file for editing in the [drawing frame editor](#).

Remove Local Frame

Removes the drawing frame from the circuit. The attributes of the drawing frame are retained as attributes of the project or of the circuit.

Reload Frame Attributes

When you insert a drawing frame, the attributes of the drawing frame are listed. These attributes are saved with the project or with the circuit drawing and can be edited and deleted. You can use the **Reload Frame Attributes** to reload all attributes from the drawing frame and thus update the attribute list of the project or of the circuit drawing.

→ Click **Pick...** to select a drawing frame.




Figure 5/2: *Select Drawing Frame* dialog window

All available frame files are displayed as a tree on the left side. The desired drawing frame can be selected in this tree. The drawing frame is then displayed in the preview.

You can find a detailed description of the options for managing the drawing frames in the section: [Manage templates](#)

5.2 Drawing frame editor

You can use the drawing frame editor to create new drawing frames and edit existing frames.

The editor can be started regardless of a specific project or page directly via the main menu and the **Manage templates...** menu item.

Alternatively, you can open the editor via the properties of the project or of an individual page. Select a drawing frame first on the *Drawing Frame* tab and then press the **Edit...** button to open this frame in the editor to edit it.

5.2.1 The structure of a drawing frame

Creating or editing a drawing frame in the editor is split up into individual small steps, which are displayed on various tabs. The individual tabs are generally to be gone through in steps from the left to the right like in a wizard. For navigation, please use the two **◀ Previous** and **Next ▶** buttons at the bottom edge of the editor.

As an alternative, you also have the option of going directly to a specific tab by clicking its title. You can thus change specific aspects of the drawing frame in a selective manner. When you use the editor for the first time, we recommend that you go through all tabs once in succession to familiarize yourself with the contents of the individual steps.

The basic structure of a drawing frame consists of the following five components:

1. Drawing page
2. Outer frame
3. Page dividers

4. Inner frame

5. Header

The drawing space that can be used with the drawing page is defined by the inner frame. The following diagram illustrates the previously mentioned elements:




Figure 5/3: Elements of a drawing frame

In the following steps, you have the option of changing all properties of these elements.

5.2.2 Drawing Size




Figure 5/4: *Drawing Size* tab

On this page of the editor, you can assign a designation and change the size and alignment of the drawing frame. At the top, you can either select one of the specified default sizes from the stored list or enter your complete own dimensions. You can adapt the alignment of the frame below.

In addition, the current dimensions are displayed to you in the preview on the right side for illustration.

5.2.3 Page border




Figure 5/5: *Page bordertab*

You have the option here of designing the outer and inner frame lines according to your requirements.

At the top you can select the line width, line type and color properties for the corresponding frame line. If desired, you can also remove one line or both lines from the drawing by means of the check box.

In the center, you can set the outer edge between the outer frame line and the edge of the drawing page, as well as the inner edge between the two frame lines. Your changes of the set values are displayed to you directly in the preview on the right side.

At the bottom, you can have additional markings drawn in the drawing frame.

5.2.4 Page Dividers




Figure 5/6: *Page Dividers* tab

The page dividers can be configured on this tab.

At the top, on the left side, you can configure the labelling properties of the individual rows. In the area below, you can configure the labelling properties of the individual columns.

For the distribution of the rows and columns you can either specify a fixed number or a specific height or width.

- If you define a specific row height or column width, then the columns/rows are entered with the specified width/height, starting at the center of the inner frame. The last column or the last row on both pages of the drawing frame may be smaller than the specified width with this distribution. The following diagram gives an example of the distribution of the columns on a DIN A4 page in landscape format with a set column width of 50 mm.




Figure 5/7: Example of column widths in the event of a specified column width

- If you instead specify a fixed number of rows or columns, the width/height of the inner frame with the specified number is split up into columns of the same size. The following diagram shows the distribution of the columns on the same DIN A4 page as previously with six columns.




Figure 5/8: Example of column widths in the event of a specified number of columns

The numbers define how the columns or rows are to be labelled. You can choose between numerical labelling and alphabetic labelling with upper or lower case. You can enter with which number or letter the caption is to begin with in the *First Item* field.

By default, the columns are labelled continuously from the left to the right and the rows from top to bottom. Select the *Descending Order* check box if you want to reverse the labelling order.

The current status of the page division is displayed to you on the right side together with special control elements for manually adjusting the division. The control elements displayed there match those in the page windows in FluidDraw and can also be used to configure the complete page division manually. The width and the height of the vision always correspond to the complete width or height of the inner frame here, however.

5.2.5 Title block customizing




Figure 5/9: Title block customizing tab

You can adjust and design the header according to your requirements here.

General design and layout of the header

The header within the drawing frame consists of a table with a specific number of columns and rows. Either a fixed text, an attribute link or an image can be entered in the individual cells of the table.

Using the **Select template...** button at the top edge of the tab, you can open a dialog that you can use to load predefined headers into the editor.




Figure 5/10: Dialog for selecting a header

You can use the dialog to select a template for the header. Either use one of the integrated templates or select a user-defined template. The selected header is displayed to you as a preview on the right side.

Selecting/highlighting cells

You can select individual cells of the table by left-clicking them. The selected cell is then displayed with a thicker, blue border. The contents of the selected cell, its cell properties and the dimensions of the corresponding row and column are shown below the displayed table.

You can highlight an area with several cells by moving the mouse over further cells while keeping the left mouse button pressed. Alternatively, you can click the first and last cell one after the other while keeping the **Shift** key pressed. You can highlight several cells not connected by clicking them with the mouse and keeping the **Ctrl** key pressed. The selected area is given a thick blue border.

Adjusting the table structure

You can change the number of rows and columns of the current table by right-clicking a cell within the table. A context menu appears for the currently selected cell. You can find commands for adding a deleting rows or columns below the **Insert** and **Delete** menu items.

You can change the width of a column or the height of a row by moving the mouse pointer to the edge of the cell, pressing the left

mouse button there and moving the cell border accordingly. The corresponding cell is thus increased and reduced in size along with the overall width/overall height of the table. Keep the **Ctrl** pressed when you move the mouse to change the size of the cell without changing the overall width/overall height of the table.

As an alternative to changing the cell width or cell height by moving the mouse, you can enter the dimensions directly in the input fields below the displayed table. First select a cell from the row / column that you want to change and then enter the desired values in the input fields.

Several cells can be joined to form one cell within the table. Such a joined cell then covers several columns and/or several rows.

To connect several cells, highlight them first in the table and then click the **Merge cells** button on the menu bar above the table displayed. Only a rectangular continuous cell area can be connected. When the connection is established, only the contents and formatting from the top left cell of the highlighted area are retained. The **Split cells** button is available to separate a joined cell.

Entering a fixed text

You can enter a fixed text in a cell by double-clicking the cell with the left mouse button. An input cursor appears in the cell and you can enter the desired text directly. You can also highlight a cell and press the F2 function key to activate direct cell input.

These texts entered by you are not saved in a language-dependent manner. That means the text you entered is shown as entered, regardless of the page or project language used later on. If you want to use a language-dependent text, you can use the predefined attribute texts, which are displayed to you in the list next to the displayed table. Highlight the desired text, drag the text with the left mouse button pressed into the desired table cell and let go of the mouse button there. Only then is the corresponding internal placeholder for the attribute text entered in the cell. For the “*Project*” attribute, for example, the internal placeholder is “~FrmAttProject”.

Text formatting

You can change the text formatting of a cell using the menu bar above the displayed table. Select those cells in the table whose formatting you want to change. Then, click the corresponding button on the menu bar or select the desired value.



Figure 5/11: Menu bar above the displayed table

Using the menu bar, you can change the following formatting properties:

- Font
- Font size
- Font style (B = bold; I = italics; U = underlined)
- Horizontal alignment (left; centered; right)
- Vertical alignment (top; centered; bottom)
- Background color
- Font color

If you select a cell in the table, the font and font size of the selected cell are automatically displayed on the menu bar. The buttons for the font style, and horizontal and vertical alignment are enabled according to the current setting in the cell.

Inserting images

You can insert an image in a cell by selecting the desired cell and then clicking the Choose picture... button below the displayed table. A dialog appears that you can use to select your image for insertion. The file formats Bitmap, JPEG, PNG and GIF are supported.

The path and the file name of the selected image are displayed to you after selecting the image in the input field using the button and the image is displayed in the highlighted cell of the table. The size of the image is adapted taking the correct width-to-height ratio of the cell into account. The maximum width or height of the cell is always utilized for display purposes. Increase the size of the cell if the displayed image is to be increased in size.

A newly inserted image is linked to the cell via the path and the file name. That is indicated by the selected *External Link* check box. For each subsequent use of the drawing frame, the image is reloaded

from the specified location. If it is not found there, a red X is displayed instead of the image.

To permanently integrate the image in the drawing frame, remove the check mark from the *External Link* check box. The image is embedded in the drawing frame and is always visible in the drawing frame regardless of the path of the original file. By embedding graphics in the drawing frame, you increase the memory space required for the drawing frame and the projects that use this frame. Therefore, it is best to use images that save space.

Setting frame lines

The frame lines in a cell are influenced using the **Borderlines** button on the menu bar above the displayed table. Select those cells in the table that you want to give a frame. Then click the small triangle at the right edge of the button to open a selection menu of the available frame lines.




Figure 5/12: Frame line selection

You can set the desired frame for the highlighted cells from this menu. By selecting **No border**, you remove all existing borders from the selected cells. Your frame selection is transferred to the button and can be set for other cells by clicking the button directly.

Frame attributes and variables

In addition to the previously described contents of the fixed texts and images, variable elements can also be inserted in the header, whose value is determined later on when the drawing frame is used in a specific project or page. These are drawing frame attributes, which are managed later on in the properties of the project or page,

and also predefined variables, which are automatically replaced by the corresponding value in the drawing.

Drawing frame attributes

Drawing frame attributes are special placeholders that you can define in the header and at whose point in the final drawing the value of the attribute of the corresponding page or of the project is displayed. That can be e.g. the name of the project, the title of the drawing or the release date.

The available attributes are displayed to you on the left side of the dialog in a list view. You can find predefined attributes, predefined variables and user-defined attributes in this list.

Every frame attribute generally consists of two parts: an attribute caption and a placeholder that is replaced by the value of the entered attribute later on. The attribute caption is to be found in the *Displayed Text* column and the placeholder in the *Default value* column. The placeholder is displayed in the *Default value* column in grey fonts in pointed brackets if no default value is entered.

To use an attribute in its frame, select the placeholder of the desired attribute in the *Default value* column and drag it, while keeping the left mouse button pressed, into the desired table cell. If you let go of the mouse button over the desired cell, the selected placeholder is entered there for the attribute. Only by entering the placeholder in the header is the selected attribute displayed on the “*Attributes*” tab later on when the drawing frame is used. You can assign a specific value to it.

You can store default values for attributes in the drawing frame. To do this, double-click the corresponding placeholder in the attribute list and enter the desired default value. It is then displayed in the header instead of the placeholder for the attribute. However, the placeholder is still entered in the corresponding cell. Later on when the drawing frame is used, the entered default value is transferred as an attribute value to the diagram. However, it can be changed at any time there. By entering a default value, you also have the option of checking if the text formatting and the size of the cell are correct.

If you want to add the attribute caption in the header in addition to the placeholder for the attribute value, then highlight the corresponding caption in the *Displayed Text* column and then drag it, with the left mouse button pressed, into the desired cell of the table. The predefined attributes use special variables for the caption in order that the attribute caption can be displayed in the corresponding page language.

In addition to the predefined attributes and variables, you have the option of defining your own attributes. To add an attribute, click the **Add Attribute...** button and enter a name for the attribute. Then, the new user-defined attribute is displayed to you in the list and you can use it like the previously described predefined attributes in the header. The only difference to the predefined attributes is that the caption depends on the language and is not automatically translated, even if there are different page languages.

Variables

The attribute list on the page on which the table is displayed contains the following predefined variables:

- Page number
- Description
- Installation
- Circuit
- Location
- File Name
- Full file path
- Full project path
- File modification date and time
- File modification date
- File modification time
- Total project pages

These predefined variables are used in exactly the same way as the previously described frame attributes. Drag the desired variable from the list into the table. The difference is that the values for the variables in the specific drawing are entered automatically, which is why you cannot specify a default value.

5.2.6 Title block location




Figure 5/13: *Title block location* tab

You can adjust the position of the header within the drawing frame here.

Select the desired position from the specified options. The modified position of the header is displayed to you in the preview on the right side.

5.3 Adding fixed elements to drawing frames

The drawing frame editor shown in the previous section can be used to create a drawing frame with the main graphic elements and, above all, a dynamic title block. Additional graphic elements, such as a watermark or a copyright notice, cannot be created within the editor. A different concept is provided for this.

Not only those files created with the drawing frame editor can be used as drawing frames. In addition, it is also possible to use each individual sheet of an existing project as a drawing frame in another project. This way you have the possibility to enrich a drawing frame with other elements.

The following example shows how you can add a watermark with text to a given drawing frame:

- Create a new project with a single page.
- Select and assign a drawing frame that you want to enrich with additional objects.
- Add all new elements to the sheet at the right location. To create a watermark, insert a text object with the menu item **Text** in the menu **Insert**. Utilize the possibilities to format a text to increase the font-size, to rotate the text or to change the color.




Figure 5/14: Example for a watermark with fixed text

You can also insert a text object that will contain an attribute value of the project or sheet. For this insert a new text object with a simple text like “ReleaseStatus”. Additionally set the option *Attribute Link* within the properties of the text object. The text will then be shown in angle brackets. The entered text “ReleaseStatus” will be the new frame attribute that will show up in the project attributes where you can enter a value for it.




Figure 5/15: Example for an additional frame attribute

- Save the new project with the enhanced drawing frame and close it.

In order for the extended drawing frame to be used in another project, the project just created must be added to the template management. This only has to be done once. The entry is then preserved and can be used like all other entries.

- Open the template management with the menu item **Manage templates...** in the menu **Manage**.
- Click with the right mouse button on the topmost node with the label *Drawing Frame* and select **Add Existing Files...** from the context menu.




Figure 5/16: Adding an existing file to the drawing frame templates

- A dialog to select a file appears, but initially the dialog does not show FluidDraw project files. You can change that by selecting a different file filter in the lower right of the dialog. Change it from “Drawing Frames (*.frm)” to “Project Files (*.fdprj; *.prj).”




Figure 5/17: Changing the file filter to show project files

- Now navigate to the path where you saved the previously created project, select the project and click **Open...**. The project is then included as a reference in the drawing frame selection and is available as a new entry.

Now you can use the page with the enhanced drawing frame as drawing frame in your projects.

- Open an existing project or create a new project.
- Select and assign the new enhanced drawing frame for the project. (In this example the page with a watermark.)




Figure 5/18: Selection of the new drawing frame with watermark from the frames project

When you have created an additional frame attribute, you will find it in the project properties in the *Attributes* tab. There you can enter an attribute value analog to the other attributes from the title block and it will show up in the prepared text field.


Notes:

- The project with the extended drawing frame can also contain several sheets, e.g. with different contents. The appropriate frame can be selected according to requirements.
- The extended drawing frame can no longer be edited directly in the drawing frame editor. If you want to change the drawing frame, reopen the frame project in FluidDraw and edit the corresponding pages. The drawing frame editor can then be called from there.

- With the extended drawing frames, it is still the case that all objects of the drawing frame are placed on drawing layer 0 and cannot be changed. A prominently placed watermark in the background does not disturb the drawing creation.

5.4 Page dividers

A circuit diagram or page can be logically divided into rows and columns, which can be labelled with numbers or letters. These page dividers are usually shown in the [drawing frame](#) and serve as a means of orientation within the page. Above all they allow the current paths (columns) of contacts to be specified in the [contact images](#).

The graphical representation of the page dividers matches the logical page dividers in the drawing frames provided. The logical page dividers can be shown and hidden via the [Show Page Dividers](#) menu item in the [View](#) menu or using the  button. They are displayed at the left edge as well as the upper edge of the circuit window.

If the page dividers are displayed you can customize them using the mouse so that they match the graphical representation of the drawing frame, for example. This customization can be done in different ways:

- Click and hold the mouse buttons in a column or row to move the entire column or row.




Figure 5/19: Page dividers

- Click and hold the mouse buttons at the outer margin of a column or row to move the margin of the column or row.




Figure 5/20: Page dividers

The opposite margin is not moved and the columns or rows are resized proportionally.

→ Click and hold the mouse buttons at the margin of an inner division in a column or row to move the margin of the column or row.







Figure 5/21: Page dividers

In this case only the adjacent columns or rows are resized.

Columns and rows can be inserted and removed using the  and  buttons.

The labelling type and the number of rows and columns can be defined using the  button. The settings are saved as page properties. The following dialog window is opened:

Page Dividers

☐ Adopt from drawing frame

☒ Setup manually

Rows

Number

Numbering

First Item

☐ Descending Order

Columns

Number

Numbering

First Item

☐ Descending Order

☐ Skip letters 'I' and 'O'

Reset

Figure 5/22: [Page](#) dialog window, *Page Dividers* tab

Adopt from drawing frame	If this option is activated then all settings that have been defined in the drawing frame are adopted.
Rows	Defines the settings for the horizontal rows.
Columns	Defines the settings for the vertical columns.
Number	Defines the number of page dividers.
Numbering	Numbers, lower case letters or upper case letters can be used for numbering.
First Item	Defines the first numbering item. Numbering is continued in the same way starting with this element.
Descending Order	Reverses the numbering order.
Skip letters 'I' and 'O'	If this option is active, the letters "I" and "O" are not used for numbering. That prevents any risk of confusion with the numbers "1" and "0".

Reset

Resets the page dividers to default values.

Additional tools for creating drawings

Chapter 6

6.1 Drawing aids

6.1.1 Grid

For arranging the symbols and inserting the [lines](#) it is often practical to show a point or line grid. You can activate or deactivate the display of the grid using the [View](#) menu item in the [Show Grid](#) menu. You can define more [grid settings](#) in the [Manage](#) menu under the [Options...](#) menu item on the *Representation Grid* tab.

In order to simplify handling the connectors snap into place when they are close to a grid line. This makes it easier to find the precise position when moving the connectors.

Note: The grid snap function may sometimes not be desired as it prevents free positioning. In this case you can keep the [Ctrl](#) key pressed during the moving operation, which temporarily deactivates the grid snap function.

6.1.2 Alignment lines

Connectors of symbols should be aligned horizontally or vertically as precisely as possible. Then, they can be connected with a straight line.

FluidDraw supports precise positioning by the [grid snap](#) function on the one hand, and by automatically displaying red alignment lines while the highlighted objects are moved on the other hand.

→ Opens a circuit file that contains several objects. Highlight one of them and move it slowly back and forth over and next to other objects.

Pay attention to the red dashed lines that appear if two or more connectors lie below each other.




Figure 6/1: Automatically displaying the alignment lines


In order to simplify handling the connectors snap into place when they are close to an alignment line. This makes it easier to find the precise position when moving the connectors.

Note: The grid snap function may sometimes not be desired as it prevents free positioning. In this case you can keep the **Ctrl** key pressed during the moving operation, which temporarily deactivates the alignment lines and the grid snap function.

6.1.3 Object snap

Various snap points can be activated for precise drawing. During a drawing operation the mouse pointer snaps into place as soon as it is close to a snap point.

The following snap functions are available, which can be selected individually via the ribbon under **Edit** *Snap*:



Press the **Ctrl** key and keep it pressed during a drawing operation to temporarily deactivate the object snap function.

6.1.4 Rulers

The rulers can be shown and hidden via **View** **Show Rulers**. They are displayed at the left-hand as well as the upper edge of the circuit window.

6.2 Drawing layers

FluidDraw supports 256 drawing layers that can be shown/hidden and disabled/enabled individually. You can also define the color, the style and the line width for each drawing layer.

Like with most other settings, you can also define drawing layers separately for the project, a project node or a page. When you create a new project, the default settings defined under **Manage** in **Options...** / *Drawing Layers* are copied. You can change these settings at any time individually in the properties of a project node or page.

Note: The **drawing frame** is in layer “0” by default.




Figure 6/2: *Drawing Layers* dialog window

Inherit From Parent Node

If this option is selected, the drawing layers defined in the project or in the parent node are used for the page.

Copy from global options

This is for copying the settings defined under **Manage** in **Options...** / *Drawing Layers*.



Please note that the global settings are then copied **once**. If the global settings for the drawing frame change later on, the locally copied drawing layers are retained. That ensures that the appearance of the circuit diagrams does not depend on the user's individual settings.

On insert objects to page	Define the drawing layer of the objects here if they are inserted via the clipboard or from another page.
Default Layer	You can select the drawing layer where newly inserted objects should be placed here. If you do not want the symbol level to be changed when objects are inserted then select the “ <i>Preserve Object Layer</i> ” option.
Number	Defines the number of the drawing layer.
Description	Defines the description of the drawing layer.
Color	Defines the color of the objects in this drawing layer.
Line Style	Defines the line style of the objects in this drawing layer.
Line Width	Defines the line width of the objects in this drawing layer.
Display	If this option is deselected, the corresponding drawing layer is not visible and cannot be edited either.
Edit	If this option is deselected, objects located in the relevant drawing layer are visible but cannot be highlighted and therefore neither moved nor deleted.

6.3 Displaying line jumps

Intersecting lines are sometimes difficult to distinguish from T-distributors. FluidDraw therefore provides the option of displaying crossing lines as *line jumps*. You can find the option as a default setting under [Manage](#) / [Options...](#) and as a page or project setting under [Representation](#)




Figure 6/3: Displaying intersections as line jumps

6.4 Selection filter

To edit the circuits, it is frequently useful to select specific object types or objects simultaneously at certain drawing layers. In addition to the methods already described with the **Ctrl** key pressed and the creation of a selection rectangle, FluidDraw provides the **Select** menu.




Figure 6/4: Object selection filter

The selection of the different object types can be used in two ways:

- Set the desired object types **before** selecting them. With this option, you define which object types are to be highlighted during subsequent selection operations. This filter can be used if you simply click an object, when you create a rectangle and also with the **Select All** command. Only objects that meet the selection criterion are highlighted.

- Set the desired object types **after** selecting them. With this option, you can subsequently limit a selection already made. First select individual objects or all objects and highlight an area with the mouse. Then deactivate those object types that you want to exclude from the selection. FluidDraw memorizes the originally selected objects so that you can adapt the object types as desired. However, more object types are never selected than were highlighted before selecting the filter.



After using the selection filter, make sure to switch back to the **All Objects** option to be able to fully edit your circuit diagram again.

Active Drawing Layer Only

With this option, the selection only applies to the selected **drawing layer**.

→ First cancel all selections by clicking a free space on the page or by pressing the **F5** key.

You can thus select the standard drawing layer without changing any highlighted objects.

→ Now select the drawing layer you want to edit from the drop-down list.

You can now combine the **Active Drawing Layer Only** option with the other criteria.

Protect connector texts

That prevents any inadvertent displacement of the connector texts if you want to move a symbol.

FluidDraw permits the positioning of identifications, connector designations and attribute links as desired. These texts move along with the corresponding symbol when it is moved. In the case of small symbols or e.g. valves with many connectors, it is possible that you inadvertently select a connector text although you wanted to move the entire symbol. In this case, you will inadvertently move the text away from the symbol.

To avoid this type of operational error, the connector texts can be protected. These texts can therefore not be moved individually. Instead the entire symbol is automatically highlighted with all other associated texts. Deactivate this option if you want to position connector texts individually again.

Layer

In this drop-down list, you define the [drawing layer](#) to which the object selection is to apply.

6.5 Cross-references

Cross-references serve to link connected parts of a circuit drawing when the entire drawing is spread across several pages. This allows lines to be interrupted, for example, and continued on another page.

FluidDraw supports two types of cross-references. Paired cross-references consist of two cross-reference symbols that refer to each other. The two cross-reference symbols are linked via a unique label that is entered for both symbols.

The option also exists to reference any object within a project from a cross-reference symbol. The cross-reference is unidirectional in this case: from the cross-reference to the target object. This allows several cross-references to refer to the same object.

Both types enable you to jump directly from a cross-reference to the associated destination. With the paired cross-reference the destination is the corresponding cross-reference, otherwise an object.

Paired cross-references are to be found as symbols in the standard library under “ *Drawing elements and cross-references*” and can be inserted in circuit drawings.

You jump to the corresponding destination either using the [Jump to Target](#) button in the properties dialog window for the cross-reference symbol or by highlighting the cross-reference and selecting the [Jump to Target](#) menu item from the context menu.

The circuit drawings involved must belong to the same [project](#). Open the [Home](#) dialog window via the [Properties...](#) menu and the *Cross-reference* menu item. Alternatively you can open this dialog window by double-clicking the cross-reference symbol or using the [Properties...](#) context menu.




Figure 6/5: *Cross-reference* dialog window

Layer	The cross-reference is assigned to this drawing layer.
Text	This text is displayed in the cross-reference.
Label	Defines the label used to identify the cross-references linked to each other.
Link	If this option is activated then the label entered represents a link to a target object. The cross-reference only works in the direction of the target object in this case. This option can be combined with the <i>Show Location</i> option to show the location of the target object.
Target Text	

If the *Show Location* option is activated then the position of the target object is displayed here. The representation of the position is defined in the *Cross Reference Representation* tab in the properties dialog window for the page or project.

If *Show Description* is activated then the text of the corresponding cross-reference is displayed for paired cross-references, otherwise the description of the target object is displayed.

Display Target Text

If this option is activated then the above-mentioned text from the *Target Text* field is displayed below the text for this cross-reference.

Jump to Target

Pressing this button opens the circuit window that contains the corresponding cross-reference. The relevant symbol is indicated by an animation.

The font, text color and alignment of the texts to be displayed can also be customized.

6.5.1 Creating cross-references from symbols

You can create a cross-reference from one or more symbols.

→ To do so highlight the corresponding symbols and select the **Home** **Create Cross-reference** menu item or the **Create Cross-reference** menu item from the context menu.

The highlighted symbols are combined into a group that represents a cross-reference with two additional texts. One of these texts shows the label used and the other the target text for the cross-reference.

6.5.2 Cross-reference representation

The position of the target object can be shown in cross-references. How it is represented can be specified on the *Cross Reference Representation* tab in the properties dialog window for the circuit or project. The position can be compiled from the “*Page number*”, “*Page*”, “*Page Column*”, “*Page Row*”, “*Target Connector*”, “*Target Object*” and “*Object Identification*” components. These refer to the target object. Separators can be specified before and after each component. The default representation is:

/ *Page number*. *Page Column* The description of the page and the page number is specified in the [Properties dialog window for the circuit](#). The page number is a [predefined placeholder](#) that can be used in [text components](#) and [drawing frames](#), among other things.




Figure 6/6: *Cross Reference Representation* tab

Inherit From Parent Node

Defines whether the representation rules for the parent node should be applied.

Copy from global options

This is for copying the settings defined under **Manage** in **Options...** / *Cross Reference Representation*.



Please note that the global settings are then copied **once**. If the global settings for displaying the cross-reference change later on, the locally copied options are retained. That ensures that the appearance of the circuit diagrams does not depend on the user's individual settings.

Suppress Inherited Parts	If this option is active, components of the cross-reference are hidden that are valid for all elements of the corresponding page or project.
Example	A position example that conforms to the specified rules is displayed here.

6.5.3 Managing cross-references

All paired cross-references in a project are listed in a dialog window that is opened using the [Project](#) [Manage Cross References...](#) menu item. Using this dialog you can jump to all paired cross-references in the project.




Figure 6/7: [Manage Cross References...](#) tab

Label	Contains the label for the corresponding cross-reference.
-------	---

Containing Page

A page containing the cross-reference in question can be selected in the drop-down list.

Jump to Target

Using this button you can jump to the corresponding cross-reference.

6.6 Drawing functions and graphical elements

Graphical elements can be inserted into a circuit via the **Insert** under *Object* or **Draw**. In order to prevent you from unintentionally moving other symbols when drawing you activate a special mode for the drawing function in which you can only perform the selected drawing functions. After every drawing operation FluidDraw returns to the normal editing mode. To insert another drawing element you must select the associated menu item or the corresponding drawing function on the toolbar again.

Note: If you want to draw several elements in succession without exiting the special drawing mode every time, then you can select the menu item or the corresponding drawing function on the toolbar while keeping the **Shift** key pressed. Drawing mode then remains active until the menu item or the drawing function is deactivated by selecting it again or another drawing function is selected without the **Shift** key being pressed.

The **Insert** ribbon page contains the **Draw** and *Object* groups with the following buttons:



Switches to the mode for inserting a **text**.



Switches to the mode for inserting an **image**.



Switches to the mode for drawing a **line**.



Switches to the mode for drawing a **rectangle**.



Switches to the mode for drawing a **circle**.



Switches to the mode for drawing an **ellipse**.



Switches to the mode for drawing a **polyline**.



Switches to the mode for drawing a **conduction line**. You can start by choosing whether you would like to draw a pneumatic, hydraulic or electric conduction line.




Switches to the mode for drawing an **interruption or potential**. You can start by choosing whether you would like to draw a pneumatic, hydraulic or electric interruption or such a potential.


The **Edit** ribbon page enables the definition of the line attributes:




The graphical elements are drawn in the specified color.




The graphical elements are drawn with the specified line style.



The graphical elements are drawn with the specified line width.



The starts of lines are drawn with the specified symbol.



The ends of lines are drawn with the specified symbol.



Any change to the line attributes does not only apply to drawing elements that will be inserted in the future, but also to any currently highlighted objects. In this case, you will be asked whether the properties are also to be transferred to the currently highlighted objects.

6.6.1 Hatching

Drawing elements that define an area, such as rectangles, circles or polylines can be given a hatching. The corresponding elements have a *Hatching* button that can be used to open the hatching dialog.




Figure 6/8: *Hatching* dialog window

First Pattern	You define the settings for the first hatching here.
Line color	Defines the color of the hatching.
Line Style	Defines the line style.
Line Width	Defines the line width.
Angle	Defines the angle of the hatching.
Distance	Defines the line spacing of the hatching.
Second Pattern	A second hatching can be activated as an option that can be combined with the first pattern.

6.6.2 Text

A text is inserted at the position of the mouse pointer with a click. That opens the *Properties* dialog window for entering the text and setting the attributes.

A text can be inserted using the corresponding button of the *Object* group on the **Insert** ribbon page.

6.6.3 Image

An image is inserted at the position of the mouse pointer with a click. That opens the dialog window for selecting an existing image file.

An image can be inserted using the corresponding button of the *Object* group on the **Insert** ribbon page.



Large background images can reduce the processing speed significantly, as when symbols are moved or edited the screen view needs to be rebuilt.

The image-specific properties can be defined in the *Properties* and *Drawing Properties* tabs of the *Picture* dialog window for the image:

The image shows a 'Drawing Properties' dialog box with the following fields and controls:

- Position:**
 - Left: 84 mm
 - Top: 255 mm
- Scale:**
 - x: 1
 - y: 1
- Rotation:** 0 Deg
- Override Color:** A checkbox (unchecked) and a color selection button.
- Display Mode:** Radio buttons for 'Background' (unchecked) and 'Foreground' (checked).
- Reset:** A button to reset all values.

Figure 6/9: *Properties* dialog window of an image: *Drawing Properties* tab

Position	Defines the top left position of the image.
Scale	Defines the scaling in x or y direction.
Rotation	Defines the rotation angle in degrees.
Override Color	Defines the color of the drawing element.
Background	Defines that the drawing element is displayed in the background. This means that all circuit symbols are on top of it. In particular this means that symbols are not covered by filled drawing elements, for example.
Foreground	Defines that the drawing element is displayed in the foreground. This means that all circuit symbols are under it. In particular it means that symbols are covered by filled drawing elements, for example.



Figure 6/10: *Properties* dialog window of an image: *Picture* tab

File	Defines the image file of the image.
External Link	If the option is selected FluidDraw only saves one link to the image file. If this option is deselected, however, the image is embedded in the circuit. This is the option to be preferred if you want to forward or archive the circuit drawing.

6.6.4 Line

A line is drawn by defining two points. In contrast to a conduction line this line is purely a drawing element. As such it can be drawn with any desired angle but does not allow connections with pneumatic or electric connectors.

A line can be inserted using the corresponding button of the **Draw** group on the **Insert** ribbon page.

The line-specific properties can be defined in the *Properties* dialog window for the line on the *Drawing Properties* tab:

The image shows a 'Drawing Properties' dialog box for a line. It contains the following fields and controls:

- Start Point:** x = 132 mm, y = 84 mm.
- End Point:** x = 177 mm, y = 75 mm.
- Scale:** x = 1, y = 1.
- Rotation:** 11.3099324741 Deg.
- Color:** A black color swatch with a dropdown arrow.
- Line Style:** A dropdown menu.
- Line Width:** 0.1 with a dropdown arrow.
- Start Cap:** A dropdown menu.
- End Cap:** A dropdown menu.
- Background:** An unselected radio button.
- Foreground:** A selected radio button.
- Reset:** A button at the bottom right.

Figure 6/11: *Properties* dialog window of a line: *Drawing Properties* tab

Start Point	Defines the x/y coordinate of the starting point.
End Point	Defines the x/y coordinate of the end point.
Scale	Defines the scaling in x or y direction.
Rotation	Defines the rotation angle in degrees.
Color	Defines the color of the drawing element.
Line Style	Defines the line style.
Line Width	Defines the line width.
Start Cap	Defines how the beginning of the line is displayed.
End Cap	Defines how the end of the line is displayed.
Background	Defines that the drawing element is displayed in the background. This means that all circuit symbols are on top of it. In particular this means that symbols are not covered by filled drawing elements, for example.

Foreground	Defines that the drawing element is displayed in the foreground. This means that all circuit symbols are under it. In particular it means that symbols are covered by filled drawing elements, for example.
Reset	Reset the settings to the default values.

6.6.5 Rectangle

A rectangle is drawn by defining two diagonally opposite corner points.

A rectangle can be inserted using the corresponding button of the **Draw** group on the **Insert** ribbon page.

The rectangle-specific properties can be defined on the *Drawing Properties* tab of the *Properties* dialog window for the rectangle:

The image shows a software dialog box titled "Drawing Properties" for configuring a rectangle. It is organized into several sections:

- Position:** Includes input fields for "Left" (225) and "Top" (33), each with a "mm" unit dropdown.
- Size:** Includes input fields for "Width" (27) and "Height" (15), each with a "mm" unit dropdown.
- Color:** A color selection area showing a black swatch and a "..." button.
- Line Style:** A dropdown menu.
- Line Width:** A dropdown menu showing "0.1".
- Scale:** Input fields for "x" (1) and "y" (1).
- Rotation:** An input field for "0" followed by a "Deg" unit label.
- Fill Area:** A checkbox that is currently unchecked.
- Hatching:** A checkbox that is currently unchecked.
- Scale/rotate:** A checkbox that is currently unchecked.
- Background/Foreground:** Two radio buttons at the bottom, with "Foreground" selected.
- Reset:** A button located at the bottom right of the dialog.

Figure 6/12: *Properties* dialog window of a rectangle: *Drawing Properties* tab

Position	Defines the top left position of the rectangle.
Scale	Defines the scaling in x or y direction.
Size	Defines the width and the height of the rectangle.
Rotation	Defines the rotation angle in degrees.
Color	Defines the color of the drawing element.
Fill Area	Fills the rectangle with the specified color.
Hatching	If this option is active, the specified hatching is used to fill the rectangle.
Scale/rotate	With this option, you define if the hatching is to be scaled and rotated with the drawing element or whether the set angles and spaces should be retained for the hatching , regardless of the drawing element.
Line Style	Defines the line style.

Line Width	Defines the line width.
Background	Defines that the drawing element is displayed in the background. This means that all circuit symbols are on top of it. In particular this means that symbols are not covered by filled drawing elements, for example.
Foreground	Defines that the drawing element is displayed in the foreground. This means that all circuit symbols are under it. In particular it means that symbols are covered by filled drawing elements, for example.

6.6.6 Circle

A circle is drawn by defining the center and the radius. You can draw a circular arc by subsequently entering a start angle and an end angle in the *Properties* dialog window for the circle under *Drawing Properties*.

A circle can be inserted using the corresponding button of the **Draw** group on the **Insert** ribbon page.

The circle-specific properties can be defined on the *Drawing Properties* tab of the *Properties* dialog window for the circle:

The 'Drawing Properties' dialog for a circle includes the following fields and options:

- Position:** Center cx (222 mm), Center cy (81 mm).
- Scale:** x (1), y (1).
- Arc:** Starting Angle (0 Deg), Ending Angle (0 Deg).
- Size:** Radius rx (9.48683298 mm), Radius ry (9.48683298 mm).
- Rotation:** 0 Deg.
- Color:** Black color swatch.
- Fill Area:** Unchecked checkbox.
- Hatching:** Unchecked checkbox.
- Scale/rotate:** Unchecked checkbox.
- Fill mode:** Solid blue fill icon selected.
- Line Style:** Dropdown menu.
- Line Width:** 0.1.
- Start Cap:** Dropdown menu.
- End Cap:** Dropdown menu.
- Background/Foreground:** Radio buttons, with 'Foreground' selected.
- Reset:** Button.

Figure 6/13: *Properties* dialog window of a circle: *Drawing Properties* tab

Position	Defines the center of the circle.
Scale	Defines the scaling in x or y direction.
Arc	Defines the start and end angles of a circular arc.
Size	Defines the radii in the x and y directions.
Rotation	Defines the rotation angle in degrees.
Color	Defines the color of the drawing element.
Fill Area	Fills the circle with the specified color.
Hatching	If this option is active, the specified hatching is used to fill the circle.
Scale/rotate	With this option, you define if the hatching is to be scaled and rotated with the drawing element or whether the set angles and spaces should be retained for the hatching , regardless of the drawing element.

Fill mode	Determines whether the <i>circle sector</i> (circle sector between the “pie” radii) or the <i>circle segment</i> (circle segment along the chord of the circle) is to be filled.
Line Style	Defines the line style.
Line Width	Defines the line width.
Start Cap	Defines how the beginning of the line is displayed.
End Cap	Defines how the end of the line is displayed.
Background	Defines that the drawing element is displayed in the background. This means that all circuit symbols are on top of it. In particular this means that symbols are not covered by filled drawing elements, for example.
Foreground	Defines that the drawing element is displayed in the foreground. This means that all circuit symbols are under it. In particular it means that symbols are covered by filled drawing elements, for example.

6.6.7 Ellipse

An ellipse is drawn by defining a center and two axially parallel radii. You can draw an elliptical arc by subsequently entering a start angle and an end angle in the *Properties* dialog window for the ellipse under *Drawing Properties*.

An ellipse can be inserted using the corresponding button of the **Draw** group on the **Insert** ribbon page.

The ellipse-specific properties can be defined in the *Properties* dialog window for the ellipse on the *Drawing Properties* tab:

The 'Drawing Properties' dialog window for an ellipse includes the following controls:

- Position:** Center cx (147 mm), Center cy (60 mm).
- Scale:** x (1), y (1).
- Arc:** Starting Angle (0 Deg), Ending Angle (0 Deg).
- Size:** Radius rx (18 mm), Radius ry (9 mm).
- Rotation:** 0 Deg.
- Color:** Black swatch.
- Fill Area:** Unchecked checkbox.
- Hatching:** Unchecked checkbox.
- Scale/rotate:** Unchecked checkbox.
- Fill mode:** Two icons for fill styles.
- Line Style:** Dropdown menu.
- Line Width:** 0.1 dropdown menu.
- Start Cap:** Dropdown menu.
- End Cap:** Dropdown menu.
- Background/Foreground:** Radio buttons, with 'Foreground' selected.
- Reset:** Button.

Figure 6/14: *Properties* dialog window of an ellipse: *Drawing Properties* tab

Position	Defines the center of the ellipse.
Scale	Defines the scaling in x or y direction.
Arc	Defines the start and end angles of a elliptical arc.
Size	Defines the radii in the x and y directions.
Rotation	Defines the rotation angle in degrees.
Color	Defines the color of the drawing element.
Fill Area	Fills the ellipse with the specified color.
Hatching	If this option is active, the specified hatching is used to fill the ellipse.
Scale/rotate	With this option, you define if the hatching is to be scaled and rotated with the drawing element or whether the set angles and spaces should be retained for the hatching , regardless of the drawing element.

Fill mode	Determines whether the <i>ellipse sector</i> (sector between the “pie” radii) or the <i>ellipse segment</i> (segment along the axis) is to be filled.
Line Style	Defines the line style.
Line Width	Defines the line width.
Start Cap	Defines how the beginning of the line is displayed.
End Cap	Defines how the end of the line is displayed.
Background	Defines that the drawing element is displayed in the background. This means that all circuit symbols are on top of it. In particular this means that symbols are not covered by filled drawing elements, for example.
Foreground	Defines that the drawing element is displayed in the foreground. This means that all circuit symbols are under it. In particular it means that symbols are covered by filled drawing elements, for example.

6.6.8 Polyline (traverse line)

A polyline (also called a line chain, section chain or polygon chain) is drawn by defining two or more points. Each mouse click sets a further vertex. The polyline is ended by clicking the same point twice.


A polyline can be inserted using the corresponding button of the **Draw** group on the **Insert** ribbon page.



The properties of the polyline can be defined on the *Properties* tab in the *Drawing Properties* dialog window:

Figure 6/15: *Properties* dialog window of a polyline: *Drawing Properties* tab

Position	Defines the top left position of the surrounding rectangle.
Scale	Defines the scaling in x or y direction.
Rotation	Defines the rotation angle in degrees.
Color	Defines the color of the drawing element.
Fill Area	If this option is active, the inner area of the polyline is filled with the specified color.
Hatching	If this option is active, the inner area of the polyline is filled with the specified hatching .
Scale/rotate	With this option, you define if the hatching is to be scaled and rotated with the drawing element or whether the set angles and spaces should be retained for the hatching , regardless of the drawing element.
Line Style	Defines the line style.

Line Width	Defines the line width.
Start Cap	Defines how the beginning of the line is displayed.
End Cap	Defines how the end of the line is displayed.
Background	Defines that the drawing element is displayed in the background. This means that all circuit symbols are on top of it. In particular this means that symbols are not covered by filled drawing elements, for example.
Foreground	Defines that the drawing element is displayed in the foreground. This means that all circuit symbols are under it. In particular it means that symbols are covered by filled drawing elements, for example.

To change the vertices of a polyline or to set new vertices switch to “polyline edit mode” by selecting the **Edit** **Edit Poly Line** menu item or by activating the  button on the toolbar.

You can move the existing vertices by clicking and dragging them. The mouse pointer changes to  when you mouse over an existing vertex. If the mouse pointer is over a line without a vertex  is displayed and a new vertex is inserted as soon as you click.

You can remove an existing vertex by clicking the corresponding vertex while keeping the **Ctrl** key pressed.

6.6.9 Connecting cable

A conduction line is drawn by defining two end points. A pneumatic or electric line of this type consists of two connectors with a line between them. Both connectors can be used as the starting point for further connections. The conduction lines can only be drawn horizontally or vertically.

On the **Insert** ribbon page in the **Link** group select the **Conduction Line...** menu item.




Figure 6/16: [Conduction Line...](#) dialog window

Type of connection line

Selects the conduction line type. The following are available: “*Pneumatic*”, *Hydraulic* and “*Electric*”.

Define multiple lines

Multiple conduction lines can be set one after the other if this option is active. You can cancel the action by pressing the **Esc** key.

If multiple conduction lines with the same distance between them are to be drawn horizontally or vertically then change the number in the “*Number of lines*” field. You specify the distance to be maintained between the lines using “*Distance*”.

Under “*Start Point Appearance*” and “*End Point Appearance*” you can define the representation of the respective end point. If the “*Display Identification*” option is selected then the identification of the start point is displayed. In order to guarantee that the same

identification is displayed for the start point and the end point, a text reference for the start point is displayed for the end point instead of its identification.

[Interruptions](#) are used as end points for conduction lines.

After confirming the dialog window you switch to a special mode where you define the end points of the line with two consecutive mouse clicks. Alternatively you can also draw a line by clicking and dragging it.

An electric conduction line can be a potential line. This is described under [Potentials and conduction lines](#).

6.6.10 Interruption/potential

If conduction lines are spread over several pages then the line ends can be assigned interruptions. Interruptions can be used to define that a conduction line is only interrupted in the drawing and is continued elsewhere. An interruption can be assigned an identification and linked with another interruption. The location of the linked interruption can be displayed at the source interruption. If an electric interruption is used with an electric line then this interruption represents a potential. The use of electric potentials is described under [Potentials and conduction lines](#).

You can insert an interruption into an existing line or position it freely in a circuit.

→ On the [Insert](#) ribbon page in the [Link](#) group select the [Interruption/Potential...](#) menu item.

A dialog window opens where you can make various settings for the interruption to be inserted.




Figure 6/17: [Interruption/Potential...](#) dialog window

Type of connector

Defines whether a pneumatic, hydraulic or electric interruption (potential) is to be inserted.

Define multiple connectors

Multiple interruptions can be set one after the other if this option is active. You can cancel the action by pressing the **F5** key.

You can edit the properties for an interruption by double-clicking it. The following dialog window opens.




Figure 6/18: *Interruption/Potential* dialog window

Layer	Defines the drawing layer for the interruption.
Identification	Defines the identification for the interruption. The identification is displayed in the circuit if the <i>Display</i> option is active.
Target	Interruptions can refer to each other in pairs. The opposite interruption can be selected from a list or entered directly in the list box. Browse... opens a dialog window where all interruptions are displayed in a tree structure and can be selected. Only interruptions that are not linked are shown in the list if the <i>Only Free Interruptions/Potentials</i> option is active.
Jump to Target	If the interruption is linked with another interruption then this button can be used to jump to the opposite interruption.
Show Location	If this option is activated and the interruption is linked with another interruption then the position of the opposite interruption is displayed as a page coordinate (e.g. page number/column).
Representation	A symbol that defines the representation of the interruption can be selected from a list. To illustrate the representation the relevant symbol always additionally shows the intersection of two lines.

6.7 Checking the drawing

Using the [\[Check Drawing\]](#) menu item in the [\[Page\]](#) menu you can have FluidDraw check your drawing for possible drawing errors. FluidDraw displays the following messages where necessary:

- *Duplicated identification labels*
- *Duplicated cross-reference labels*
- *Unresolved link targets*
- *Superimposed objects*
- *Lines through connectors*
- *Superimposed lines*
- *Open connectors*
- *Open pneumatic connectors*
- *Open hydraulic connectors*
- *Open electric connectors*
- *Incompatible connections*
- *Cyclic object references*
- *Objects outside the drawing area*
- *Missing translations*
- *Translated numbers detected*
- *Ambiguous terminal strip references*
- *Unassigned cables*
- *Unassigned terminals*
- *Duplicated terminal references*
- *Connection errors found in the GRAFCET diagram.*

— *Syntax errors found in GRAFCET expression.*

If there are messages, the corresponding objects are highlighted after confirming the dialog window.

The object browser

Chapter 7

The tab for the object browser is on the right side below the project window by default. This window can be attached just like the library or the project window, removed from the main window and hidden.

Whereas the project window gives a hierarchical overview of the pages of a project, the object browser provides a hierarchical view of all main components, secondary symbols, sub-objects, lines, terminal strips, etc. A filter can be used to show or hide specific object types in a selective manner. In addition, there is an input field for a text filter including placeholders.

7.1 Navigating in the object browser

The tree view of the object browser provides you with a quick overview of the components used, their hierarchy, links and their location.




Figure 7/1: Object browser: tree view

Starting at an object, any secondary symbols, sub-objects and the page on which it is positioned are displayed as a structure. Opens the node to view the corresponding elements. Double-click a node in the object tree to display the corresponding page, select an object or open the properties dialog, depending on the context.

Depending on the object type, various links are displayed as sub-nodes. All terminals of a terminal strip can thus be found, for example, or interruptions can be monitored. Conduction lines indicate e.g. the connectors connected to them and the corresponding components.

If you move your mouse on to an object node for a moment, a small preview window appears, showing the symbol or the corresponding page.




Figure 7/2: Object browser: links of a conduction line

The context menu that you can access using the right mouse button provides more functions. You can jump to the object here, copy it, delete it or open the properties.

7.2 Filter criteria for the object browser

You use the filter criteria to determine which object types are to be displayed in the object browser. For a better overview, you can hide the complete filter area using the corresponding button. If you press the button again, the filter options are displayed again.




Figure 7/3: Object browser: filter criteria

Match case

Defines whether the (upper or lower) case is to be taken into account in the filter text in the input field.

Whole word

With this option, only those objects are displayed that contain the filter text as a complete word.

Wild cards

You can apply this option to use placeholders in the filter text. The asterisk “*” stands for any number of characters of any kind and the question mark “?” represents precisely one character of any kind. If e.g. the *Whole word* and *Wild cards* options are active, when the filter entry “MM*” is made objects with the identification “MM1” and also with the identification “MM23” is displayed. If you enter “MM?” only “MM1” fits because the question mark replaces the “2” in “MM23”. The “3” remains, which is not detected by the placeholder. As the *Whole word* option is set “MM23” is not displayed.

Reset

Resets the filter criteria to the default setting.

Manage Product Database

Chapter 8

As well as the [Festo product catalog](#), user-defined product databases can also be managed in a FluidDraw-specific data format. These product databases can be created from scratch or opened as an existing FluidDraw product database file.

It is also possible to import databases that were not created using FluidDraw. Note that the external product databases cannot be managed in FluidDraw. This must be done using suitable database tools. The product databases are imported as a copy in the FluidDraw-specific data format.

A product or data record at least contains the “*Supplier*”, “*Part number*” and “*Symbol Name*” attributes. Each product can be assigned a symbol using the “*Symbol Name*” attribute. You can add any number of other attributes.

The dialog window for managing the product databases is opened using the [Manage](#) [Custom Product Databases...](#) menu item.




Figure 8/1: *Manage Product Database* dialog window

Product Database	Using this drop-down list you can select the product database that you want to manage.
New...	Using this button you can create a new product database. You will then be asked for a file name under which the product database should be saved.
Open...	Opens a file selection dialog window that you can use to open an existing FluidDraw product database.
Import...	Opens a file selection dialog window that you can use to open an external product database. The database must be in CSV (Comma-Separated Values) format, which most database programs can generate. Further settings for import are described further below.

Remove From List	Removes the selected product database from the drop-down list. The associated file is not changed.
Products	This tab displays the product database as a table. The “ <i>Supplier</i> ” attribute features a drop-down list containing all suppliers that can be selected. The suppliers are listed on the <i>Suppliertab</i> .
Supplier	This tab lists all suppliers in the product database. Further suppliers can also be added and provided with additional information.
Export...	Exports the selected table (<i>Products</i> or <i>Supplier</i>) as a CSV file.
Delete	Deletes the highlighted product from the product database.
Add Attribute...	Further attributes can be added to both the <i>Products</i> table and the <i>Suppliertable</i> .
Attribute Properties...	Opens a dialog window where the attribute properties can be defined. The dialog window is described further below.
Assign Symbol...	<p>Opens a dialog window where you can select a symbol that is assigned to the highlighted product.</p> <p>If a file was selected for importing an external product database then various settings can be made using the following dialog window. FluidDraw analyzes the CSV file to be imported and suggests practical default settings.</p>

Product Database

Delimiter

☐ Tabulator
☐ Comma
☒ Semicolon
☐ Other

Text Identifier

☐ Double Quote (")
☐ Single Quote (')
☒ None

Character Code

65001 Unicode (UTF-8)

☒ First Row is Column Header

Column Assignment

Column	Import Attribute	Predefined Attribute	Data Type
Origin sort order	<input checked="" type="checkbox"/>		String
Lieferant	<input checked="" type="checkbox"/>	Supplier	String
Teilenummer	<input checked="" type="checkbox"/>	Part number	String
Symbolname	<input checked="" type="checkbox"/>	Symbol Name	String
Order code 1	<input checked="" type="checkbox"/>		String
Order code 2	<input checked="" type="checkbox"/>		String
X-length	<input checked="" type="checkbox"/>		String
Artikelbenennung	<input checked="" type="checkbox"/>	Product name	String
Typ	<input checked="" type="checkbox"/>	Type	String
Kundenteilenummer	<input checked="" type="checkbox"/>	Customer part	String

Select All Invert Selection

First Table Row 2

Preview

	Origin sort order	Supplier	Part number	Symbol Name	Order code 1	Order code 2	X-length	Product name	Type	Customer part no.	Other
2	172	Festo	161792	00991254	DGPL-2...		10	Linear dr...	DGPL-2...	X0013500	Festo Lin...
3	1052	Festo	1463254	00991235	DSBC-3...		10	ISO cylin...	DSBC-3...	X0014578	Festo IS...
4	38	Festo	14320	00991235	DSNU-1...		110	ISO cylin...	DSNU-1...	X0013445	Festo IS...
5	1056	Festo	1463766	00991235	DSBC-5...		140	ISO cylin...	DSBC-5...	X0014165	Festo IS...
6	42	Festo	15221	00991736	DGO-12...		150	Linear dr...	DGO-12...	X0013113	Festo Lin...

OK Cancel

Figure 8/2: *Product Database* dialog window

Delimiter

Defines the separator that can be used to distinguish the attributes.

Text Identifier

Defines whether and how quotation marks have been added to texts.

Character Code

Defines the character set to be used.

Column Assignment

Defines the attributes (columns) to be imported from the database and the attributes predefined in FluidDraw that they should be assigned to. The data type of the attribute can also be specified. You can select all attributes using the **Select All** button and reverse the selection using the **Invert Selection** button.

- First Row is Column Header

Defines that the first row contains the column headers (attribute names).
- First Table Row

Defines the row from which the data records are to be imported.
- Preview

Displays a preview of the data records that are being imported.
- The following dialog window opens if the **Export...** button was selected to export either the *Products* or *Supplier* table as a CSV file.




Figure 8/3: *Product Database* dialog window

- Delimiter

Defines the separator that can be used to distinguish the attributes.

Text Identifier	Defines whether and how quotation marks are to be added to texts.
Character Code	Defines the character set to be used.
Column Selection	Defines the attributes to be exported. You can select all attributes using the Select All button and reverse the selection using the Invert Selection button.
Column Header	Defines whether an additional first row containing the attribute names as column headers should be exported.
Preview	Displays a preview of the data records that are being exported.
	Further attributes for the Add Attribute... and <i>Products</i> tables can be added using the <i>Supplier</i> button.




Figure 8/4: Add Attribute dialog window

Different types of attributes can be added.

Predefined Attribute	Attributes predefined in FluidDraw can be selected from a drop-down list. These include <i>Product name</i> , <i>Remark</i> and <i>Description</i> .
Predefined Online Service	For most of the components in the Festo product catalog there is additional information that can be accessed via the Internet. It includes documentation, CAD drawings, product images, spare parts, etc. These sources for the highlighted component can be

accessed directly via the context menu in the circuit diagram. To also be able to use this function with your own product databases, external links to corresponding web sites can be stored under the corresponding categories.

User Defined Attribute

If this option is selected you can specify an attribute name and type for the new attribute.

You can list and remove the attributes in the **Attribute Properties...** and *Products* tables using the *Supplier* button. The “*Supplier*”, “*Part number*” and “*Symbol Name*” attributes cannot be deleted.




Figure 8/5: Attribute Properties dialog window

The selected attribute can be removed using the **Delete Attribute** button.

Chapter 9

Translation tables can be managed using FluidDraw. Each row in the table contains texts in different languages. Each column contains one language. The text ID is a special column. It is used as a placeholder for a text and can be used at different points in FluidDraw. Depending on the set language, the text in the corresponding language may be displayed instead of the text ID.

Words					
	German	English	Spanish	French	Text ID
	A4-Aufnahmerah...	A4 mounting frame	Bastidor de mont...	Cadre de montag...	?mountingframea4
	Abänderung	modification	modificación	modification	?modification
	abarbeiten	process	desarrollar	travailler	?Process

Figure 9/1: Example of a translation table

The text ID can be selected as desired. In the example above the English term with a preceding question mark was used.

It is also possible to use a language as the text ID. This must be specified during import, which is described further below. We do not recommend this approach since the text ID may not always be unique. For example, in the example above the word “modification” occurs twice, but is translated differently depending on the context.

The translation tables are stored in a FluidDraw-specific file format. The translation table and language to be used are specified in a project or circuit on the *Language* tab in the properties dialog window. You can find further information under [Language](#).

Text IDs can be used in user-defined attributes for both the attribute name and the attribute value. The text is displayed on a yellow background in the set language in the corresponding dialog windows. As soon as you want to edit an attribute name or attribute value the text ID is displayed again in the corresponding field.

	Attribute	Value		Attribute	Value
	process		▶	?Process	

Figure 9/2: Text IDs in user-defined attributes

FluidDraw provides a search dialog for finding a text ID for a specific text in the selected translation table. When you are editing a text box the following dialog can be opened using the **Translation Table...** button.




Figure 9/3: *Translation Table* dialog window

Search

Enter a language text here to find the associated text ID. You do not need to enter the text in full; you can select the desired row directly.

The selected text ID is displayed in the text box after you confirm the selection.

If the user-defined attributes are used in parts lists then they are displayed in the parts lists in the corresponding language. Note that the predefined attributes are independent of the chosen language in the translation table. The language of the predefined attributes is defined by the language set for the [Festo product catalog](#).

Text IDs can also be used in [text components](#).

The dialog window for managing the translation tables is opened using the **Manage Translation Tables...** menu item.




Figure 9/4: *Manage Translation Tables* dialog window

Translation Table	Using this drop-down list you can select the translation table that you want to manage.
New...	Using this button you can create a new translation table. You will then be asked to specify a file name under which the translation table should be saved.
Open...	Opens a file selection dialog window that you can use to open an existing FluidDraw translation table.
Import...	Opens a file selection dialog window that you can use to open an external translation table. The translation table must be in CSV

	(Comma-Separated Values) format, which most database programs can generate. Further settings for import are described further below.
Remove From List	Removes the selected translation table from the drop-down list. The associated file is not changed.
Extract Project Texts	If you want to create a new translation table for an existing project, you can use it to collect the texts used in the project and use them as an initial list for the translations.
Extract Page Texts	If you want to create a new translation table for an existing page, you can use it to collect the texts used in the page and use them as an initial list for the translations.
Words	This tab displays the translation table.
Export...	Exports the translation table as a CSV file.
Delete	Deletes the highlighted language entry from the translation table.
Add Language...	Adds a further language to the translation table.
Languages...	Opens a dialog window that lists all languages and can be used to remove a language.
	If a file was selected for importing an external translation table then various settings can be made using the following dialog window. FluidDraw analyzes the CSV file to be imported and suggests practical default settings.




Figure 9/5: *Translation Table* dialog window

Delimiter

Defines the separator that can be used to distinguish the languages.

Text Identifier

Defines whether and how quotation marks have been added to texts.

Character Code

Defines the character set to be used.

Column Assignment

Defines the languages to be imported from the database and the languages predefined in FluidDraw that they should be assigned to. You can select all languages using the **Select All** button and reverse the selection using the **Invert Selection** button.

- First Row is Column Header Defines that the first row contains the language names.
- First Table Row Defines the row from which the data records are to be imported.
- Preview Displays a preview of the data records that are being imported.

The following dialog window opens if the **Export...** button was selected to export the translation table as a CSV file.




Figure 9/6: *Translation Table* dialog window

- Delimiter Defines the separator that can be used to distinguish the languages.

Text Identifier	Defines whether and how quotation marks are to be added to texts.
Character Code	Defines the character set to be used.
Column Selection	Defines the languages to be exported. You can select all languages using the Select All button and reverse the selection using the Invert Selection button.
Column Header	Defines whether an additional first row containing the language names as column headers should be exported.
Preview	Displays a preview of the data records that are being exported.
	Further languages can be added using the Add Language... button.




Figure 9/7: Add Language dialog window

Two types of languages can be added.

Predefined Language	Languages predefined in FluidDraw can be selected from a drop-down list.
User Defined Language	You can enter any language if this option is selected.




Figure 9/8: Languages dialog window


The languages in the selected translation table can be listed and removed using the Languages button. The “*Text ID*” column cannot be deleted.

Chapter 10

FluidDraw allows both automatic and manual dimensioning.

10.1 Drawing dimensions

The **Insert** ribbon in the **Dimension** group has the buttons that you can use to select a corresponding mode for drawing the dimension arrows. The following buttons are available:



Horizontal, vertical and diagonal dimensioning is done by defining two points for the section as well as then clicking to position the dimension text. Angular dimensioning requires the center point to be defined as well as two points for the angle. The fourth click in turn defines the position of the dimension text. The **Flag** dimensioning function can also be used for general labelling of important points in the circuit. Two points for a line with any pitch and a final click for the text are needed for this.

10.2 Settings for dimensioning




Figure 10/1: *Dimension* dialog window

Layer	Defines the drawing layer for the dimension.
Automatic Dimensioning	Activates or deactivates automatic adaptation of dimensioning when the dimension length is changed.
Length	If the <i>Automatic Dimensioning</i> option is deactivated you can enter any number that is displayed as the length dimension. A unit can also be selected. <i>Show Unit</i> defines whether the unit should be displayed.
Decimals	Defines the number of decimal places.
Factor	Determines the factor with which the real length is multiplied for the displayed value. This is necessary if you are creating a drawing with a scale other than 1:1.
Color	Defines the color for the dimension.

Line Style Defines the line style for the dimension.

Line Width Defines the line width for the dimension.

Dimensions, like all other objects in FluidDraw, can be moved, rotated, mirrored and scaled. The display value of the dimension is automatically adapted during scaling if the *Automatic Dimensioning* option is activated.

Equipment identifications and designation conventions

Chapter 11

FluidDraw supports the structured and hierarchical assignment of equipment identifications, i.e. a complete equipment identification can be made up of several component identifications.

The following attributes can be used for structuring and are put together according to predefined conventions to form a complete equipment identification:

- *Installation*
- *Location*
- *Circuit*
- *Component*
- *Connector*

The *Installation*, *Location* and *Circuit* attributes can be specified for a symbol, circuit and project. You can specify whether the attributes should be applied from a parent element (node). For example, you can apply the installation information from the circuit diagram so that it does not have to be individually entered for each symbol.

Designation conventions describe how the individual *Installation*, *Location*, *Circuit*, *Component* and *Connector* attributes are put together to form a full identification. They specify the order in which the individual attributes are put together to form a full identification and the separators (prefix or postfix) used between them.

The following example serves to illustrate this. The list below represents a set of designation conventions. Each attribute can have a preceding (prefix) or a trailing (postfix) separator. The separators to be used are inserted in quotation marks. The specified set of designation conventions corresponds to the default setting in FluidDraw for electrical engineering.

- “=” *Installation*
- “+” *Location*
- “.” *Component*

The value of the *Component* attribute is “B1” and is stored at the symbol to be identified. *Installation* is given the value “G1” and *Location* is given the value “X1”, which are both stored at the circuit. A note is included at the symbol that these attributes should be applied from the circuit. The full equipment identification is then as follows:

— =G1+X1-B1

If it is clear from the context that *Installation* and *Location* are stored at the circuit then this information can be hidden when displaying the equipment identification in the circuit for a better overview. The *Suppress Inherited Parts* option must be selected at the associated symbol for this. The identification that is displayed is then:

— -B1

FluidDraw also supports the hierarchical structuring of identifications. Using a hierarchy makes sense if a symbol is a subobject of another object, for example the plug in a plug strip or the solenoid coil in a solenoid valve. The full identification is put together according to the defined designation conventions. The *Component* attribute is also added in accordance with the defined object hierarchy. You start at the top hierarchy level when identifying an object.

The hierarchy is defined by establishing a reference between a symbol (object) and the parent object. To illustrate this, we will continue with the example described above. The symbol with the *Component* attribute with the value “B1” was not previously hierarchically structured. This is changed by defining at the symbol that it has “A1” as the parent symbol. The full identification of “B1” is as follows:

— =G1+X1-A1-B1

The identification that is displayed remains unchanged.

11.1 Renumber Designations

Designations of symbols are automatically assigned when symbols are created. FluidDraw supports the reassignment of the designations within a circuit diagram or for all pages of the project. You can define which symbols are to get new identifications and the order in which they are to be renumbered.

Renumbering is started via the [Page](#) [Renumber Designations...](#) or [Project](#) [Renumber Designations...](#) menu. The following dialog window opens.




Figure 11/1: *Renumber Designations* dialog window

Object Types

For each symbol you can specify the designation convention to be used. You can specify the designation conventions to be taken into consideration during renumbering under *Object Types*. Only those symbols with the appropriate convention are given a new identification.

Renumber Unenumerated Only (e.g. ?V1)

Only symbols that have not yet been given an identification are taken into account.

If the *Enumerate Automatically* option is selected on the [Designation Conventions](#) tab in the program options then FluidDraw automatically assigns identifications for newly created symbols. If this option is not active IDs beginning with a question mark will be assigned. According to the convention, FluidDraw interprets these symbols as not having any identification.

Renumber main components first, then sub-components

If this option is active renumbering is done in two passes. The main elements are re-identified in the first pass and the subordinate elements in the second pass. A main element is e.g. a valve and its silencers are subordinate objects.

Labeling Order

The labelling order can be defined using the various buttons.

Renumbering is started after you click the **Next** button.




Figure 11/2: *Renumber Designations* dialog window

Current Identification

Shows the current full identification.

New Identification

Contains the suggested new identification for the component. You can change this suggestion. The new full identification is displayed in the *Full Identification* field.

Full Identification	Shows the new full identification.
Displayed Identification	Shows the new identification as it is displayed in the circuit. If the <i>Suppress Inherited Parts</i> option is selected then parts of the identification such as “ <i>Installation</i> ”, “ <i>Circuit</i> ” or “ <i>Location</i> ” are hidden if they have been stored in the circuit diagram or project.
Designation Conventions	The designation conventions for the component to be identified can be selected here.
Inherit From Page	<p>If this option is not active the following identification components can be defined for the symbol: “<i>Installation</i>”, “<i>Location</i>” and “<i>Circuit</i>”. Only components that are used in the set designation convention are available.</p> <p>The Next button applies the new identification and the Skip button leaves the old identification unchanged. The system then continues with the next symbol.</p>

Component attributes

Chapter 12

The FluidDraw circuit symbols correspond to the components in the [Festo product catalog](#) to a large extent. Even if you have not installed the [product catalog](#) FluidDraw can read most of the component attributes from the database supplied with the program.

Open the *Properties* dialog window for the component by double-clicking a symbol or using the [Home](#) menu and the [Properties...](#) menu item.

12.1 Component attributes in the *Properties* dialog window

-MM5 Properties

Symbol Name: 00991227

Description: ☐ Display

Part number: 171187

Layer: 1

☒ Display in Parts Lists

Identification: MM5 ☐ Display

Identification | Catalog Properties | User Defined Properties | Drawing Properties

Attribute	Value	Display
Part number	171187	<input type="checkbox"/>
Symbol Name	00991227	<input type="checkbox"/>
Order code 1	DSAG-10-1-P	<input type="checkbox"/>
Type	DSAG-10- -P	<input type="checkbox"/>
Packaging unit	1	<input type="checkbox"/>
Item name	Round cylinder	<input type="checkbox"/>
Other	End cap with threaded lug	<input type="checkbox"/>
Unit	PCS	<input type="checkbox"/>
x-Hub	1	<input type="checkbox"/>

OK Cancel

Figure 12/1: *Properties* dialog window of a component

The properties of a component are stored as attribute value pairs. The attributes are split up into different groups. The first group contains general properties:

Symbol Name: 00991227

Description: ☐ Display

Part number: 171187

Layer: 1

☒ Display in Parts Lists

Identification: MM5 ☐ Display

Figure 12/2: Detail from the *Properties* dialog window for a component: general properties

Symbol Name	Displays the name of the circuit symbol. The symbol name is used to assign fitting products in the Festo product catalog . The symbol name cannot be changed by the user.
Description	Contains a more detailed description or the complete name of the circuit symbol where applicable. The user can change it. The identification is shown as text in the circuit drawing if the “ <i>Display</i> ” option is selected.
Part number	The part number identifies a product unambiguously. You can enter the part number manually or use the <input type="button" value="Find..."/> button the product catalog to search for it. Only in the event of a selection via the product catalog are the component attributes stored in the catalog automatically applied. You can find these attributes in the <i>Properties</i> dialog window of the component on the <i>Catalog Properties</i> tab.
Layer	In this drop-down list, you define the drawing layer of the symbol. Depending on the setting for drawing layers , the symbol might not be displayed or might not be able to be edited. In order to make the symbol visible or change its settings, you have to temporarily activate the drawing layer in the <input type="button" value="Page"/> or <input type="button" value="Project"/> menu under the <input type="button" value="Drawing Layers..."/> menu item.
Identification	Here you can assign an identification that uniquely identifies the component in the circuit diagram. The identification is shown as text in the circuit drawing if the “ <i>Display</i> ” option is selected.

Note: FluidDraw automatically assigns a unique identification when inserting or copying circuit symbols. An automatically assigned identification text begins with a question mark and can be edited by

the user (FluidDraw shows a warning if you are assigning an identification that already exists).

You can make more detailed settings for the equipment identification on the [Identification](#) tab.

Display in Parts Lists

Deselect this option if you do not want the symbol to appear in the parts lists.

12.2 Identification

On the “*Identification*” tab you can enter properties that influence how the identification for the symbol is displayed in the circuit diagram. You can find further information under [Equipment identifications and designation conventions](#).

The screenshot shows the 'Identification' tab of a 'Properties' dialog window. It contains several settings for equipment identification:

- ☐ Treat as Contact Actuator
- Sub-Symbol: [Dropdown menu]
- Parent Object: [Dropdown menu] with 'Browse...' and 'Find Target...' buttons.
- Full Identification: [Text field with '-MM5'] and [Text field with 'MM5'] with an ☒ Inherit prefix/postfix checkbox.
- ☐ Suppress Inherited Parts
- Displayed Identification: [Text field with '-MM5']
- Designation Conventions: [Dropdown menu with 'Fluidics'] and a 'Designation Conventions...' button.
- Installation: [Text field] with ☒ Inherit From Parent Object
- Location: [Text field] with ☒ Inherit From Parent Object
- Circuit: [Text field] with ☒ Inherit From Parent Object

Figure 12/3: Detail from the *Properties* dialog window for a component: *Identification* tab

Treat as Contact Actuator

If this option is activated then contacts can be linked with this symbol and the symbol is assigned a contact image. This allows the number of symbols that can actuate contacts to be extended as a

	user-defined setting. For example it allows custom relay magnets to be defined.
Parent Object	If this option is activated then a parent object can be specified whose identification is used to make up the full identification. Parent objects can be selected via the list box or their full identification entered directly. The “ Browse... ” button opens a dialog window that shows all objects in the project as a tree.
Full Identification	This field shows the full equipment identification.
Inherit prefix/postfix	If this option is deactivated then the separators that are inserted before (prefix) or after (postfix) the identification can be specified. The separators specified in the designation conventions are ignored in this case. In combination with parent objects this enables aspect changes as described in EN 81346-1.
Displayed Identification	This field shows the equipment identification displayed in the circuit diagram. If the <i>Suppress Inherited Parts</i> option is selected then parts of the identification such as “ <i>Installation</i> ”, “ <i>Location</i> ” or “ <i>Circuit</i> ” are hidden if they have been stored in the circuit diagram or project. The parts of the parent object’s identification are also hidden if a parent object was specified.
Designation Conventions	Here you define the designation convention to be used for the identification. The following are available: <i>Fluidics</i> , <i>Electrics</i> , <i>User Defined</i> and <i>Free Input</i> . The properties dialog window for the circuit where the designation conventions can be displayed and customized is opened using the Designation Conventions... button.
Installation	The <i>Installation</i> property that can be used as part of the identification is defined in this field. If the <i>Inherit From Parent Object</i> option is selected then the property is applied from the circuit, project or specified parent object. This field is only visible if <i>Installation</i> is used in the set designation convention.
Location	The <i>Location</i> property that can be used as part of the identification is defined in this field. If the <i>Inherit From Parent Object</i> option is selected then the property is applied from the circuit, project or specified parent object. This field is only visible if <i>Location</i> is used in the set designation convention.

Circuit

The *Circuit* property that can be used as part of the identification is defined in this field. If the *Inherit From Parent Object* option is selected then the property is applied from the circuit, project or specified parent object. This field is only visible if *Circuit* is used in the set designation convention.

12.3 Catalog Properties

Component attributes from the product catalog as well as attributes specified by the user are displayed in tabular form on various tabs. The table entries from the catalog cannot be edited. The value of an attribute is listed in the “*Value*” column. This value can be displayed as text in the circuit diagram next to the symbol if the “*Display*” option is activated.

The component attributes applied from the product catalog are displayed on the “*Catalog Properties*” tab.




Figure 12/4: Detail from the *Properties* dialog window for a component: *Catalog Properties* tab

12.4 User Defined Properties

You can enter your own component attributes on the “*User Defined Properties*” tab.




Figure 12/5: Detail from the *Properties* dialog window for a component: *User Defined Properties* tab

Text Buffer

When you edit a text box, you can use this button to insert a text that you would have recently entered elsewhere. That saves work and any input errors.

Translation Table...

If you are editing a text box you can use this button to open a [search dialog](#) via which you can find the text ID for a language text from the translation table.

To change an entry, the corresponding row must be highlighted with a click. By another click of the table cell to be changed, you can edit the entry in the cell.

A row can be deleted by first clicking the row to highlight it. The highlighted row can then be deleted using the **Del** key.

You can add any attributes of your own by filling in the empty cells in the last row.

12.5 Drawing Properties

You can enter a number of drawing properties that influence how the symbols are displayed in the circuit diagram on the “ *Drawing Properties*” tab.

Drawing Properties

Position

Left

29.25

mm

Top

102.375

mm

Scale

x

1

y

1

Rotation

0

Deg

☐ Override Color

...

Reset

Figure 12/6: Detail from the *Properties* dialog window for a component: *Drawing Properties* tab

Position Defines the top left position of a component.

Scale	Defines the scaling factor in the x or y direction. The scaling factor can also be defined using the mouse pointer. This is described in the section: “Scaling symbols” .
Rotation	Defines the rotation angle in degrees. The rotation angle can also be defined using the mouse pointer. This is described in the section: “Rotating symbols” .
Override Color	If this option is selected, you can select a different color for displaying the symbol.
Reset	Sets the geometry settings to the default values: scaling to 1, rotation to 0 and <i>“Override Color”</i> deactivated.

12.6 Main and secondary elements

As described under [Component attributes in the Properties](#) dialog window the FluidDraw circuit symbols correspond to the components in the [Festo product catalog](#) to a large extent. These symbols are called main elements. However there are also secondary elements, which do not correspond to elements in the Festo product catalog. These secondary elements are usually symbolic representations of a partial aspect of an associated main element.

All product properties are stored at the main element. The secondary elements only have a description and a reference to the associated main element. In electrical engineering in particular, components such as relays are divided into main and secondary elements where the coil is the main element and the contacts are the secondary elements.

12.7 Linking main and secondary elements

Main and secondary elements are linked using the symbol for the secondary element. The circuit diagram detail shows a relay comprising a coil as the main element and two contacts as the second-

ary elements. The contacts are to be linked with the coil. This information is evaluated when displaying the [contact image](#).




Figure 12/7: Relay comprising coil with two contacts

The symbol identifications are the default settings used in FluidDraw. The symbols are not linked to each other yet.

➞ Open the corresponding properties dialog window by double-clicking a contact.




Figure 12/8: Properties dialog window for a contact

Description	Defines a description of the secondary element. In the case of a contact, this is shown in the contact image .
Main Component	A compatible main element can be selected from a list. The main element identification can also be entered directly as text.
Browse...	Opens a dialog that shows all compatible main elements as a tree in accordance with the object hierarchy.
Link	If this box is given a check mark then the secondary element is logically linked with the main component. If the main component is then renamed, the link is retained and the identification of the linked secondary element is adapted as appropriate to the main element identification.
Find Target...	If the secondary element is logically linked with a main element, a search can be performed for the associated main element using this button.
Display	If this box is given a check mark then the main element's identification is shown as the identification for the secondary element.
Suppress Inherited Parts	If there are designation conventions assigned to the main element, parent parts of the identification that are defined in the circuit diagram or project are hidden.

→ From the list of compatible main elements select “Q1” . Proceed in the same way for the second contact.

Selecting from the list of compatible main elements automatically establishes the logical links between the contacts and the coil. The circuit diagram should now look like as follows.




Figure 12/9: Relay comprising coil with two contacts

If you now change the identification of the coil in “Q2” the logical links mean that the identifications at the contacts are automatically also changed to “Q2” .

Examples of this are relays with the coil as the main element and the contacts as secondary elements as well as electromagnetic directional control valves with the pneumatic symbol as the main element and the valve solenoids as secondary elements in the electrical part of the circuit diagram.

12.8 Linking solenoid valves and solenoid coils

The coils belonging to solenoid valves are usually displayed separately in the electrical part of a circuit diagram. The link between a solenoid valve and the associated coils is defined at the solenoid valve symbol.

The following circuit diagram shows a solenoid valve and the symbols for two separate solenoid coils. No link has been established yet between the solenoid valve and the coils.



Figure 12/10: Solenoid valve and two separate coils

There are two ways of establishing a link between a solenoid valve and a coil. The first is using the properties dialog window for the solenoid valve.

- ➞ Open the appropriate properties dialog window by double-clicking the solenoid valve and select the *Connector Labels* tab.




Figure 12/11: *Properties* dialog window, *Connector Labels* tab

This tab shows all solenoid valve's connectors. Connectors refer, among other things, to the logical connection options for the solenoid coils. The input fields of the left-hand electric connector are described below. The descriptions apply in the same way to the right-hand connector and other types of logical connectors.

Electric Connector (Left)

The identification for the left-hand solenoid coil can be entered in this list box or selected from a list. When you click this field the corresponding connector is highlighted in the preview. This helps to locate the connector, particularly when dealing with turned or mirrored symbols.

Browse...	Opens a dialog that shows all compatible solenoid coils as a tree in accordance with the object hierarchy.
Link	If this box is given a check mark then the solenoid coil is logically linked with the connector at the solenoid valve. If the solenoid coil is renamed the link is retained and the identifications of the coils at the solenoid valve are changed to match the coil identifications.
Find Target...	If the connector at the solenoid valve is logically linked with a coil a search can be performed for the associated coil using this button.
Display	If this box is given a check mark the coil's identification is shown as the identification for the solenoid valve connector.

→ Select: “-K1” from the list of compatible solenoid coils.



Figure 12/12: Left connector linked with “-K1” coil

The second way to link a solenoid valve with a coil is to double-click the solenoid valve's connector directly. The coil connectors are represented like pneumatic connectors within the solenoid valve by means of small circles.

→ Double-click the right connector of the solenoid valve.

A dialog window opens whose fields correspond to the entries for a connector on the *Connector Labels* tab of the *Properties* dialog window.




Figure 12/13: *Connector* dialog window

→ Select: “-K2” from the list of compatible solenoid coils.

The (electric) connectors of the solenoid valve are now linked with the solenoid coils.



Figure 12/14: Link between solenoid valve and solenoid coils

The above-mentioned ways of linking a solenoid valve and coils should only be used if each symbol has been individually inserted into the circuit diagram. For projects, FluidDraw manages the associated coil symbols for each solenoid valve internally. When a solenoid valve is inserted into a circuit diagram, the associated solenoid coils are simultaneously placed in a special library. This concept is described under [Unplaced objects](#).

12.9 Attributes of the text components

In FluidDraw, text components are for inserting comments and captions, on the one hand. On the other hand, they can be used to define identifications and accessories without symbol representa-

tion. Double-click a text or select the [Home](#) menu and the [Properties...](#) menu item to open the *Properties* dialog window for the text component.




Figure 12/15: *Properties* dialog window for a text component

A text component has all attributes of a [standard component](#). The text properties are to be found on the “*Edit Text*” tab.




Figure 12/16: Detail from the *Properties* dialog window for a text component: *Edit Text* tab

Edit Text

Enter your text in the input field on the left side. You can also enter a multi-line text. For a line break, press the **Return** key.

Alignment

Defines the horizontal or vertical alignment of the text in the box.

Font...

Defines the font type of the text.

Color...

Defines the color of the text.

Frame Text	Draws a frame around the text box.
Fixed Width	Normally, FluidDraw automatically adapts the width of the text boxes to the text contents. You can define a fixed width with this option if you do not want it. That may be practical if you have only limited space. The text is then compressed, if necessary, in order that it fits in the defined box.
Attribute Link	If this option is activated a text that identifies a link to an attribute is displayed instead of the text entered. The value of the selected attribute is displayed in the circuit diagram. You can find a detailed description of this function under Linking text components with attributes . A Predefined variable... predefined placeholder such as the page number can also be selected using the button.
Character Map...	Opens a dialog with all available characters to facilitate the input of letters and symbols that cannot be accessed directly using the keyboard.
Translation Language	<p>Defines the language from the selected translation table to be used. The text is displayed in the selected language, provided the selected translation table has a corresponding entry for this language.</p> <p>The language defined on the page is used by default. In deviation, e.g. to create a multilingual document, you can select a different language for every text.</p>
Translation Table...	If you are editing a text box you can use this button to open a search dialog via which you can find the text ID for a language text from the translation table.

12.10 Linking text components with attributes

Text components can also display attributes of other components, values of [predefined placeholders](#), attributes of a circuit or the project. The text component must be linked to the corresponding attribute for this. The linked attribute is defined in the input field of the “*Edit Text*” tab in the *Properties* dialog window for the text

component. The activated *Attribute Link* option defines that the text in the text box should not be displayed but rather interpreted as a link.

Example:

Let us assume your project is called “Project1” and has the page “Page1”. On it is a “V1” symbol whose value of the “supplier” attribute you want to display, i.e. in the example the value “Festo”.

→ Insert a text component into the circuit drawing by selecting the **Text** entry on the **Insert** ribbon page in the *Object* group and then left-clicking the circuit drawing. The *Properties* dialog window for the text component then opens.

Note: You can open the dialog window of an existing text component by double-clicking it or using the **Home** menu and the **Properties...** menu item.

→ Select the *Attribute Link* option and then click the **Browse...** button.

A window opens displaying the hierarchy of all available attributes. Please note that only those objects are listed that have an identification assigned by the user. Identifications beginning with a question mark “?” are not also listed. These are identifications that have been automatically assigned by FluidDraw. The desired attribute is to be found under “*Attribute Tree*” - “Project1” - “Page1” - “Supplier”.




Figure 12/17: *Browse Attributes* dialog window

→ Highlight the desired “supplier” attribute and then click the **Select** button.

In the input field the “Project1.Page1.-V1. *Supplier*” value is displayed and in the preview “Festo” is displayed. The complete and unique name of an attribute also includes all hierarchy levels, starting with the project. The individual levels in the name are separated by dots. It is also possible to only enter the attribute name in the input field. In this example “supplier”. The attribute is searched for in the hierarchy upwards, starting with the text component. If the desired attribute is not found at the component, the attribute is searched for in the circuit and then in the project.

If the attribute is not found, the attribute name is displayed in pointed brackets in the circuit. The missing attribute can be created at a later point in time. The link is then created automatically.



A text object as an attribute link can display various attribute values and variables, provided it is in its own text line.

12.10.1 Text constants

If the *Attribute Link* option is selected, the entered texts are not displayed directly, but interpreted as attributes or predefined variables. If a fixed text is to be displayed in addition to an attribute or variable value, it can be inserted in quotation marks. Such text constants must be in a line of their own, like also the links.




Figure 12/18: *Edit Text* dialog window with a text constant

12.11 Text components with predefined links

For component attributes and connector identifications that can be displayed, text components are automatically created that are linked to the corresponding attributes. Open the *Display Attribute* dialog window for adapting how the text is displayed by double-clicking the text component or via the [Home](#) menu and the [Properties...](#) menu item.




Figure 12/19: *Display Attribute* dialog window

Alignment	Defines the horizontal or vertical alignment of the text in the text box.
Scale	Defines the scaling factor of the text in the x or y direction. Note: You can also change the text size by selecting another font size in the font type dialog window. You open this dialog window using the Font... button under <i>Text Attributes</i> .
Rotation	Defines the rotation angle of the text box in degrees.
Font...	Defines the font type of the text.
Color...	Defines the color of the text.
Frame Text	Draws a frame around the text box.
Find Target...	The destination of a linked text is the attribute to which the text refers. This button is used to open the <i>Properties</i> dialog window of the object that includes this attribute.

12.12 Changing the properties of several objects simultaneously

If several different objects are highlighted, a dialog window appears with different categories on selecting the **Properties...** menu item in the **Home** menu. Corresponding tabs are available for the various object types depending on the objects highlighted.




Figure 12/20: *Properties* dialog window with several highlighted objects

The individual tabs of the dialog contain the same control elements as the dialogs of the individual objects.



If a specific setting does not have the same value for all objects selected, this is indicated by the fact that the control element indicates an “undefined” state or no value is entered. If you keep it this way, the individual values of this property remain untouched for the selected objects. If you change the value, however, it is adopted for all objects selected.

Managing projects

Chapter 13

FluidDraw supports the management of projects by being able to combine different pages under one name in a project file.

13.1 Creating a new project

→ Select the **File** / **New...** menu item from the **Project...** menu and enter a file name for the new project.

Project files have the file extension **fdprj**.

In the project window, a project is displayed hierarchically. The top element is the project node. Any sub-folders and the corresponding pages are displayed underneath. It is practical to create sub-folders for various content-related areas, such as for pneumatic connections, electrical activations and [parts lists or other reports](#).




Figure 13/1: Hierarchical representation in the project window

The folders and pages in the project tree can be moved interactively with the mouse to change the order. You can also change the hierarchy by dragging folders to another position. If you hold down the **Ctrl** key, you can also move the nodes using the cursor keys on the keyboard.

13.2 Project node

Every project has a project node as the topmost element. The project node is used to save all project-specific settings. Right-clicking a project node opens a context menu. You can also find the menu items in the [Project](#) menu. You can also find the functions for adding and removing files here.

Under the [Project](#) menu item from the [Properties...](#) menu you can define properties for the project. Properties that can be specified for both projects and circuits are described under [Circuit and project properties](#).

13.3 page node

A page node is created beneath the project node for every page file that belongs to the project. The page node is used to save all circuit-specific settings.

Right-clicking a page node opens a context menu containing the following menu items:

Open...	Opens the selected page in a window. The window can also be opened by double-clicking the node in the project tree.
Close Windows	Closes the window of the selected page.
Delete	Deletes the selected page and removes it from the project.
Rename...	Changes the description of the selected page.
Properties...	In this dialog window you can enter data for the page.




Figure 13/2: [Page](#) dialog window: *Drawing Size* tab

Here you can define the circuit dimensions and orientation, both of which are relevant for printing.

Renumber Pages...

Opens a dialog window for renumbering the pages.




Figure 13/3: [Renumber Pages...](#) dialog window

Prefix

Defines the prefix. It precedes all pages.

Start number

Defines the first page number of the new numbering.

Postfix

Defines the postfix. It is attached to all pages.

Leading zeros

Defines the number of places. An appropriate number of zeros precede numbers with a small number of digits.

Only this project node

Defines if only the pages are to be renumbered that are directly under this node or all pages in all sub-folders of the selected node. Note: Select the topmost project node and remove this option if you want to renumber all pages of the entire project.

13.4 Global objects

Most symbols are for components that correspond directly to a part number. Some symbols have several representations in the circuit, whereas others are sub-objects of other symbols. Certain components do not have any direct equivalent in the circuit. These include terminal strips, cables and also [valve terminals](#).

Terminal strips

The individual terminals are drawn in the circuit diagram. A terminal strip can be entered in the properties dialog for the terminals. These terminal strips are not displayed as symbols, however, but are managed by FluidDraw as *global objects*.

Cables

The individual cable symbols are inserted in the circuit diagram. A cable can be entered in the properties dialog for the cable symbols. Like the terminal strips, these cables are not displayed as symbols but are also managed by FluidDraw as *global objects*.

Valve terminals

If a valve terminal is created by [inserting an order code](#), the corresponding valve slices, end plates, etc. are to be found as grouped symbols on a circuit page. These symbols represent actual components. However, they should not appear individually in parts lists. Instead the virtual “valve terminal” object includes all attributes to be displayed in the parts lists. Such valve terminal objects are also managed by FluidDraw as *global objects*.

There are three ways to edit the properties of global objects:

Find Target, Jump to Target

In the properties dialog of a subordinate object, a terminal or a cable symbol, you have the option of jumping to the corresponding parent object.




Figure 13/4: Properties dialog window: *Find Target*

Object browser

Global objects are displayed in the object browser just like all other objects on the pages of the project.




Figure 13/5: Object browser: displaying global objects

[Manage Terminal Strips...](#),
[Manage Cables...](#), [Manage](#)
[Global Objects...](#)

In the [Project](#) menu under [Manage](#) you can open special dialogs that allow you to manage the various global objects. Here, you can also open the corresponding properties dialogs, delete objects or create new ones.




Figure 13/6: [Manage Global Objects...](#) dialog window

13.5 Unplaced objects

Various symbols consist of a main element and several secondary elements. For solenoid valves in particular FluidDraw manages the associated solenoid coils automatically. The linking of solenoid valves with their solenoid coils is described in detail under [Linking solenoid valves and solenoid coils](#).

If a main element is inserted into a circuit diagram, the associated coils are automatically entered in the *Unplaced Objects* symbol library.




Figure 13/7: Circuit diagram with solenoid valve and associated solenoid coils in the *Unplaced Objects* symbol library

The associated coils are already internally linked with the solenoid valve in the circuit diagram. Clicking one of the “electric connectors” in the solenoid valve automatically highlights the corresponding coil in the *Unplaced Objects* library.




Figure 13/8: Highlighting the connector link with associated solenoid coil

As soon as you drag a coil from the library into a circuit diagram it is “used up” and removed from the library. The valve is entered as the parent object for the coil.




Figure 13/9: Inserting a solenoid coil

Assigning a new identification to the coil has a direct effect on the valve since the coil and valve are linked. The identification is displayed at the valve.




Figure 13/10: Automatic linking of solenoid valve and solenoid coil

If you delete the solenoid coil in the circuit diagram it is automatically added to the *Unplaced Objects* symbol library again. This symbol library is completely self-managing.

Page and project properties

Chapter 14

pages and projects have a number of common properties. The properties set in the project can be used by pages in the project. All properties that can be specified for both pages and projects are listed below. The figures show dialog windows for the pages.

As pages normally contain circuits, the term circuit is used as a synonym for page in the following. pages can also contain e.g. parts lists.




Figure 14/1: Properties dialog window

Properties

The file name field displays the file name of the circuit or project along with the complete path. The file name is transferred to the

	input field for the “ <i>Description</i> ” and can be edited there. This entry is displayed at the upper edge of the window as well as next to the circuit or project node.
Page number	Here you can specify a page number. The page number can be made up of any character string. The page number can be accessed using the predefined placeholder “%PageNumber” . This placeholder can also be used in text components and drawing frames .
Drawing Frame	Here you can make settings for the drawing frame. This function is described in the section: Drawing frame .

14.1 Attributes

Any number of attributes can be created for every circuit or node in a project. The attributes are listed in a table on the “ *Attributes*” tab. New attributes can be entered in the empty cells at the end of the table. The use of attributes is described in the section: [Attributes of the nodes in a project](#).

The attributes of a project node are automatically copied to all circuit list nodes (inherited) and are thus available in all circuit drawings.

This concept is particularly useful for the [drawing frames](#) if project attributes are to be displayed in the circuit diagram, for example. You can find further information in the section: [Linking text components with attributes](#).

Circuit attributes copied from a project cannot be edited initially. The corresponding row in the [Page](#) tab of the *Attributes* dialog window is greyed out and the “ *Inherit From Project*” option in the column is activated.

However it is possible to overwrite a copied attribute in a circuit. The option in the “ *Inherit From Project*” column must be deactivated for this. The value of the attribute can then be edited. This function can be used to assign individual page numbers in the [drawing frame](#), for example. If the “ *Inherit From Project*” option is

reactivated then the attribute value is copied from the project again.

Attributes

Translation Table...

	Attribute	Value	Action	Inherit From Project	Comment
►	Additional text 1		Delete	<input type="checkbox"/>	
	Additional text 2		Delete	<input type="checkbox"/>	
	Revision 3, Index		Delete	<input type="checkbox"/>	
	Revision 3, Text		Delete	<input type="checkbox"/>	
	Revision 3, Date		Delete	<input type="checkbox"/>	
	Revision 3, Name		Delete	<input type="checkbox"/>	
	Revision 2, Index		Delete	<input type="checkbox"/>	
	Revision 2, Text		Delete	<input type="checkbox"/>	
	Revision 2, Date		Delete	<input type="checkbox"/>	
	Revision 2, Name		Delete	<input type="checkbox"/>	
	Drawn, Date		Delete	<input type="checkbox"/>	
	Drawn, Name		Delete	<input type="checkbox"/>	

Figure 14/2: *Attributes* tab

Attribute	This column contains the name of the attribute.
Value	This column contains the value of the attribute.
Action	The buttons in this column allow the following actions: if the attribute was created in the parent project node then the “Find Target...” action is available. Clicking this opens the <i>Project</i> or <i>Circuit</i> dialog window for the project node as the destination that contains the corresponding attribute. If the attribute was created in the same node then the “Delete” action that allows you to delete the attribute is available.
Inherit From Project	If the attribute was created in the same node then this option is deactivated and greyed out. This applies to all attributes of the project node since it does not have a parent node. For child nodes the value of the attribute from the project node is copied when this option is activated. After deactivating this option it is possible to locally overwrite the attribute value.

Comment	Here you can enter a comment on the attribute.
Translation Table...	If you are editing a text box you can use this button to open a search dialog via which you can find the text ID for a language text from the translation table.

14.1.1 Predefined placeholders

FluidDraw provides a number of predefined placeholders. These placeholders can also be used in [text components](#) and [drawing frames](#).

The placeholders begin with a percentage sign. The following predefined placeholders are some of those available:

%PageNumber	<p>The page number is specified in the properties dialog window for the circuit diagram.</p> <p>If reports are spread across several pages, the number of the sub-page is added to the page number with a minus sign. If, for example, the entered page number is “42-01” and the page displayed is the third page in a report then the placeholder “%PageNumber” is replaced by the character string “42-01-03”.</p>
%PageDescription	The description for the page is specified in the properties dialog window for the circuit diagram .
%PageCircuit	Specifies the “ <i>Circuit</i> ” value of the page’s designation convention.
%PageLocation	Specifies the “ <i>Location</i> ” value of the page’s designation convention.
%PageInstallation	Specifies the “ <i>Installation</i> ” value of the page’s designation convention.
%PageFileName	Stands for the file name of the page without the file path.
%PageFullFilePath	Stands for the file name of the page with the full file path.

%PageFileDateTime	Stands for the date and time of the most recent change to the circuit diagram.
%PageFileDate	Stands for the date of the most recent change to the circuit diagram.
%PageFileTime	Stands for the time of the most recent change to the circuit diagram.
%ParentDescription	Stands for the description of the page's parent project node.
%ProjectDescription	Stands for the description of the project.
%ProjectFullFilePath	Stands for the file name of the project with the full file path.
%TotalPages	Specifies the total number of pages of the project.

14.2 Page Dividers

Page dividers can only be defined for pages. Editing page dividers is described under [Page dividers](#).

14.3 Basic Unit Length

The symbols in the FluidDraw symbol libraries are created according to various DIN ISO standards. Instead of specifying absolute units of length, the standards simply use a relative basic unit of length "M". All symbols have been created with reference to this basic unit of length "M". The actual size of the symbol is not defined until the symbol is inserted into a circuit.

Information on how to convert the basic unit of length "M" is stored with the circuit diagram. You can change the set values for a circuit diagram by opening the properties dialog window for the circuit

diagram using the [Page Properties...](#) menu. You will find the relevant settings on the *Basic Unit Length* tab.




Figure 14/3: *Basic Unit Length* tab

As soon as the value of “M” is changed, the sizes of the existing symbols are recalculated with respect to the specified basic unit of length. The specification has no effect on elements in the drawing frame.

The *Basic Unit Length* tab is also to be found in the project settings. The settings made on this tab are used as a template for circuit diagrams created from scratch in the project tree.

14.4 Language

The language settings are to be found on the *Language* tab. The settings made on this tab affect language-dependent text, etc. in parts lists. The language used for program elements such as buttons is defined via the program options, see [Language](#).




Figure 14/4: *Language* tab

Inherit From Parent Node	Copies the language settings from the parent project node.
Copy from global options	This is for copying the settings defined under Manage in Options... / Language .
Product Catalog	Defines the language used for the Festo product catalog . All product attributes are displayed in the relevant language. The predefined attributes are also displayed in this language.
Translation Table	Defines the translation table to be used.
Translation Language	Defines the language from the selected translation table to be used. The user-defined attributes are displayed in the selected language.

14.5 Encryption

Projects and circuit diagrams can be encrypted. The encryption method used is AES-128. pages that are components of a project cannot be encrypted individually. In such a case, you can only encrypt the entire project.




Figure 14/5: *Encryption* tab

Enable Encryption

This option activates and deactivates encryption. When encryption is activated the password to be used can be entered in the *Password* input field.

14.6 Designation Conventions




Figure 14/6: *Designation Conventions* tab

This tab is used to define the settings for the designation conventions. You can find further information under [Equipment identifications and designation conventions](#).

Copy from global options

This is for copying the settings defined under [Manage](#) in [Options... / Designation Conventions](#).

Frame Identification

Defines that the identifications produced by the selected set of conventions are framed.

Specifications can be made for *Installation*, *Location* and *Circuit* that are evaluated for displaying the symbol identifications. If the *Inherit From Parent Node* option is active then the specification is applied from the parent project node.

Example

The example shown illustrates the effects of the selected designation conventions.

14.7 Cross Reference Representation




Figure 14/7: *Cross Reference Representation* tab

This tab is used to define the settings for the cross-reference representation. You can find further information under [Cross-reference representation](#). If the *Inherit From Parent Node* option is active then the settings are applied from the parent project node.

Copy from global options

This is for copying the settings defined under [Manage](#) in [Options...](#) / *Cross Reference Representation*.

Example

Illustrates the effects of the settings using an example.

14.8 Representation




Figure 14/8: *Representation* tab

This tab is used to define the settings for the crossing lines. You can find more information under [Line jumps](#). If the *Inherit From Parent Node* option is active then the settings are applied from the parent project node.

Copy from global options

This is for copying the settings defined under [Manage](#) in [Options... / Appearance](#).

Display Line Jump

Crossing lines are represented as jumps.

14.9 Display Attributes

Display Attributes

☐ Inherit From Parent Node

Copy from global options

Attribute Name	Display	Frame Text	Alignment
Identification	<input checked="" type="checkbox"/>	Individual	Individual
Type	<input checked="" type="checkbox"/>	No frame	Individual
Item name	<input type="checkbox"/>	No frame	Bottom
Cross-Section, Cable	<input type="checkbox"/>	No frame	Bottom
Length, Cable	<input type="checkbox"/>	No frame	Bottom
Cable Type, Cable	<input type="checkbox"/>	No frame	Bottom
Customer part no.	<input type="checkbox"/>	No frame	Bottom
Description	<input type="checkbox"/>	No frame	Bottom
Order code 1	<input type="checkbox"/>	No frame	Bottom
Order code 2	<input type="checkbox"/>	No frame	Bottom
Part number	<input type="checkbox"/>	No frame	Bottom

Apply settings

Reset

Figure 14/9: Display Attributes tab

FluidDraw can automatically display the attributes of the objects in the circuit. The table in this tab serves this purpose. The same texts with attribute links are created for the selected attributes as those which can also be activated in the [properties dialog for symbols](#).

- Inherit From Parent Node

If this option is selected, the attributes to be displayed defined in the project or in the parent node are used for the page.
- Copy from global options

This is for copying the settings defined under [Manage](#) in [Options...](#) / *Display Attributes*.
- Attribute Name

This column contains the attribute name whose value is to be displayed.
- Display

If this option is activated, a text with the selected representation is automatically inserted when inserting a new symbol or after assigning attributes or catalog properties.

Frame Text	Here you set the style of the frame. There are different styles available like rectangle or ellipse. The setting “ <i>Individual</i> ” retains the existing setting.
Alignment	Defines the position and alignment of the attribute text with respect to the associated object. The setting “ <i>Individual</i> ” uses the positions defined for the individual symbols to display the designation and attributes.
Apply settings	By default, the settings in this dialog only affect newly inserted objects and existing objects whose attributes have been added or changed. With this button, you can apply the settings to the existing objects of the page or to all pages of the project node.
Reset	Resets the settings to the default values.

Position numbers

Chapter 15

For different applications it is useful to assign a unique number to the same products within a project. Like a construction plan, where all screws of a size are listed at the beginning and numbered e.g. S1 to S5, so that later on in the plan the position number can be used to refer to a specific screw. FluidDraw supports the automatic assignment of such fixed position numbers for identical products in the circuit. Identical products in FluidDraw means that certain objects in the circuit have the same product data (more precisely: catalog and/or user-defined properties). Whenever a new object is added to the project and the relevant product data is filled in, a position number is assigned to the object. The position number is similar to the sequence number of an accumulated parts list. However, the position number does not change if the parts list is sorted differently or if objects are inserted or deleted. Position numbers can be changed manually at any time and thus adapted to current requirements.

A position number can be assigned to the following objects in the project:

- Main and sub-components
- Connection lines
- Cables
- Terminal strips

Of the objects mentioned, however, only those objects that are also displayed in a parts list are taken into account, i.e. those that have the “*Display in Parts Lists*” option. The position number is stored in a user-defined attribute of the respective object. This makes it easy to display the position number in the circuit, to manipulate it directly and to include it in reports.

15.1 Dialog Manage position numbers

Via the menu item **Project** / **Manage position numbers...** you reach the dialog for managing the position numbers. This dialog is

used to fundamentally activate or deactivate the automatic assignment of position numbers for a project. Once activated, the rules for assigning position numbers can be adjusted here and the current position numbers can be managed.

Position numbers

☒ Use fixed position numbers for same products

Numbering: 10, 20, 30, 40, 50, ... Define...

Attribute: Pos.No. ☒ Display Attribute Properties...

Current position numbers Renumber... Sorting... Criteria for same products...

Pos.No.	Part number	Supplier	Order code 1	Order code 2	Customer part no.	Quan.	Identification	Location
10	<input type="checkbox"/> 2187	Festo	MC-2-1/8			1	Q2	/1.5
20	<input type="checkbox"/> 151160	Festo	GRLA-M5-B			4	R1, R2, R3, R4	/1.2, /1.2, /1.3, /1.4
30	<input type="checkbox"/> 163319	Festo	DNC-32-25-PPV			2	M1, M2	/1.2, /1.3
40	<input type="checkbox"/> 192592	Festo	LFR-3/8-D-7-O-MINI			1	K1	/1.4
S04	<input checked="" type="checkbox"/> 525725	Festo	MA-40-10-R1/8-E-RG			1	P1	/1.5
60	<input type="checkbox"/> 533258	Festo	QBT-1/4-5/16-U-M			1	T1	/1.5

Add Remove * Mandatory field

Insert report into project OK Cancel

Figure 15/1: Dialog for position number management

Use fixed position numbers for same products

This option switches the automatic assignment of position numbers on and off.

This option is disabled by default for all projects. If you want to use position numbers in your current project, activate the option. By setting this option, the other controls in the dialog are activated and can be used.

Existing position numbers are not deleted if you deactivate the option at a later time.

Numbering

Here you can see a preview of the position numbers generated by the numbering scheme currently defined. With the **Define** button the numbering scheme can be changed. Details can be found in the following section [Changing the numbering scheme](#).

Note: If you already have position numbers and then change the numbering scheme, the existing position numbers are not automat-

ically changed to the new scheme. If you want to change the existing position numbers, use the options for [“Renumber”](#).

Attribute Name

This is the name of the user-defined attribute in which the position number is stored. The [Define](#) button can be used to change the name of the attribute. Details can be found in the following section [“Changing the attribute for the position number”](#).

Current position numbers

As in an accumulated parts list, this table lists all the objects that are relevant for assigning position numbers. This means that only those objects are listed here for which the necessary product data is entered and the option “*Display in Parts Lists*” is set. In addition, this list can contain user-defined entries if certain assignments are to be fixed.

You can use the table to check the assigned position numbers and change them directly. The buttons above and below the table are used to manipulate the entries in the table.

In the default setting, the contents of the table do not correspond 1:1 to the standard report “*Accumulated Parts List*”, since the criteria for assigning position numbers are formulated somewhat differently than the columns in the accumulated parts list. However, you can adjust the criteria for the same products so that both match. Details can be found in the following section [“Adjustment of criteria for identical products”](#).

Renumber

Allows certain entries in the table to be renumbered automatically.

Sorting

Adjust the sorting of the listed objects in the table. Sorting has a direct effect on “Renumbering”.

Criteria for same products...

Determines which product data, i.e. catalog and/or user-defined attributes, must be filled in so that a position number is assigned to a product. It also determines which products are considered identical and thus receive the same position number.

Add

Adds a new user-defined entry to the table.

Remove

Deletes the selected user-defined entries from the table if they are not currently used in the project.

The **OK** button closes the dialog and applies all changes to the current project. In other words: As long as you do not confirm and close the dialog with **OK**, your changes will not take effect. You can use this to test and discard changes by leaving the dialog via the **Cancel** button. In this case your project will not be changed.

15.2 Assignment of the position numbers

If position number assignment is activated, a position number is assigned for the following objects in the project:

- Main and sub-components
- Connection lines
- Cables
- Terminal strips

For an object to receive a position number, the following additional conditions must also be fulfilled:

- The option “*Display in Parts Lists*” must be set.
- At least the mandatory product data must be entered.

In principle, position numbers can only be assigned to those objects that contain the relevant product data to distinguish the individual products. A distinction is made between mandatory fields and optional fields. At least the mandatory fields must contain a value, otherwise no position number can be determined for an object. The optional fields serve to further differentiate between different products. In the standard setting, “*Supplier*” and “*Part number*” are defined as mandatory fields. These two attributes must therefore be at least present and filled in so that a position number can be assigned. It doesn't matter whether the corresponding attributes are listed in the catalog properties or in the custom properties.

position numbers are assigned either directly when a new object is inserted into the project or directly after an object has been edited,

mainly by adding product data. The system first checks whether a position number already exists in the project for the product data in question. If so, the existing position number is assigned to the object. Only if no other object with the same product data exists, a new position number is assigned and entered.

Some standard actions in the project are used to further illustrate the assignment of position numbers:

Insert a symbol from the standard library

If a symbol from the standard library is inserted, it does not yet have any product data. At this point, the inserted symbol is not yet assigned a position number. A position number is not assigned until product data has been assigned to the symbol via a product catalog or entered directly in the properties.

Insert a symbol from a user library or file

Here it depends on whether the relevant attributes for distinguishing the products are already present or not when the component is inserted into the circuit. If, for example, this data is already stored in a symbol from a user library, a position number is also assigned.

Insert a symbol from the Festo catalog, a user database, a shopping cart or via Festo QuickSearch

When pasting from these sources, the symbol is usually used to insert corresponding catalog data. If these data meet the criteria for identical products, a position number is assigned when the data is inserted.

If a new position number is assigned when inserting a new object, the system always checks whether there are other objects in the project with identical product data but without position numbers. The newly assigned position number is then also entered in these objects so that it is maintained uniformly for all the same products.

If it should happen that different position numbers are entered for the same products, this is recognized by the dialog for managing position numbers and the smallest position number found is automatically entered in all objects in order to restore a uniform status in the project.

The assignment of position numbers can be adapted to a certain extent to individual requirements. This is described in more detail below.

15.2.1 Change in the numbering scheme

Via the **Define** button in the “*Numbering*” area of the position number management you can open the following dialog for adjusting the numbering:


The image shows a 'Numbering' dialog box with a blue title bar. It contains two main sections: 'Numeric' and 'Alphabetical'. The 'Numeric' section is selected with a radio button. It includes fields for 'Prefix', 'Start number' (set to 10), 'Postfix', 'Step width' (set to 10), a checkbox for 'Leading zeros', and a 'Digits' field (set to 2). A 'Preview' field shows the sequence '10, 20, 30, 40, 50, ...'. The 'Alphabetical' section is unselected and shows a 'Preview' field with the sequence 'A, B, C, ..., Z, AA, AB, ..., AZ, BA, BB, ...'. At the bottom right are 'OK' and 'Cancel' buttons.

Figure 15/2: Dialog for adjusting the numbering

Here you can basically choose whether the numbering should be based on a sequence of numbers (numeric) or letters (alphabetic). Select the type of numbering you require by selecting the appropriate option. With numerical numbering, you can make various settings for formatting the position numbers and adjust the number sequence. After changing the settings, the preview below the settings is updated directly, so you can always see the effect of your changes. Click on **OK** to accept the selected numbering scheme. Note that the new procedure is not automatically applied to existing position numbers. Use the “Renumber” options to change existing position numbers if necessary.

Change the attribute for the position number

The **Define** button in the *Attribute Name* area of the position number management allows for the modification of the attribute name used for storing the position number. Clicking the button opens the following dialog:




Figure 15/3: Change of the attribute for the position number

The default setting is that the position number is entered in the user-defined attribute with the predefined name “Item No.”. If you want to change this, activate the option “*User Defined Attribute*”. All user-defined attributes already existing in the project are then available for selection. If you would like to use a completely new attribute instead, you can create it again using the **Add Attribute...** button.

If you select an existing attribute, the contents in this attribute are not changed by selecting the attribute for use for the position number alone. After you have left the dialog, the new attribute is displayed in the table with the current position numbers in the first column with any existing values.

When a position number is entered by automatic numbering, the comment of the attribute notes that this assignment is automatic and not manual. This is done by entering the text “<auto>” in the comment. Thus it is directly recognizable from the component that this is an automatically entered value.

If the attribute for the position number is changed later, the following happens:

1. All attribute values are copied from the old attribute to the new attribute
2. If the old attribute was filled automatically, it is deleted. Manual entries or changes to the old attribute are thus retained.

This procedure ensures that manually entered data is retained when the attribute is changed.

Adaptation of criteria for identical products

Decisive for the allocation of position numbers is the definition of the criteria by which certain products are to be distinguished. These criteria can be adjusted in the following dialog, which can be opened by clicking the **Criteria for same products...** button.




Figure 15/4: Adaptation of criteria for same products

This dialog lists the attributes that are used to differentiate between different products. Certain predefined attributes are available for selection here, as well as the attributes currently used in the project objects. It does not matter whether the attribute is entered as a catalog or user-defined attribute in a component.

In addition to the attribute, the column “ *Mandatory field*” defines which of the attributes are considered mandatory and which optional. The attributes marked as mandatory fields must exist and be filled in so that the object is assigned a position number. The optional fields need not be specified. If optional attributes are contained in an object, the values in these attributes are used to distinguish products more precisely.

The **Add** button can be used to add additional attributes to the criteria. Via **Remove** previously marked entries can be deleted.

The list of attributes must contain at least one attribute and be marked as mandatory. The criteria cannot consist exclusively of optional fields. Therefore not all hooks can be removed from the column “ *Mandatory field*” in the dialog.

With the two buttons to the right of the list of attributes, the order of the attributes can be adjusted. However, this only affects the display in the table in position number management and not the assignment of position numbers.

If the product criteria are changed and other mandatory criteria are selected, this fundamentally changes which objects in the project are assigned a position number and which are not. It can happen that objects that previously had valid product criteria no longer have valid product criteria. The position number is automatically deleted from these objects after changing the product criteria.

Custom entries

The table with the current position numbers automatically lists all objects that exist in the project and are provided with the necessary product data. In addition to these automatic entries, further user-defined entries can be added to the table. These entries can then be used to store position numbers for specific products that are not currently included in the project in advance.

You add a new fixed or custom entry to the table by clicking the **Add** button below the table. A new empty entry is then created in the table with the option “ *User Defined*”, in the column with the user icon in the header. In contrast to the automatic entries, a new user-defined entry allows you to enter the values for which this position number should apply in the columns with the criteria for identical products. It is important that you enter at least the man-

datory product data so that the entry can be used to assign a position number.

Remove entries

The entries in the table are generated automatically on the basis of the existing objects in the project, similar to an accumulated parts list. You can see which position number is used in which object from the list of labels in the corresponding column of the table.

In addition to these automatic entries, the table may also contain entries that are currently not used in the project. For these entries nothing is entered in the column “*Identification*”. These can be either currently unused user-defined entries or entries recently used in the project.

You can remove such unused entries from the table by selecting these entries and then pressing the **Remove** button. All entries that are currently used in the project cannot be deleted.

15.2.2 Manual adjustment of the position numbers

Define individual values in the dialog

In the table with the current position numbers, the position number is always displayed in the first column with the attribute name as the heading at the front of the table. The entries in this column can be edited and each position number can be changed directly here.

If you change a position number manually in this way, this line is then automatically marked as a user-defined entry. You can see this by the fact that after entering the position number, the checkbox in the column “*User Defined*” is set. This protects this line from automatic changes by the “Renumber” function and the manually changed value is also retained when the other entries are “Renumbered”.

Renumbering

Above the table with the current position numbers is the **Renumber** button. A click on this button opens the following dialog:




Figure 15/5: Dialog for “Renumber”

Here you can select whether all entries in the table should be renumbered or only those for which no position number is currently entered. By default, user-defined entries are not taken into account during numbering so that the manually entered values are not lost. However, you can also have the custom entries numbered by checking the “*Include user-defined entries*” option.

The numbering of the entries in the table is from top to bottom and thus depends on the current sorting of the entries. With the **Sort-ing** button you can change the sorting of the entries and thus achieve a different numbering.

Only those entries will be numbered where at least the mandatory product data are entered. If there are user-defined entries for which the mandatory product data are not completely filled in, they are not numbered.

Overwriting the position number directly in the object

The position number is stored in the individual object as a user-defined attribute. It is possible to change the position number directly there. If you change the position number there, you will be asked whether you want to adopt this position number as a user-defined position number for all identical products. If you confirm this request, the position number is entered in all objects with identical product data, so that the newly specified position number is still unique for all identical products in the circuit.

15.2.3 Display of the position number in the parts list

The position number is not included in the standard template for the single position and accumulated parts list. With the following steps you can add the position number to the parts list:

1. Call up the properties of the corresponding parts list. If you have not yet inserted a parts list into the project, you can do this via the menu item [Insert](#) / *Report*.
2. Switch to the “*Column selection*” tab in the parts list properties. In the list of “available columns” on the left page, look for the entry “Item No. (*User Defined Attribute*)”. (If you have selected a different attribute name for the position number, search for this name)
3. Double-click on the entry to add the column to the parts list.
4. Using the buttons to the right of the table, you can change the order of the columns in the parts list if necessary.

Tables

Chapter 16

FluidDraw provides *fixed* tables and *automatic* reports. Whereas a *table* is for displaying fixed lines and columns with static or dynamic contents, an *report* is used to list objects of a page or of the entire project according to specific rules and automatically adapt them if objects are added or omitted.

FluidDraw provides typical reports, such as parts lists, terminal diagrams or content overviews. These templates can be adapted flexibly. You can also use an editor with a wide range of functions to define individual reports and then save them as user-defined templates. You can find more information in the section: [Reports](#).

16.1 Using tables

Tables can be inserted using the [Insert](#) menu under [List](#). A table is inserted at the position of the mouse pointer with a click like the [drawing elements](#). That opens a dialog, which can be used to define the initial size of the table. The table is then inserted in the current page and the properties dialog window opens for filling in and formatting the table.




Figure 16/1: Properties of a table

16.1.1 Editing contents

You can change the contents and formatting of the table using the table's properties dialog window. The way to edit the table is similar to that of familiar Office products.

To enter any text, highlight the desired cell using the mouse and enter the text using the keyboard. To edit existing text in a cell without overwriting it completely, press the F2 function key. That takes you to the cell where you can edit the existing contents.

In addition to fixed text, attribute links and predefined placeholders can also be used in tables. The contents of the corresponding cell then result dynamically from the value of the corresponding attribute link or the predefined placeholder. If you want to enter an attribute link in a cell, select the *Attribute Link* option below the view of the table to do this. Then, either select a predefined place-

holder using the **Predefined variable...** button or select an attribute using the **Browse...** button.

Texts from a translation table stored in the project/page can also be used in the table. You can use the **Translation Table...** button to select a text from the translation table. The text from the translation table is displayed in the corresponding translation language of the page that contains the table.

Images can also be inserted in individual cells instead of a static or dynamic text. The **Choose picture...** below the displayed table can be used to load an image file and insert it in the currently highlighted cell. The inserted image is always scaled to the available size of the cell. In the program options, you can define if an image is embedded by default when it is inserted in the table or if only a reference to the original file is inserted. Images are always embedded with the default setting.

Existing table data e.g. of an Office application can usually be applied using copy and paste. Only the contents are applied, no formatting. If the copied table is bigger than the current table, it can be increased in size accordingly on request.

16.1.2 Formatting

Via the toolbar above the table in the properties dialog, you can change the formatting of the currently selected cells of the table.

You can define the column width and row height of the corresponding columns and rows of the table interactively using the mouse. To do this, move the mouse pointer to the edge of a cell in the table. There, the mouse pointer is converted into a shift pointer and, keeping the left mouse button pressed, you can move the edge of the cell, thus changing the column width or row height.

Chapter 17

In addition to compiling the circuit documentation, overviews in tabular form of the components used are required in various views. A parts list or order list of all components for procuring the required parts, a terminal diagram for the correct wiring by the electrical engineer in the control cabinet and a tube list for the correct identification and connection of all pneumatic components by the equipment manufacturer.

17.1 Using reports

Reports can be inserted using the **Insert** menu under **List**, a report is inserted at the position of the mouse pointer with a click like the [drawing elements](#).

In previous versions of FluidDraw a defined set of reports was available that could be adapted to your requirements to a limited extent. With version 6, these options have been expanded significantly, so that now all reports provided can be adapted very flexibly to the requirements of the corresponding project.

Reports in FluidDraw are always a tabular list of objects. The result of a report that is displayed on a page in the project is created dynamically while the program is running and displayed in the circuit diagram. If any change is made to the objects included in the report, this is automatically reflected in the report result.



In version 6, reports have been completely re-designed and implemented. The layout of the templates provided corresponds to that of the known templates in version 5. Reports from version 6 are not downward-compatible with version 5. That means reports created using version 6 cannot be displayed in version 5.

The use of some standard reports is shown first in the following sections. Then the basic concepts of the reports are described in detail.

17.2 Parts lists

All those objects are listed in the predefined parts lists that have set the “*Display in Parts Lists*” ID in their properties. That applies to the following elements of the project: main components, sub-components, connection lines, terminal strips and cables.

If a part number from the Festo catalog or a separate product database is assigned to a symbol, the ID is automatically set. The ID is not automatically set for conduction lines. Please open the properties here and set the ID so that it appears in the parts list.

Single position parts list

Each object is listed individually in the parts list.

Accumulated parts list

All objects with the same part number, type, item name and supplier are summarized in one line. The total number of components summarized in the line is displayed in the *Quantity* column.

17.2.1 Inserting a new parts list

Proceed as follows to insert a new parts list:

- In the **Insert** menu select *Report* under **List**.
- Select a point on the page where the new parts list is to be inserted. That opens a selection dialog that you can use to select a report that is to be inserted on the current page.
- You can find the single position parts list on the left side of the tree structure under *Standard reports* ⇒ *Parts lists* ⇒ *Single Position Parts List*. Select *Single Position Parts List*. As soon as

you select the entry, a preview of the report is displayed on the right side for the currently open project.

→ Confirm the selection the parts list by exiting the selection dialog using the **OK** button.

Before the report is inserted at the desired point on the page, a properties dialog appears with the settings of the selected report. You have the option of defining specific settings here directly before the report is inserted in the circuit diagram.

Confirm the properties dialog and the parts list is inserted in the circuit diagram at the point you selected.

17.2.2 Adapting a parts list

You can use the properties dialog of the parts list to define important settings and adapt the parts list to a certain extent.

You can generally select the drawing layer at the top right and at the bottom left, the **Save as new template...** button provides you with the option of saving the current report as a new template.

In addition, the details of the parts list are defined on the individual tabs of the properties dialog, which are now explained in detail.




Figure 17/1: Properties of the parts list: *Object selection* tab

On the object selection tab, you can select which pages of the project are to be taken into account in the parts list.

Include this page's components only

Only lists the components of the page on which the parts list is positioned.

Include All Project Files

Lists all components from all pages of the project.

Include Selected Files:

Only lists the components from the selected pages of the project.

Exclude global objects

Excludes [global objects](#) from the report.




Figure 17/2: Properties of the parts list: *Column selection* tab

You can use the *Column selection* tab to influence which columns are to be included in the parts list and how the parts list is sorted.

All columns are listed on the *Selected columns* table that are currently included in the parts list. A column of the parts list is displayed in every line with the following data:

ID	Consecutive number of the corresponding column.
Column heading	Heading of the corresponding column in the parts list.
Contents	Contains one or more placeholders, similar to the predefined placeholders in a text box for the property or the attribute that is to be displayed in this column.
Display	Defines whether the column is displayed or not.

Those columns are displayed in the list under *Available columns* that can also be added to the parts list. You can use the buttons between the *Available columns* list and the *Selected columns* table to add more columns to the parts list or remove selected

columns from the existing list. You can use the buttons to the right of the table to change the order of the columns.

Below the table *Selected columns* the button *Combine columns* is available for merging columns. The button is deactivated as long as only one row is selected in the table. When more than one row is selected, the *Combine columns* button is activated. If this button is pressed, the following dialog opens in which the details of the summary can be defined.




Figure 17/3: Combine columns

Column heading	The column header of the new merged column.
Combination	The first value found in the selected columns is output in the combined column.
Concatenation	The contents of the selected columns are displayed in the combined column one after the other, separated by the specified separator.
You can adapt the sort order of the parts list using the Sorting button. Click this button to open the sort dialog.	




Figure 17/4: Default sort order of a parts list by the *Identification* column

Sorting in ascending order by the *Identification* column is set by default.




Figure 17/5: Properties of the parts list: *Appearance* tab

How the parts list is displayed on the page can be adjusted on the *Appearance* tab. The changes made are displayed directly in the preview.

17.2.3 Adding user defined attributes to the parts list

The templates supplied for parts lists and accumulated parts lists are designed to list components with stored catalog data from the Festo catalog or from your own product database. If components are inserted via the menu items [Insert](#) => [From Festo Catalog...](#) or [From Custom Database](#) or subsequently assigned catalog data via a part number, the evaluations immediately contain the appropriate data. The situation is different if user-defined attributes for type, supplier etc. are used and these are to be listed in the parts list. To do this, the supplied template must be modified accordingly. This is possible in the properties of an report in the *Column selection* tab.




Figure 17/6: Properties of the parts list: *Column selection* tab

On the left-hand side of the *Column selection* tab, a list is displayed with all properties of the components contained in the project that are available for evaluation. These are the properties of components, lines, terminal strips and cables. The properties are indicated here with their name. To differentiate between user-

defined attributes and catalog attributes, the suffix *User Defined Attribute* is appended to the name of those attributes.

The standard templates for item BOMs and summarized BOMs are designed to list the part number, type, and item name from the catalog attributes, and description and vendor from the user-defined attributes. You can recognize this by the placeholders entered in the *Contents* column. “dki-attribute” refers to catalog attributes and “user-attribute” to user-defined attributes.

If you do not use product databases in your project and store the product data such as the type directly in the user-defined properties, the template must be adapted as follows:

- In the *Available columns* list, search for the user-defined attributes that you have entered. Look for the suffix *User Defined Attribute*.
- Select the required attributes and add them to the parts list. You can use the > button or drag and drop the columns into the list of selected columns.

The selected user-defined columns are now also displayed in the parts list. The two buttons to the right of the table with the selected columns can be used to adjust the order of the columns in the parts list.

If you do not use any components with product data in your project, you can delete the corresponding columns from the parts list by selecting them and clicking **Delete**.

However, it is often the case that both components with catalog data, such as Festo products, and components without catalog data are present in the circuit diagram. In this case, it is unpleasant that the catalog attributes and the user-defined attributes are output with the same heading in different columns. This can be solved by combining the corresponding columns into one column. To do this, proceed as follows:

- Select the columns with the same heading or meaning in the table *Selected columns*. Press and hold the **Ctrl** key to select several rows successively.

- As soon as more than one line is selected, the *Combine columns* button is activated. Click this button. The following dialog appears, in which you can define how the columns should be combined.




Figure 17/7: Combine columns

- If necessary, change the column header and leave the summary type at *Combination*.

The selected columns are then replaced by the new combined column, which now combines the contents of the previous columns in one column.

17.2.4 Editing the parts list contents

The identification, description and user-defined attributes of individual components in the parts list can be edited directly in the parts list on the page.

- Insert a parts list on a page and highlight it by simply clicking it with the left mouse button.
- Then, switch to edit mode by selecting **Edit** from the context menu of the report (right mouse button). Alternatively, you can also highlight the report and select **Edit** ⇒ **Edit List/Table** in the menu.

In edit mode, all fields that cannot be changed are highlighted in grey. The remaining fields can be edited directly.

→ If you click such a field, you can change the contents. Finally, confirm your input with Enter or by using the arrow up/down keys to switch to another line.

The new value is then transferred directly to the component.

Note: If you change the identification of a component, as the sort order in the parts list is changed that may also change the position of the component in the parts list. Therefore, pay attention to the order of the components if you want to edit several identifications in succession.

17.2.5 Exporting a parts list

Every parts list can be exported to a text file with separators. These files can then easily be further processed with other applications, such as spreadsheet programs.

→ Highlight the parts list you want to export and open the context menu. Select **Export...** from the context menu.

The following export dialog appears in which you can define the format for export.




Figure 17/8: Settings for exporting a parts list

Column Header	If this option is selected, the column headings of the parts list are displayed in the first line.
Quotation Marks	If this option is selected, all values of the parts list are displayed in quotation marks.
Delimiter	You can define here which separators are to be used to separate the individual columns.
Character Code	<p>Defines the character coding for the text file created. Change this value if umlauts and special characters are not exported correctly.</p> <p>After confirming the export dialog, you can define the location and file name of the text file to be created. Then, the parts list is exported.</p>

17.2.6 Sending it to the Festo Online Shop

All components of a parts list that have a part number and for which either Festo or nothing is entered as the supplier can be sent to the Festo Online Shop and transferred to the shopping basket there. A parts list may basically also include products of other suppliers, which are filtered out during transmission to the Online Shop.

→ To transfer the selected parts list to the Online Shop, select Send to Festo Online Shop... from the context menu.

The standard Internet browser defined on your PC automatically opens. The parts list is displayed to you again there with the items relevant to the Online Shop. You have the option of adapting the quantity again here prior to transfer to the shopping basket. Click *Send* to transfer the items to the shopping basket.

17.2.7 Differences between parts lists in version 5 and 6

The reports in version 6 have been greatly improved compared to the lists in version 5, so that they can be better adapted to individual requirements. Previously, tube lists or cable diagrams, for example, were fixed and could not be supplemented with additional columns. With the standard templates for reports, we try to simulate the predefined lists of version 5. However, there are some points that work somewhat differently in the new reports as compared to the known lists of version 5.

In the case of parts lists, this applies especially to the automatic listing of attributes. In the old part lists of version 5, every newly added user-defined attribute was automatically listed in the parts list. This is no longer the case with the new part lists in version 6. Certain columns are preset in the standard template for the item parts list and are not automatically supplemented with new columns when new attributes are defined. This means that if new user-defined attributes are added, they must be added manually via the part list properties. You do this by opening the parts list properties

and switching to the *Column selection* tab. There you can select from the list on the right those attributes and properties that you want to appear in the parts list.

Another difference to version 5 is that user-defined attributes no longer automatically overwrite catalog attributes with the same name. Instead, certain columns can be grouped together in the new reports.

Tip: In principle, you only have to customize the parts list once to meet your individual requirements. You can then use the **Save as new template...** button in the parts list properties to save it as a new template. You can then use your individual template instead of the standard template for new part lists.

17.3 Table of contents

The table of contents consists of a list of all pages or of selected pages of a project. The name of the page and the number of pages are displayed.

You can use the properties of the table of contents to have further attributes of the individual pages displayed, such as date information, change notes, etc.

17.3.1 Inserting a new table of contents

→ Select the Report item from the **Paste** menu.

→ Select the point on the page where the table of contents is to be inserted.

→ You can find the table of contents in the tree under *Standard reports* ⇒ *Index / Directories* ⇒ *Table of contents*. Select it

and click **OK**. Alternatively, you can also double-click the entry in the tree.

17.3.2 Adapting the table of contents

You can define in the properties of the table of contents which pages are to be displayed and which additional page attributes are also to be displayed.

17.4 Connector lists / terminal diagrams

In addition to the previously described parts list, the accumulated parts list and the table of contents, there are further pre-defined reports that are to be found in the selection dialog in the branch with the connector lists and terminal diagrams.

17.5 Reports in detail

Reports in FluidDraw are always a tabular list of certain, selected objects.

The selection of the objects to be listed is therefore the basis for the report. An *object* at this point refers to the various elements of a project, such as components, conduction lines, terminals, cables, etc. How objects are structured in the reports is described in the following section on object selection.


The result of a report is always a table with values of the properties of the selected objects. The table created consists of a defined number of header lines and a variable number of position or result lines. The header lines are displayed once at the beginning of the

table. If the report is distributed over several pages, the header lines are displayed again on each page.

A table template consisting of the header lines and a template for the position line are the basis for the table view. Details are provided in the following section on representation.

The reports in FluidDraw provide several ways of evaluating the objects included in the project. However, the following reports are not possible:

- Cross-project reports are not possible. You can only create reports within a project that refer to the current project.
- Filters on grouped data can be defined. Reports for listing all components that occur more than five times in the project are not possible, for example.
- Sub-queries or nested reports are not possible.

Various dialogs are used in FluidDraw to influence the properties or the structure of a report. If you double-click a report on the page or its properties, the properties dialog appears first. Only certain, selected settings of the report can be modified in this dialog. The “” button can then be used to open a further dialog with the details of the report. In this dialog, the report can be adapted completely, compared to the properties dialog.

This separation into two dialogs is done in FluidDraw to simplify the use of reports during daily work and to conceal the complex details of a report. The dialogs are designed such that it should normally not be necessary to jump to the details of a report when using a report in the project. The corresponding details only need to be adapted if the basic structure of a report needs to be adapted.

For a comprehension of the concepts and dialogs described below, we recommend that you study the default reports provided with their settings and use them as the starting point for your own reports. All concepts described below are used more or less in the default reports and are thus explained.

17.5.1 Object selection

Every FluidDraw project consists of a wide range of different objects, such as components, conduction lines, cables, terminal strips and terminals, which are organized on different sides. In addition, there are **global objects** in which the higher-order data of several components is stored, such as for a valve terminal.

The object selection defines which of these objects from the project are to be taken into account in the report. Should the report include all connector lines or should it be a report of all components including their connections? This is defined fundamentally with the object selection and determines which properties and attributes are available for displaying the results of the report.

Every object in FluidDraw has certain properties and attributes, which can be displayed and edited using the properties dialog of the corresponding object. These are e.g. the description of a page or a component, the various IDs such as “*Display in Parts Lists*” or the catalog and user-defined attributes. In the object selection, you can define filter criteria based on the values of these properties and attributes to limit the number of objects listed in a suitable manner.

The object selection is split up into two views:

Object selection at properties dialog

The properties dialog contains the selection of the pages included in the report and it displays the quick filters.

Object selection at report details

You can use the “**Edit details...**” button in the properties dialog of a report to access the details of the report. You can specify in detail there on the object selection tab which objects are to be taken into account in the report.




Figure 17/9: Details of a report: *Object selection* tab

The objects included in the report are listed under “*Selected objects*”. You can use the “**Add**” button to select an object class and add it to the report. You can use the **Remove** button to remove the currently selected object class from the report again.

If you highlight a selected object class, additional control elements are displayed below the list of selected objects that you can use to define filter criteria for the object class selected.

Simplified quick filter

This option defines how the quick filters, which are explained below, are displayed in the properties dialog.

Hide page selection

Defines whether the report can be limited to specific pages or not in the properties dialog.

If you press the **Add** button, the following dialog appears for selecting the object class:




Figure 17/10: Selecting an object class in the *Object selection*

Object hierarchy

Some objects in FluidDraw are organized in a hierarchical structure, which is also displayed in the [object browser](#). That applies e.g. to the terminals of a terminal strip or to the connectors of a component.

a report can use this hierarchical structure in the object selection e.g. to also evaluate the corresponding sub-objects for the corresponding main object at the same time, or to be able to define specific filters at the sub-object.

That means that e.g. specific main components can be evaluated and also all connectors of precisely these main components. The question is only how the sub-objects, i.e. in the example the connectors of the main components, are to appear in the report. There are generally two ways to do this. They are illustrated using the following example. The following three cylinders with their connectors are evaluated:




Figure 17/11: Circuit diagram example for illustrating the output mode

In the event of a report of the main components only, like in a single position parts list, you will get the following result:

Selected objects			Pos. No.	Identification
... Main Component - <filtered>			1	-MM1
			2	-MM2
			3	-MM3

Figure 17/12: Result of the object selection with main components only

The circuit diagram contains the three main components that meet the filter criteria for selecting objects. In this example, the same criterion is used as in the single position parts list (“*Display in Parts Lists*” must be set). Therefore, the result of the report has three lines, one line for each component.

If the connectors of the main components are now also to be evaluated, the connectors can also be added to the object selection as sub-selection for the main components. The object selection would then look like as follows:


Selected objects	
	Main Component - <filtered>
.....	Connector


Figure 17/13: Object selection with main components and connectors

The report now not only contains the main components but also the corresponding connectors of the main components. In this example, components M1 and M2 each have two connectors and M3 has one connector. Previously, only main components were listed in the result. Where are the additional connectors now to be displayed? For this, there are the following two options, that are distinguished via the output mode:

Next to each other

In *Next to each other* output mode, the sub-objects are each displayed in the same line with their parent object. For the example, this would then look like as follows:

Selected objects		List mode	Next to each other
Main Component - <filtered>			
Connector			



Pos. No.	Component	Connector
1	-MM1	1
2	-MM1	2
3	-MM2	1
4	-MM2	2
5	-MM3	1


Figure 17/14: Report result in 'next to each other' mode with main components and connectors

The result now has five lines as the three components have a total of five connectors.

Below each other

In *Below each other* output mode, the sub-objects are displayed in their own separate rows below the main objects. For the example, this would look like as follows:

Selected objects		List mode	Below each other
Main Component - <filtered>			
Connector			



Pos. No.	Component/Connector
1	-MM1
2	1
3	2
4	-MM2
5	1
6	2
7	-MM3
8	1

Figure 17/15: Report result in 'below each other' mode with main components and connectors

The result now has eight lines: three for the components and five for the connectors. This representation highlights the hierarchy of the objects. That can be further emphasized by coloring the object classes, like in the example here.

Contents of the report result

As previously shown, the result of the report in the event of an object selection with sub-objects depends on the selected output mode. That does not only apply to the number of result lines creat-

ed, but also to the contents of the result lines. If the definition was made in the column selection for a specific column that e.g. the identification is to be displayed there, it depends on the corresponding output mode selected how this is interpreted.

In *Below each other* output mode, the individual objects selected are displayed below each other in the result. That means that precisely one object is represented in the result with each line. In this case, the properties selected in the column selection therefore always refer to the corresponding object of the line. In the example above, the identification of the main component would be displayed in a column with the identification, followed by the identification of the connectors in the lines below.

In *Next to each other* output mode, the main objects are displayed with their sub-objects together in one line, as described above. The number of sub-objects determines the number of result lines. In this case, the properties selected in the column selection refer to the selected sub-objects. In the example above, that means that only the identification of the corresponding connectors is displayed in succession a column with the identification. In the example above, this is the third column with the heading: *Connector*.

If you want to access the properties of a main object in an output line in *Next to each other* output mode, what is called a level selector must be inserted in front of the variable. It has the following syntax:

Level selector	level
e[0].	Topmost level of the object selection
e[1].	First sub-level of the object selection
e[2].	Second sub-level of the object selection
e[3].	Third sub-level of the object selection

In the example above, the level selector e[0] was used for the second column with the *Component* heading to display the identification of the main component. Therefore in the column select, for the *Component* column “e[0].designation” is entered as the content whereas for the third *Connector* column, only “designation” is entered.

Selected columns

ID	Column heading	Contents
1	Pos. No.	row-id
2	Component	e[0].designation
3	Connector	designation

Figure 17/16: Example of the use of the level selector

Filter criteria

The selected object classes can be limited to specific objects using a separate filter. It is thus e.g. possible to only have those components of a specific supplier displayed or whose identification starts with a specific letter.

To configure or adapt the filter criteria for an object class, highlight them in the list of the selected objects. An additional group then appears with input fields for the filter criteria. The input fields in this group always only apply to the currently selected object class from the view of the objects to be listed. A separate filter can thus be set individually for every class.

A filter consists of one or more filter criteria that are listed in individual lines. Every filter criterion consists of the following elements:

ID

An automatically assigned consecutive number for the filter criterion. This ID is used later on in the filter logic for the identification of a filter criterion.

Property

A specific property or an attribute by which the object selection is to be limited. The properties of the corresponding object class are available here. The available attributes are determined from the current project. That means that e.g. for the *Main Component* object class, all attributes are available here that are currently used in the components of the project.

1. OP

Defines the first operator for this filter criterion. The following operators are available:

Operator	meaning
=	Is equal to
⟷	Unequal
{ }	Is empty

!{ }	Is not empty
[*]	Contains
[!*]	Does not contain
>	Greater than
>=	Same or greater than
<	Smaller than
<=	Same or smaller than

1. Value	The value for the application with the first operator.
2. OP	To define a value range, a second operator can be defined here. The first and second operators are always linked logically with AND.
2. Value	The value for the application with the second operator.
Comparison method	Controls how the comparison operators such as greater than or smaller than are applied. This is especially important for properties that include both letters and numbers.
Quick filter	If this ID is set, the filter criterion is provided in the properties dialog on the object selection tab as a quick filter. The filter criterion value can thus be adapted quickly and directly in the properties of the report and does not need to be changed in the details of the report.
Lock operators	Disables the operators against changes in the quick filter in the properties dialog. Only the value for the filter criterion can then be changed in the properties dialog, not the operator.
Display name	Defines a display name for the selected property in the quick filter.
Filter logic	
	If more than one filter criterion is specified, by selecting the filter logic you can define how the individual criteria are to be linked to each other. The following selection is available here:
AND conjunction	All criteria must be met in order that an object appears in the report.

OR disjunction

At least one criterion must be met in order that an object appears in the report.

User Defined

The individual criteria are linked to each other by a user-defined logic. It can be entered in the input field to the right of the selection. The individual criteria are addressed via their corresponding ID number. AND and OR are available as the operators. Partial expressions can be inserted in round brackets. The following filter logic is thus e.g. possible: *1 AND (2 OR 3)*

The filter logic is checked directly while it is entered and if there are errors a note is displayed directly in the input field. As soon as the entered filter logic is valid, it can be applied using the Apply button and saved.

17.5.2 Column selection

The column selection is used to define which properties or attributes of the selected objects are to be output in which column of the report. That defines the basic structure of the report result as the report result always has as many columns in the position lines as selected here and that have the Show ID.




Figure 17/17: Details of a report: *Column selection* tab

Selected columns

The main element of the column selection is the table of selected columns. All columns taken into account in the report are listed here with the following data:

ID

Consecutive numbering of the column. Is used as the index for addressing the column headings.

Column heading

Freely selectable column heading for the corresponding column.

Contents

The contents of the column. This is explained in more detail below.

Display

Defines whether the column is displayed in the report result or not. A hidden column can still be used for sorting and/or for grouping.

Function

The column is only displayed in the table if the *Group* option is selected. Defines the grouping function for the corresponding column of the report.

Available columns

The list of available columns is to be found on the left side of the tab. All those properties and attributes are listed there that are not included yet in the report. This is controlled using the *Hide already*

used columns option below the list. Deselect this option if you also want to view the properties already used in the list.

The list of available properties contains all properties and attributes of the objects from the current project. That means only those attributes are available here that are also used in the objects of the current project.

Adapting the selected columns

You can add new columns of the report using the buttons between the list with the available columns and the selected columns or delete columns. Alternatively, you can use the **Add** button to create a new empty column at the end of the list of columns and use the **Remove** button to delete the currently selected column.

You can also transfer new columns from the list of available columns via drag and drop to the list of the selected columns. This has the benefit that you can define directly at which position the new column is to be inserted.

You can use the two buttons to the right of the list of the selected columns to change the order of the columns.

Contents of a column

Normally only one placeholder is specified in the *Contents* field of an individual column for a property of the objects to be listed. This can e.g. be the part-number placeholder for the part numbers of components.

In addition, a fixed text can be entered in quotation marks if it is also to be displayed in every line of the result. For example, by entering "T:" part-number in the result, the fixed text "T:" can precede every part number. The quotation marks can be omitted if the fixed text does not contain any letters or numbers. That means individual separators, such as blanks, colons etc. can also be entered without quotation marks.

In this field it is still also permitted to specify several placeholders for properties. The corresponding placeholder is replaced in the resulting list with the value of the property. It is thus possible e.g. to display several properties together in one column. For example, you could enter part-number:attribute[*Supplier*] to display the part number and the supplier together in a column, separated by a colon.

If no value is specified for the property of the placeholder used or if this property does not exist in the listed object, the placeholder is replaced by an empty string.

Sorting

Every report can be sorted by one or more selected columns. The sort order is set using a separate dialog that can be accessed using the **Sorting** button.




Figure 17/18: Dialog for sorting a report by specific columns.

You can use the buttons above the sort criteria to add more sort criteria, delete/copy existing criteria or change their order. The columns of the sort criteria have the following contents:

Column

Selection of the column by which sorting is carried out.

Order

A..Z: ascending order; Z..A: descending order

Mode

Default (natural)
Natural sort order of the values. (A1 < A2 < A11)
Alphabetical
Lexographic sort order of the values. (A1 < A11 < A2)
Numeric
An attempt is made to interpret the contents of the column as a number and to sort according to this number.

Grouping

Instead of specifying each individual object in the result of the report, the result can also be summarized. To do this, select the “*Group*” option at the top right of the tab. After selecting the option, the additional “Function” column appears in the table of the selected columns. The grouping function can be selected for every col-

umn in this new column. The following grouping functions are available:

Group	Defines the column as a criterion by which its values are to be grouped.
List	Connects the grouped individual values to form a list separated by commas.
Sum	Calculates the sum of the grouped individual values.
Minimum	Calculates the minimum of the grouped individual values.
Maximum	Calculates the maximum of the grouped individual values.
Count	Determines the number of grouped individual values.

An example of the grouped report is the standard template of the accumulated parts list.

17.5.3 Appearance

The table view of the report in the project can be set in a similar manner to the object selection in the properties dialog and also in the details of the report. The options in the properties dialog are more limited than in the details of the report. The drawing properties can only be edited in the properties dialog.




Figure 17/19: Properties of a report: *Appearance* tab

In the properties dialog, you can define the following settings on the *Appearance* tab:

- Font size**

Adaptation of the font height in percent of the font used in the report. The size of the table is not changed by this adjustment.
- Additional Line Spacing**

Increases the height of all lines by the specified percentage factor. (50% means that every line is displayed with 1.5 times the height.) That does not change the font height.
- Additional Cell Spacing**

Increases the width of all columns by the specified percentage factor. (50% means that every column is displayed with 1.5 times the width.)
- Lines per Page**

You can also use this option to define how many lines of the report result are to be displayed on each page. If this option is selected and a value greater than 0 is entered, the report result is displayed distributed among several pages. The specified number of lines refers to the result lines below the header lines of the report. The header of the report is repeated on every page.




Figure 17/20: Properties of a report: *Drawing Properties* tab

In the properties dialog, you can define the following settings on the *Drawing properties* tab:

Anchor Position

The result of a report is created dynamically from the current data of the project and is updated accordingly on a continuous basis. That may change the size of the report on the page. You can use this option to define which corner of the report is to have a fixed position on the page. If the report is updated, this point remains fixed and the report only grows in the other direction.

Scale Factor

Defines the scaling of the report in the horizontal and vertical directions.

Rotation

Defines the rotation angle for rotating the table.

You can use the Reset button to reset all values on this tab to the default settings.




Figure 17/21: Details of a report: *Appearance* tab

The basic table template for the table view of the report can be adjusted in detail on the Appearance tab in the details of a report.

The table template is displayed in the center of this tab. It is split up into header lines and a single position line. The header lines and the position line are displayed in the table template with a small space between them to emphasize the difference between the header part and the position part. No space is displayed between the header and position lines at this point in the finished report on the page. There is also a note in the dialog to the right of the header lines that informs you which lines belong to the header lines.

The table template defines the basic structure for the output of the report in the project. The specified header lines are output once in the header of the report and the position line is duplicated according to the number of lines in the result. Therefore, the position line is only displayed once here in the view of the template. Afterwards, in the result of the report, it is naturally displayed several times, if applicable. Unlike on the Appearance tab in the properties dialog, this view is not a preview of the result of the report, it only represents the structure.

The number of header lines of a report is generally not limited and a report without header lines is also possible. There is always only precisely one position line, by contrast.

The number of columns of the table template matches the number of selected columns with *DisplayID* on the column selection tab. The variables/placeholders of the corresponding column in the column selection are entered in the position line, in the respective column. In addition to the column selection, the contents can also be adapted here. The available properties of the selected objects are provided in the *Variables* list on the left side of the tab for this purpose. They can be assigned to the corresponding cells of the table template e.g. using drag and drop.

Variables can also be used in the headers of a report in addition to fixed texts. To use the column heading defined in the column selection there is the fixed column[x] variable. The ID of the corresponding column must be entered instead of the x. This variable is replaced by the corresponding column heading when the report is created.

Like in the position lines, properties of the selected objects can also be output in the header lines. For this, the same variable can be used that was specified in the position line. When you create the report, the first object is applied to replace this property.

Like in the position line, fixed texts and variables can be combined in the header lines. However, unlike in the position lines it is not necessary to insert a fixed text explicitly in quotation marks in the header lines and if a variable could not be replaced it is retained in the form of text.

Each cell of the template can be given a specific formatting using the toolbar above the table. This works here like the formatting of cells of the table drawing element or the header of a drawing frame. The formatting options are described in more detail in these chapters.

In addition to the toolbar above the table, the background color can be set below the table for various lines of the report. Select here for which lines you want to save a specific background color. Changes concerning the position line, such as a background color for uneven lines are only visible in the project.

Functional diagram

Chapter 18

You can find the function diagram in the FluidDraw standard library. You can apply the functions in the [Edit](#) menu to the function diagram. Double-click the function diagram, or use the [Home](#) page and the [Properties...](#) menu item to open the *Functional diagram*.

The *Functional diagram* can be used to draw a function diagram with signal lines, signals and diagram lines. The lines of the function diagram consist of two parts: the table text boxes on the left and the diagram area on the right. The table text boxes may consist of several columns and an adjustable grid can be applied to the diagram area. The grid represents the different states of the diagram in rows and the time sections in columns.




Figure 18/1: Functional diagram

18.1 Edit modes

The *Functional diagram* provides various edit modes that are selected via the toolbar at the top of the editor. The edit modes and their operation are shown briefly below.

You can always use the **Esc** key to switch back from every mode into *Edit Mode*. The current selection is cancelled with the right mouse button. That can be particularly helpful e.g. for drawing signal lines (see [Draw signal lines and insert signal connections](#)).

18.1.1 Edit Mode



In *Edit Mode*, the objects can be adapted within the function diagram. Objects can be moved and the size of free text boxes and table text boxes can be changed.

To move an object, click it with the left mouse button and keep it pressed. If you move the mouse, a preview of the new position of the object is displayed. The object is moved to the new position when you let go of the left mouse button.


To change the size of a text box, move the mouse pointer to the edge (or to the corner if it is a free text box) until the cursor is converted into the “change size” cursor. With a left-click and by keeping the mouse button pressed, you can now adapt the size of the text box. If a text box is reduced in size to the extent that the text no longer fits in it, the font size is reduced. However, if the size of the text box is increased, that will also increase the font size up to the previously selected font size.

All moving and dragging operations can be cancelled using the **Esc** key. As already mentioned, the current selection can be cancelled by a click with the right mouse button. **Undo** and **Redo** can be used to undo and redo operations.

Properties of objects can be changed in *Edit Mode* by double-clicking the object. That opens the properties dialog window for the object.

Selected objects (apart from diagram columns and table text boxes) can be deleted by pressing the **Del** key.

In addition, in *Edit Mode*, you can copy texts between the table text boxes by clicking a table text box while keeping the left mouse button pressed. The text of the box is displayed at the mouse pointer and if you let go of the left mouse button over another table text box it is copied there. If you keep the **Shift** key pressed when you let go of the left mouse button, the text is moved and removed from the original text box.




18.1.2 Drawing a diagram curve



The diagram lines can be drawn in this mode. A vertex is created on the grid of the diagram column with each left-click. The points are automatically connected.

Keeping the left mouse button pressed, you can move existing vertices like in *Edit Mode*. Marked vertices are shown in grey. The **Del** key is used to delete a selected vertex.

Should the automatic connection of points in diagram line mode not result in the desired diagram, points can be exchanged by dragging one point to the other. For this, the points must be below each other vertically (in the same step). The points are exchanged and the automatic connection is created.



It is also possible to create a “peak” within a step. Set a point in the diagram and set another point within the same step (vertically below each other). Then set a point at the starting point. That results in a vertical deflection.

18.1.3 Insert text boxes



Text boxes can be inserted with a left-click in this mode. Free text boxes can be created above the table text boxes, in the diagram column and also below and to the right of the diagram. When you create a text box, the text box dialog opens, in which the text and the font can be set. The text box is adapted to the text entered when the dialog is confirmed.

In “*Edit Mode*”, you can change the size and the position of a text box with the mouse pointer.

18.1.4 Insert signal elements



In this mode, signal lines can be inserted in the diagram columns with a left-click. If you select the *Insert signal elements* button with a simple left-click, after adding a new signaling element, the mode switches back to *Edit Mode*. If you select the mode with a double-click, you can add several signaling elements in succession.

The signaling elements are aligned with the grid of the diagram column by default. If the signaling element is to be positioned freely, you can keep the **Alt** key pressed during positioning, which prevents any alignment with the grid.

Keeping the left mouse button pressed, you can move signaling elements like in *Edit Mode*.

18.1.5 Draw signal lines and insert signal connections



In this mode, signal lines can be freely created and automatically inserted between diagram vertices or from signaling elements.

Creating signal lines freely

Vertices are added to the current line with a left-click. If no line is selected, the first click creates a single vertex and the second click creates a line to the second vertex. All other vertices are immediately added to the selected line, as shown in the preview. You can press the **F5** key to exit the mode completely and switch back to *Edit Mode*.

To start a new signal line, you can cancel the current selection with a right-click and start a new signal line with a left-click.

An existing line can be continued by clicking once with the right mouse button (cancel selection) and then left-clicking to select the starting point / end point of an existing signal line. It is marked and the line can be continued.

Individual vertices that do not belong to any signal line are deleted when signal line mode is exited.


If you keep the **Shift** key pressed when setting a vertex, the new point is aligned vertically or horizontally to the currently selected vertex. To do this, the mouse pointer must be moved roughly to the same height above / below or next to the starting point.

You can insert another vertex within an existing signal line by keeping the **Ctrl** key pressed while you click the desired point on the line with the left mouse button.

Creating signal lines from signaling elements

Every signaling element has a connecting point for signal lines. Starting at this point, signal lines can be automatically drawn to a grid point. The editor creates a signal line with vertices and arrow head.

To create a signal line this way, you must first right-click the selection to cancel it. Then, move the mouse pointer over a the connecting point of the signaling element until the cursor is converted into a connecting cursor. If you now click with the left mouse button and keep it pressed, a preview of the new signal line is displayed, which can be moved to the desired grid point. The new signal line is created when you let go of the left mouse button.




Creating signal lines between diagram vertices

Signal lines can be created between vertices of the diagram lines with support. After cancelling the selection (right-click with the mouse), the cursor is moved over a vertex of the diagram line until it changes and becomes a connecting cursor. If you now click with the left mouse button, keep it pressed and move the mouse pointer over another diagram line vertex, a preview of the new signal line is

displayed. The new signal line is created when you let go of the left mouse button.

The signal line is created, as shown in the preview, with vertices and is given an arrow head.



Creating signal links

Signal lines can be connected using signal links. If you move the mouse pointer over a signal line, the mouse pointer is converted into a connecting cursor. If the selection was previously empty, left-click the signal line to create a signal link. It is used as the starting point for the linked signal line. An existing signal line can also be

ended with a signal link if the last point ends on a signal line, as described.

Signal links can be moved on the signal line in *Edit Mode* and, unlike vertices, they cannot be positioned freely.


Signal links are displayed as logical AND links by default (filled, large circle). In the signal link properties dialog, the representation can also be converted to a logical OR link.



18.1.6 “Format” mode



With “Format” mode, properties of a text box can be copied and transferred simply to other text boxes. If “Format” mode is activated, the [corresponding dialog](#) opens immediately in which all properties of a text box (apart from the size) can be selected. If a text box is already selected when the mode is activated, the values of the selected text box are applied. They can be subsequently changed. If no text box is selected, the last settings are used.

After confirming the dialog, the cursor changes to the “Format” cursor. Left-click a text box (free text box or table text box) to transfer all properties. The mode can be exited at any time by pressing the **Esc** key.





For a new function diagram, you can use the “Format” dialog at the start to define how all newly created text boxes are to be formatted by selecting the “*Use as default*” option. This has no effect on text boxes already in the diagram.

18.2 Properties dialogs

The properties dialogs of the various objects are listed in the following sections and the individual options are explained. The properties dialogs can be accessed by double-clicking an object with the left mouse button. Only the general diagram properties of the complete function diagram can be accessed using the [Properties...](#) button.

18.2.1 Diagram properties dialog

Click the **Properties...** button to open the diagram properties dialog that includes basic settings for the function diagram (e.g. the number and size of the table text boxes).




Figure 18/2: *Functional diagram*: properties

Text columns – Number	Defines the number of table text boxes. If the number is changed, all table text boxes are adapted to a standard size.
Text columns – Width	Defines the width of the individual table text box. If the width is changed, all table text boxes are set to the selected width.
Diagram columns – Number	Defines how many grid columns the diagram column is to have. The number of grid columns in the diagram column can also be changed by pulling the right edge of the diagram.
Diagram columns – Width	Defines how large the space is to be between the grid columns.
Color	Opens the color dialog that enables the color to be selected in which the grid lines are drawn in the diagram columns.
Row height	Defines the height of a row. Unlike the width of the individual table text boxes that can be subsequently adapted, all rows have the same height. The height of the rows can also be adapted by pulling the lower edge of the diagram.

18.2.2 Text box properties dialog

Double-click a text box to open the text box properties dialog, in which the font and the alignment can be set.




Figure 18/3: Text box: properties

Font...	Opens the font dialog that you can use to set the font and font size. The function diagram editor also supports text in bold, italics, crossed out and underlined.
Color	Opens the color dialog that enables the font color to be selected.
Frame	For free text boxes only: specifies whether a frame is to be drawn around the text box. If no frame is drawn, the text box is displayed on a transparent background. If this option is selected, the text box is given a white background.
Width	Defines the width of the current text box. If the size is changed the current text is reduced in size if it is too long. If it is a table text box, the size of the complete table column is adapted. Unlike when

changing the width of a table text box with the mouse, with this option the cell is increased / reduced in size without changing the size of adjacent text boxes.

Height	Defines the height of the current text box. If the size is changed the current text is reduced in size if it is too high. If it is a table text box, the height of all lines is adapted.
Horizontal adjustment	Specifies the horizontal alignment of the text within the text box.
Vertical adjustment	Specifies the vertical alignment of the text within the text box.
Negate text	Negates the text in the text box. Like in mathematics, a line is drawn over the actual text for this.
Using a text box as a table	To format the contents of a text box like a table, you can use tabulators. They are inserted by keeping the Ctrl key pressed while pressing the Tab key. Each line can thus be split up into cells of equal size that are arranged according to the alignment. Each text box line can have a different number of cells. The arrangement of text within the cell is thus highly flexible.

18.2.3 Diagram columns properties dialog

Double-click a diagram column to open the diagram columns properties dialog, in which the numbering, the grid and the representation of the column can be adapted.




Figure 18/4: Diagram columns: properties

States – Number	Specifies the number of states, thus defining the number of horizontal lines of the diagram column.
States – Base state	Defines the basic state of the diagram column. Diagram curves that are drawn between two points in the basic state are displayed with a thinner line.
Numbering – Number	Specifies how many steps are to be numbered. 0 must be entered if numbering is not to be carried out.
Numbering – Start column	Defines the column at which numbering is to be started.
Numbering – Start number	Defines the number with which numbering is to be started.
Numbering – Step width	Defines the increment between two numbers. With an increment of 2 and a start number of 1, numbering would be 1, 3, 5, 7, etc.
Numbering – Loop	Specifies whether the numbering is to represent a loop. If this option is selected, an equality sign and the start number are also

displayed after the last number. For 3 numbered steps with a start number of 1 and an increment of 1, numbering would be 1, 2, 3=1.

Representation – Display arrows

Specifies whether two arrows are to be displayed in the top left corner of the diagram column that point to the right and downwards.

Representation – Display grid

Specifies whether the grid of the diagram column is to be displayed.

Representation – Display text 1

Defines whether a text box is to be displayed. The text box is displayed to the right of the horizontal arrow if the *Display arrows* option is selected. The text box is linked to this diagram column and cannot be moved to any other line.

Representation – Display text 2

Defines whether a text box is to be displayed. The text box is displayed to the right of the vertical arrow if the *Display arrows* option is selected. The text box is linked to this diagram column and cannot be moved to any other line.

Representation – Line color

Opens the color dialog that enables the color of the diagram lines to be selected.

18.2.4 Signaling element properties dialog

Double-click a signaling element to open the properties dialog for signaling elements, in which the representation of the signal can be selected.




Figure 18/5: Signaling element: properties

Signal type	Specifies how the signaling element is to be displayed.
Display description	Defines whether a text box is to be displayed for labelling the signaling element. The text box can be moved freely. However, it is linked to the signal. When moving the signal, the text box is moved along with it.
Color	Opens the color dialog that enables the color of the signaling element to be selected.

18.2.5 Signal lines properties dialog

Double-click a signal line to open the signal lines properties dialog, in which the color and the display options of the signal line can be set.




Figure 18/6: Signal lines: properties

Display description	Inserts a text box that can be moved on the signal line.
Display additional description	Inserts a text box that can be used to add an additional description. The text box can be positioned freely. However, it is linked to the description on the signal line. If the text box is moved on the signal line the additional description is moved along with it.
Start with arrow	An arrow head is displayed at the start of the line. The arrow head can be moved freely on the line.
End with arrow	An arrow head is displayed at the end of the line. The arrow head can be moved freely on the line.
Color	Opens the color dialog that enables the color of the signal line to be selected.

18.2.6 Signal link properties dialog

Double-click a signal link to open the signal link properties dialog, in which the representation of the signal link can be selected.




Figure 18/7: Signal link: properties

Representation

Specifies how the signal link is displayed.

18.2.7 “Format” dialog

Click the “Format” button to open the “Transfer format” dialog, in which the settings can be selected that can then be transferred to other text boxes.




Figure 18/8: Transferring the format

Font...	Opens the font dialog that you can use to set the font and font size. The function diagram editor also supports text in bold, italics, crossed out and underlined.
Color	Opens the color dialog that enables the font color to be selected.
Frame	For free text boxes only: specifies whether a frame is to be drawn around the text box. If no frame is drawn, the text box is displayed on a transparent background. If this option is selected, the text box is given a white background.
Horizontal adjustment	Specifies the horizontal alignment of the text within the text box.
Vertical adjustment	Specifies the vertical alignment of the text within the text box.
Negate text	Negates the text in the text box. Like in mathematics, a line is drawn over the actual text for this.
Use as default	Specifies whether the selected settings are to be applied as the default settings to all new text boxes.

18.3 Rows

The number of rows and their position in the function diagram can be subsequently changed. Therefore, in addition to adding and deleting rows, it is also possible to copy rows with their complete contents or move them in the diagram.

18.3.1 Add row



Click the *Add row* button to add a new, empty row at the end of the function diagram. The table text boxes are created with the default settings (see [Defining default settings](#)).

18.3.2 Insert row



Click the *Insert row* button to add a new, empty row in front of the selected row. If an object is selected that is in a line, the new line is inserted above the assigned line.

18.3.3 Copy row

It is possible to copy lines in the function diagram. As the diagram lines and texts of the table text boxes are frequently similar or identical, the copy function saves a great deal of manual work.



Click the *Copy row* button to copy the currently selected line and insert it under the selected line. If an object is selected that is in a line, the assigned line is copied.

When copying, the contents and settings of the table text boxes and the diagram column, the diagram lines and the signaling elements are copied. Free text boxes and signal lines are not copied.

18.3.4 Moving rows

Rows in the function diagram can be subsequently moved. That enables a flexible arrangement of existing rows without having to delete rows.



Click the “*Move row up*” and “*Move row down*” buttons to move the currently selected row up / down. If an object is selected, the corresponding row is moved. All objects of the row are also moved, apart from free text boxes. As vertices of signal lines are also affected, moving a row can result in changes in the signal lines.

18.3.5 Delete row



Click the “*Delete row*” button to delete a highlighted diagram row. If an object is selected that is in a row, the assigned row is deleted.

18.4 Scrolling and zooming in and out

The mouse wheel can be used to scroll the view vertically (if scroll bars are displayed). If you keep the **Shift** key pressed, you can use the mouse wheel to scroll horizontally.



Click the “**Zoom In**” and “**Zoom Out**” buttons to increase / reduce the size of the view. If you keep the **Ctrl** key pressed, you can also use the mouse wheel to change the zoom factor.



The “**Standard Size**” button can be used to restore the default zoom factor.



The “**Fit to Window**” button is used to automatically select the zoom factor so that the complete function diagram is displayed in maximum size.

Special functions for electric circuits

Chapter 19

19.1 Potentials and conduction lines

The creation of horizontal and vertical potential lines is supported by drawing [conduction lines](#). The end points of the conduction line consist of [potentials](#) that also serve as interruptions. In the dialog window for drawing conduction lines you can specify whether the potentials should have an identification.

In this following, three horizontal potential lines are to be drawn where each line comes from a preceding page “1” and is to be continued on a page “3”.

To open a dialog window where you can make the settings displayed, press the [Conduction Line...](#) button in the [Link](#) group on the [Insert](#) ribbon page.




Figure 19/1: Settings for the potential lines to be created

You can then define the end points of the line with two consecutive mouse clicks.




Figure 19/2: Three horizontal potential lines

The identifications of the potentials can be changed. In this example we want to rename the potential from L4 to L6.

- ➞ Double-click the left-hand potential L1. Then enter L4 for the identification in the dialog window.

Then, the following prompt opens.




Figure 19/3:

FluidDraw supports the automatic renaming of the potentials linked with the source potential. If you answer “Yes”, the potential L1 on the right-hand side is also renamed as L4.

➔ Rename the potentials L2 and L3 to L5 and L6 in the same way.

➔ Then enter the corresponding labels for the predecessors or successors in the properties dialog windows for the potentials. If the corresponding cross-references have the same labels in the respective predecessor and successor pages, the potential lines might look like as follows.




Figure 19/4: Three horizontal potential lines with cross-references

19.2 Cables and wiring

Cables and wiring are represented in the circuit diagram by a special cable symbol. All lines defined by the cable symbol are assigned to a cable or to wiring. You can define for the symbol whether it is a cable or wiring.

A wiring only summarizes the defined lines (wires) graphically in the circuit diagram and is assigned the identification “W” by default. Wiring is not listed in reports such as cable maps and cable lists. Unlike a cable, wiring cannot be assigned to a product. With wiring, product information can only be saved in the lines.

If the cable symbol represents a cable then a cable object must be assigned to the symbol. Product properties can be saved in the cable object and are analyzed in cable maps and cable lists, etc. Several cable symbols can refer to same cable object. This is the case if, for example, a cable has to be spread over several pages.




Figure 19/5: Cable symbol

→ To define a cable or a wiring select the **Cable** button in the **Electrics** group on the **Insert** ribbon page.

This activates a mode that allows you to insert a cable symbol by making two consecutive clicks. All lines that are below the cable symbol are initially assigned to a wiring.

If you want to use a cable instead of a wiring you can assign a cable object to the symbol using the properties dialog window for the cable symbol.




Figure 19/6: *Cable Symbol* dialog window, *Wires* tab

Layer

Defines the drawing layer for the cable symbol.

Cable – Wiring

Defines whether the cable symbol represents a cable or wiring comprising single wires. Any wiring is not listed in cable maps, etc. If *Wiring* is selected then an identification can be specified that can be displayed with *Display Identification*.

If *Cable* is selected then an existing cable object can be assigned to the cable symbol using a drop-down list. A new cable object can be created using the **Create New...** button. Clicking **Properties...** opens the properties dialog window for the selected cable object.

Wires

In order to analyze cable maps the component connectors that join a wire must be determined. The connectors are automatically entered in the list box if they can be uniquely assigned. If a unique assignment is not possible, the relevant connector must be select-

ed manually via the list box. The identification of the individual wires can also be entered. These are saved in the individual lines (wires). The wire identifications are displayed at the cable symbol using the *Display* button.

Reverse Direction

The entries in the *From* and *To* columns are automatically defined as the direction of the wires when creating the cable symbol. Clicking the **Reverse Direction** button reverses the directions of all wires.

Renumber From:

Clicking this button rennumbers all wires defined by the cable symbol, starting with the number entered in the list box.




Figure 19/7: *Cable Symbol* dialog window, *Display Attributes* tab

On the “*Display Attributes*” tab you can select the attributes of the associated cable object that are to be displayed at the cable symbol.

→ Click the **Create New...** button to create a new cable symbol.

The following dialog window opens.




Figure 19/8: *New Cable* dialog window

Identification

Enter the identification for the cable here.

Number of Wires

Enter the number of lines (wires) in the cable here. The number can be higher than the lines below if, for example, a concrete cable has unconnected wires. If the associated cable symbols covers more lines than are defined in the cable object, a warning is output when the page is checked and the corresponding entries are highlighted in color in the cable lists.

After you specify the identification for the cable and confirm the dialog, the cable object is created and the cable symbol is assigned to it.

→ Click the **Properties...** button to edit the properties of the cable object.




Figure 19/9: *Properties* dialog window: *Cable* tab

Number of Wires

Defines the number of lines (wires) in the cable. The number can be higher than the lines covered by the associated cable symbols if, for example, a concrete cable has unconnected wires. If the associated cable symbols covers more lines than are defined in the cable object, a warning is output when the page is checked and the corresponding entries are highlighted in color in the cable lists.

The associated cable symbols are listed in rows in the table. You can jump to the associated cable symbol using the “Find...” button. The *User Defined Properties* tab in the properties dialog window for the cable symbol lists the cable-specific product properties such as *Cable Type* and *Length*. These properties and the entries in the *Cable* tab are analyzed in the cable map, etc.

19.2.1 Managing cables

All cables within a project can be listed and renamed using the [Manage Cables...](#) button in the [Manage](#) group of the [Project](#) ribbon page. You open the [Properties...](#) properties dialog window for the relevant cable object using the button.



In older versions of FluidDraw it was possible to assign a cable to a specific page. That sometimes caused confusion; all cables therefore now become *global objects* that belong directly to the project and not to an individual page any more.

For existing circuits created with a previous version of FluidDraw, you can still access all cables belonging to the page via the [Manage Cables...](#) menu item under [Page](#).




Figure 19/10: **Manage Cables...** dialog window

You can add a new cable object to the project using the **Create New...** button.

After pressing the **Create New...** button for confirmation, a dialog opens where you can define the name and number of wires for the new cable object. The dialog window is described under [Cables and wiring](#).

19.2.2 Inserting a cable map

You can insert an associated cable map for a cable into the circuit diagram. You do this by inserting a cable map into a circuit diagram and then assigning a cable to this diagram.

→ To insert a cable map in the circuit diagram, press the *Report* button in the **List** group on the **Insert** ribbon page.

The mouse pointer changes to a crosshair. Click the position in the circuit diagram where you want to insert the cable map.

A dialog window then opens where you can assign the relevant cable and customize the appearance.

19.2.3 Inserting a cable list

You can insert a cable list into a circuit diagram.

→ To insert a cable list in the circuit diagram, press the *Report* button in the **List** group on the **Insert** ribbon page.

The mouse pointer changes to a crosshair. Click the position in the circuit diagram where you want to insert the cable list.

A dialog window then opens where you can select the associated cables and customize the appearance.

19.3 Terminals and terminal strips

19.3.1 Setting terminals

You can set individual terminals or multiple terminals in one step.

→ To define an individual electric terminal select the **Terminal** button in the **Electrics** group on the **Insert** ribbon page.

This activates a mode that allows you to insert a terminal by clicking a free point on the electric line.




Figure 19/11: Inserting a terminal

As soon as you have set a new terminal this way the dialog window containing the settings for this terminal appears. You can use this dialog window to assign the terminal to a terminal strip. This assignment can also be made or changed later.









Figure 19/12: *Terminal* dialog window

Description	Contains the description of the terminal or the terminal designation.
Display	If this box is given a check mark then the description entered is displayed next to the terminal.
Layer	Defines the drawing layer for the terminal.
Pos.	Defines the position of the terminal within the associated terminal strip . An entry is only possible once the terminal has been assigned to a terminal strip .
Level	Defines the level of the terminal.
Display	If this box is given a check mark then the terminal's level is displayed next to the terminal.
Internal # External	Changes the direction of the terminal. The direction is indicated in the circuit by an arrow that shows which connector is inside the control cabinet and which is outside. The arrow head points at the control cabinet.

Show Direction	If this box is given a check mark then the direction arrow is displayed at the terminal.
Terminal Strip	Defines the terminal strip containing the terminal in question. The list contains the terminal strips already created. You open the properties dialog window for the selected terminal strip using  . You can also create a new terminal strip using  .
Display Identification	If this box is given a check mark then the identification for the associated terminal strip is displayed next to the terminal.

19.3.2 Setting multiple terminals

As well as the option of setting individual terminals, FluidDraw also offers a mode that allows you to set multiple terminals one after the other. You can keep inserting terminals by simply clicking the electric lines until you exit the mode again.

→ To do this, click the  button in the  group on the  ribbon page.




Figure 19/13: Setting multiple terminals

The operation begins with a dialog window where you can make some settings for the new terminals. Above all you need to first select an existing [terminal strip](#) or create a new one. If a suitable [terminal strip](#) does not already exist then a prompt for creating a new one automatically appears.




Figure 19/14: *Define Multiple Terminals* dialog window

Description

Defines how the new terminals are to be numbered. The *Enumerate Manually* option allows you to specify a start number at which numbering continues. Otherwise a free terminal from the selected [terminal strip](#) is automatically used. The start number “2” was specified in the example shown.

Display

If this box is given a check mark then the description entered is displayed next to the terminal.

Direction

Defines the direction of the new terminals. The direction is indicated in the circuit by an arrow that shows which connector is inside the control cabinet and which is outside. The arrow head points at the control cabinet. The direction can also be changed later using the properties dialog window for the individual terminals.

Layer

Defines the drawing layer for the line.

Terminal Strip

Defines the [terminal strip](#) containing the terminals in question. The list contains the [terminal strips](#) already created. You open the properties dialog window for the selected [terminal strip](#) using [Properties...](#). You can also create a new terminal strip using [Create New...](#).

Display Identification

If this box is checked then the identification for the associated [terminal strip](#) is displayed next to the new terminals.

19.3.3 Creating terminal strips

FluidDraw does not treat terminal strips as visible objects within the circuit pages which explains why they cannot be interactively selected using the mouse in order to highlight them, delete them or change their properties. Terminal strips can either be managed via the associated [terminals](#) or using the [Manage Terminal Strips...](#) menu item under [Page](#) or [Project](#).




Figure 19/15: *New Terminal Strip* dialog window

All properties can also be changed later at any time. You open the properties dialog window for a terminal strip via any [terminal](#) in that terminal strip using the [Properties...](#) button.




Figure 19/16: *Terminal Strip* dialog window

External Target

If the destination of a terminal *inside* the control cabinet is unambiguous due to the wiring, FluidDraw automatically enters the identification for the connected component. Otherwise the list contains the identifications of all objects that can be reached from the terminal. The destination search can be controlled by selecting a [junction symbol as a T-distributor](#).

Internal Target

The destinations of the terminals *outside* the control cabinet are listed here. As with the internal destinations, unique links are automatically entered.

Find...

Jumps to the associated terminal in the circuit diagram.

19.3.4 Managing terminal strips

All terminal strips within a project can be listed and renamed using the [Manage Terminal Strips...](#) menu item from the [Project](#) menu. You open the [Properties...](#) [properties dialog window](#) for the relevant terminal strip using the button.



In older versions of FluidDraw it was possible to assign a terminal strip to a specific page. That sometimes caused confusion; all terminal strips therefore now become *global objects* that belong directly to the project and not to an individual page any more. For existing circuits created with a previous version of FluidDraw, you can still access all terminal strips belonging to the page via the [Manage Terminal Strips...](#) menu item under [Page](#).




Figure 19/17: [Manage Terminal Strips...](#) dialog window

You can add a new terminal strip to the project using the [Create New...](#) button.

A new dialog opens where you can define the properties of the new terminal strip. The dialog window is described under [Creating terminal strips](#).

19.4 Terminal diagram

You can insert an associated terminal diagram for a terminal strip into the circuit diagram. You do this by inserting a corresponding report into a circuit diagram and then assigning a terminal strip to this diagram.


→ To insert a terminal diagram in the circuit diagram, press the *Report* button in the [List](#) group on the [Insert](#) ribbon page.

The mouse pointer changes to a crosshair. Click the position in the circuit diagram where you want to insert the terminal diagram.

A dialog window then opens where you can assign the relevant terminal strip and customize the appearance.

19.4.1 Setting links

You can set what are called *links* in a terminal strip. These links are drawn in the circuit diagram as regular electric lines and marked as links. The [representation of the T-distributors](#) can be customized using their properties dialog window. The following example shows a circuit diagram with a terminal strip X1 with 10 terminals and the associated terminal diagram. A link plug is to be set between terminals “7” and “8” at layer “1”, a link plug between “8” and “9” at layer “2” and a wire link between “9” and “10”.



Terminal Strip -X1			
Terminal	Links		Identification
	Link Plug	Wire Link	
1			-S1
2			-Q1
3			-K1
4			-K1
5			-K2
6			-Q1
7			-K1
8			-K2
9			-Y1
10			-Y2

Figure 19/18: Terminal diagram

→ Double-click the electric line between terminals “7” and “8”.




Figure 19/19: Setting a link

The properties dialog window for the electric line opens. The options for setting the links are in the top right:




Figure 19/20: Detail of the *Line (electric)* dialog window

Link

Defines that this line is to be treated as a link.

Link Plug

Defines that the link is a link plug.

Level

Specifies the layer if a link plug was selected.

Wire Link

Defines that the link is a wire link.

➔ Set “*Link*”, “*Link Plug*” and “*Level*3”.

FluidDraw tracks the line across one distributor point at most. This means that the specified link finds the contacts “7” and “8”. This link is represented in the terminal diagram as follows.


Terminal Strip -X1			
Terminal	Links		Identification
	Link Plug	Wire Link	
1			-S1
2			-Q1
3			-K1
4			-K1
5			-K2
6			-Q1
7			-K1
8			-K2
9			-Y1
10			-Y2

Figure 19/21: Terminal diagram with link representation

→ Proceed in the same way to set a link plug between “8” and “9” at layer “2” and a wire link between “9” and “10”.

The terminal diagram then has the following appearance.





Terminal Strip -X1			
Terminal	Links		Identification
	Link Plug	Wire Link	
1			-S1
2			-Q1
3			-K1
4			-K1
5			-K2
6			-Q1
7			-K1
8			-K2
9			-Y1
10			-Y2

Figure 19/22: Terminal diagram with link plugs and wire links

19.5 Contact image

The contact images can be displayed within a circuit diagram beneath relay coils and similar symbols. The contact images list all contacts of the associated relay coil and show which current paths these contacts are in. The division of the page or circuit diagram can be defined using the [page dividers](#).

→ To show or hide a contact image, press the **Display Contact Images** button in the *Contact image* group on the **View** ribbon page.

Contact images can be highlighted, moved and aligned like other symbols.




Figure 19/23: Contact image

You can have all contacts in a contact image displayed in a list and customize the appearance by double-clicking the contact image or highlighting the contact image and selecting the [Home](#) menu item from the [Properties...](#) menu.




Figure 19/24: *Contact Image* dialog window

You can customize the representation of the contact image on the “*Print Options*” tab.

The “*Contacts*” tab lists all associated contacts. You can jump to the corresponding contact in the circuit diagram using the **Jump to Target** button.

Chapter 20

20.1 Printing circuits and parts lists

FluidDraw projects can be printed by opening the *Print* dialog window via the **File** menu and the **Print...** menu item.




Figure 20/1: *Print* dialog window

Printer

Select the desired output device from the list of available printers.

Properties...	This button is for opening the dialog for setting the printer options.
Print to File	Select this option if you want to output the print data to a file.
Print Project Files	If you are working in a project, you can select which circuits and parts lists are to be printed.
Copies	Select the number of copies. If the printout consists of several pages, you can make FluidDraw output stacks of paper sorted accordingly.
Scale	<p>You can increase or reduce the output size by entering a scaling factor. If the dimensions of the area to be printed are larger than the printable area on the paper then the printout is spread over several pages (tiled). You can see the page divisions in the print preview.</p> <p>Note: Please note that it may not always be possible to precisely comply with the page margins. Therefore you should plan a certain amount of leeway for the page margin.</p>
Page	Here you can specify additional margins in order to manually customize the print area.
Margins	You can select which page the print preview displays.

20.2 Importing DXF files

Files stored in DXF format can be imported while retaining most element attributes. If some special features are taken into account when creating a drawing using a CAD program, you can extend the symbol library of FluidDraw without any trouble.




Figure 20/2: Dialog window, [DXF Import...](#)

Drawing Size


Defines the paper size for import. The preview is also set to this size.

Include objects on paper space

Applies the objects in DXF format in the paper area.

Include objects on model space

Applies the objects in DXF format in the model area.

Include hidden objects	Applies the objects defined in DXF format as hidden.
Scale Factor	Defines the scaling factor for import.
Fit to Paper Size	Adapts the scaling in such a way that the complete drawing fits in the paper area defined above.
	Not all DXF programs make a distinction between paper and model areas. This also depends on how the CAD drawing was created. The preview in the import dialog can be used in cases of doubt to simply test which options produce the desired result.

20.3 Exporting circuits

The FluidDraw circuits can be saved as a file with a variety of different formats. The BMP, JPG, GIF, WMF, PNG, DXF, PDF, SVG, TIF and PDF formats are available. Once you have selected the **File** menu item from the **Export...** menu a dialog window opens where you can define the different settings for export. The settings depend on the format selected.




Figure 20/3: *Export Page* dialog window

Then, you will be asked to select a file name or enter a new one.

Format

Select the desired file format.

Resolution

Defines the resolution. This setting is only available for specific image formats.



Bear in mind that a high resolution will result in very large files being created, which can make the export process take longer. You can cancel the image export at any time, however.

Color depth	Defines the color depth. This setting is only available for specific image formats.
Transparent background	Sets a transparent background. This setting is only available for specific image formats.
Print lattice	Exports the background grid set in the page.
Encode unicode characters	Displays umlauts and special characters with a special code. This option is only necessary for the DXF format.
Export cross-reference links	Exports termination points and other connected objects as links. This option is only available for the DXF format.
Override Color	Links that you click with the mouse during export can thus be displayed in the defined color. The existing links are thus easier to recognize. This option is only available for the DXF format.
Total project pages equals selection	When exporting, only the selected pages are counted and used for the predefined variable "%TotalPages. This is mainly displayed in the drawing frame as the total number of project pages.
Create overview page (PDF format only)	Use this option to create an overview page. This contains the selected project pages as thumbnails on a single page. This option is only available for the PDF format.
Drawing Layers...	Select which drawing layers you want to show or hide when exporting.
Target Size	Define the desired scaling or the absolute export size here.

Template management

Chapter 21

Templates for specific contents are managed at several points in FluidDraw. Every file contains a template. Previously, these were only drawing frames. With version 6, however, this concept has been extended to include project templates and report templates.

The templates are stored in individual files to make it easier to exchange them as well as to facilitate their joint use. These templates are managed using a standardized central dialog that can be accessed via the menu item: [\[Manage\]](#) / [\[Manage templates...\]](#).

21.1 Template management dialog




Figure 21/1: Dialog for managing templates

You can select the template type whose templates you want to organize on the left side of the dialog. The currently selected template type is always displayed on the right side.

As every template is stored in a single file, template management is primarily for the clear organization of access to these files, which may be located in very different directories on the local PC, removable data storage media or network drives. The aim is therefore to create options so that the user can manage and make these templates accessible in such a way that fast access to the template required is ensured.

The main element on the right side of the dialog for template management is a flexible folder structure similar to the project tree in the project explorer or the Windows file system. How you can adapt this folder structure to your own requirements is described in detail below.

21.2 Adjustment of the folder structure

By default, the folder structure has two directory links below the main folder for the corresponding template type. This is the reference to the default templates provided in the installation directory of the program and also the reference to the user folder of the current folder in which normally the user-defined templates are stored. The reference to the installation directory cannot be changed. The reference to the user folder can be changed, however.

→ To do this, highlight the link and click the **Edit...** button below the folder structure. You can then select another directory that is to be searched for the user's own templates.

The two default references to the default templates and to the user-defined templates cannot be deleted, but they can be hidden.

→ To do this, highlight the corresponding link in the folder structure and click the corresponding **Hide** button.

Apart from the restrictions for these two predefined folders, you can define the folder structure as desired. You can use the following basic elements to define your own structure:

Add folder...

Directory link

You can use the **Add folder...** button to add a virtual folder to the folder structure to an existing folder, e.g. from the local hard disk or a network drive. A link to this directory is then added to the structure and the directory including all sub-directories is searched for templates of the currently selected template type. All templates found in the corresponding directory are displayed in the structure below the directory link. If templates are found in sub-directories, they are also listed.

Add files...

File link

You can use the **Add files...** button to add individual or several concrete templates to a virtual folder of the structure.

New Folder...

Virtual directory

You can use the **New Folder...** button to create a virtual folder in the folder structure. Virtual folders, directory links or individual file links can be inserted in this virtual folder. These three buttons are only available if a virtual folder is selected in the folder structure. To begin with, this is only the main folder of the corresponding template type at the very top in the folder structure. The other buttons below the folder structure can be used to subsequently modify it.

Create Copy...

Creates a copy of the selected template in the file system. You can use this function to create copies of the templates provided and then adapt them to your own requirements.

Edit...

If a template is currently selected in the folder structure, it is opened for editing. If a directly link is selected a dialog opens for selecting a different directory.

Rename...

Allows templates and virtual folders to be renamed.

Remove

Removes the selected object from the folder structure. No files are deleted from the file system when this is done. The button is not available for the default directories or for the elements below a directory link.

Options

Chapter 22

The **Options...** button of the *Options* group on the **Manage** ribbon page takes you to the *Options* dialog window that permits various program settings.

22.1 General

Language

Program English (US) ▾

Menu bar

☐ Use classic style menus

Dialog boxes

☐ Leave property dialogs open

Project

☒ Undo operation across all projekt pages

☒ Create Unplaced Objects

Check for updates at startup

☒ Disable automatic updates

☐ Notify about updates

☐ Notify about updates and download automatically

Check for updates now...

Figure 22/1: *Options* dialog window: *General* tab

22.1.1 Language

Program

Defines the language for the program interface including dialog windows and messages.

22.1.2 Menu bar

Use classic style menus

FluidDraw uses ribbons by default with pages and groups for displaying the menus and buttons. If the “*Use classic style menus*” option is active, the classic menu representation is used.

22.1.3 Dialog boxes

Leave property dialogs open

The properties dialogs of various objects remain open by default until they are closed by the user. You can continue to work on the circuit diagram while the dialogs are open. Any number of dialogs can remain open simultaneously. This performance is also called *non-modal*.

Depending on the way you work, it may be practical to keep several properties dialogs open simultaneously. However, that can also get confusing very quickly. You can deselect the option if you desire. Then, any dialog open for editing must be closed first before other edit functions can be used. This is also referred to as *modal*.

22.1.4 Project

Undo operation across all project pages

If you want to undo an operation, use the corresponding [Undo](#) function. You can also undo multiple operations by using the function several times.

If you edit different pages of a project alternately, it may be desired to undo all operations made on the various project pages in precisely the same order. Alternatively, you can define that the undo operation always only applies to the page you are just editing.



Please note that operations that change different pages of a project simultaneously may result in undesired results if the undo operations are not carried out in chronological order. That includes e.g.

spreading valve terminal on to several pages or editing global objects such as terminal strips or cables.

Create Unplaced Objects

Some symbols such as for solenoid valves in the pneumatic diagram require additional corresponding solenoid coils in the electrical part. FluidDraw can automatically provide the corresponding components in a special library when such objects are inserted. It is on the left in the area with the component library. It is managed separately for each open project and has the caption: *Unplaced Objects*.

If you do not require these components that were automatically added to the project, deselect the *Create Unplaced Objects* option.

22.1.5 Check for updates at startup

FluidDraw can search the Internet for a new version when the program starts. You can activate or deactivate the automatic search here.

Check for updates now...

As soon as there is an Internet connection you can use this button to trigger the search for a new FluidDraw version.

22.2 Save




Figure 22/2: *Options* dialog window: *Save* tab

Compress Files

FluidDraw normally compresses the stored files in order to save memory capacity on the disk. If you deactivate the option the files are saved as XML files without compression. You can find further information in the [Circuit files](#) section.

Create Backup Files

The “*Create Backup Files*” option is used to create previous versions of stored files with the file extension **bak**. You can restore the previous version this way.

Verify File Write

Activate this option if you want to ensure after a save operation that the file was written correctly.

Create Folder For New Projects

A folder with the project name where all project files are stored is automatically created when a new project is created if this option is active.

Embed Image Files

If you want to insert an [image file](#) in FluidDraw you will be requested to select a file path. You have the choice of embedding the image or of saving the file path as an external link.

You define the desired default setting here. If you frequently want to forward or archive your circuit drawings, you should embed the images.

Save source path

If you have embedded an [image file](#) the original file path is no longer required. However, it may still be practical if you can also see later on where the image came from.



Please note that even if the option is selected the image is not updated if the image file has changed. The file path is for your information only. If you desire an automatic update, do not embed the image but create an external link instead.

22.3 Product Catalog

Figure 22/3: *Options* dialog window: *Product Catalog* tab

Retrieve additional data
when inserting products

If this option is active, FluidDraw will attempt to obtain additional product properties via an Internet connection.



When this is done, no individual or personal data is transferred to Festo or third parties.

Products

Specifies which products from the Festo product catalog are to be used, for example *Europe* or *Festo worldwide*.

Default period for shopping baskets	From Festo Shopping Basket can be used to import shopping baskets in FluidDraw. You define here what period is set as the filter by default. You can also change this period later on using the insertion dialog.
Language	Defines the language used for the Festo product catalog .
Insert symbols with type attribute	If this option is selected, when components are inserted from the Festo product catalog with the circuit symbol, a text box is automatically inserted with a link to the attribute with the type designation of the product.
Insert FluidDraw symbol instead of catalog symbol	There are different symbol representations for some products. If you insert anything from the Festo product catalog you can choose which symbol you want to apply. You define the default setting with this option.
Insert legacy valve terminal symbols	FluidDraw can automatically convert order codes of some frequently used valve terminals into the corresponding symbol representation. You can select here whether you prefer the new horizontal representation or the vertical representation of the previous version of FluidDraw.
Text fields for accessories	If you insert accessories without symbol representation, texts appear with the type designation of the products. You can limit the number of text boxes inserted here.

22.4 Folder Locations

The screenshot shows the 'Folder Locations' tab of the 'Options' dialog. It contains several sections, each with a text input field and a 'Browse...' button. All input fields contain the path 'C:\Users\John\Documents\FluidDraw'.

Folder Locations	
Project Templates	C:\Users\John\Documents\FluidDraw Browse...
Project Files	C:\Users\John\Documents\FluidDraw Browse...
Library Files	C:\Users\John\Documents\FluidDraw Browse...
Drawing Frames	C:\Users\John\Documents\FluidDraw Browse...
Database Files	C:\Users\John\Documents\FluidDraw Browse...
User defined reports	C:\Users\John\Documents\FluidDraw Browse...
Page Files	C:\Users\John\Documents\FluidDraw Browse...

Figure 22/4: *Options* dialog window: *Folder Locations* tab

Project Templates	This is the default path for your own project templates.
Project Files	This is the default path for opening and saving projects.
Library Files	This is the default path for opening and saving libraries.
Drawing Frames	This is the default path for opening and saving drawing frames .
Database Files	This is the default path for opening and saving database files .
User defined reports	This is the default path for your own reports, such as parts lists, terminal diagrams, wiring lists, etc.

Page Files

This is the default path for opening and saving circuits.

22.5 Translation Table




Figure 22/5: *Options* dialog window: *Translation Table* tab

Translation Table

Defines the [translation table](#) to be used.

Translation Language

Defines the language from the selected [translation table](#) to be used.

22.6 Connector Links




Figure 22/6: *Options* dialog window: *Connector Links* tab

22.6.1 Connect Automatically

FluidDraw supports the [automatic connection of connectors](#). The following settings define which connectors should be automatically created.

Pneumatic – Horizontal	Pneumatic connectors that are on one horizontal line are automatically connected when a symbol is inserted or moved.
Pneumatic – Vertical	Pneumatic connectors that are on one vertical line are automatically connected when a symbol is inserted or moved.
Electric – Horizontal	Electric connectors that are on one horizontal line are automatically connected when a symbol is inserted or moved.
Electric – Vertical	Electric connectors that are on one vertical line are automatically connected when a symbol is inserted or moved.
GRAFCET – Horizontal	Connectors of GRAFCET objects that are on one horizontal line are automatically connected when a symbol is inserted or moved.
GRAFCET – Vertical	Connectors of GRAFCET objects that are on one vertical line are automatically connected when a symbol is inserted or moved.

Allow connections between
same connector types only

Only connectors of the same type can be connected if this option is active. For example a line from an electric connector to a pneumatic connector cannot be created in this case.

22.7 Warnings




Figure 22/7: Options dialog window: Warnings tab

22.7.1 Warnings

Enable Background Check

All circuits are checked during editing if this option is active. Only the criteria that would lead to the warnings specified under “ Show Warnings” are checked. Objects that caused an error are highlighted in red in the circuit. If this option is not active then the check

must be triggered manually using the [Page](#) – [Check Drawing](#) menu.

Drawing Tools

Objects that result in a warning are highlighted in red. If you also activate this option the reason is displayed in an information window if you move the mouse over the relevant object.

22.7.2 Show Warnings

Different types of warnings that FluidDraw should or should not issue can be activated and deactivated here. These warnings include “*Duplicated identification labels*” and “*Superimposed objects*”.

22.8 Appearance

Override Default Settings

Font

Segoe UI

Pen width

0.1

mm

View

☒ Display Snap Radius

☐ Display Line Jump

Zoom

Mouse wheel +

Ctrl

☐ Reverse direction of rotation

Grid

Grid Width

2

M

Style

Line

Figure 22/8: Options dialog window: Appearance tab

22.8.1 Override Default Settings

Font	Defines the default font used to insert text.
Pen width	Defines the default line width used to insert drawing elements.

22.8.2 View

Display Snap Radius	To simplify the connection of connectors, FluidDraw draws a small circle around the connector points of the circuit symbols. Deselect
---------------------	---

the *Display Snap Radius* option to stop the representation of the circle.

Display Line Jump

Defines the default setting for displaying [line jumps](#). That improves the recognizability for intersecting lines. You only set the default value here. To change the representation on an existing page, you can also find this option at the page and project settings.

22.8.3 Zoom

Mouse wheel

Defines the direction and the additional key to be used to zoom in and out using the mouse wheel.

22.8.4 Grid

To display the grid press the [Show Grid](#) button in the *Drawing Tools* group on the [View](#) ribbon page.

Grid Width

You set the width of the grid here. In addition to values such as “mm” you can also specify the relative [basic unit of length](#) “M” .

Style

You set the grid style here.

22.9 Designation Conventions

This tab is used to define the default settings for the designation conventions. You can find further information under [Equipment identifications and designation conventions](#).



The settings are only applied to newly created projects or circuits. They have no effect on existing objects.

Default Settings

☐ Automatically frame identification for free input

☒ Enumerate Automatically

☒ Consider All Project Files

User Defined

= Installation ☐

+ Location ☐

- Component ☐

: Connector ☐

Example =1+2-K3:4

☐ Frame Identification

Reset

Figure 22/9: *Options* dialog window: *Designation Conventions* tab

22.9.1 Default Settings

Automatically frame identification for free input	Defines that the identifications are framed in the event of a free input without using the designation conventions.
Enumerate Automatically	Defines that the identifications of newly inserted symbols are automatically numbered.
Consider All Project Files	All project files and not just the current circuit are taken into account for numbering if this option is active.

22.9.2 User Defined

Frame Identification

Defines that the identifications are framed.

22.10 Cross Reference Representation

The screenshot shows a dialog window titled "Default Settings". It contains several rows of controls, each with a checkbox, a dropdown menu, and a small square button. The first row has a checked checkbox, a dropdown menu showing "Page number", and a small square button. The second row has an unchecked checkbox, a dropdown menu showing "Page Row", and a small square button. The third row has an unchecked checkbox, a dropdown menu showing "Page Column", and a small square button. The fourth row has an unchecked checkbox, a dropdown menu showing a downward arrow, and a small square button. The fifth row has an unchecked checkbox, a dropdown menu showing a downward arrow, and a small square button. The sixth row has an unchecked checkbox, a dropdown menu showing a downward arrow, and a small square button. At the bottom, there is an "Example" label, a text box containing "/1.C3", and a "Reset" button. Below the text box, there is a note: "Note: type \n for line break".

Figure 22/10: *Options* dialog window: *Cross Reference Representation* tab

This tab is used to define the default settings for the cross-reference representation. You can find further information under [Cross-reference representation](#).

The settings are only applied to newly created projects or circuits. They have no effect on existing objects.

22.10.1 Default Settings

Example	Illustrates the effects of the settings using an example.
Reset	Resets the settings to the settings defined in FluidDraw.

22.11 Text Sizes

Identification

Component	Segoe UI	10
Conduction Line	Segoe UI	8
Terminal Strip	Segoe UI	10
Cable	Segoe UI	10
Connector	Segoe UI	8

Label/Attribute

Attribute Value	Segoe UI	10
Text Object	Segoe UI	12
Cross-reference	Segoe UI	8
Dimension	Segoe UI	10

Reset

Preview

100%

ADVC-4-5-P

M1

1 2

-W2

P1

W

24 mm

-X1 1

Text

Figure 22/11: Options dialog window: Text Sizes tab

This tab defines the font sizes to be used for objects newly inserted into the circuit diagram.

Preview

The defined fonts and font sizes are shown here according to an example.

22.12 Dimension

This tab is used to define the default settings for the dimensions. You can find further information under [Dimension](#).




Figure 22/12: *Options* dialog window: *Dimension* tab

All settings are only applied to newly created dimensions. They have no effect on existing dimensions in the circuit.

22.12.1 Default Settings

Layer	Defines the drawing layer where the newly created dimensions are placed.
Automatic Dimensioning	Activates or deactivates automatic dimensioning. If this option is activated then the displayed dimensioning is automatically adapted if the dimensions are scaled.
Unit	Defines the unit to be used for the dimension.
Show Unit	Defines whether the unit should be displayed.
Decimals	Defines the number of decimal places.
Scale Factor	Determines the factor with which the real length is multiplied for the displayed value. This is necessary if you are creating a drawing with a scale other than 1:1.

22.12.2 Preview

The default settings of the dimensions are shown here using an example.

22.13 Drawing Layers

This tab is used to define the default settings of the [drawing layers](#).



The settings are only applied to newly created projects or circuits. The settings have no effect on existing pages.

Default Settings

	Description	Color	Line Style	Line Width	Display	Edit
▶ 0		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input type="checkbox"/>
1		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
4		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
5		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
6		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
7		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
8		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
9		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
10		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
11		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
12		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
13		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
14		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
15		Individual	Individual	Individual	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Reset

Figure 22/13: Options dialog window: Drawing Layers tab

Default Settings

Resets the settings of the drawing layers to the default values.

22.14 Display Attributes

This tab is used to define the default settings of the [automatically displayed attributes](#)..



The settings are only applied to newly created projects or circuits. The settings have no effect on existing pages.

Default Settings					
Attribute Name	Display	Frame Text		Alignment	
Identification	<input checked="" type="checkbox"/>	Individual	▼	Individual	▼
Type	<input checked="" type="checkbox"/>	No frame	▼	Individual	▼
Item name	<input type="checkbox"/>	No frame	▼	Bottom	▼
Cross-Section, Cable	<input type="checkbox"/>	No frame	▼	Bottom	▼
Length, Cable	<input type="checkbox"/>	No frame	▼	Bottom	▼
Cable Type, Cable	<input type="checkbox"/>	No frame	▼	Bottom	▼
Customer part no.	<input type="checkbox"/>	No frame	▼	Bottom	▼
Description	<input type="checkbox"/>	No frame	▼	Bottom	▼
Order code 1	<input type="checkbox"/>	No frame	▼	Bottom	▼
Order code 2	<input type="checkbox"/>	No frame	▼	Bottom	▼
Part number	<input type="checkbox"/>	No frame	▼	Bottom	▼
Remark	<input type="checkbox"/>	No frame	▼	Bottom	▼
Supplier	<input type="checkbox"/>	No frame	▼	Bottom	▼
Symbol Name	<input type="checkbox"/>	No frame	▼	Bottom	▼
Pos.No. (User Defined Attribute)	<input checked="" type="checkbox"/>	Stadium shape	▼	Bottom left	▼
Length, Cable (User Defined Attribute)	<input type="checkbox"/>	No frame	▼	Bottom	▼
Cable Type, Cable (User Defined Attrib...	<input type="checkbox"/>	No frame	▼	Bottom	▼

Reset

Figure 22/14: *Options* dialog window: *Display Attributes*

Reset

Resets the settings of the attributes to be displayed automatically to the default settings.

Ribbon overview

Chapter 23

23.1 Quick access toolbar

The quick access bar provides some functions that are frequently used and that are therefore available regardless of the currently selected ribbon page.



Save File



Undo



Redo



Check Drawing



Connect Automatically

23.2 File

File



New

New / Page

Opens a new window for creating a new **page** that is added to the current project.

New / Project

Opens the dialog window for creating a new **project**.

New / Project from template...

Opens the dialog window for creating a new **project** that is based on a project template.



Open...

Opens the dialog window for selecting an existing **project** or a circuit file. The most recently opened files can be selected for opening from a list.



Save File

Saves the active project.



Save All

Saves all open projects.



Save Project As...

Saves the active project under a new name on the data storage medium. With external file references you must bear in mind that changes to these files affect all projects containing them.



Print...

Opens the FluidDraw dialog window *Print* for setting the [print options](#) for the active project.



Close

Closes the active project.

Import/Export



DXF Import...

Opens the dialog window for selecting a stored [DXF file](#). The selected file is then converted into a FluidDraw drawing. The original file remains unchanged.



Export...

[Exports](#) the circuit drawing of the active window as BMP, JPG, GIF, PNG, TIF, WMF, DXF, PDF or SVG file to the data storage medium.



Save as Component Library...

Saves the active project as a library. A new library symbol is then created for every circuit. The project name is applied as the name of the new library with the file extension **lib**.

23.3 Home

Clipboard



Paste

Inserts the objects from the clipboard into the active circuit.



Copy

Copies the selected objects to the clipboard.



Cut

Deletes the selected objects and inserts them in the clipboard.

Select



Properties...

If the circuit symbol is selected, opens the *Properties* dialog window for entering the [component properties](#). It can also be used to apply the attributes from the [Festo product catalog](#).

If you highlight the component connector, the *Connector* dialog window opens for entering the [connector properties](#).

When a line segment is highlighted a dialog window opens enabling you to enter the [line properties](#).

If several objects are highlighted, a [dialog window](#) appears with the different and common properties of the highlighted objects.

Select All

Highlights all objects of the active circuit.



Delete

Deletes the highlighted objects of the active circuit.



Delete Connector

Deletes the highlighted [component connector](#).

Group



Group

Groups the highlighted objects.



Create Macro Object

Creates a **macro object** from the highlighted objects.



Ungroup/Break Off

Deletes the highlighted **groups** or **macro objects**.



Create Cross-reference

Creates a **cross-reference**.

Rotate



Right

Rotates the highlighted objects 90 degrees clockwise. **Grouped objects** are rotated around the center of the group rectangle.



Left

Rotates the highlighted objects 90 degrees anti-clockwise. **Grouped objects** are rotated around the center of the group rectangle.

Mirror



Horizontally

Mirrors the highlighted objects horizontally. **Grouped objects** are mirrored at the axis of the group rectangle.



Vertically

Mirrors the highlighted objects vertically. **Grouped objects** are mirrored at the axis of the group rectangle.

Align

The buttons of this group can be used to **align** the highlighted objects to each other.

Drawing Layers

Highlighted objects can be assigned to the specified **drawing layer**. If no objects are highlighted, the specified drawing layer is the standard layer.

Zoom



Fit to Window

Selects the zoom factor that allows the entire circuit drawing to fit in the window.



Standard Size

Shows the circuit drawing in its original size.



View Detail

Defines the new view by drawing a rectangle with the left mouse button pressed.



Previous View

Shows the circuit drawing in the last view. Activate this function repeatedly to switch back and forth between the views last set.

23.4 Insert

Object



Text

Inserts a [text](#) at the mouse position.



Picture

Inserts an [image file](#) at the mouse position.

Draw

In this group, you can find functions for freely drawing [graphical elements](#) such as lines, rectangles and circles.



Line

Draws a [line](#) by defining two end points.



Rectangle

Draws a [rectangle](#) by defining two diagonally opposite corner points.



Circle

Draws a [circle](#) by defining the center and the radius.



Ellipse

Draws an [ellipse](#) by defining a center and two axially parallel radii.



Poly Line

Draws a [polyline](#) by defining the vertices with successive mouse clicks. The drawing operation can be cancelled by pressing the [Esc](#) key or by clicking the right mouse button. The last vertex must be set with a double-click.

Symbol



Find Symbol Description...

Opens the [search dialog](#) for selecting a symbol by its appearance or by its description.



From Festo Catalog...

Opens the [Festo product catalog](#) for selecting a component via the product properties.



From Custom Database

Opens a dialog window similar to the [Festo product catalog](#) for selecting a component via the product properties. It is not the database of the Festo product catalog that is used, however, but the selected [user database](#).

Collection



From Festo Shopping Basket

From Festo Shopping Basket / Online (Internet access required)...

Opens the dialog for applying components from an existing [online shopping basket](#).

From Festo Shopping Basket / Offline (from local product catalog)...

Opens the dialog for applying components from an existing [offline shopping basket](#).



From File...

Opens the dialog window for selecting an existing text file in CSV format that was created by export from the Festo product catalog.

Link



Conduction Line...

Opens a dialog window that defines the settings for one or more [conduction lines](#) that are to be inserted in the circuit diagram after the dialog window is confirmed.



Interruption/Potential...

Adds an [interruption](#) or an [electric potential](#) to the circuit diagram.



Define Connector...

Creates a new [component connector](#) the next time you use the left mouse button to click a circuit symbol.

Electrics



Terminal

Inserts a [terminal](#) in the circuit diagram.



Multiple Terminals...

Inserts [multiple terminals](#) in the circuit diagram.



Cable

Inserts a [cable](#) in the circuit diagram.

List



Table

Inserts a fixed [table](#) in the page.



Report

Inserts an [report](#) in the page.

Dimension

Using the buttons of this group, you can insert a [dimensioning symbol](#) in the active page.

23.5 Select

You can use these options to set [selection filters](#).

Options

Active Drawing Layer Only

The selection filters only include the currently selected drawing layer.

Protect connector texts

Prevents any inadvertent displacement of the [connector texts](#).

Object Types

Select the desired [object types](#) here.

All Objects

Main Components

Sub components

Connection Lines

Component Designations

Line Designations

Connector Designations

Cable Designations

Text Objects

Attribute Links

Terminals

Cables

Lines

Rectangles

Circles/Ellipses

Poly Lines

Images

Tables and reports

Drawing Layers

Defines the drawing layer to which the filters apply when the [Active Drawing Layer Only](#) option is selected.

23.6 Edit

Edit



Enable Rotate

Activates and deactivates “Rotation permitted” mode that allows you to [rotate symbols](#) using the mouse pointer.



Enable Scale

Activates and deactivates “Scaling permitted” mode that allows you to [scale symbols](#) using the mouse pointer.



Edit Poly Line

Activates or deactivates “Edit Polyline” mode that allows you to [edit a polyline](#).



Edit List/Table

Activates or deactivates “Edit Table” mode that allows you to [edit a table](#).



Connect Automatically

FluidDraw supports the [automatic connection of connectors](#). You can temporarily activate or deactivate the function with this option.

Snap

Defines the options for the [object snap](#).



Snap to End Point



Snap to Mid Point



Snap to Intersection



Snap to Center




Snap to Grid



Snap to Connector


Color



Color


Defines the drawing color. This setting applies both to future drawing operations, therefore also (on request) to the currently marked objects.

Line Style




Line Style

Defines the line style. This setting applies both to future drawing operations, therefore also (on request) to the currently marked objects.




Line Width

Defines the line width. This setting applies both to future drawing operations, therefore also (on request) to the currently marked objects.



Start Cap

Defines how the beginning of the line is displayed. This setting applies both to future drawing operations, therefore also (on request) to the currently marked objects.



End Cap

Defines how the end of the line is displayed. This setting applies both to future drawing operations, therefore also (on request) to the currently marked objects.

T-Node



T-Node

Defines how the T-distributor is displayed. This setting applies both to future drawing operations, therefore also (on request) to the currently marked objects.

23.7 View

Drawing Tools



Show Page Borders

Shows or hides the page borders in the form of a red rectangle. This rectangle represents the limits of the paper format set using the [Drawing Size...](#) menu. You use the [print preview](#) to decide whether and how the drawing is distributed over several pages.



Show Grid

Shows a **background grid** in the active circuit window. The grid settings can be made on the **Tools** tab under the **Options...** menu item in the *General* menu.



Show Rulers

Shows or hides the rulers in the active circuit window.



Show Page Dividers

Shows or hides the **page dividers** in columns and rows. Cross-references can refer to the column and row containing a symbol. The position and number of the columns and rows can be interactively defined via the page dividers shown.

Show Connector Descriptions

Shows or hides the connector descriptions. The *Display* option can be selected in the properties dialog window for the connectors. This option is only evaluated if "**Individual**" was selected.

None

Hides all connector descriptions regardless of the settings at the connectors.

All

Shows all connector descriptions regardless of the settings at the connectors.

Individual

Shows only the connector descriptions for those connectors with the *Display* option activated.

Show Terminal Directions

Shows or hides the direction arrows at the terminals. The arrow head points at the control cabinet.

None

Hides all arrows regardless of the settings at the terminals.

Individual

Shows only the arrows for those terminals with the *Show Direction* option activated.

All

Shows all arrows regardless of the settings at the terminals.

GRAFCET

Defines whether for GRAFCET elements the formula is to be preferably displayed or a text description.

Use settings of individual elements

Description, if available

Always show formula

Display Contact Images

Shows or hides the [contact images](#).

Window



New Window

Opens a window with an additional view of the active window.



Navigation Pane

Opens an overview window with a miniature view of the entire circuit drawing. The currently visible part of the active window is displayed as a white area. The non-visible part of the drawing is on a grey background. By creating a rectangle with the mouse pointer in the overview window, you can determine a section of the circuit drawing that is displayed in the active window. Simply click in the overview window with the left mouse button to move the visible area while maintaining the zoom factor.



Cascade

Cascades the windows.



Tile Horizontally

Arranges the windows below each other.



Tile Vertically

Arranges the windows next to each other.



Close All

Closes all open windows.

23.8 Page

Drawing



Check Drawing

Checks the active circuit drawing for [drawing errors](#).

Numbering



Renumber Designations...

Opens a dialog window enabling you to interactively [renumber the symbol identifications](#).

Manage



Manage Terminal Strips...

Opens a dialog window enabling you to manage the [terminal strips in the circuit](#).



Manage Cables...

Opens a dialog window enabling you to manage the [cable objects in the circuit](#).

Properties



Drawing Size...

Opens a dialog window enabling you to set the [size of the drawing](#).



Drawing Layers...

Opens a *Drawing Layers* dialog window enabling you to set the properties of the [drawing layers](#).



Language...

Opens a dialog window enabling you to set the [circuit language](#).



Properties...

Opens a dialog window for entering the [circuit properties](#).

23.9 Project

Page



Import Current Page

Adds the active window to the file list of the open [project](#).



Delete Current Page

Removes the active window from the file list of the open [project](#).

Numbering



Renumber Designations...

Opens a dialog window enabling you to interactively [renumber the symbol identifications](#).



Renumber Pages...

Opens a [dialog for renumbering the project pages](#).

Manage



Manage Terminal Strips...

Opens a dialog window enabling you to manage the [terminal strips in the project](#).



Manage Cables...

Opens a dialog window enabling you to manage the [cable objects in the project](#).



Manage Cross References...

Opens a dialog window enabling you to manage the [cross-references in the project](#).

Manage Global Objects...

Opens a dialog window enabling you to manage the [global objects](#).

Properties



Drawing Layers...

Opens a *Drawing Layers* dialog window enabling you to set the properties of the [drawing layers](#).



Language...

Opens a dialog window enabling you to set the [project language](#).



Properties...

Opens the dialog window for entering the [project properties](#).

23.10 Library

Add



Create New Library...

Creates a new [library](#).



Add Existing Library...

Opens the dialog window for selecting a stored library file with the file extension **.lib**. The library stored in the file is then added to the library window.



Add Existing Symbol Folder...

Opens the dialog window for selecting an existing folder. The entire contents of the selected folder including all circuit symbols and sub-folders are displayed as a library.

Active Library



Sort Current Library Alphabetically

Sorts the contents of the active library alphabetically. This function is only available for libraries created by the user. Write-protected libraries are automatically sorted and cannot be resorted by the user.



Rename Active Library...

Opens a dialog window for entering the name of the library. This function is only available for libraries created by the user. In write-protected libraries, the name of the folder is displayed on the tab.



Close Current Library

Removes the active library from the list in the library window. The library file is not deleted by this action and can be opened again using the **Library** menu and the **Add Existing Library...** menu item.

Identification

Two-letter designations

This is for defining if the reference designations of the components from the **standard libraries** are to be proposed with one or two

reference code letters. Two letters are normally used according to newer standards.

Manage reference designations...

If a symbol does not have a default identification in the library or if you want to change it, you can assign an individual identification to every symbol. This [dialog](#) provides you with an overview of all user IDs.

23.11 Manage

Sources



Manage templates...

Opens a dialog window for managing [templates](#).



Custom Product Databases...

Opens a dialog window for managing the [product databases](#).



Translation Tables...

Opens a dialog window for managing [translation tables](#).

Options



Options...

Opens the dialog window with [program settings](#), [file paths](#) and [language options](#).



Restore Defaults...

Resets the program settings to the default values. This enables you to undo unintentional settings made.

Note: Use this function if you feel that FluidDraw is behaving unexpectedly or files and windows appear to have suddenly disappeared.

Licenses



License Information...

Opens the dialog window with information on the license currently used.



Manage Licenses...

Opens the [Online license manager](#) where the licenses that belong to a ticket number can be managed.

23.12 Help

User's Guide



Contents

Displays the contents of the FluidDraw help pages.



Index

Displays the index of the FluidDraw help pages.



Search

Displays the search dialog of the FluidDraw help pages.

Version



Check for updates...

As soon as there is an Internet connection you can use this menu item to trigger the search for a new FluidDraw version.



About...

Displays the FluidDraw program information.

Adjust Ribbon

Chapter 24

Using the new “*Adjust ribbon*” dialog, the new user interface of FluidDraw can be adjusted completely to the users individual preferences. Besides adjusting the default configuration, all new user configurations can be created, exported and imported. Changes to the shortcuts are also possible using the dialog.

You can access the configuration dialog via the quick access at the top of the window.




Figure 24/1: “Adjust ribbon” in the quick access bar




Figure 24/2: Adjust Ribbon Dialog

FluidDraw allows almost complete customization to the ribbon. This includes deleting and customizing predefined default pages and

groups. Every page can be deleted to start with an empty ribbon, which can be built from scratch to fit the users needs.

24.1 The Ribbon

The new ribbon interface in FluidDraw P6 works similar to ribbon interfaces from other common software. It is divided in pages, groups and commands, the latter of which also able to contain sub commands. In the tree view this results in a maximum of 4 levels. On the top level, the pages are housed, which contain the groups housing the commands.




Figure 24/3: Up to 4 levels

24.2 Tree view and Command view

By default, the dialog opens up showing in tree view mode, which displays the ribbons default configuration on the left side and the user configuration on the right side. Upon opening the dialog for the first time, both sides are identical.




Figure 24/4: Command view

The tree view mode can be changed to the command view mode. In command view mode, all commands are listed alphabetically on the left side, providing easy access to select the desired command.

24.3 Adding Elements

You can edit the user configuration using the mouse or the buttons inside the dialog. To add an element to the configuration, first select the position inside the right tree view, where you want to insert the new element.



New elements are inserted behind the selected element on the right side. On inserting a page while e.g. a command is selected, the page is added after the page housing the selected command.

Afterwards, select the element, which is to be inserted, in the left tree view or command view. The “**Add**” button is then shown as active. By pressing the button or using the context menu when right clicking the element to insert, the selected element is copied into the right tree view.



Some elements, like separators or mutual exclusive commands, cannot be added using the Add button. New separators can be added using “**New...**” - “*Separator*”. Mutual exclusive commands, like “**View**” - “**Show Terminal Directions**” - “**None**”, “**Individual**”, “**All**” cannot be added on their own, but only the whole group “**Show Terminal Directions**” can be added.

You can also select elements from the left-hand tree by mouse and drag them over into the right tree to copy them. An insert point is shown for valid operations while dragging the element. Release the mouse to perform the operation.




Figure 24/5: Drag&Drop Operation




Figure 24/6: Operation completed

24.4 Removing Elements

As previously mentioned in [the introduction](#), all predefined elements can be removed from the user configuration. You can delete any element by either selecting it in the right tree and clicking the “Remove” button or right clicking the element and selecting the “**Remove**” command from the context menu.

24.5 Moving Elements

The elements in the right-hand tree can be moved and arranged. You can use either the buttons “**Up**” and “**Down**” or the respective entries in the context menu. Elements always move on their own level, so groups will always be child elements of pages and may jump to the next or previous page accordingly. Additionally, drag&drop is also available to move elements with the preview showing like described in [Adding Elements](#).

24.6 Creating new Elements


Using the “**New...**” button, you can create new pages, groups and separators. After selecting the position in the right-hand tree to insert the new element at, it is inserted by clicking the respective entry in the “New” menu.





Separators can only be inserted when a command is selected.

New pages are initially named “*New Page*” whereas new groups are initially named “*New Group*”. Using the “**Rename...**” function, you can of course change the names to your liking. Being user defined elements, the names will be shown in bold font. Separators are added by using the “**New...**” – “*Separator*” button. They get inserted after the selected command as well and will be deleted on saving the configuration, if they are the last element inside a group.


24.7 Renaming Elements







Click the “**Rename...**” button underneath the right-hand tree to rename any element but separators. Like user created elements, renamed elements are shown in **bold font**.



Besides user created new pages and groups, all renamed elements can be reverted to their original name. Right click the respective element and select “ *Revert name to ‘#’*” from the context menu.



Elements with customized names, showing up in bold font, won’t be translated on switching the language. Resetting an elements name will result in the element being translated again.

24.8 Large / Small Symbol

To highlight commands that are more important or to allow for a better layout, the size of the commands in the ribbon can be changed. Use the check box “ *Large Symbol*” beneath the right-

hand tree to switch between large and small display of the command. On selecting the command, the check box gets checked accordingly. If checked, the symbol is displayed as a large symbol ([*Large Symbol*]) is displayed behind the command name in the tree as well).



Not all elements support the large symbol appearance. This includes all commands displaying a check box or radio button themselves as well as separators.

24.9 Reset to default settings

Using the “**Reset**” button on the right side beneath the right-hand tree, all changes can be reverted and the default configuration is restored.



Restoring the default configuration also reverts all shortcuts to their default assignment.


24.10 Import / Export

Customized configurations can be exported and imported via the “*Adjust ribbon*” dialog. This way, different configurations can be designed to fit individual scenarios that can easily be exchanged. Exchanging customized configurations with other users is also possible. Ribbon configurations are saved with the file extension PathExtFdic.



On importing a ribbon configuration, the currently used configuration is discarded and can only be restored by cancelling the dialog. Export your current configuration before importing another configuration, if you plan to use the current configuration again later.


24.11 Assign shortcuts



Using the “*Assign Shortcut...*” button, you can access the configuration dialog for shortcuts. The dialog allows for any assignment of shortcuts to single commands. All currently assigned shortcuts can also be viewed in the dialog.

Each row in the command list shows the commands name, the default position in the ribbon as well as the current shortcut.


24.11.1 Assign new Shortcut





First, select the command from the list you wish to customize and select the shortcut text field afterwards. Shortcuts support an arbitrary combination of the modifier keys **Shift**, **Ctrl** and **Alt** and any regular key. You can also decide not to use the modifier keys at all and directly assign a key. After selecting the text field, press the shortcut you want to use on the keyboard. Assign the showed shortcut by clicking the “Assign” button.



If the shortcut is already assigned to another command, a red warning message appears below the text-field. Assigning the shortcut will have to be confirmed in an additional dialog then. If a shortcut from the text field is not assigned on changing the command, a prompt will ask if the shortcut should be discarded.








24.11.2 Remove Shortcut

If a command with an assigned shortcut is selected, you can remove the shortcut by clicking the “**Remove**” button next to the shortcut. Removing a shortcut this way will not bring up a prompt to confirm.



If you want to delete all assigned shortcuts at once, use the “*Remove all shortcuts*” button. You will have to confirm the operation in a prompt again.

24.11.3 Restore shortcuts

Using the “**Reset**” button the default assignment for shortcuts can be restored. In contrast to the *Adjust ribbon* dialogs “**Reset**” button, this will only reset all shortcuts, the ribbon configuration is left unchanged.

Index

A

Alignment	87
Alignment line	117
Attribute link	199
Auxiliary line	117

B

Backup copies	338
Blanking plug	79
BMP	
export	328

C

Cable	303, 306
manage	306
Cable list	308
Cable map	307
Check	
drawing	150
Circle	139
Circuit	
check	150
input	325
node	208
open	208
output	325
print	325
properties	208
Component attributes	181
Compression	
files	338
Conduction lines	299
Configurable cylinders	84
Configurable directional control valves	82
Connector	
connect	69
define	81
delete	82
identification	79
properties	79
seal	79

Connector Labels	194
Contact	191
Contact image	324
Control line	77
Cross Reference Representation	128
Cross-reference	
create from symbol	126
Cylinder	
configure	85
Cylinder editor	85
D	
Defining page dividers	113
Delete	
line	79
Designation conventions	175
Designations	
numbering	177
Dialog	
cable	303, 306
circle	140
circuit	46
component	182
connector	80
contact	191
Cross Reference Representation	128
diagram properties	287
dimension	173
drawing area	290
drawing frame	92, 93
drawing layers	120
drawing size	46
electric line	78
electric terminal	310
ellipse	142
Functional diagram	278
image	134
line	78, 79, 136
line chain	144
line options	293
Manage Cross References...	129
object browser	
filter	155
page	216

pneumatic line	78
polyline	144
print	325
project	46, 216
rectangle	138
secondary element	191
section chain	144
set multiple terminals	313
signal link	294
signaling elements	292
text	197
text options	288
wiring	303
Dimension	172
Dimensioning	172
Directional control valves	
configure	83
Drawing element	130
Drawing frame	91
create	91
import	91
use	91
Drawing frames with watermarks	108
Drawing layer	119
DXF	
export	328
DXF file	
import	326
E	
Edit	
circuit	61
Electric line	145
Ellipse	141
Equipment identifications	175
Export	328
F	
Festo product catalog	61
G	
GIF	
export	328

Graphical element	130
Grid	117
Grid options	348
Group	86
delete	87
form	86

H

Hatching	131
Hide	
automatically	59
Hide window	59

I

ID code	66, 67
Image	133
Image file	133
Insert	
symbol	52
Inserting T-distributors	72
Interruption	147

J

JPG	
export	328

L

LabelTranslationTable	342
Language text	
search	165
Layer	119
Libraries	51
Library	54, 59
Library window	59
Line	135
delete	79
electric	145
intersect	121
move	74
pneumatic	145

Line chain	143
Line jump	121
Line segment	74
Line type	
define	77
Link	199
Links	320

M

Macro object	
create	86
delete	87
Manage Cross References...	129
Mirror	87, 89

O

Object browser	59
tree view	153
line	154
Object snap	118
Online shop	63
Options	
Appearance	347
Connector Links	343
Cross Reference Representation	350
Designation Conventions	348
Dimension	353
Display Attributes	355
Drawing Layers	354
Folder Locations	341
General	335
Grid	348
Save	338
Text Sizes	352
Translation Table	342
Warnings	345
Order code	66, 67

P

page	
node	208
open	208
properties	216

Page dividers	220
Parts list	
print	325
PDF	
export	328
Pneumatic line	145
PNG	
export	328
Polygon chain	143
Polyline	143
Potential	147
Potentials	299
Predefined attributes	219
Predefined placeholders	219
Predefined variables	219
Print	325
Product catalog	61
Project	58, 59, 207
add	208
node	208
print	325
properties	216
remove	208
XML file	58
Project window	59
Properties	216
Properties dialog	46
cable symbol	303
circle	140
component	182
connector	80
contact	191
Cross Reference Representation	128
cylinder	85
dimension	173
directional control valves	83
drawing layers	120
electric line	78
ellipse	142
image	134
line	78, 79, 136
line chain	144
Manage Cross References...	129
page	216
pneumatic line	78

polyline	144
project	216
rectangle	138
secondary element	191
section chain	144
text	197
wiring	303
Properties dialog window	
cable	306
electric terminal	310
set multiple terminals	313

R

Rectangle	137
Ribbon	357
Ribbon page	
Edit	369
File	357
Help	380
Home	359
Insert	363
Library	377
Manage	379
Page	374
Project	376
Select	366
View	371
Rotate	88

S

Scale	89
Search	
symbol	53
Secondary element	191
Section chain	143
Selection	
object types	
object filter	
filter	122
Shopping basket	63
insert	63
Show	
automatically	59

Show window	59
Silencer	79
Snap	118
Storage locations	341
SVG	
export	328
Symbol	
align	87
group	86
insert	61
mirror	87, 89
move	61
rotate	88
scale	89
search	53
Symbol library	54
Symbols	51

T

T-distributor	
set	81
Terminal	310
Terminals	313
Text	133
Text attributes	199
Text component	196
Text constant	202
Text ID	
search	165
Text link	199
TIF	
export	328
Tiles	
printout	46
Toolbar	
drawing	130

V

Valve editor	83
Valve terminal	66, 67
delete	66
distribute	67
symbol	66

W

Wiring _____ 303

WMF
 export _____ 328

Working line _____ 77

X

XML file _____ 58