
# **FESTO**



Key features

### Innovative

- Ideal housing surface design ensures that cleaning agents can run off, thus significantly reducing time and effort spent on cleaning
- Flow rate up to 780 l/min
- Sub-D multi-pin plug connection, front or rear
- I-Port interface/IO-Link, front or rear

#### Versatile

- Valves in individual grid
- Freely extendable system with individual sub-bases and modular tie rods
- Up to 32 solenoid coils
- Easy subsequent conversion and extension
- Air supply can be extended using additional pressure zones with power supply modules or sub-bases with an additional power supply
- Wide pressure range
  −0.9 ... 8 bar
- Wide range of valve functions

#### Reliable


- Use of materials that are resistant to corrosion and media
- Fast troubleshooting thanks to LEDs on the valves
- Easy to service thanks to replaceable valves
- Manual override, optionally non-detenting
- Efficient sealing thanks to 5 tie rods and redundant seals
- NSF-H1 greasing, FDA-compliant materials

### Easy to assemble

- Supplied as ready-to-assemble, inspected unit
- Individually configurable pneumatic connections (straight or angled fittings, or with screw-in thread)
- Reduced outlay on selection, ordering, assembly and commissioning
- Excellent corrosion resistance and degree of protection (IP69K) enable assembly under harsh ambient conditions outside of a control cabinet

**FESTO** 

Key features



#### **Equipment options**

Valve functions

- 5/2-way valve, single solenoid
- 5/2-way valve, double solenoid
- 2x 3/2-way valve, normally open
- 2x 3/2-way valve, normally closed
- 2x 3/2-way valve,
   1x normally open,
   1x normally closed
- 5/3-way valve, mid-position pressurised
- 5/3-way valve, mid-position closed
- 5/3-way valve, mid-position exhausted
- 2x 2/2-way valve,
  1x normally closed,
  1x normally closed, reversible
- 2x 2/2-way valve, normally closed
- 1x 3/2-way valve, normally closed, external compressed air supply
- 1x 3/2-way valve, normally open, external compressed air supply

#### Special features

- Maximum of 32 valve positions
- Maximum of 32 solenoid coils
- Parallel modular valve linking
- Integrated reduction of holding current
- Any compressed air supply
- Creating pressure zones
- Modular, individually extendable tie rods
- · Valve positions in individual grid
- Freely selectable fittings/tubing sizes at each port

#### Valve terminal selection

Valve terminal configurator

The online catalogue is a quick and easy way to select an MPA-C valve terminal. This includes a convenient valve terminal configurator, making it much easier to order the right product.

The valve terminals are fully assembled according to your order specification and are individually checked. This reduces assembly and installation time to a minimum.

You can order an MPA-C valve terminal using the order code.

MPA-C ordering system

→ Internet: mpac
CTEU ordering system

→ Internet: cteu

## Online via: → www.festo.com

2D/3D CAD data

You can request the CAD data for a valve terminal you have configured. To do so, start the product search as described above. Go to the shopping basket and click on the CAD icon (compass). On the next page, you can generate a 3D preview or request a data format of your choice via e-mail.

Key features

#### Multi-pin plug connection




The signal flow from the controller to the valve terminal takes place via a pre-assembled or self-assembled multi-wire cable to the multi-pin plug connection, which substantially reduces installation time.

The valve terminal can be equipped with up to 32 solenoid coils. This corresponds to 2 to 32 valves.
The multi-pin cable should be no longer than 30 m.

#### Versions:

- Sub-D connection, 25-pin
- Sub-D connection, 44-pin

#### I-Port interface/IO-Link



I-Port/IO-Link consists of a central master and the I-Port interface/
IO-Link devices connected via special connecting cables. This permits a decentralised layout of the devices. The connection type corresponds to a star topology.

In other words, only one module or one valve terminal can be connected to each I-Port.

The I-Port interface from Festo is based on IO-Link and is compatible with IO-Link in certain areas.

As well as communication, the I-Port interfaces also handle the power supply for the connected devices. The maximum length of a string is 20 m.

#### Versions:

• Sub-D connection, 9-pin

#### Modular pneumatic components


The modular design of the MPA-C enables maximum flexibility right from the planning stage, and makes it exceptionally easy to service during operation.

The system consists of sub-bases, valves and blanking plates.

The sub-bases form the support system for the valves. They contain the connection ducts for supplying compressed air to and venting from the valve terminal as well as the working ports for the pneumatic drives for each valve.

The sub-bases are joined together via a tie rod system. This consists of a threaded rod, threaded sleeve and screw. The threaded rod/sleeve combination is selected as appropriate for the chosen number of individual bases.

A valve terminal can be easily extended by adding individual sub-bases or power supply modules. This is done by inserting suitable tie rod extenders between the threaded rod and the sleeve.




Peripherals overview

#### **FESTO**

### Valve terminal pneumatics

MPA-C valve terminals with multi-pin plug connection or I-Port interface/ IO-Link can be expanded by up to 32 solenoid coils/valve positions. Each individual sub-base is available with a valve position for valves with one or two solenoid coils.

Double solenoid valve positions can be equipped with any valve or a blanking plate. Single solenoid valve positions can only be equipped with single solenoid valves or a blanking plate.



Des	cription	Brief description	→ Page/Internet
1	Left-hand end plate	With connections for compressed air supply/exhaust air	33
2	Electrical interlinking module	Electrical interlinking module for single sub-base, single/double solenoid	-
3	Sub-base, individual	Sub-base with one valve position for valve with one or two solenoid coils	32
4	Solenoid valve	With one or two solenoid coils	31
5	Cover	For one valve position	31
6	Separator	For pressure zone separation	33
7	Power supply module	With connections for compressed air supply/exhaust air	33
8	Right-hand end plate	With connections for compressed air supply/exhaust air and external pilot air supply	33
9	Screw	Tie rod system, connects the sub-bases	32
10	Push-in fitting	For pneumatic connections	34
11	Plug	Enables conversion from internal to external pilot air supply	-
12	Blanking plug	For sealing ports that are not required	35
13	Mounting	Spacer bolts for mounting the valve terminal	33
14	Sleeve	Tie rod system, connects the sub-bases	32
15	Tie rod extender	For subsequent modular extension of the valve terminal	32
16	Threaded rod for tie rod	Clamps the sub-bases between the end plates	32
17	Connecting cable	For I-Port interface or for multi-pin plug connection	33, 33

Key features – Pneumatic components

#### **FESTO**

#### Sub-base valve



The MPA-C offers a comprehensive range of valve functions. All valves are equipped with a piston spool and patented sealing system that facilitates efficient sealing, a broad pressure range and a long service life. They have a pneumatic pilot control for optimising performance.

The air for this is supplied by means of a central pilot air supply.

Sub-base valves can be replaced quickly since the tubing connections remain on the sub-base.

This design is also particularly slim.

Whatever valve function is required, there are sub-base valves with one solenoid coil (monostable) or with two solenoid coils (bistable or two single solenoid valves in one housing).

#### Design

#### Valve replacement

The valves are located under the cover. The cover and each valve are mounted on the sub-base with two screws,

which means that they can be replaced easily. The sturdy mechanical structure of the cover and sub-bases ensures efficient, durable sealing.

#### Extension

Vacant positions (blanking plates) can be replaced by valves at a later date. The dimensions, mounting points and existing pneumatic installations remain unchanged during this process. The valve code (M, J, N, NS etc.) is located on the front of the valve, underneath the manual override, and can be read through a inspection window in the cover.



#### - Note

A filter must be installed upstream of valves operated in vacuum mode.

This prevents any foreign matter in

the intake air getting into the valve (e.g. when operating a suction cup).

5/2-way valve			
Circuit symbol	Code	Description	
14 4 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Position function 1-32: M	Single solenoid     Pneumatic spring return	<ul> <li>Reversible</li> <li>Operating pressure –0.9 +10 bar</li> </ul>
14 4 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Position function 1-32: MS	Single solenoid     Mechanical spring return	<ul> <li>Reversible</li> <li>Operating pressure –0.9 +8 bar</li> </ul>
14 4 2 12 14 5 1 3 12	Position function 1-32: J	Double solenoid     Reversible	• Operating pressure −0.9 +10 bar



Key features – Pneumatic components

2x 3/2-way valve									
Circuit symbol	Code	Description							
12/14 82/84 1 5 3	Position function 1-32: N	<ul><li>Single solenoid</li><li>Normally open</li></ul>	<ul> <li>Pneumatic spring return</li> <li>Operating pressure 3 10 bar</li> </ul>						
10 10 10 11 12/14 82/84 1 5 3	Position function 1-32: NS	Single solenoid     Normally open     Mechanical spring return	<ul> <li>Reversible</li> <li>Operating pressure –0.9 +8 bar</li> </ul>						
12/14 1 5 82/84 3	Position function 1-32: K	<ul><li>Single solenoid</li><li>Normally closed</li></ul>	<ul> <li>Pneumatic spring return</li> <li>Operating pressure 3 10 bar</li> </ul>						
12/14 82/84 1 5 3	Position function 1-32: KS	Single solenoid     Normally closed     Mechanical spring return	<ul> <li>Reversible</li> <li>Operating pressure –0.9 +8 bar</li> </ul>						
10 12/14 82/84 1 5 3	Position function 1-32: H	<ul> <li>Single solenoid</li> <li>Normal position         <ul> <li>1x closed</li> <li>1x open</li> </ul> </li> </ul>	<ul> <li>Pneumatic spring return</li> <li>Operating pressure 3 10 bar</li> </ul>						
12/14 82/84 1 5 3	Position function 1-32: HS	<ul> <li>Single solenoid</li> <li>Normal position</li> <li>1x closed</li> <li>1x open</li> </ul>	<ul> <li>Mechanical spring return</li> <li>Reversible</li> <li>Operating pressure -0.9 +8 bar</li> </ul>						

**FESTO** 

Key features – Pneumatic components

<b>5/3-way valve</b> Circuit symbol	Code	Description	
14 W 4 2 W 12 14 84 5 1 3 82 12	Position function 1-32: B	Mid-position pressurised <sup>1)</sup> Mechanical spring return	<ul> <li>Reversible</li> <li>Operating pressure –0.9 +10 bar</li> </ul>
14 W 4 2 W 12 14 84 5 1 3 82 12	Position function 1-32: G	Mid-position closed <sup>1)</sup> Mechanical spring return	<ul> <li>Reversible</li> <li>Operating pressure –0.9 +10 bar</li> </ul>
14 W 4 2 W 12 14 84 5 1 3 82 12	Position function 1-32: E	Mid-position exhausted <sup>1)</sup> Mechanical spring return	<ul> <li>Reversible</li> <li>Operating pressure –0.9 +10 bar</li> </ul>

If neither solenoid coil is energised, the valve assumes its mid-position by means of spring force.
 If both coils are energised at the same time, the valve remains in the switching position it had assumed previously.

3/2-way valve						
Circuit symbol	Code	Description				
20 4 14 84 2 5	Position function 1-32: W	<ul> <li>Single solenoid</li> <li>Normally open</li> <li>External compressed air supply</li> <li>Pneumatic spring return</li> <li>Reversible</li> </ul>	• Operating pressure -0.9 +10 bar The pressure supplied at working port 2 (-0.9 +10 bar) can be switched for both internal and external pilot air supplies.			
42 (14) 2 14 84 4 3	Position function 1-32: X	Single solenoid     Normally closed     External compressed air supply     Pneumatic spring return     Reversible	• Operating pressure -0.9 +10 bar The pressure supplied at working port 4 (-0.9 +10 bar) can be switched for both internal and external pilot air supplies.			

2x 2/2-way valve			
Circuit symbol	Code	Description	
12/14   82/84   1	Position function 1-32: D	<ul><li>Single solenoid</li><li>Normally closed</li></ul>	<ul> <li>Pneumatic spring return</li> <li>Operating pressure 3 10 bar</li> </ul>
12 12 1 12 1 12 1 12 1 12 1 1 1 1 1 1 1	Position function 1-32: DS	Single solenoid     Normally closed     Mechanical spring return	<ul> <li>Reversible</li> <li>Operating pressure –0.9 +8 bar</li> </ul>
12/14 5 82/84 1	Position function 1-32: I	<ul> <li>Single solenoid</li> <li>1x normally closed</li> <li>1x normally closed, only reversible</li> </ul>	<ul> <li>Pneumatic spring return</li> <li>Operating pressure 3 10 bar</li> <li>Vacuum at port 3/5 only</li> </ul>

Key features - Pneumatic components

#### **FESTO**

#### Cover plate




Vacant position (code L) without valve function, for reserving valve positions on a valve terminal.

The valve and vacant position are located under a cover.

Using a combination of a cover and a sub-base without a valve is not permissible unless a blanking plate is also being used.

#### Exhaust air functions - Check valve



1 Check valve

The check valves prevent the air from being pushed back (back pressure) from the ducts 3 and 5 into the solenoid valve.

This prevents the back pressure from having a disruptive effect on other connected actuators.

The check valves are integrated into ducts 3 and 5 of the sub-bases.

The check valves should be installed according to the specifications using the enclosed assembly tool. Following

assembly, the check valves cannot be

removed.

Please see the relevant assembly instructions:

→ www.festo.com/sp

#### Compressed air supply and exhausting

The valve terminal MPA-C is supplied with compressed air via:

- Right-hand end plate
- Left-hand end plate
- Power supply modules
- Sub-bases with additional power supply

All pneumatic connections are located at the rear of the valve terminal.

Exhausting (ducts 3 and 5) can take place using a choice of:

- Right-hand end plate
- Left-hand end plate
- Power supply modules
- Sub-bases with additional power supply

Ducts 3 and 5 are routed completely separately in the terminal.


The pilot air exhaust (duct 82/84) is completely separate from ducts 3 and 5. Its port is located in the right-hand end plate, together with the ports for the pilot air supply (12/14) and the pressure compensation port (L).

- 1 Left-hand end plate with electrical connection (multi-pin plug or I-Port interface/IO-Link) and pneumatic connections 1, 3
- 2 Sub-base with mounting holes and pneumatic connections 2 and 4
- 3 Sub-base without mounting holes and pneumatic connections 2 and 4

All valves in the valve terminal are supplied by a common pilot air source, regardless of the pressure zones that are present.

The supply can take place using a choice of the following methods:

- Internal (from duct 1 on the righthand end plate) or
- External (from duct 12/14)
- Power supply module with pneumatic connections 1, 3 and 5
- 5 Sub-base with additional power supply, with pneumatic connections 1, 3, 5 and 2, 4
- 6 Right-hand end plate with pneumatic connections 1, 3, 5 and L, 12/14, 82/84




- Note

If a gradual pressure build-up in the system using a soft-start valve is chosen, an external pilot air supply

should be connected so that the pilot pressure applied during switch-on is already very high.

Key features – Pneumatic components

Compressed air supply and pilot air supply									
Graphical illustration	Code	Туре	Notes						
Right-hand end plate									
3	Pilot air: Z	VMPAC-EPR-IN	<ul> <li>Internal pilot air supply</li> <li>Pilot air is branched internally from port 1 in the right-hand end plate</li> <li>For operating pressure in the range 3 8 bar</li> <li>Thread connection size G3/8 (port 1, port 3 and port 5)</li> <li>Thread connection size G1/8 (port 82/84 and port L)</li> <li>Blanking plug in port 12/14</li> </ul>						
3 — D — D — D — D — D — D — D — D — D —	Pilot air: –	VMPAC-EPR-EX	<ul> <li>External pilot air supply</li> <li>Pilot air supply (3 8 bar) is connected at port 12/14 on the right-hand end plate</li> <li>For operating pressure in the range –0.9 8 bar (suitable for vacuum)</li> <li>Thread connection size G3/8 (port 1, port 3 and port 5)</li> <li>Thread connection size G1/8 (port 12/14, 82/84 and port L)</li> </ul>						
	<u> </u>	<u> </u>	1						
Left-hand end plate		T							
3 ① D 1 5	Outlet, electrical connection: U	VMPAC-EPL	With electrical connection (multi-pin plug connection or I-Port interface/IO-Link) and pneumatic connections 1, 3 and 5:  • Electrical connection, outlet direction at top  • Electrical connection, outlet direction at bottom  • Thread connection size G3/8						






11

supply	Compressed air supply and pilot air supply									
Code	Туре	Notes								
Type of module block 1-40: U	VMPAC-SP-0	Additional power supply modules can be used for larger terminals or to create pressure zones.  Supply modules can be configured at any point upstream or downstream of the sub-bases.  Power supply modules contain the following ports:  • Compressed air supply (port 1)  • Exhaust air (port 3 and port 5)  • Thread connection size G3/8								
	VMPAC-AP-14-SP	Sub-bases with an additional power supply can be used for larger terminals or to create pressure zones.  Sub-bases with an additional power supply contain the following ports:  • Compressed air supply (port 1)  • Exhaust air (port 3 and port 5)  • Thread connection size G1/4								
	Type of module block 1-40: U  ply Sub-base with additional pneumatic	Type of module block 1-40: U VMPAC-SP-0  ply  Sub-base with additional pneumatic VMPAC-AP-14-SP								

Key features – Pneumatic components

#### Creating pressure zones and separating exhaust air



If different working pressure levels are required, the MPA-C offers a range of options for creating pressure zones. Duct 1 and/or duct 3 and/or duct 5 are blocked by inserting a separator in the sub-base. Each pressure zone must have its own supply. The following supply options are available:

- Left-hand end plate
- Right-hand end plate
- Power supply module

If you are using sub-bases with an additional power supply, each valve in the valve terminal could be operated within a separate pressure zone. A pressure zone is created by separating the internal supply ducts using a special separator. Each pressure zone must have its own compressed air supply.

Compressed air can be supplied and exhausted via a supply module and/or the right-hand end plate.

The MPA-C allows you to select any

position for the power supply modules and the sub-bases with pressure zone separation.

The sub-bases with pressure zone separation are integrated into the terminal at the factory as specified in your order.

They can be distinguished by their coding, even when the valve terminal is assembled. Duct separation always takes place to the right of the sub-base.


#### **Example: Compressed air supply and pilot air supply**

External pilot air supply

The image opposite shows an example of creating and connecting an air supply in the case of an external pilot air supply.

The pilot air (duct 12/14) is supplied centrally to the entire valve terminal via the right-hand end plate.

Pressure zone separation always takes place to the right of the sub-base with separator(s).



Key features - Assembly

#### **FESTO**

#### Sub-base



The MPA-C is based on a modular system consisting of sub-bases and valves. The sub-bases are joined together using tie rods and thus form the support system for the valves. They contain the connection ducts for supplying compressed air to and venting from the valve terminal as well as the working ports for the pneumatic drives for each valve.

The sub-bases are joined together via tie rods. The tie rod consists of a

threaded rod, threaded sleeve and

In principle, sub-bases have a modular structure.

The threaded rod/sleeve combination is selected according to the number and width of the individual sub-bases. To add further blocks, simply loosen the tie rod and adapt with extenders. There are no restrictions on extensions; a tie rod could be

constructed almost entirely from extenders.

Each solenoid coil must be assigned to a specific pin of the multi-pin plug for the valve to be activated. Regardless of whether vacant positions or valves are used, sub-bases occupy:

- One coil/address (single solenoid valves)
- Two coils/addresses (double solenoid valves)


#### Valve terminal assembly

Sub-bases with threaded holes are available for the MPA-C valve terminal. Therefore, the valve terminal can be assembled either in a control cabinet or on any even surface using spacer bolts.


It can be assembled in any position. However, the selected mounting position should allow dirt to be cleaned off and cleaning agent to be drained. The mounting surface must be able to support the weight of the valve terminal and any forces that arise, and must enable torsion-free assembly.

Sub-bases directly connected to the right- and left-hand end plates and every fifth sub-base within the valve terminal must be provided with mounting holes.

#### Assembly with tubing throughfeed




#### Assembly with spacer bolts



Key features – Assembly

#### Tie rod

Structure



- 1 Threaded rod
- 2 Tie rod extender
- 3 Sleeve
- 4 Screw

#### Mode of operation

The tie rod for the MPA-C consists of four parts:

- Threaded rod
- Tie rod extender
- Sleeve
- Screw

This enables valve terminals of any length to be created.

It takes just 4 steps to assemble the tie rod and the valve terminal:

- Screw the sleeves to the threaded rods
- Push the rod/sleeve combination into the tie rod shafts of the subbases and push the power supply modules onto the left-hand end plate
- Screw the rod/sleeve combination onto the left-hand end plate
- Push on the right-hand end plate and secure with screws that engage into the sleeves

The tie rod enables the valve terminal to be extended at a later date. This is done by loosening the tie rod screws and disassembling the relevant components. The additional sub-base or power supply module is inserted at the required location. The previously disassembled components are then re-assembled.

To compensate for the change in length, the tie rod must be extended by the increase in length. This is done by screwing in extenders between the threaded rod and sleeve.

## •

## Note

To ensure the valve terminal is properly sealed, you must:

- Check the seals between the sub-bases and replace them, if necessary, before the assembly stage during conversion work
- Tighten the tie rod screws in the correct order
- Tighten the tie rod screws to the correct torque

Key features – Assembly



#### Tie rod - Components and design

Tie rod (threaded rod)



The threaded rod is used to construct a cost-optimised fixed-grid tie rod.

#### Tie rod extender



The valve terminal can be extended almost infinitely using tie rod extenders.

The tie rod extenders are inserted between the threaded rod and the sleeve.

#### Sleeve



The primary purpose of the sleeve is to compensate for tolerances that occur, for example, when the seals are compressed between the sub-bases during assembly.

The sleeves come in different lengths, tailored to the use of a tie rod in a fixed grid as well as generally for the individual modular tie rods.

#### Screw



The entire valve terminal is clamped via the tie rod using the screw. Tolerances that occur, for example when the seals are compressed between the sub-bases during assembly, are compensated for by the interaction of the screw and sleeve.

#### Individual modular tie rod







Tie rods can be constructed entirely using tie rod extenders. The threaded rod and sleeve are required to compensate for tolerances that occur, for

example when the seals are compressed between the sub-bases during assembly.

#### Fixed-grid tie rod with extension









The tie rod extenders are inserted between the threaded rod and the sleeve.

They are available in suitable lengths for sub-bases and supply modules.

#### Fixed-grid tie rod







The fixed-grid tie rod minimises assembly costs when assembling previously defined valve terminals. These valve terminals can be extended at any time. The threaded rod (and, if applicable, the sleeve too) must be replaced if the valve terminal length is reduced.



Key features – Assembly

Ordering data – Fixed-grid tie rod							
Number of sub-bases and power supply	Tie rod		Sleeve		Tie rod extender		
modules	Part No.	Туре	Part No.	Туре	Part No.	Туре	
1	8025286	VMPAC-ZAS-5	8025283	VMPAC-ZAH-46	_	_	
2	8025286	VMPAC-ZAS-5	8025285	VMPAC-ZAH-66	-	_	
3	8025287	VMPAC-ZAS-45	8025284	VMPAC-ZAH-56	-	-	
4	8025288	VMPAC-ZAS-85	8025283	VMPAC-ZAH-46	-	-	
5	8025288	VMPAC-ZAS-85	8025285	VMPAC-ZAH-66	-	-	
6	8025289	VMPAC-ZAS-125	8025284	VMPAC-ZAH-56	-	-	
7	8025290	VMPAC-ZAS-165	8025283	VMPAC-ZAH-46	-	-	
8	8025291	VMPAC-ZAS-205	8025282	VMPAC-ZAH-36	-	-	
9	8025291	VMPAC-ZAS-205	8025284	VMPAC-ZAH-56	-	-	
10	8025292	VMPAC-ZAS-245	8025283	VMPAC-ZAH-46	-	-	
11	8025293	VMPAC-ZAS-285	8025282	VMPAC-ZAH-36	-	-	
12	8025293	VMPAC-ZAS-285	8025285	VMPAC-ZAH-66	-	-	
13	8025294	VMPAC-ZAS-325	8025283	VMPAC-ZAH-46	-	-	
14	8025295	VMPAC-ZAS-365	8025282	VMPAC-ZAH-36	-	-	
15	8025295	VMPAC-ZAS-365	8025285	VMPAC-ZAH-66	-	-	
16	8025296	VMPAC-ZAS-405	8025284	VMPAC-ZAH-56	-	-	
17	8025297	VMPAC-ZAS-445	8025282	VMPAC-ZAH-36	-	-	
18	8025297	VMPAC-ZAS-445	8025285	VMPAC-ZAH-66	-	_	
19	8025298	VMPAC-ZAS-485	8025284	VMPAC-ZAH-56	-	-	
20	8025299	VMPAC-ZAS-525	8025282	VMPAC-ZAH-36	-	-	
21	8025299	VMPAC-ZAS-525	8025285	VMPAC-ZAH-66	-	-	
22	8025300	VMPAC-ZAS-565	8025284	VMPAC-ZAH-56	-	_	
23	8025301	VMPAC-ZAS-605	8025283	VMPAC-ZAH-46	-	_	
24	8025301	VMPAC-ZAS-605	8025285	VMPAC-ZAH-66	-	-	
25	8025302	VMPAC-ZAS-645	8025284	VMPAC-ZAH-56	-	_	
26	8025303	VMPAC-ZAS-685	8025283	VMPAC-ZAH-46	-	_	
27	8025303	VMPAC-ZAS-685	8025285	VMPAC-ZAH-66	-	-	
28	8025304	VMPAC-ZAS-725	8025284	VMPAC-ZAH-56	-	_	
29	8025305	VMPAC-ZAS-765	8025283	VMPAC-ZAH-46	-	_	
30	8025305	VMPAC-ZAS-765	8025284	VMPAC-ZAH-56	8038824	VMPAC-ZAE-20	
31	8025306	VMPAC-ZAS-805	8025284	VMPAC-ZAH-56	-	-	
32	8025307	VMPAC-ZAS-845	8025283	VMPAC-ZAH-46	-	-	
33	8025307	VMPAC-ZAS-845	8025284	VMPAC-ZAH-56	8038824	VMPAC-ZAE-20	
34	8025308	VMPAC-ZAS-885	8025285	VMPAC-ZAH-66	-	-	
35	8025309	VMPAC-ZAS-925	8025283	VMPAC-ZAH-46	-	-	
36	8025309	VMPAC-ZAS-925	8025284	VMPAC-ZAH-56	8038824	VMPAC-ZAE-20	
37	8025310	VMPAC-ZAS-965	8025285	VMPAC-ZAH-66	-	_	
38	8025311	VMPAC-ZAS-1005	8025283	VMPAC-ZAH-46	-	_	
39	8025311	VMPAC-ZAS-1005	8025284	VMPAC-ZAH-56	8038824	VMPAC-ZAE-20	
40	8025312	VMPAC-ZAS-1045	8025285	VMPAC-ZAH-66	-	-	

Key features - Display and operation

#### **FESTO**

#### Display and operation

Signal status display

Each solenoid coil is allocated an LED that indicates its signal status.

- Indicator 12 shows the signal status of the coil for duct 2
- Indicator 14 shows the signal status of the coil for duct 4

#### Manual override

The manual override (MO) enables the valve to be actuated when not electrically activated or energised.


The valve is switched by pushing the manual override.

#### Cover

The inspection window for the signal status display and valve designation, and the manual override mechanism, are located in the cover.

Irrespective of this, the valves below are always equipped with signal status display and manual override.

#### Indicators and control elements



- 1 Left-hand end plate with electrical connection (multi-pin plug or I-Port interface/IO-Link)
- 2 Manual override (for each pilot solenoid coil, non-detenting)
- 3 Signal status display (for each pilot solenoid coil)
- 4 Inspection window for valve designation
- 5 Cover without manual override




#### Note


A valve actuated manually (by means of the manual override) cannot be reset electrically.

Conversely, an electrically actuated valve cannot be reset using the manual override.

#### Manual override (MO)



1 Press in the plunger of the MO using a blunt plastic pin.
The pilot valve switches and actuates the main valve.



- 2 Remove the pin.

  Spring force pushes the plunger of the MO back.

  The pilot valve returns to its ini-
  - The pilot valve returns to its initial position and so too the single solenoid main valve (this is not the case with a double solenoid valve).

17

Key features - Display and operation

#### **FESTO**

### Display and operation

Labels

The following can be used as labels:


- Laminated thermal transfer stickers
- Laser-printed stickers
- Laser printing directly onto the valve terminal surface

Labels can be applied to all sides of the valve terminal and to its individual components. The possible size of the labelling surfaces can be taken from the

dimensional drawing ( $\rightarrow$  30).

It is not possible to label the valves located beneath covers in addition to the information printed on by the manufacturer.

The valve positions are therefore labelled on the covers or on the sub-bases




- Note

When applying labels, the requirements in terms of cleaning and environmental emissions must be observed, especially for stuck-on labels.

Key features – Electrical components

### **FESTO**

#### Electrical power as a result of current reduction



Each solenoid coil is protected with a spark arresting protective circuit as well as against polarity reversal.
All valve types are additionally equipped with integrated current reduction.

MPA-C valves are supplied with operating voltage in the range 21.6 ... 26.4 V (24 V +/-10%).

#### Electrical connection - Left-hand end plate



The electrical connection from the valves to the higher-order controller is in the left-hand end plate.

Switching between the various

connection options is easy: simply swap the left-hand end plate; the pneumatic interlinking remains as is. The valves are switched by means of positive or negative logic (PNP or NPN). Mixed operation is not permitted.

#### Guidelines on addressing for valves/solenoid coils

The numbering of the addresses goes from left to right in ascending consecutive order. The following applies at the individual valve positions: address x for coil 14 and address x+1 for coil 12.

Each sub-base occupies a defined number of addresses/pins:

- For 1 solenoid coil: 1
- For 2 solenoid coils: 2



Note

If a single solenoid valve is assembled on a double solenoid valve position, the second address (for coil 12) is also occupied and cannot be used.

19

Variants of the left-hand end pl	ate			
Graphical illustration	Code	Туре	Maximum number of addresses	Notes
Outlet, electrical connection at to	ор			
	Electrical connection: MS1	VMPAC-EPL-MP-SD25-0	24	Electrical connection Sub-D, 25-pin
	Electrical connection: MS3	VMPAC-EPL-MP-SD44-0	32	Electrical connection Sub-D, 44-pin
	Electrical connection: PT	VMPAC-EPL-IP-O	32	Electrical connection Sub-D, 9-pin I-Port interface/IO-Link
Outlet, electrical connection at b	ottom			
	Electrical connection: MS1	VMPAC-EPL-MP-SD25	24	Electrical connection Sub-D, 25-pin
	Electrical connection: MS3	VMPAC-EPL-MP-SD44	32	Electrical connection Sub-D, 44-pin
	Electrical connection: PT	VMPAC-EPL-IP	32	Electrical connection Sub-D, 9-pin I-Port interface/IO-Link

Key features – Electrical components

Pin allocation for electrical multi-pin plug connection - Sub-D plug, 25-pin, connecting cable NEBV-C-S1WA25									
	Pin	Address/	Wire colour <sup>2)</sup> of	F	Pin	Address/	Wire colour <sup>2)</sup> of		
		coil	connecting cable			coil	connecting cable		
	1	0	WH	1	14	13	BN GN		
14+	2	1	BN	1	15	14	YE WH		
+ 2   15+   + 3	3	2	GN	1	16	15	BN YE		
16+ + 4	4	3	YE	1	17	16	GY WH		
17+ + 5	5	4	GY	1	18	17	BN GY		
18+	6	5	PK	1	19	18	WH PK		
19+ 7	7	6	BU	2	20	19	BN PK		
+ 8	8	7	RD	2	21	20	BU WH	å	
22+ 9	9	8	ВК	2	22	21	BN BU	- 🖣 - Note	
+10	10	9	VT	2	23	22	RD WH	The drawing shows the view onto the	
+11     24+   +12	11	10	GY PK	2	24	23	BN RD	pins of the Sub-D plug.	
25+ +13	12	11	RD BU	2	25	0 V <sup>1)</sup>	BK WH		
	13	12	GN WH						

 <sup>0</sup> V for positive switching control signals; connect 24 V for negative switching control signals; mixed operation is not permitted.
 To IEC 757

Pin allocation for electrical multi-pin plug connection - Sub-D plug, 44-pin, connecting cable NEBV-C-S1WA44										
	Pin	Address/ coil	Wire colour <sup>2)</sup> of connecting cable		Pin	Address/ coil	Wire colour <sup>2)</sup> of connecting cable	Pin	Address/ coil	Wire colour <sup>2)</sup> of connecting cable
	1	0	WH		18	17	BN GY	35	n.c.	n.c.
(31 + 1)	2	1	BN		19	18	WH PK	36	n.c.	n.c.
	3	2	GN		20	19	BN PK	37	n.c.	n.c.
	4	3	YE		21	20	BU WH	38	n.c.	n.c.
	5	4	GY		22	21	BN BU	39	n.c.	n.c.
	6	5	PK		23	22	RD WH	40	n.c.	n.c.
	7	6	BU		24	23	BN RD	41	n.c.	RD GN
	8	7	RD		25	24	BK WH	42	n.c.	RD YE
+ + +	9	8	BK		26	25	BK BN	43	0 V <sup>1)</sup>	BK GN
+ + +	10	9	VT		27	26	GN GY	44	0 V <sup>1)</sup>	BK YE
	11	10	GY PK		28	27	YE GY		·	
	12	11	RD BU		29	28	GN PK	é		
	13	12	GN WH		30	29	YE PK	- [	- Note	
44 30 + )	14	13	BN GN		31	30	GN BU			ws the view onto the
	15	14	YE WH		32	31	YE BU		s of the Sub-E	
	16	15	BN YE		33	n.c.	n.c.	P		- F0-
	17	16	GY WH		34	n.c.	n.c.			

 <sup>0</sup> V for positive switching control signals; connect 24 V for negative switching control signals; mixed operation is not permitted.
 To IEC 757

Key features – Electrical components


#### **FESTO**

### I-Port interface/IO-Link

The I-Port interface/IO-Link enables the MPA-C valve terminal to be connected to the following systems:

- I-Port master from Festo (CPX terminal, CECC)
- Fieldbus node CTEU from Festo
- IO-Link master
  The maximum distance between the
  I-Port/IO-Link master and valve terminal with I-Port interface/IO-Link is
  20 m.

The 5-pin connecting cables contain the power supply for the valves; separate from this is the power supply for the internal valve terminal electronics and the control signals.



Pin allocation for I-Port interface/IO-	Link -	- Sub-D plug, 9-pin, connecting cable NEBC-C-S1WA9		
	Pin	Designation	Wire colour <sup>1)</sup> of	
			connecting cable	
	1	Communication signal C/Q, data transmission line	BK	
+ 1	2	0 V DC load voltage supply for valves and outputs	GY	
6 + + 2	3	0 V DC supply voltage for electronics and sensors	BU	
7 + + 3	4	24 V DC load voltage supply for valves and outputs	WH	<b>≜</b>
8 + 4	5	24 V DC supply voltage for electronics and inputs	BN	- Note
(9 + + 5 )	6	n.c.	n.c.	The drawing shows the view onto the
	7	n.c.	n.c.	Sub-D plug on the I-Port interface/
	8	n.c.	n.c.	IO-Link.
	9	n.c.	n.c.	

1) To IEC 757

Key features – Electrical components

**FESTO** 

#### Instructions for use

Equipment

Operate system equipment with unlubricated compressed air if possible. Festo valves and cylinders are designed so that, if used as intended, they will not require additional lubrication and will still achieve a long service life.

The quality of compressed air downstream of the compressor must correspond to that of unlubricated compressed air. If possible, do not operate all of your system equipment with lubricated compressed air. The lubricators should, where possible, always be installed directly upstream of the actuator used. Incorrect additional oil and too high an oil content in the compressed air reduce the service life of the valve terminal.

Use Festo special oil OFSW-32 or the alternatives listed in the Festo catalogue (as specified in DIN 51524 HLP32; basic oil viscosity 32 CST at 40  $^{\circ}$ C).

#### Bio-oils

When using bio-oils (oils which are based on synthetic or native ester, e.g. rapeseed oil methyl ester), the maximum residual oil content of 0.1 mg/m³ must not be exceeded (see ISO 8573-1 Class 2).

#### Mineral oils

When using mineral oils (e.g. HLP oils to DIN 51524, parts 1 to 3) or similar oils based on poly-alpha-olefins (PAO), the maximum residual oil content of 5 mg/m<sup>3</sup> must not be exceeded (see ISO 8573-1 Class 4).
A higher residual oil content irrespective of the compressor oil cannot be permitted, as the basic lubricant would be flushed out over time.

**FESTO** 

Technical data

- N - Flow rate
Up to 780 l/min

- **[]** - Valve width 14 mm

- **\** - Voltage 24 V DC



General technical data								
Valve terminal design	Modular and expandable							
Electric activation	ulti-pin plug							
	I-Port interface/IO-Link							
Type of actuation	Electrical							
Type of pilot control	Electrical							
Nominal operating voltage [V DC]	24							
Permissible voltage [%]	±25							
fluctuations								
Maximum number of valve positions	32							
Maximum number of pressure zones	32							
Valve size [mm]	14							
LED signal status display	LED							
Pilot air supply	Internal or external							
Degree of protection	IP65, IP67, IP69K							

Operating and environment	tal condition	S						
Operating medium		Compressed air to ISO 8573-1:2010 [7:4:4] <b>→</b> 22						
Note on operating/pilot med	lium	ubricated operation possible (in which case lubricated operation will always be required)						
Operating pressure	[bar]	-0.9 +8						
	[bar]	3 8 (external pilot air supply)						
Pilot pressure	[bar]	3 8 (internal pilot air supply)						
Ambient temperature	[°C]	-5 +60						
Temperature of medium	[°C]	-5 +50						
Storage temperature	[°C]	-20 +40						
Corrosion resistance class C	RC <sup>1)</sup>	4						
CE marking		To EU EMC Directive <sup>2)</sup>						
(see declaration of conformi	ty)							
KC mark		KC EMC						
Food-safe <sup>3)</sup>		See supplementary material information						
Certification		UL - Recognized (OL)						
		RCM trademark						

<sup>1)</sup> Corrosion resistance class CRC 4 to Festo standard FN 940070

3) Additional information www.festo.com/sp → certificates.

Particularly high corrosion stress. Outdoor exposure under extreme corrosive conditions. Parts exposed to aggressive media, for instance in the chemical or food industries. These applications may need to be supported by special tests (

ted by special tests (→ also FN 940082) using appropriate media.

2) For information about the applicability of the component see the manufacturer's EC declaration of conformity at: www.festo.com/sp → User documentation.

If the component is subject to restrictions on usage in residential, office or commercial environments or small businesses, further measures to reduce the emitted interference may be necessary.



Technical data

Safety characteristics	
Shock resistance	Shock test with severity level 2 to FN 942017-5 and EN 60068-2-27
Vibration resistance	Transport application test with severity level 2 to FN 942017-4 and EN 60068-2-6

Technical data – Valve	s																		
Code for position funct	ion 1-32		М	J	N	K	Н	В	G	Е	Х	W	D	1	MS	NS	KS	HS	DS
Design			Pisto	Piston spool valve															
Sealing principle			Soft	Soft															
Lap			Overlap																
Manual override			Non-o	Non-detenting, detenting															
Type of reset		Pneumatic spring					Mechanical spring			Pneumatic spring			Mechanical spring						
Switching times	On	[ms]	13	9	12	12	12	16	13	13	12	12	12	10	13	12	12	12	10
	Off	[ms]	30	-	38	38	38	50	52	50	20	20	30	28	30	23	23	23	25
	Change- over	[ms]	-	24	-	-	-	26	26	26	-	-	-	-	-	-	-	-	-
Standard nominal flow	rate	[l/min]	720	770	730	760	730	690	660	550	510	450	720	730	730	550	600	550	570
Operating pressure [bar]		-0.9 .	+10	3 1	0		-0.9 .	+10		-0.9 .	+10	3 1	0	-0.9 +8					
Pilot pressure [bar]		3 8	38																
Maximum assembly torque for [Nm] valve mounting		0.65																	

Safety characteristics – Valves								
Maximum positive test pulse [μs]	400							
with 0 signal								
Maximum negative test pulse [µs]	200							
with 1 signal								
Shock resistance	Shock test with severity level 2 to FN 942017-5 and EN 60068-2-27							
Vibration resistance	Transport application test with severity level 2 to FN 942017-4 and EN 60068-2-6							




Technical data


Pneumatic connections	5	
Right-hand end plate		
Supply	1	Thread G3/8
Exhaust port	3	Thread G3/8
,	5	Thread G3/8
	L	Thread G1/8
Pilot air supply	12/14	Thread G1/8
Pilot exhaust air	82/84	Thread G1/8
Left-hand end plate		
Supply	1	Thread G3/8
Exhaust port	3	Thread G3/8
Landust port	5	Thread G3/8
	)	Illiedu G5/6
Power supply module		
Supply	1	Thread G3/8
Exhaust port	3	Thread G3/8
	5	Thread G3/8
Sub-base		
Working ports	2	Thread G1/4
Working ports	4	Thread G1/4
	<u> </u>	1111COU 02/17
Sub-base with addition	al power supply	
Supply	1	Thread G1/4
Exhaust port	3	Thread G1/4
	5	Thread G1/4
Working ports	2	Thread G1/4
	4	Thread G1/4

Technical data

### Pilot pressure p2 as a function of working pressure p1 with external pilot air supply

For valves with code for position function 1-32: M, J, B, G, E, W, X





-2 -1 0 1 2 3 4 5 6 7 8 9 10 11

p1 [bar]

For valves with code for position function 1-32: N, K, H, D, I

For valves with code for position function 1-32: MS, NS, KS, HS, DS



Current consumption per solenoid coil at nominal voltage								
Nominal pick-up current	[mA]	50						
Nominal current with current	[mA]	10						
reduction								
Time until current reduction	[ms]	20						

Materials	
Sub-base	Reinforced PA
Power supply module	Reinforced PA
End plate	Reinforced PA
Valve	Die-cast aluminium
Cover	Reinforced PA
Seals	EPDM, NBR
Separator for pressure zone separation	Reinforced PA, NBR
Tie rod	Stainless steel
Spacer bolt	Stainless steel
Note on materials	RoHS-compliant




Technical data

Product weight	
	Approx. weight [g]
Sub-base	160
Power supply module	156
Left-hand end plate	246
Right-hand end plate	224
Valve	77
Cover	42
Vacant position	23
Separator for pressure zone separation	15
Screw for tie rod	3
Sleeve for tie rod, 36/46/56/66 mm	6/8/9/11
Tie rod extender, 21/27 mm	3/4
Spacer bolt	80

Product weight – Threaded rods, tie rods																	
Length [mm]		5	45	85	125	165	205	245	285	325	365	405	445	485	525	565	605
Threaded rods, tie rods	[g]	2	11	20	29	38	47	54	65	72	80	89	98	109	118	127	136
									,				,				
Length [mm]		645	685	725	765	786	805	845	866	885	925	946	965	1005	1026	1045	
Threaded rods, tie rods	[g]	145	154	163	170	174	181	188	192	198	205	209	214	225	229	234	

**FESTO** 


Technical data



<sup>1)</sup> n = Total number of sub-bases/valve positions and power supply modules

Technical data

Right-hand end plate



80.5

40.5

139.3

121.8

104.3

81.8


55.3

28.8

35.4

19.6

Technical data



30

Ordering data	le i	lv., c:		la	_
	Code	Valve function		Part No.	Туре
ndividual solenoid v					
	5/2-way valve	T			
1	Position function 1-32: M	Single solenoid	578806	VMPA14-M1HF-M-PI	
	Position function 1-32: MS	Single solenoid		578817	VMPA14-M1HF-MS-PI
		Mechanical spring return			
•	Position function 1-32: J	Double solenoid		578805	VMPA14-M1HF-J-PI
	2x 3/2-way valve	T			
	Position function 1-32: N	Normally open		578813	VMPA14-M1HF-N-PI
	Position function 1-32: NS	Normally open,		578819	VMPA14-M1HF-NS-PI
		mechanical spring return			
	Position function 1-32: K	Normally closed		578812	VMPA14-M1HF-K-PI
	Position function 1-32: KS	Normally closed,		578818	VMPA14-M1HF-KS-PI
		mechanical spring return			
	Position function 1-32: H	1x normally open, 1x normal		578814	VMPA14-M1HF-H-PI
	Position function 1-32: HS	1x normally open, 1x normal	ly closed,	578821	VMPA14-M1HF-HS-PI
		mechanical spring return			
	5/3-way valve	<del>,</del>			
	Position function 1-32: B	Mid-position pressurised		578807	VMPA14-M1HF-B-PI
	Position function 1-32: G	Mid-position closed		578809	VMPA14-M1HF-G-PI
	Position function 1-32: E	Mid-position exhausted	578808	VMPA14-M1HF-E-PI	
	3/2-way valve	<del>,</del>			
	Position function 1-32: W	Normally open, external com	578811	VMPA14-M1HF-W-PI	
	Position function 1-32: X	Normally closed, external cor	578810	VMPA14-M1HF-X-PI	
	2x 2/2-way valve	<del>,</del>			
	Position function 1-32: D	Normally closed		578815	VMPA14-M1HF-D-PI
	Position function 1-32: DS	Normally closed,		578820	VMPA14-M1HF-DS-PI
		mechanical spring return			
	Position function 1-32: I	1x normally closed, 1x norma	ally closed,	578816	VMPA14-M1HF-I-PI
		reversible only			
lover		T.			
960	-	Cover over a valve position	Without manual override	576588	VMPAC-VC-14
			With manual override for	576586	VMPAC-VC-MO-14-1
			one pilot control		
$\checkmark$			With manual override for	576587	VMPAC-VC-MO-14-2
			two pilot controls		
Blanking plate	T	T			
	Position function 1-32: L	Blanking plate for a valve pos		573729	VMPA14-RP
		a self-adhesive label is suppl	ied.		
$\rightarrow$					
Check valve					
ancer valve	Pneumatic connection 3:	Check valve for installation in	8030830	VMPA14-RV	
	SH	(scope of delivery: 10 check v	0037020	Y 1111 17 17 17 Y	
<b>ELL</b>	Pneumatic connection 5:	George of delivery. To check to	aires, one assembly loui)		
<b>→</b>	QH				
	Ψ1				

	ring data Code Description			Part No.		Type	PU <sup>1</sup>
onnecting plate		·					
<b>△</b>	Type of module block	For 1 solenoid coil	_		576572	VMPAC-AP-14-1	1
	1 - 40: F		With mounting holes		576574	VMPAC-AP-14-B-1	1
			With additional power	supply	576576	VMPAC-AP-14-SP-1	1
	Type of module block				576573	VMPAC-AP-14-2	1
	1 - 40: E	With mounting holes			576575	VMPAC-AP-14-B-2	1
•	1 ,0.2	With modifying notes  With additional power su			576577	VMPAC-AP-14-SP-2	1
			with additional power supply		370377	VIII ACAI 14 31 2	
e rod							
~	_	Threaded rod for tie rod,	width across flats 5 mm	5 mm	8025286	VMPAC-ZAS-5	5
		The threaded rod/sleeve	combination is selected	45 mm	8025287	VMPAC-ZAS-45	5
		based on the number an	d width of the individual	85 mm	8025288	VMPAC-ZAS-85	5
		sub-bases.		125 mm	8025289	VMPAC-ZAS-125	5
				165 mm	8025290	VMPAC-ZAS-165	5
				205 mm	8025291	VMPAC-ZAS-205	5
				245 mm	8025292	VMPAC-ZAS-245	5
				285 mm	8025293	VMPAC-ZAS-285	5
				325 mm	8025294	VMPAC-ZAS-325	5
				365 mm	8025294	VMPAC-ZAS-365	5
				405 mm	8025296	VMPAC-ZAS-405	5
				445 mm	8025297	VMPAC-ZAS-405	5
				485 mm	8025297	VMPAC-ZAS-445	5
				525 mm	8025299	VMPAC-ZAS-525	5
				565 mm	8025300	VMPAC-ZAS-565	5
				605 mm	8025301	VMPAC-ZAS-605	5
				645 mm	8025302	VMPAC-ZAS-645	5
				685 mm	8025303	VMPAC-ZAS-685	5
				725 mm	8025304	VMPAC-ZAS-725	5
				765 mm	8025305	VMPAC-ZAS-765	5
				786 mm	8032685	VMPAC-ZAS-786	5
				805 mm	8025306	VMPAC-ZAS-805	5
				845 mm	8025307	VMPAC-ZAS-845	5
				866 mm	8032686	VMPAC-ZAS-866	5
				885 mm	8025308	VMPAC-ZAS-885	5
				925 mm	8025309	VMPAC-ZAS-925	5
				946 mm	8032687	VMPAC-ZAS-946	5
				965 mm	8025310	VMPAC-ZAS-965	5
				1005 mm	8025311	VMPAC-ZAS-1005	5
				1026 mm	8032688	VMPAC-ZAS-1026	5
				1045 mm	8025312	VMPAC-ZAS-1045	5
~	_	Tie rod extender for cons	structing the valve	21 mm	8038824	VMPAC-ZAE-20	5
		terminal with tie rods in	-				
		Tie rod extender for subs		27 mm	8025281	VMPAC-ZAE-14	5
		valve terminal with a sub		2,	3023201		
	_	Sleeve, internal hex 4 m		36 mm	8025282	VMPAC-ZAH-36	5
/)		Steeve, internation 4 III		46 mm	8025283	VMPAC-ZAH-46	5
				56 mm	8025284	VMPAC-ZAH-56	5
				66 mm	8025285	VMPAC-ZAH-66	5
	_	Screw set M4x38 with ex	stornal hovagon 6 mm	38 mm	8025280	VMPAC-ZAH-66 VMPAC-M4X38	5
	_			OO IIIIII	0023280	VIVITAC-IVI4A38	)
		with sealing disc, for tie	ıuu	1			

<sup>1)</sup> Packaging unit quantity.



Ordering data						
	Code	Description			Part No.	Туре
Mounting						
	Type of mounting: Y	Spacer bolts for mounting	the valve	4 pieces	576585	VMPAC-BA
		terminal				
Separator						
	_	For pressure zone separat	tion	3 pieces	576578	VMPAC-TE-1-3-5
		р		5 p		
Power supply module	T=	T				
	Type of module block	With electrical interlinkin	g module		576569	VMPAC-SP-0
	1-40: U					
3000						
<b>V</b>						
Right-hand end plate						
	Pilot air: Z	With internal pilot air sup	ply		576563	VMPAC-EPR-IN
		, and process out	. 9			
	Dilet ein	Mile			F7/F//	VAADAC EDD EV
	Pilot air: –	With external pilot air sup	ply		576564	VMPAC-EPR-EX
Left-hand end plate	Tel	Tet	C   D 05		T	VIII S EDI NO COO
	Electrical connection:	Electrical connection at	Sub-D, 25-p		576557	VMPAC-EPL-MP-SD25
	MS1 Electrical connection:	bottom	24 addresse		57/550	VAADAC EDI AAD CD//
			Sub-D, 44-p		576559	VMPAC-EPL-MP-SD44
	MS3 Electrical connection: PT		Node with I-Port		576561	VMPAC-EPL-IP
~	Licetrical connection.		interface		370301	VIIII AC-LI L-II
			32 addresse	۵ς		
	Electrical connection:	Electrical connection at	Sub-D, 25-p		576558	VMPAC-EPL-MP-SD25-0
	MS1	top	24 addresse			
	Electrical connection:	,	Sub-D, 44-p	in,	576560	VMPAC-EPL-MP-SD44-0
	MS3		32 addresse			
	Electrical connection: PT		Node with I-	Port	576562	VMPAC-EPL-IP-O
			interface			
		32 addre		es		
	-	-				
Connecting cable for I-	-Port interface/IO-Link					
	Connecting cable: FH	9-pin socket, Sub-D, oper	r cable end	2.5 m	2376018	NEBC-C-S1WA9HS-K-2.5-N-B-LE5-PT-S10
	Connecting cable: FI	5-wire		5 m	2376019	NEBC-C-S1WA9HS-K-5-N-B-LE5-PT-S10
	Connecting cable: FJ			10 m	2376020	NEBC-C-S1WA9HS-K-10-N-B-LE5-PT-S10
	_	Dlug connector M4 2::4	nin stra!-l-1	x length <sup>1)</sup>	4106124	NEBC-C-S1WA9HS-KN-B-LE5-PT-S10
	_	Plug connector M12x1, 5-pin, straight, for connecting cable NEBC-C-S1WA9			175380	FBS-M12-5GS-PG9
		TOT CONTRECTING CADIC MEBO	C-31WAY			
<b>W</b>						
Connecting cable for n	nulti-pin plug connection					
	Connecting cable: FA	25-pin socket, Sub-D, ope	en cable end	2.5 m	2265131	NEBV-C-S1WA25HS-K-2.5-N-LE25-S10
	Connecting cable: FB	25-wire		5 m	2265132	NEBV-C-S1WA25HS-K-5-N-LE25-S10
	Connecting cable: FC			10 m	2265133	NEBV-C-S1WA25HS-K-10-N-LE25-S10
	Connecting cable: FD	44-pin socket, Sub-D, ope	en cable end	2.5 m	577376	NEBV-C-S7WA44HS-K-2.5-N-LE36-S10
	Connecting cable: FE	36-wire		5 m	577377	NEBV-C-S7WA44HS-K-5-N-LE36-S10
	Connecting cable: FG			10 m	577378	NEBV-C-S7WA44HS-K-10-N-LE36-S10
	Connecting capte: 10			10 111	סוכוונ	HEDA C-31 MM44HI3-W-10-M-FE30-310

	Code	Information on housing	Connecting	For tubing O.D.	Part No.	Туре	PU <sup>1)</sup>
		materials	thread	[mm]		,,	
ısh-in fitting, str	aight	-		_			
	Type of push-in fitting:	Nickel-plated brass	G1/8	4	578338	NPQH-D-G18-Q4-P10	10
	NPQH			6	578339	NPQH-D-G18-Q6-P10	10
				8	578340	NPQH-D-G18-Q8-P10	10
			G1/4	6	578341	NPQH-D-G14-Q6-P10	10
			,	8	578342	NPQH-D-G14-Q8-P10	10
				10	578343	NPQH-D-G14-Q10-P10	10
				12	578344	NPQH-D-G14-Q12-P10	10
			G3/8	8	578345	NPQH-D-G38-Q8-P10	10
				10	578346	NPQH-D-G38-Q10-P10	10
				12	578347	NPQH-D-G38-Q12-P10	10
				14	578348	NPQH-D-G38-Q14-P10	10
	Type of push-in fitting:	High-alloy stainless steel	G1/8	6	1366257	NPCK-C-D-G18-K6	1
	NPCK	,	,	8	1490383	NPCK-C-D-G18-K8	1
			G1/4	8	1691701	NPCK-C-D-G14-K8	1
				10	1489336	NPCK-C-D-G14-K10	1
			G3/8	10	1489614	NPCK-C-D-G38-K10	1
	Type of push-in fitting:	PBT	G1/8	4	186095	QS-G1/8-4	1
	QS		01/0	6	186096	QS-G1/8-6	1
				8	186098	QS-G1/8-8	1
			G1/4	6	186097	QS-G1/4-6	1
			01/4	8	186099	QS-G1/4-8	1
				10	186101	QS-G1/4-10	1
				12	186350	QS-G1/4-12	1
			G3/8	8	186100	QS-G3/8-8	10
			63/8	10	186102	QS-G3/8-10	10
				12	186102	QS-G3/8-10 QS-G3/8-12	1
				16	186347	QS-G3/8-16	1
						Q2 32/2 22	
h-in L-fitting			1				
	Type of push-in fitting:	Nickel-plated brass	G1/8	4	578280	NPQH-L-G18-Q4-P10	10
	NPQH			6	578281	NPQH-L-G18-Q6-P10	1
				8	578282	NPQH-L-G18-Q8-P10	1
			G1/4	6	578283	NPQH-L-G14-Q6-P10	1
				8	578284	NPQH-L-G14-Q8-P10	1
				10	578285	NPQH-L-G14-Q10-P10	1
				12	578286	NPQH-L-G14-Q12-P10	1
			G3/8	8	578287	NPQH-L-G38-Q8-P10	1
				10	578288	NPQH-L-G38-Q10-P10	10
				12	578289	NPQH-L-G38-Q12-P10	10
				14	578290	NPQH-L-G38-Q14-P10	10
	Type of push-in fitting:	PBT	G1/8	4	186116	QSL-G1/8-4	10
	QS		01/0	6	186117	QSL-G1/8-6	10
				8	186119	QSL-G1/8-8	10
			G1/4	6	186118	QSL-G1/4-6	10
			01/4	8	186120	QSL-G1/4-8	10
				10	186122	QSL-G1/4-10	10
				12	186351	QSL-G1/4-12	1
			G3/8	8	186121	QSL-G3/8-8	10
				U	100121	435 03/0 0	
				10	186123	QSL-G3/8-10	10

<sup>1)</sup> Packaging unit quantity.

Ordering data								
	Code	Information on housing materials	Connecting thread	For tubing O.D. [mm]	Part No.	Туре	PU <sup>1)</sup>	
Push-in L-fitting, lon	g							
	Type of push-in fitting: NPQH	Nickel-plated brass	G1/8	4	578263	NPQH-LL-G18-Q4-P10	10	
				6	578264	NPQH-LL-G18-Q6-P10	10	
			G1/4 6 578266 NPQH 8 578267 NPQH	NPQH-LL-G18-Q8-P10	10			
				6	578266	NPQH-LL-G14-Q6-P10	10	
				8	578267	NPQH-LL-G14-Q8-P10	10	
				10	578268	NPQH-LL-G14-Q10-P10	10	
			G3/8	10	578269	NPQH-LL-G38-Q10-P10	10	
	Type of push-in fitting: P	PBT	G1/8	4	186127	QSLL-G1/8-4	10	
				6	186128	QSLL-G1/8-6	10	
				8	186130	QSLL-G1/8-8	10	
			G1/4	6	186129	QSLL-G1/4-6	10	
				8	186131	QSLL-G1/4-8	10	
				10	186133	QSLL-G1/4-10	10	
					12	132596	QSLL-G1/4-12	10
			G3/8	8	186132	QSLL-G3/8-8	10	
				10	186134	QSLL-G3/8-10	10	
				12	186135	QSLL-G3/8-12	10	

<sup>1)</sup> Packaging unit quantity.

Ordering data						
	Code	Description		Part No.	Туре	PU <sup>1)</sup>
Pneumatic silence	r					
	-	Connecting thread	G1/8	161419	UC-1/8	1
				165004	UC-1/4	1
			G3/8	1707427	UC-3/8	1
				576759	UC-3/8-20	20
				·		
Blanking plug						
	_	Thread, external hexagon	G1/8	196720	CDVI5.0-B-G1/8	1
			G1/4	8035644	CDVI5.0-B-G1/4	1
			G3/8	196712	CDVI5.0-B-G3/8	1
User documentation	on					
	Documentation: DE	MPA-C pneumatics	German	8023739	GDCV-MPAC-DE	
	> Documentation: EN		English	8023740	GDCV-MPAC-EN	
	Documentation: FR		French	8023742	GDCV-MPAC-FR	
	Documentation: ES		Spanish	8023741	GDCV-MPAC-ES	
	Documentation: IT		Italian	8023744	GDCV-MPAC-IT	
	Documentation: ZH		Chinese	8023745	GDCV-MPAC-ZH	

<sup>1)</sup> Packaging unit quantity.

## **Festo - Your Partner in Automation**





1 Festo Inc.

5300 Explorer Drive Mississauga, ON L4W 5G4 Canada

#### **Festo Customer Interaction Center**

Tel: 1877 463 3786 Fax: 1877 393 3786



## 2 Festo Pneumatic

Av. Ceylán 3, Col. Tequesquináhuac 54020 Tlalnepantla, Estado de México

## **Multinational Contact Center**

01 800 337 8669



#### 3 Festo Corporation

1377 Motor Parkway Suite 310 Islandia, NY 11749



#### **Regional Service Center**

7777 Columbia Road Mason, OH 45040

#### **Festo Customer Interaction Center**

1 800 993 3786 1 800 963 3786 customer.service.us@festo.com

Connect with us









