## **Electrical connection technology, for AS-interface** Technical data – ASI-SS

**FESTO** 

- Configuration plug for master: the connector must be plugged into the master before the configuration process. The operating voltage can then be applied. If the plug is removed during operation of the master, the master configuration is stored in non-volatile memory.
- 2-pin



General technical data					
Туре	ASI-SS-CONFIG				
Mounting position	Any				
Protection class	IP65				
Material of contact	Bronze				
Material of contact surface	Nickel-tin alloy				
Material of housing	Polybuteneterephthalate				
Operating temperature [°C]	-40 +85				

Ordering data								
View	Type of mounting	Nominal voltage	Nominal current per contact	Product	Туре	Part No.		
				weight				
		[V]	[A]	[g]				
	Knurled screw	250 AC	3	10.7	ASI-SS-CONFIG	18 961		

