


- Compact Performance:
 Maximum flow with minimum
 space requirement
- Mounted on-site
- Short tubing lengths, short cycle times
- Huge range of valve functions
- Comprehensive electrical connection concept
- Integrated assembly and installation concept
- Pneumatic multi-connector plate
- 24-hour delivery service

FESTO

Key features



Innovative

- Cubic design for exceptional performance and low weight
- Low installation and bus connection costs
- Decentralised machines and system structures, for example
 - in handling technology
 - in conveyor technology
 - in the packaging industry
 - in sorting systems
 - in upstream machine functions
- Integrated diagnosis, condition monitoring (Fieldbus Direct)

Flexible

- Flexible and cost-effective connection of 2 to 8 valve slices
- Highly flexible thanks to:
- various pneumatic functions (valve variants)
- different pressure ranges
- vacuum switches
- integrated vacuum generation
- relay plates with floating electrical outputs
- Separator plates for the formation of pressure zones
- Blanking plates for future expansion

Reliable

- LED displays
- Manual valve overrides
- Protection class to IP65
- CE, UL symbol

Easy to mount

- Ready-to-install unit, preassembled and tested
- Lower costs for selection, ordering, assembly and commissioning
- Secure wall mounting or H-rail mounting
- Pneumatic multi-connector plate fast assembly without the need to replace the fixed tubing
- Assembly optimised for control cabinets

The pneumatic part as well as individual and multi-pin plug connections are described in detail on the following pages.


Information on the electrical functions can be found in

the chapters

- → CPV with Fieldbus Direct 4 / 4.7-2
- → AS-interface components 4 / 4.9-258
- → CP installation system 4 / 4.6-2



Key features



Equipment options

Valve functions

- 5/2-way valve, single solenoid
- 5/2-way valve, double solenoid • 2x 3/2-way valve, normally open
- 2x 3/2-way valve, normally closed
- 2x 3/2-way valve, 1x normally open, 1x closed
- 5/3-way valve, mid-position closed
- 5/3G function, mid-position closed
- 5/3E function, mid-position exhausted
- 5/3B function, mid-position pressurised
- 2x 2/2-way valve, normally closed
- 2x 2/2-way valve, 1x normally open, 1x closed
- 5/2-way valve, single solenoid, fast-switching
- Vacuum generator
- Vacuum generator and 2/2-way valve with ejector pulse

Certain terminals allow the choice of a relay plate with two floating contacts in place of a valve sub-base.

Special features

Individual connection

• 2 ... 8 valve positions, max. 16 solenoid coils

Fieldbus Direct

• 8 valve positions, max. 16 solenoid coils

Multi-pin plug connection

• 4, 6 or 8 valve positions, max. 16 solenoid coils

Electrical connection for ET200X

• 8 valve positions, max. 16 solenoid coils

AS-interface

• 2, 4 or 8 valve positions, max. 8 solenoid coils

• 4, 6 or 8 valve positions, max. 16 solenoid coils

CP installation system

FESTO

Online via: → www.festo.com/en/engineering

Key features

Valve terminal configurator

A valve terminal configurator is available to help you select a suitable valve terminal CPV. This makes it much easier for you to find the right product.

The valve terminals are fully assembled according to your order specifications and individually tested. This reduces the amount of assembly and installation required to a minimum.

You order a valve terminal type 10 using the order code.

Ordering system for type 10 → 4 / 2.1-58 Configuration 18210 WALVE TERNINAL CRYSTA N

Product Specification
Conference 1
Conference 2
Conference 2
Conference 3
Con

The illustration above provides an example of a valve terminal configuration.

The following steps explain how you arrive at the order code:

Once you have called up the Festo home page, select the online version of the digital product catalogue from the "Products" submenu: this will bring you directly to the home page for the Pneumatic Catalogue. Activate the "Direct Search" menu.


Here you can specify a "Part No." (e.g. 18210), "Type" (e.g. CPV14) or "Article Designation" (e.g. valve terminal) to find your "Search result". Click on the blue shopping basket to complete the selected product according to your specifications (this does not initiate an order).

You will then be prompted to configure the product.
Select "Configurator".
You can then configure the valve terminal step by step (from the top down) according to your requirements.
Select the "Finish" menu to continue on with the ordering process.

Key features

Electrical connections

Individual connection



Connection is independent of the control technology used. This ensures correct polarity during installation.
The connector plug is equipped with

an LED which indicates switching status, and an overvoltage protective circuit. It also features a built-in current reduction circuit.

Individual connection permits the selection of 2 to 16 solenoid coils (divided between two to eight valve slices, including in uneven stages).

FESTO

Multi-pin plug connection



Control signals from the controller to the valve terminal are transmitted via a pre-assembled multi-wire cable, which substantially reduces installation time. The current reduction circuit for the valves is also integrated in the multi-pin plug connection.

This valve terminal can be equipped with 4 to 16 solenoid coils (4, 6 or 8 valve slices).

AS-interface connection





A special feature of the AS-interface is its ability to simultaneously transmit data and supply power via a two-wire cable. The encoded cable profile prevents connection with incorrect polarity. If the valves have to be disconnected from mains power in an emergency, they can also be supplied with electrical power via a separate connection.

The valve terminal with AS-interface can be configured as follows:

- without inputs with two or four valve slices (max. 4 solenoid coils) and additional power supply set using DIL switch
- with four inputs and four valve slices (max. 8 solenoid coils)
- with four or eight inputs and four or eight valve slices (max. 8 solenoid coils) and additional power supply
- with four or eight inputs and four or eight valve slices incl. vacant position or positions (max. 6 solenoid coils) and additional power supply for A/B operation to SPEC. 2.1

Further information


→ 4 / 4.9-258

FESTO

Key features

Electrical connections

CP/CPI installation system



Valve terminals with fieldbus connection are intended for connection to higher-order fieldbus nodes or to control blocks. A fieldbus node or control block also allows the connection of decentralised input/output modules. The following fieldbus protocols are supported:


- Festo fieldbus, ABB CS31, Moeller Suconet K
- Interbus
- Allen Bradley (1771 RIO)
- DeviceNet
- Profibus DP, 12 MBd
- CANopen
- CC-Link

Four strings with up to 32 inputs and outputs can be connected to a field-bus node or control block. The CPV valve terminal is treated like an output module with up to 8 outputs (4, 6 or 8 valve slices/4 to 16 sole-noid coils per terminal) here. The connector cables transmit the power supply for the input modules and the load voltage for the valves as well as control signals.

Further information

→ 4 / 4.6-2

Fieldbus Direct



Fieldbus Direct is a system for the compact connection of a CPV, CPV-SC, CPA-SC or CDVI valve terminal to different fieldbus standards such as Profibus and DeviceNet.

The fieldbus node is directly integrated in the electrical interface of the valve terminal and therefore takes up only a minimal amount of space.


The CP string extension option allows the functions and components of the CP system to be used.

Instead of an output module with 8 digital outputs, a valve terminal with 4, 6 or 8 valve slices (4 to 16 solenoid coils per terminal) can be used.

Further information

→ 4 / 4.7-2

ET200X pneumatic interface for CPV10 and CPV14



Adaptation of the CPV valve terminal to the input/output module ET200X from Siemens:

The combination of the ET200X functional modules and the pneumatic functions of the CPV valve terminal provides a highly integrateable automation solution for systems using electrical and pneumatic drives with

- 8 valve slices for up to 16 CPV valves
- Fast and secure contacting to IP65
- CPV10 and CPV14 valve terminals
- High degree of protection IP65/IP67
- Modular design

Peripherals overview



The CPV valve terminal is of unique design. It permits the flexible combination of pneumatic performance, electrical connection technologies and a wide range of mounting options. The generously sized flow ducts and powerful flat plate silencers ensure high flow rates. This means that even comparatively large pneumatic cylinders can be driven with ease. All valves are in the form of valve slices. They are optimised for flow

performance and are also extremely compact. Two functions per valve slice (e.g. 2x 3/2-way valves) mean that twice the component density can be achieved. This saves space and reduces costs.

The cubic design permits exceptional performance yet a comparatively low weight. The benefits of this design are obvious when the valve terminal is used on a moving installation.

However robustness must not be

sacrificed in favour of compactness. The connecting thread and mounting attachments are metallic.

The manual override for the valves can be adapted for different operating situations. If, for example, a detenting manual override is required for setting-up mode, the manual override can be easily converted for that application in a way that rules out operational errors. The clear, large labelling system also contributes to

the safe operation of the valve terminal.

A particular plus is the range of electrical connection technologies supported. All types of valve actuation are possible, from individual valve connections up to bus systems with versatile expansion options. The integration of electrical input and output modules permits cost-effective solutions within the different installation concepts.

FESTO


The design principle


The cubic design provides a clearly assigned function on each side. Thus, for example, the electrical connection is mounted on the top surface.

An optional inscription label holder can be placed on the front of the valve terminal. The different combination options ensure the optimum solution for the task at hand.

- Pneumatic supply connections on the left, right or underneath
- Pneumatic working lines and functional modules (vertical linkage) from underneath
- Manual operation/identification on the front
- Electrical connection surface on the top
- Mounting surface at the back or even at the front via a pneumatic multi-connector plate

Certification		
		Certified variants
	Certification to UL 429	All
c Jus	Certification to CSA 22.2 No. 139	
	Use in hazardous locations	Multi-pin plug connection, individual connection
	Class I, Division 2, Groups A,B,C and D	
	Certification to UL 1604	
	Certification to CSA 22.2 No. 213	
	In accordance with EU directive 94/9/EC (ATEX directive)	
$\langle x3 \rangle$	Use in hazardous locations	
	In accordance with EU directive 89/336/EEC (EMC directive)	All
CE	Interference emission tested to EN 61 000-6-4	
	Interference immunity tested to EN 61 000-6-2	





- Basic electrical unit (Fieldbus
 Direct, CP installation system,
 AS-interface, multi-pin plug connection, individual connection)
- 2 Right-hand end plate with flat plate silencer
- 3 Comprehensive range of valve functions
- 4 Right-hand end plate (threaded connection not in conjunction with pneumatic multi-connector plate)
- 5 Holder for inscription label
- 6 QS push-in fittings
- 7 Functional module (vertical linkage)
- 8 Pneumatic multi-connector plate
- 9 Left-hand end plate (threaded connection not in conjunction with pneumatic multi-connector plate)
- 10 Left-hand end plate with flat plate silencer
- 11 H-rail mounting
- 12 Wall mounting
- 13 Plug socket with cable for individual connection



Key features – Pneumatic components

Valves

CPV valves are series manifold valves, i.e. in addition to the valve function they contain all of the pneumatic ducts for supply, exhaust and the working lines. The supply ducts are a central component of the valve slices

and allow a direct flow of air through the valve slices.

This helps achieve maximum flow rates. All valves have a pneumatic pilot control for optimising performance. The valve function is based on a piston spool system with a patented sealing principle that guarantees its suitability for a wide range of applications as well as a long service life. The pneumatic components and

functions are always identical for all actuator types. Most functions are also available in the various valve sizes (spacing). Restrictions are noted where applicable.

Valve fu	Valve function									
Code	Circuit symbol	Size			Description					
		10	14	18						
M	14 4 2	П		П	5/2-way valve, single solenoid					
F	1 1				Pneumatic spring return The valve slice F has a modified pilot system that permits quicker on/off					
-	14 84 5 1 3 12				switching times.					
			_	_	Only available for size 10 mm					
					• Fast switching					
					Pneumatic spring return					
J	14 4 2 12				5/2-way valve, double solenoid					
	14 84 5 ₁ 3 12									
С					2v 2/2 wayyaha single salansid					
L .	4 2				2x 3/2-way valve, single solenoid Normally closed					
	112			П	Pneumatic spring return					
					,					
	1482/84 1 12 11 3/5									
N	4 2				2x 3/2-way valve, single solenoid					
	110				Normally open					
					Pneumatic spring return The first fi					
	1482/84 1 12 11 3/5				The function of a 5/3-way valve pressurised in mid-position can be realised with these valves in the open initial position					
Н					2x 3/2-way valve, single solenoid					
' '	14 110				Normally					
					1x open (pilot control 12)					
					1x closed (pilot control 14)					
	1482/84 1 12 11 3/5				For optimised cylinder movement. Corresponds to valve function M with					
					simultaneous actuation of both solenoid coils (5/2-way, single solenoid). Since					
					the piston area on each side can be pressurised or exhausted separately, it					
					means that the cylinder can move faster.					
					Pneumatic spring return					

Valve terminal type 10 CPV, Compact Performance Key features – Pneumatic components

FESTO

Valve fur	Valve function									
Code	Circuit symbol	Size			Description					
		10	14	18						
G	14 84 5 1 3	-	_	-	5/3-way valve, mid-position closed Only available for size 18 mm Double solenoid Spring force return					
	82/84 A 2 2 112/14 112 112	•	•	-	5/3G function, mid-position closed For size 10 and 14 The valve function "mid-position closed" is created from one 2x 3/2-way valve, normally closed (code C). The valve kit CPV10-BS-5/3G-M7 or CPV14-BS-5/3G-1/8 (incorporates a double piloted non-return function) is used for this. This valve kit is intended for applications with one working pressure level per valve slice, i.e. it may not be used in dual-pressure applications (where there are different pressure levels at port 1 and 11). If other valve slices are to be used in dual-pressure mode, then the valve slice equipped with the 5/3G valve kit must be separated from compressed air duct 1 and 11 by means of a separator plate (code T). Not in first or last valve position.					
	1482/84 1 12 11 3/5	•	•	-	5/3E function, mid-position exhausted The valve function "mid-position exhausted" is created from one 2x 3/2-way valve, normally closed (code C). • Pneumatic spring return					
	1482/84 1 12 11 3/5	•	•	•	5/3B function, mid-position pressurised The valve function "mid-position pressurised" is created from one 2x 3/2-way valve, normally open (code N). • Pneumatic spring return					
D	14 82/84 1 12 11	•	-	-	2x 2/2-way valve, single solenoid Normally closed Pneumatic spring return					
	14 110 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		•	•	2x 2/2-way valve, single solenoid Normally 1x open 1x closed Control side 14 normally closed Control side 12 normally open Pneumatic spring return					

Valve terminal type 10 CPV, Compact Performance Key features – Pneumatic components

Additional pneumatic functions									
Code	Circuit symbol	Size			Description				
		10	14	18					
A	Vacuum generator 4 2 14 84 1 3/5 11	•	•	•	Vacuum generation according to the ejector principle. Vacuum slices of different widths for different suction capacities. Combinations with a number of vacuum slices and/or directional control function slices are possible on the same valve terminal. In principle, an open connection is formed between the exhaust duct 3/5 and the working line 4. When the nozzle is not switched, the resulting back pressure in the exhaust duct flows back into the working line. When the nozzle is switched, the vacuum can be greatly reduced by resulting				
E	Vacuum generator with ejector pulse	•	•	•	back pressure. This effect is improved through optimised exhausting. This effect does not occur where there is only one vacuum generator per valve terminal and where separator plates (code S) are used for separation. • Vacuum generator on control side 14 • Reset via mechanical spring and pneumatic spring • Ejector pulse on control side 12 (code E) • Note air supply and exhaust when using more than two vacuum generators				
P	2x one-way flow control valve, supply air	-	•	-	Module (actuator) for direct flange mounting on the CPV valves. Also suitable for pneumatic multi-connector plates. Different valve actuators cannot be combined. Not with valve function G Not in first or last valve position with accessories M, P, V (pneumatic multi-connector plate)				
Q	2x one-way flow control valve, exhaust air	•	•	-	Module (actuator) for direct flange mounting on the CPV valves. Also suitable for pneumatic multi-connector plates. Different valve actuators cannot be combined. Not with valve function G Not in first or last valve position with accessories M, P, V (pneumatic multi-connector plate)				
V	One-way flow control valve for vacuum	•	•	_	The module CPVBS-GRZ-V has a built-in non-return valve as well as a throttle function for adjusting the ejector pulse. The non-return valve serves to temporarily maintain the vacuum, even if the vacuum generator is switched off. The module is suitable for vacuum generators (code A, E). • Not in first or last valve position with accessories M, P, V (pneumatic multiconnector plate)				

Valve terminal type 10 CPV, Compact Performance Key features – Pneumatic components

FESTO

Creating pressure zones

Different pressures at port 1 and 11 result in two pressure levels per valve. This means, for example, that a cylinder drive can be extended with high pressure and retracted with low pressure to save energy.

The maximum number of pressure zones possible is determined by the combination of the following components:

- Use of a separator plate
- End plate pair type
- Valve slice type

You can divide the CPV valve terminal into 2 to 4 pressure zones by using separator plates.

Separat	Separator plates										
Code	Graphical symbol	Size	size		Note						
		10	14	18							
T	Separator plate (for formation of pressure zones), supply duct 1 separated Pilot exhaust air 82/84 Pilot supply air 12/14 Exhaust air 3/5 Main air 1 Main air 11	•	•	•	A separator plate (code T) is used to separate the duct for the air supply (port 1 and 11) to provide two pressure zones. Not in first or last valve position Not with compressed air supply A, B, C, D, U, V, W, X						
S	Separator plate (for formation of pressure zones), supply duct 1 and exhaust 3/5 separated Pilot exhaust air		-	•	The separator plate (code S) interrupts the exhaust duct 3/5 as well as the supply duct 1 and 11. This plate should be used if one of the pressure zones is under vacuum to avoid any effects on the vacuum or to prevent backpressure on neighbouring valve functions. • Not in first or last valve position • Not with compressed air supply A, B, C, D, U, V, W, X (single-side compressed air supply)						
L	Vacant position (spare position) Pilot exhaust air		•	•	A vacant position is formed by using a blanking plate (code L) and a valve can be positioned here at a later date.						
R	Relay plate (2 floating contacts)	-	•	-	A relay plate (code R) with (normally open contact) can also be used instead of a valve slice. Each relay plate has two relays for actuating two electrically isolated outputs. Load capacity: 24 V DC, 1 A. • Connecting cable KRP-1-24 • An inscription label holder cannot be used						

Valve terminal type 10 CPV, Compact Performance

Key features – Pneumatic components

Examples: Pneumatic supply


External pilot supply air, flat plate silencer at both ends

Pneumatic supply via pneumatic multi-connector plate

Code H

The diagram opposite shows an example for the configuration and connection of the compressed air supply with external pilot supply air. Port 12/14 on the pneumatic multiconnector plate is equipped with a fitting for this purpose. Ports 3/5 and 82/84 are drawn off via the flat plate silencer.

One separating seal each can be used optionally to create pressure zones.




Internal pilot supply air, ducted exhaust air or screw-in silencer

Pneumatic supply via end plates: Code Z

The diagram opposite shows an example for the configuration and connection of the compressed air supply with internal pilot supply air. Here the pilot supply air is branched at the left-hand end plate of port 1 or 11. Ports 3/5 and 82/84 are drawn off via the screw-in silencer.

One separating seal each can be used optionally to create pressure zones.




Valve terminal type 10 CPV, Compact Performance Key features – Pneumatic components

FESTO

Example: Creating pressure zones


CPV with separator plate T

The valve terminal CPV facilitates the creation of up to 4 pressure zones. The diagram shows an example for the configuration and connection of four pressure zones using separator plate code T – with external pilot supply air.



- 2 Blast pulse 2 bar
- 4 Friction stroke 4 bar

Key features - Pneumatic components



The two end plates which supply the valve slices with pressure and exhaust them are a characteristic feature of a CPV valve terminal.

- Large duct cross sections ensure maximum flow rates even when multiple valves are switched in parallel
- Large flat plate silencers in the end plates
- Internal/external pilot supply air

Each individual valve is supplied with compressed air from two individual ducts (supply ports 1/11) and exhausted via a large, integrated exhaust duct (exhaust 3/5). This design permits unique flexibility and functionality. It is the easiest way of realising a number of pressure zones per terminal or combinations of vacuum applications.

The valve terminal is supplied via end plates, either on the left, on the right,

or on both sides. End plate combinations other than those listed are possible (on request).

FESTO

Pilot supply air


Internal pilot supply air:

Internal pilot supply air can be selected if the supply pressure at pneumatic port 1 is 3 ... 8 bar. With internal pilot supply air, the branch line is located in the right-hand end plate. There is no port 12/14.

External pilot supply air:

External pilot supply air is required if the supply pressure at pneumatic port $1 \text{ is } \le 3 \text{ bar or } \ge 8 \text{ bar. In this case,}$ pressure of $3 \dots 8 \text{ bar is applied at}$ port 12/14. If a gradual pressure build-up in the system using a pressurised on-off valve is required, external pilot supply air should be selected whereby the control pressure applied during switch-on is already very high.

End plates



Example of an end plate: The figure shows a left-hand end plate with external pilot supply air. The exhaust ports 3/5 and 82/84 can be fitted with threaded connections or silencers. Ports 12/14 and 11 are not provided in end plates used for internal pilot supply air. Port 82/84 is always present and should be fitted with a silencer. Port 12/14 is internally connected with port 1.

When using a separator plate to form two pressure zones, pilot supply air at both sides is always required.

Valve terminal type 10 CPV, Compact Performance Key features – Pneumatic components

FESTO

	nd plate combination for compressed air supply via end plate										
Code	Graphical symbol	Size			Note						
	Type of pilot air supply (pilot supply air)	10	14	18							
U	Internal pilot supply air 82/84 3/5 12/14 11 11	•	•	•	 Ports in right-hand end plate only No pressure zone separation permissible Not suitable for vacuum 						
V	Internal pilot supply air 82/84 3/5 12/14 11	•	•	•	 Ports in left-hand end plate only No pressure zone separation permissible Not suitable for vacuum 						
W	External pilot supply air 82/84 3/5 12/14 11 1			•	 Ports in right-hand end plate only No pressure zone separation permissible Suitable for vacuum 						
X	External pilot supply air 82/84 12/14 11 11	•	•	•	Ports in left-hand end plate only No pressure zone separation permissible Suitable for vacuum						
Y	Internal pilot supply air 82/84 12/14 11 1	•	•	•	 Ports in left-hand and right-hand end plate Max. 3 pressure zones Valves to the left of the separator plate suitable for vacuum 						
Z	External pilot supply air 82/84 12/14 11 11 11	-	•	•	 Ports in left-hand and right-hand end plate Max. 4 pressure zones Suitable for vacuum 						

• Maximum number of pressure zones: 3

• Only for accessories M, P, V (pneumatic multi-

Suitable for vacuum


connector plate)


Valve terminal type 10 CPV, Compact Performance

12/14

11

Key features – Pneumatic components






Valve terminal type 10 CPV, Compact Performance Key features – Pneumatic components

FESTO

End pla	ate combination for compressed air supply via pneumatic multi-connector plate with flat pla	te sil	ence	r	
Code	Graphical symbol	Size			Note
	Type of pilot air supply (pilot supply air)	10	14	18	
E	External pilot supply air 82/84 3/5 12/14 11 1	•			 Ports on pneumatic multi-connector plate Exhaust air vented via flat plate silencers at right Pressure zone separation only permissible with separator plate (code T) Maximum number of pressure zones: 4 Suitable for vacuum Only for accessories M, P, V (pneumatic multi-connector plate)
F	External pilot supply air 82/84 3/5 12/14 11 1	•			 Ports on pneumatic multi-connector plate Exhaust air vented via flat plate silencers at left Pressure zone separation only permissible with separator plate (code T) Maximum number of pressure zones: 4 Suitable for vacuum Only for accessories M, P, V (pneumatic multi-connector plate)
G	Internal pilot supply air 82/84 3/5 12/14 11 1	•	•	•	 Ports on pneumatic multi-connector plate Exhaust air vented via flat plate silencers at left Pressure zone separation only permissible with separator plate (code T) Maximum number of pressure zones: 3 Not suitable for vacuum Only for accessories M, P, V (pneumatic multi-connector plate)
Н	External pilot supply air 82/84 3/5 12/14 11 1	•	•	•	 Ports on pneumatic multi-connector plate Exhaust air vented via flat plate silencers at both ends Pressure zone separation permissible Suitable for vacuum Only for accessories M, P, V (pneumatic multi-connector plate)
J	Internal pilot supply air 82/84 3/5 12/14 11 1	•	•	•	 Ports on pneumatic multi-connector plate Exhaust air vented via flat plate silencers at both ends Pressure zone separation permissible Maximum number of pressure zones: 3 Valves to the left of the separator plate suitable for vacuum Only for accessories M, P, V (pneumatic multi-connector plate)
K	Internal pilot supply air 82/84 3/5 12/14 11 1	•	•	•	 Ports on pneumatic multi-connector plate Exhaust air vented via flat plate silencers at right Pressure zone separation permissible Maximum number of pressure zones: 3 Suitable for vacuum in combination with separator plate Only for accessories M, P, V (pneumatic multi-connector plate)

Key features – Pneumatic components

Pneumatic connection



The working lines are located directly in the valve slices. Threaded connections and Quick Star push-in fittings (QS) are available for different tubing sizes. The supply ports are located in the end plates or in the pneumatic


multi-connector plate.
Push-in fittings are available fully

assembled.
The following working lines can be selected:


- Large push-in fittings: Code A
- Small push-in fittings: Code B
- Threaded connections: Code C
 Connection sizes for the threaded and
 QS push-in fittings can be found in the table below.

FESTO

Pneumatic multi-connector plate



CPV valve terminal



Connect	Connection sizes									
Connect	ion to ISO 5599	CPV10	CPV14	CPV18	Remarks					
1/11	Main air	G ¹ /8	G1/4	G3/8	Fitting in end plate or pneumatic multi-connector plate					
2/4	Working line	M7 (QS6/QS4)	G ¹ /8 (QS8/QS6)	G1/4 (QS10/QS8)	Connection in valve slice, connection for push-in fitting in brackets					
3/5	Exhaust air right-hand/left-hand end plate or	G ³ /8	G ¹ / ₂	G ¹ / ₂	For ducted exhaust air					
	pneumatic multi-connector plate	G1/4	G3/8	G½	For silencer					
12/14	Pilot supply air connection/pilot exhaust air connection	M5	G ¹ / ₈	G1/4	For ducted exhaust air					
82/84	Exhaust air right-hand/left-hand end plate or	M5	G1/8	G1/4	For ducted exhaust air					
	pneumatic multi-connector plate	M7 (M5) ¹⁾	G ¹ / ₈	G ¹ / ₄	For silencer					

1) with pneumatic multi-connector plate with flange

Key features - Pneumatic components



Pneumatic multiple connector plate

A one-piece sub-base which contains both working lines and supply ports is available in the form of a pneumatic multiple connector plate. These subbases allow the valve terminal as a pneumatic "function" to be separated from the tubing connections.

The pneumatic multiple connector plate permits different mounting options from wall mounting to direct passage through a housing wall.

Service-friendly and flexible connection technology thanks to the following:


- Common connection via the pneumatic multiple connector plate with all connections on one side
- The valve terminal can be removed/

fitted using only 4 screws, whereby the pneumatic components remain fully connected

- Quick removal/fitting
- No faults upon recommissioning as a result of incorrect connection of tubing


Pneumatic multiple connector plate for wall/machine mounting

with flange, code P



- Multiple connector plate projects past the end plates
- Through mounting holes (without thread) in the flange
- Two additional holes running crossways through this multiple connector plate also allow rear mounting of the CPV valve terminal

without flange, code M




- Multiple connector plate fits flush with the end plates
- Mounting holes (with thread) for wall or foot mounting are on the connection side of the pneumatic multiple connector plate

1 Mounting holes


Pneumatic multiple connector plate for control cabinet assembly

with supply connections, code GQC



- Multiple connector plate projects past the end plates
- Mounting holes (with thread) in the flange
- Multiple connector plate with seal

without supply connections, code GQD



- Multiple connector plate fits flush with the end plates
- The mounting holes (with thread) are on the connection side of the pneumatic multiple connector plate
- Multiple connector plate with seal

1 Mounting holes



Note


The outer valve slices cannot be equipped with valve extensions (e.g. one-way flow control valve) when using the pneumatic multiple

connector plate with mounting flange. CPV valve terminals with flat plate silencers are only suitable for wall mounting.



Valve terminal type 10 CPV, Compact Performance

Key features – Pneumatic components



Valve terminal type 10 CPV, Compact Performance Key features – Pneumatic components


FESTO

Pneumatic connection: Fittin	g set for pneumati	supply								
	Code	Port	Designation	Size 10	Size 14	Size 18				
	Pneumatic			QS6	QS8	QS10				
	supply			Туре	Туре	Туре				
	Without pneun	natic multi-connector pl	ate							
	А, В	82/84	Blanking plug	B-M5	B-1/8	B-1/4				
		3/5	Blanking plug	B-3/8	B-1/2	B-1/2				
3.		1	Push-in fitting	QS-1/8-8-I	QS-1/4-10-I	QS-3/8-12-I				
	C, D	82/84	Blanking plug	B-M5	B-1/8	B-1/4				
**		3/5	Blanking plug	B-3/8	B-1/2	B-1/2				
		1	Push-in fitting	QS-1/8-8-I	QS-1/4-10-I	QS-3/8-12-I				
		12/14	Push-in fitting	QSM-M5-6-I	QS-1/8-8-I	QS-1/4-10-I				
	NA (* c)	100								
	•	c multi-connector plate		D M7	D 1/2	D 1/				
	E, F, H	82/84	Blanking plug	B-M7	B-1/8	B-1/4				
		3/5	Blanking plug	B-1/4	B-3/8	B-1/2				
		1/11	Push-in fitting	QS-1/8-8-I	QS-1/4-10-I	QS-3/8-12-I				
		12/14	Push-in fitting	QSM-M7-6-I	QS-1/8-8-I	QS-1/4-10-I				
	G, J, K	82/84	Blanking plug	B-M7	B-1/8	B-1/4				
	0, ,, 10	3/5	Blanking plug	B-1/4	B-3/8	B-1/2				
		on right in 1, left	Push-in fitting	QS-1/8-8-I	QS-1/4-10-I	QS-3/8-12-I				
		on right in 11	Blanking plug	B-1/8	B-1/4	B-3/8				
		12/14	Blanking plug	B-M7	B-1/8	B-1/4				
		12/11	2109 \$1003	J,	5 70	5 /4				
. 1333	With pneumatic multi-connector plate code: P, GQC									
	E, F, H	82/84	Blanking plug	B-M5	B-1/8	B-1/4				
		3/5	Blanking plug	B-1/4	B-3/8	B-1/2				
		1/11	Push-in fitting	QS-1/8-8-I	QS-1/4-10-I	QS-3/8-12-I				
		12/14	Push-in fitting	QSM-M5-6-I	QS-1/8-8-I	QS-1/4-10-l				
	G, J, K	82/84	Blanking plug	B-M5	B-1/8	B-1/4				
		3/5	Blanking plug	B-1/4	B-3/8	B-1/2				
		on right in 1, left	Push-in fitting	QS-1/8-8-I	QS-1/4-10-I	QS-3/8-12-I				
		on right in 11	Blanking plug	B-1/8	B-1/4	B-3/8				
		12/14	Blanking plug	B-M5	B-1/8	B-1/4				

Key features - Pneumatic components



Functional modules



CPV10-BS-5/3G-M7 CPV14-BS-5/3G-1/8

Valve kit 5/3G for creating a 5/3-way function, mid-position closed, for size 10 and 14:


The valve function "mid-position closed" is created from one valve slice with 2x 3/2-way valve, normally closed (valve function code C).

The valve kit CPV10-BS-5/3G-M7 or CPV14-BS-5/3G-1/8 (which incorporates a double piloted non-return function) is used for this.

This valve kit is intended for applications with one working pressure level per valve slice, i.e. it may not be used in dual-pressure applications (where there are different pressure levels at port 1 and 11).

FESTO

Additional functions for valve positions



These valve extensions (vertical linkage) can be used to add further pneumatic functions to CPV valve terminals size 10 and 14:

- Two one-way flow control valves for flow regulation directly at the valve terminal for
 - supply air flow control
 - exhaust air flow control
- The vacuum flow control module must be used with the vacuum generator with or without ejector pulse and provides a non-return function and adjustable ejector pulse.


The additional functions cannot be used in the first or last valve position in combination with the pneumatic multi-connector plate.

2x one-way flow control valve for supply air flow control Additional function code P



CPV10-BS-2xGRZZ-M7 CPV14-BS-2xGRZZ-1/8

2x one-way flow control valve for exhaust air flow control Additional function code Q



CPV10-BS-2xGRAZ-M7 CPV14-BS-2xGRAZ-1/8

Vacuum flow control module

Additional function code V



CPV10-BS-GRZ-V-M7 CPV14-BS-GRZ-V-1/8

Key features - Assembly



Mounting options

The valve terminals have holes for four mounting screws, the mounting side is the pneumatic threaded connector side. These holes are also used to mount a valve terminal on the pneumatic multi-connector plate.

There are other mounting options in addition to this mounting method:

- H-rail mounting
- Wall mounting
- Wall mounting via flanged multiconnector plate
- On rear side via wall mounting
- On head side (CPV10/14 with IC connection only)
- Mounting via through-hole in wall

The attachments are mounted with a screw and fixing bolt on the left-hand and right-hand end plates.

Examples of mounting options

H-rail: Mounting code H



for valve terminal CPV10/14: CPV10/14-VI-BG-NRH-35 (mounting code H)




for valve terminal CPV18: CPV18-VI-BG-NRH-35 (mounting code H)




H-rail to EN 60715, not for accessories M, P, V (pneumatic multiconnector plate)




Wall mountings Through-hole in wall, for example on



Wall mounting via pneumatic multiconnector plate



Attachment for wall mounting




for valve terminal CPV10/14: CPV10/14-VI-BG-RWL-B (mounting code U)



for valve terminal CPV18: CPV18-VI-BG-RW (mounting code W)



Attachment for individual connection (mounting code X) and ET200X (included in the scope of delivery)



for valve terminal CPV10/14: CPV...-VI-BG-ET200X



Valve terminal type 10 CPV, Compact Performance Key features – Display and operation

Manual override tool

Three types of manual override are available:

- Non-detenting with slide
- Detenting
- Blocked

A subsequent conversion of the manual override (MO) from nondetenting to detenting or blocked is possible at any time.

The locking clip on the valve must be removed to this end. This is only possible after the individual valve has been removed or the tie rod of the valve terminal has been released.



See the user documentation for instructions.

FESTO

Code	Graphical symbol	Size			Note
2000		10	14	18	
N	Manual override, non-detenting	•	•	•	In the "non-detenting" version, the blue slide is held via a locking clip. A pointed object (e.g. pen, etc.) can be used to activate the MO through the opening.
R	Manual override, detenting	•	•	•	In the "detenting" version, the manual override is activated by pushing the slide. The non-locking function can be realised by re-installing the locking clip.
V	Manual override, blocked	•	•	•	In the "blocked" version, non-detenting or detenting activation of the MO is prevented by means of a cover. Like the push-in locking clip, the cover can be added subsequently, but cannot be detached from the valve once this has been done.



Key features – Display and operation

Display and operation

You will find the following LEDs for displaying the switching status on the electrical connections of the CPV valve terminal:


- Display of the switching status of the pilot solenoid coil 12 for output 2
- Display of the switching status of the pilot solenoid coil 14 for output 4
- Readable from the "top" as well as from the "front"

With an individual connection the LED is located in the connector plug.

Inscription labels


- Clip with inscription field on cable socket (with individual connection)
- Inscription clips on connection node (multi-pin plug, AS-interface, CP installation system, Fieldbus Direct)

CPV valve terminal with individual connection



- 1 Pre-assembled connection socket for each pilot solenoid coil
- 2 Inscription label (for each connection socket)
- 3 Yellow LED, signal status display for pilot solenoid coils (for each connection socket)
- 4 Earth terminal

CPV valve terminal with multi-pin plug connection



- 5 Terminal lug for pilot solenoid coil 14
- 6 Terminal lug for pilot solenoid coil 12
- Sub-D multi-pin plug (9-pin for valve terminals with 4 valves, 25-pin for valve terminals with 6 or 8 valves)

Key features - Display and operation

Inscription system

Inscription labels can be affixed as follows:

- On the top of the electrical interface unit
- On the inscription label holder
 The inscription label holder permits
 the addition of inscription labels,
 protects the manual overrides and
 prevents them from being accidentally
 activated. The inscription labels are
 used to record additional information
 regarding the valves.

The inscription label holders can be ordered together with the valve terminal using the order code. The relevant inscription labels are supplied in a frame and are ordered separately using part numbers.

Transparent inscription label holder


The transparent inscription label holder CPV...-VI-ST-... offers a further labelling option, for example for large paper labels that can be read from both sides.

The inscription label holder cannot be used together with relay plate.



The Word templates for CPV label holders can be found at: www.festo.com/en/engineering

FESTO



Ordering data											
	Code	Designation	Туре	Part No.							
Inscription label holde	scription label holder										
	Z	Holder for inscription labels	CPVVI-BZ-T	Dependent on the number of valve positions 4 / 2.1-58							
	T	Holder for inscription labels, transparent	CPVVI-ST-T								
1											
Inscription labels	,										
	-	6x10 mm, 64 pieces in frames	IBS-6x10	18 576							
	-	9x20 mm, 20 pieces in frames	IBS-9x20	18 182							

FESTO Key features – Electrical components

Electrical connection

Contacts which are fitted on the top of the valve slice form the interface for various electrical connection options. The electrical connection is attached from above using four screws. This


means that the valve terminal can be adapted to different electrical requirements or fieldbus protocols using the same pneumatic part.

Electrical power 80% [mA] 60% 40%

20%

CPV10/14 valves are actuated by means of an integrated current reduction circuit, which reduces power consumption and heat build-up. This current reduction circuit is integrated in the electrical interface unit (multipin plug or fieldbus connection) or in the individual connecting cable. During switch-off, the voltage peaks are limited to 38 V DC.

Individual connection



Integration is only carried out in the pneumatic part with individual connection whereby the solenoid valves are connected with individual cables.

40 60 80

t [ms]


Ordering data					
	Code	Designation		Туре	Part No.
Plug socket with cabl	e for individual co	nnection, electrical, for CPV10/14			
//	D	Plug socket with cable (suitable for chain link trunking)	2.5 m	KMYZ-7-24-2,5-LED-PUR	193 683
	E	Plug socket with cable (suitable for chain link trunking)	5 m	KMYZ-7-24-5-LED-PUR	193 685
	F	Plug socket with cable (suitable for chain link trunking)	10 m	KMYZ-7-24-10-LED-PUR	196 070
	•		•		*
Plug socket with cabl	e for individual co	nnection, electrical, for CPV18			
.//	D	Plug socket with cable	2.5 m	KMEB-2-24-2,5-LED	174 844
	E		5 m	KMEB-2-24-5-LED	174 845




Connecting cables are pre-assembled. They include a protective circuit and an LED indicating the operating status.

Valve terminal type 10 CPV, Compact Performance

Key features – Electrical components






1) not for IC connection

FESTO

Key features – Electrical components

Multi-pin plug connection



In addition to pneumatic integration, multi-pin plug connection results in integration of the electrical side as well, and facilitates connection from the control cabinet to the valve terminal via a single cable.

Sub-D 9-pin and 25-pin plugs are used for connection. The plug housing of the KMP-...- cable provides the Sub-D connectors with IP65 protection.

The following sizes of plug connector are used:

- 4-fold valve terminal: 9-pin
- 6-fold valve terminal: 25-pin
- 8-fold valve terminal: 25-pin

Pre-assembled connecting cables are available for easy connection.
Standard lengths of 5 m and 10 m can be supplied. The pre-assembled connecting cables are also available in a design suitable for chain link trunking.

The cable KMP6-... can alternatively be used for applications with IP40 protection.

Ordering data						
	Code	Designation			Туре	Part No.
Multi-pin cable						
	Y	Plug socket (Sub-D plug can be crimped), for self-assembly	9-pin		SD-SUB-D-BU9	18 708
			25-pin		SD-SUB-D-BU25	18 709
11	R	Connecting cable, IP65, polyvinyl chloride	9-pin	5 m	KMP3-9P-08-5	18 698
			25-pin		KMP3-25P-16-5	18 624
	S		9-pin	10 m	KMP3-9P-08-10	18 579
Multi-pin cable Y R			25-pin		KMP3-25P-16-10	18 625
T	-	Connecting cable, IP65, polyurethane	9-pin	5 m	KMP4-9P-5-PUR	193 014
		(suitable for chain link trunking)	25-pin		KMP4-25P-5-PUR	193 018
	-		9-pin	10 m	KMP4-9P-10-PUR	193 015
			25-pin		KMP4-25P-10-PUR	193 019
	-	Connecting cable, IP65, polyvinyl chloride	9-pin	5 m	KMP4-9P-5-PVC	193 012
		(suitable for chain link trunking)	25-pin		KMP4-25P-5-PVC	193 016
			9-pin	10 m	KMP4-9P-10-PVC	193 013
			25-pin		KMP4-25P-10-PVC	193 017
/)	ъ	Connecting cable, IP40, polyvinyl chloride	9-pin	2.5 m	KMP6-09P-8-2,5	531 184
M ~6"		Only for CPV10/14	25-pin		KMP6-25P-20-2,5	530046
			9-pin	5 m	KMP6-09P-8-5	531 185
**************************************			25-pin		KMP6-25P-20-5	530 047
			9-pin	10 m	KMP6-09P-8-10	531 186
			25-pin		KMP6-25P-20-10	530 048

Valve terminal type 10 CPV, Compact Performance Key features – Electrical components

Pin allocation - Pre-assemble	d multi-pin cable (viewed from plu	ıg-in direction)			
	Plug view	Pin	Core colour	Valve 24 V DC	
Cable with 25-pin Sub-D plug fo	or 6-fold and 8-fold valve terminal	<u> </u>			
		1	White	1	14
	140 01	2	Green		12
	150 02	3	Yellow	2	14
	II 0.3II	4	Grey		12
	160 04	5	Pink	3	14
	170 05	6	Blue		12
6/	180	7	Red	4	14
	190 07	8	Magenta		12
	200 0 8	9	Grey-pink	5	14
	210 09	10	Red-blue		12
	010	11	White-green	6	14
	230	12	Brown-green		12
	240 012	13	White-yellow	7	14
	250 O13	14	Yellow-brown		12
		15	White-grey	8	14
		16	Grey-brown		12
		17			
		18			
		19			
		20			
		21			
		22			
		23			
		24	Brown	(0 V) ¹⁾	
		25	Black	(0 V) ¹⁾	
Cable with 9-pin Sub-D plug for	r 4-fold valve terminal				
		1	White	1	14
	(6 O 1)	2	Green		12
		3	Yellow	2	14
	8 ○ ○ 3	4	Grey		12
	9004	5	Pink	3	14
/ /	0 5	6	Blue		12
4/	<u> </u>	7	Red	4	14
		8	Magenta		12
		9	Black	Common	

^{1) 0} V for positive switching control signals; connect 24 V for negative switching control signals; mixed operation is not permitted.

Key features - Electrical components



Valve terminal type 10 - AS-interface valve terminal

The AS-interface permits the spatial distribution of individual components or small component groups.

The AS-interface connection of valve terminal type 10 can be used to control 3, 4, 6 or 8 solenoid coils.

The valve terminal cover contains the LEDs which indicate the operating status and the protective circuit for the valves. The standard AS-interface protocol permits a maximum of

4 inputs and 4 outputs in one unit. The use of 2 AS-interface slaves in one valve terminal means that 8 inputs and 8 outputs can be controlled in an 8-fold valve terminal (8 solenoid coils).

All CPV valve terminals can be operated using additional functions, e.g. relay plates or vacuum generators.

Valve terminals CPV with inputs are also available for A/B operation to SPEC 2.1.

AS-interface control


- For 2, 4 or 8 valves
- Great variety thanks to the wide range of modules in the system

AS-interface with A/B operation


- For 3 or 6 valves
- All of the benefits of the simple installation system are retained
- 100% more inputs/master

- 50% more outputs/master
- Improved diagnosis of peripheral errors
- More AS-interface functions in Specifications 2.1 and 3.0.
- → AS-interface components Info 220 4 / 4.9-258


AS-interface valve terminal with auxiliary power supply



AS-interface valve terminal with auxiliary power supply and inputs



CP installation system, valve terminal



Integration of valve terminal type 10 into a fieldbus system or independent control system is accomplished by connecting the terminals to the corresponding fieldbus node or control block with simple, pre-assembled terminal connectors.

The installation system integrates the valve terminal CPV and various I/O modules, etc. into a single installation concept.

The 5-pin connecting cables carry the supply power and control signals. The valve terminal cover contains the LEDs which indicate the operating status and the protective circuits for the valves.


Max. 8 valve slices for up to 16 CPV valves

The CP string is used to exchange the input and output states of the connected modules with the CP fieldbus node.

➤ CP installation system 4 / 4.6-2

Key features – Electrical components





Fieldbus Direct is a system for the connection of one valve terminal to nine different fieldbus standards. The most important systems including Profibus, Interbus, DeviceNet and CANopen are supported.

The CP string extension option allows

the functions and components of the CP installation system to be used.

The optional string extension allows an additional valve terminal and I/O modules to be connected to the Fieldbus Direct fieldbus node.

The valve terminals are available in all three sizes, 10, 14 and 18 mm, each with 8 valve slices.

FESTO

→ CPV with Fieldbus Direct 4 / 4.7-2


ET200X pneumatic interface for CPV10 and CPV14

Adaptation of CPV valve terminal to Siemens ET200X I/O module. The combination of the ET200X functional modules and the pneumatic functions of the CPV valve terminal provides a highly integrateable automation solution for systems using electrical and pneumatic drives with


- 8 valve slices for up to 16 CPV
- Fast and secure contacting to IP65
- CPV 10 and CPV 14 valve terminals
- High degree of protection IP65/IP67
- Modular design

- Large number of I/O modules
 - digital I/O
 - analogue I/O
 - supply branching for activation of AC motors
- PROFIBUS DP interface

Mounting kit for ET200X CPV-...-VI-BG-ET200X (included in the scope of delivery)



Specific data on the ET200X pneumatic interface can be found in Siemens product catalogues.







FESTO

Instructions for use

Equipment

Operate your equipment with unlubricated compressed air if possible.
Festo valves and cylinders are
designed for operation under normal
use without any additional lubrication, yet still have a long service life.
The quality of compressed air downstream from the compressor must
correspond to that of unlubricated
compressed air. If possible, do not
operate all of your equipment with
lubricated compressed air. The
lubricators should, where possible,
always be installed directly upstream
of the actuator used.

Incorrect additional oil and too high an oil content in the compressed air reduce the service life of the valve terminal.

Use Festo special oil OFSW-32 or the alternatives listed in the Festo catalogue (as specified in DIN 51524 HLP32; basic oil viscosity 32 CST at 40 °C).

Bio-oils

When using bio-oils (oils which are based upon synthetic or native ester, e.g. rapeseed oil methyl ester), the maximum residual oil content of 0.1 mg/m³ must not be exceeded (see ISO 8573-1 Class 2).

Mineral oils

When using mineral oils (e.g. HLP oils to DIN 51524, parts 1 through 3) or similar oils based on poly-alphaolefins (PAO), the maximum residual oil content of 5 mg/m³ must not be exceeded (see ISO 8573-1 Class 4). A higher residual oil content irrespective of the compressor oil cannot be permitted, as the basic lubricant would be flushed out over time.

Valve terminal type 10 CPV, Compact Performance Technical data

Flow rates of up to CPV10: 400 l/min CPV14: 800 l/min CPV18: 1600 l/min

- 「】 - Valve width CPV10: 10 mm CPV14: 14 mm CPV18: 18 mm

- **** - Voltage 24 V DC



General technical data										
		CPV10	CPV14	CPV18						
Constructional design		Electromagnetically actuated piston spool valve								
Lubrication		Lubrication for life, PWIS-free (free of paint-wetting impairment substances)								
Type of mounting		Via pneumatic multi-connector plate								
		Via backwall								
		On H-rail								
Mounting position		Any								
Manual override		Non-detenting/detenting/blocked								
Width	[mm]	10	14	18						
Nominal size	[mm]	4	6	8						
Nominal flow rate without	[l/min]	400	800	1600						
fitting										
Pneumatic connections ¹⁾										
Pneumatic connection		Via end plate								
Supply port	1/11	G1/8	G ¹ / ₄	G3/8						
Exhaust port	3/5	G ³ / ₈ (G ¹ / ₄)	G ¹ / ₂ (G ³ / ₈)	G ¹ / ₂						
Working lines	2/4	M7	G1/8	G1/4						
Pilot supply air port	12/14	M5 (M7)	G1/4	G1/4						
Pilot exhaust air port 82/84		M5 (M7)	G1/8	G1/4						

¹⁾ Connection dimensions in brackets for pneumatic multi-connector plate



Technical data

Operating and environmen													
Valve function order code	M	F	J	N	С	Н	G	D	I	А	E		
Operating medium	Filtered compressed air, lubricated or unlubricated, inert gases → 4 / 2.1-34												
Grade of filtration [µm]				erage po	re size)								
Operating pressure	With internal pilot supply air	[bar] 3 8											
	With external pilot supply air	[bar]	-0.9 +10										
	$P_1 = P_{11}$												
	Pilot supply air P ₁₂ =P ₁₄	[bar]	3 8										
Ambient temperature [°C]				-5 +50 (vacuum generators: 0 +50)									
Temperature of medium [°C]				-5 +50 (vacuum generators: 0 +50)									
Storage temperature [°C]				-20 +40									
Relative air humidity at 25	95 with no condensation												
Corrosion resistance class	CRC ¹⁾		2 (vacuum generators 1)										

1) Corrosion resistance class 1 according to Festo standard 940 070
Components requiring low corrosion resistance. Transport and storage protection. Parts that do not have primarily decorative surface requirements, e.g. in internal areas that are not visible or behind covers.

Corrosion resistance class 2 according to Festo standard 940 070

Components requirements which are in direct contact with a normal industrial environment or media such as coolants or lubricating agents.

Valve response times [ms]												
Valve function order code		М	F	J	N	С	Н	G	D	1	А	E
CPV10												
Response times	on	17	13	-	17	17	17	20	15	15	-	15
	off	27	17	-	25	25	25	30	17	17	-	17
	change-	-	-	10	-	-	-	-	-	-	-	-
	over											
CPV14												
Response times	on	25	-	-	24	24	24	22	13	13	-	13
	off	35	-	-	30	30	30	30	16	16	-	16
	change-	-	-	12	-	-	-	-	-	-	-	-
	over											
CPV18												
Response times	on	18	-	-	18	18	18	14	14	14	-	14
	off	26	-	-	24	24	24	32	20	20	-	20
	change-	-	-	12	-	-	-	-	-	-	-	-
	over											

Valve terminal type 10 CPV, Compact Performance Technical data

Electrical data				
		CPV10	CPV14	CPV18
Operating voltage	[V]	24 DC (+10/-15%)		
Edge gradient (IC and MP only)	[V/ms]	> 0.4 minimum voltage increase	time to reach the high-current ph	ase
Limitation of the voltage peaks	[V]	38 DC		
when switching off				
Residual ripple	[Vss]	4		
Electrical power consumption	[W]	0.6 (0.45 at 21 V);	0.9 (0.65 at 21 V)	1.5 (0.95 at 21 V)
		(with CPV10-M11H 0.65)		
Duty cycle	[%]	100%		·
with pilot supply air P ₁ =P ₁₁	[bar]	-0.9 +10		
Electromagnetic compatibility of CP	valve	Interference emission tested to E	N 61 000-6-4, "Interference emis	sion in industrial areas"
terminal with CP connection		Interference immunity ¹⁾ tested to	EN 61 000-6-2, "Interference im	munity in industrial areas"
Protection against electric shock (pr	rotection	By means of PELV power supply to	ınit	
against direct and indirect contact t	to			
EN 60204-1/IEC 204)				
Explosion protection class ²⁾		In accordance with EU directive (ATEX directive) 94/9/EC, II 3G/D E	Ex nA T5 X −5°C ≤ Ta ≤ 50°C T 80°C P65
UL ²⁾		Certification to UL 429, CSA 22.2	2 No. 139	
CE certification ²⁾		In accordance with EU directive 8	39/336/EEC (EMC directive)	
Protection class to EN 60 529		IP65 (for all types of signal trans	mission in assembled state)	

The maximum signal line length is 30 m
 → Page 4 / 2.1-7

Relay plate				
		CPV10	CPV14	CPV18
Operating voltage	[V]	20.4 26.4 DC		-
Electrical power consumption		1.2 W		-
No. of relays		2 with electrically isolated outputs		-
Load current circuit		Each 1 A/24 V DC +10%		-
Relay response times	on	5 ms		-
	off	2 ms		-

Data on vibrations and	shock in accordance wit	h DIN/EC68			
		CPV10	CPV14	CPV18	
Vibration resistance		Tested to DIN/IEC 68/E	N 60 068, Parts 2-6		
	Transport	3.5 mm travel at 2 9) Hz		
		1 g acceleration at 9	. 200 Hz		
	Operation/use	0.35 mm travel at 10 .	60 Hz		
		5 g acceleration at 60	150 Hz		
Shock resistance		Tested to DIN/IEC 68, P	Parts 2-27		
		30 g acceleration with	11 ms duration		
Continuous shock resista	ance	Tested to DIN/IEC 68, P	Parts 2-29		

Valve terminal type 10 CPV, Compact Performance Technical data

FESTO


Materials			
	CPV10	CPV14	CPV18
Basic electrical unit	Die-cast aluminium, polyamide, nit	rile rubber	
Valve slices	Die-cast aluminium		
Valve module 5/3G	Cast aluminium, polyacetate		
Relay plate	Polyamide, brass		
Blanking plate/separator plate	Polyamide		
End plates	Die-cast aluminium		
Flat plate silencer	Die-cast aluminium, polyethylene		
Pneumatic multi-connector plate	Wrought aluminium alloy		
Inscription label holder	Polyacetate, polyvinyl chloride		
Seal	Nitrile rubber, hydrogenated nitrile	rubber	


Product weight			
Approx. weights	[g] CPV10	CPV14	CPV18
Electrical connection plates with AS-i connection			
on CP valve terminals with 2 valve positions	85	130	275
on CP valve terminals with 4 valve positions	110	175	355
on CP valve terminals with 8 valve positions	400	460	-
Electrical connection plates with CP connection			
on CP valve terminals with 4 valve positions	145	230	375
on CP valve terminals with 6 valve positions	180	250	450
on CP valve terminals with 8 valve positions	200	300	540
Electrical connection plates with MP connection			
on CP valve terminals with 4 valve positions	110	170	400
on CP valve terminals with 6 valve positions	140	230	425
on CP valve terminals with 8 valve positions	165	275	515
End plates (2 pieces)	160	280	740
Pneumatic multi-connector plate			
on CP valve terminals with 2 valve positions	120	270	520
on CP valve terminals with 4 valve positions	165	390	750
on CP valve terminals with 6 valve positions	225	510	870
on CP valve terminals with 8 valve positions	270	630	1300
Flat plate silencer	147	234	-
Relay plate	35	55	-
Blanking plate	25	45	90
Separator plate	25	45	90
Valve sub-bases, vacuum generators	65	110	260
Functional module: 5/3G function	46	105	-
Functional module: One-way flow control valves	25	54	125


Technical data

Vacuum generators


Vacuum as a function of operating pressure









Air consumption as a function of operating pressure




Evacuation time for a volume of 1 litre at P_{nominal}



Suction capacity as a function of partial vacuum at P_{nominal}




FESTO



Valve terminal type 10 CPV, Compact Performance Technical data

		L1	L2	L3	L4	L5	L6	L7	L8	D1	D2	D3	D4
	2-fold	50	41.8										
	3-fold	60	51.8										
	4-fold	70	61.8										
CPV10	5-fold	80	71.8	62	71	52.8	15	9.5	11.8	M7	G1/8	G3/8	M5
	6-fold	90	81.8										
	7-fold	100	91.8										
	8-fold	110	101.8										
	2-fold	68	58										
	3-fold	82	72										
	4-fold	96	86										
CPV14	5-fold	110	100	78	89	58.8	20	9.5	11.8	G1/8	G1/4	G1/2	G1/8
	6-fold	124	114										
	7-fold	138	128										
	8-fold	152	142										
	2-fold	96	85.5										
	3-fold	114	103.5										
	4-fold	132	121.5										
CPV18	5-fold	150	139.5	106.5	118	73	20	9.5	21.6	G1/4	G3/8	G1/2	G1/4
	6-fold	168	157.5										
	7-fold	186	175.5										
	8-fold	204	193.5										


FESTO



Valve terminal type 10 CPV, Compact Performance Technical data


		L1	L2	L3	L4	L5	L6	L7	L8	L28	L29	L30	D1
	2-fold	50	41.8							67	84		
	3-fold	60	51.8							77	94		
	4-fold	70	61.8							87	104		
CPV10	5-fold	80	71.8	62	71	52.8	15	9.5	11.8	97	114	2.5	M7
	6-fold	90	81.8							107	124		
	7-fold	100	91.8							117	134		
	8-fold	110	101.8							127	144		
	2-fold	68	58							85	102		
	3-fold	82	72							99	116		
	4-fold	96	86							113	130		
CPV14	5-fold	110	100	78	89	58.8	20	9.5	11.8	127	144	3	G1⁄8
	6-fold	124	114							141	158		
	7-fold	138	128							155	172		
	8-fold	152	142							169	186		
	2-fold	96	85.5							127	158		
	3-fold	114	105.5							145	176		
	4-fold	132	121.5							163	194		
CPV18	5-fold	150	139.5	106.5	118	73	20	9.5	21.6	181	212	4.55	G1/4
	6-fold	168	157.5							199	230		
	7-fold	186	175.5							217	248		
	8-fold	204	193.5							235	266		

FESTO




		L1	L2	L3	L4	L5	L6	L7	L9	L10	L11	L12	L13
	4-fold	70	61.8							10	50		
CPV10	6-fold	90	81.8	62	71	52.8	15	9.5	39.5	10	70	23.5	58.8
	8-fold	110	101.8							20	70		
	4-fold	96	86							23	50		
CPV14	6-fold	124	114	78	89	58.8	20	9.5	61.8	27	70	23.5	58.8
	8-fold	152	142							41	70		
	4-fold	132	121.5							41	50		
CPV18	6-fold	168	157.5	106.5	118	73	20	9.5	88.4	49	70	28	63
	8-fold	204	193.5							67	70		

Valve terminal type 10 CPV, Compact Performance




		L1	L2	L3	L4	L5	L6	L7	L12	L14	L15	L16	L17
	2-fold	50	41.8						-	40.0	20.4	2.5	25.5
CPV10	4-fold	70	61.8	62	71	52.8	15	9.5	23.5	10.9	38.1	2.5	35.5
	8-fold	110	101.8	1					23.3	-	-	-	-
	2-fold	68	58						-	14	52		35.5
CPV14	4-fold	96	86	78	89	58.8	20	9.5	23.5	14	32)	33.3
	8-fold	152	142						23.3	-	-	-	-
	2-fold	96	85.5						-	27.4	68.2	10.4	40
CPV18	4-fold	132	121.5	106.5	118	73	20	9.5	28	27.4	00.2	10.4	40
	8-fold	204	193.5	1					20	-	-	-	-

FESTO



		L1	L2	L3	L4	L5	L6	L7	L18	L19	L20	L21
	2-fold	50	41.8						-	-	-	-
CPV10	4-fold	70	61.8	62	71	52.8	15	9.5	10.9	38.1	35	3
	8-fold	110	101.8						10.4	38.6	31.9	3
	2-fold	68	58						-	-	-	-
CPV14	4-fold	96	86	78	89	58.8	20	9.5	18.8	46.8	43.3	5
	8-fold	152	142						18.8	46.8	46.3	5


Valve terminal type 10 CPV, Compact Performance



		L1	L2	L3	L4	L5	L6	L7	L9	L10	L11	L12	L22
CPV10	4-fold	70	61.8							10	50		
	6-fold	90	81.8	62	71	52.8	15	9.5	39.5	10	70	23.5	46
	8-fold	110	101.8							20	70		
CPV14	4-fold	96	86							23	50		
	6-fold	124	114	78	89	58.8	20	9.5	61.8	27	70	23.5	46
	8-fold	152	142							41	70		
CPV18	4-fold	132	121.5							41	50		
	6-fold	168	157.5	106.5	118	73	20	9.5	88.4	49	70	28	50.5
	8-fold	204	193.5	1						67	70		

FESTO

Technical data



9.5

79.8

36.6

31.2

41.7

59.6

35.9

CPV18

8-fold


204

193.5

106.5


118

Valve terminal type 10 CPV, Compact Performance




		L1	L2	L3	L4	L5	L6	L7	L23	L24	L25	L26	L27
CPV10	8-fold	110	101.8	62	71	52.8	15	9.5	35.5	34.6	25	26.2	36.7
CPV14	8-fold	152	142	78	89	58.8	20	9.5	52.8	34.6	46	26.2	36.7
CPV18	8-fold	204	193.5	106.5	118	7	20	9.5	79.8	36.6	72	31.2	41.7

FESTO





	CPV10							CPV14						
	2-fold	3-fold	4-fold	5-fold	6-fold	7-fold	8-fold	2-fold	3-fold	4-fold	5-fold	6-fold	7-fold	8-fold
L1	74	84	94	104	114	124	134	90	104	118	132	146	160	174
L2	48	58	68	78	88	98	108	64	78	92	106	120	134	148
L3	58	68	78	88	98	108	118	74	88	102	116	130	144	158




				CPV18			
	2-fold	3-fold	4-fold	5-fold	6-fold	7-fold	8-fold
L1	96	114	132	150	168	186	204
L2	66	84	102	120	138	156	174


Valve terminal type 10 CPV, Compact Performance






FESTO






Valve terminal type 10 CPV, Compact Performance Technical data



		L1	L2	L3	L4	L5	L6	D1	D2	D3	D4	D5
	2-fold	49.5	42.5	70	63	15	10	M7	G1/8	G1/4	M7	M4
CPV10	4-fold	69.5	62.5									
Crv10	6-fold	89.5	82.5									
	8-fold	109.5	102.5									
	2-fold	67.5	53.5	86.6	76.6	20	14	G1/8	G1/4	G3/8	G1/8	M4
CPV14	4-fold	95.5	81.5									
Cr V14	6-fold	123.5	109.5									
	8-fold	151.5	137.5									
	2-fold	95.5	87.5	119.6	108	20	18	G1/4	G3/8	G1/2	G1/4	M5
CPV18	4-fold	131	123									
CIVIO	6-fold	167	159									
	8-fold	203	195									


Valve terminal type 10 CPV, Compact Performance Technical data

FESTO




		L1	L2	L3	L4	L5	L6	D1	D2	D3	D4
	2-fold	74	62	73	40	15	10	M7	G1/8	G1/4	M5
CPV10	4-fold	94	82								
CFVIO	6-fold	114	102								
	8-fold	134	122								
	2-fold	92	80	89	59	20	14	G1/8	G1/4	G3/8	G1/8
CPV14	4-fold	120	108								
CFV14	6-fold	148	136								
	8-fold	176	164								
	2-fold	119	107	118	88	20	18	G1/4	G3/8	G ¹ / ₂	G1/4
CPV18	4-fold	155	143								
Crv10	6-fold	191	179								
	8-fold	227	215								

Valve terminal type 10 CPV, Compact Performance




		L1	L2	L3	B1	B2	В3	D1	D2	H1
	2-fold	49.5	-	10	70	40	15	M7	M5	10
CPV10	4-fold	69.5	28							
CFVIU	6-fold	89.5	49							
	8-fold	109.5	68							
	2-fold	67.5	13	14	86.6	55.6	15.5	G ¹ /8	M5	14
CPV14	4-fold	95.5	40							
CFV14	6-fold	123.5	68							
	8-fold	151.5	96							





		L1	L2	L3	B1	B2	В3	D1	D2	D3	D4	H1
	2-fold	82	62	10	84	64	10	M7	M5	G1/4	G1/8	15
CPV10	4-fold	102	82									
CFVIU	6-fold	122	102									
	8-fold	142	122									
	2-fold	102	82	14	99	79	10	G1/8	M5	G3/8	G1/4	20
CPV14	4-fold	130	110									
Cr v 14	6-fold	158	138									
	8-fold	186	166									

FESTO




Туре	B1	D1	D2	H1	L1	L2
CPV10-BS-5/3G-M7	9.9	M7	M2.5	22	55.8	23
CPV14-BS-5/3G-1/8	13.8	G1/8	M3	28	72.8	30





Туре	B1	D1	D2	H1	H2	L1	L2	L3
CPV10-BS-2xGRM7	9.9	M7	M2.5	26	6	55.8	41.4	22.9
CPV10-BS-2xGRZ-VM7							-	
CPV14-BS-2xGR1/8	13.8	G1/8	M3	32	8	72.8	53.15	28.65
CPV14-BS-2xGRZ-V1/8							-	

Valve terminal type 10 CPV, Compact Performance



Valve terminals type 10 CPV, Compact Performance – Individual connection Ordering data – Modular products




	pneumatic part	Size	No. of valv positions	e Working ports	Electrical connection	Manual override	Pneumatic supply
18 200	10P	10	2 8	A, B, C	IC	N, R	U, V, W, X, Y, Z,
18 210		14					A, B, C, D, E, F,
18 220		18					G, H, J, K
Order							
example			_			_	
18 200	10P	- 10	- 8	С	- IC	- N	- U

Or	derir	ig table						
Siz	e.		10	14	18	Condi- tions	Code	Enter code
M	1	Module No.	18 200	18 210	18 220			
		Basic configuration						
	2	Valve terminal, pneumatic part	Valve terminal type 10, CF	γ			10P	10P
	3	Size	10	14	18			
	4	No. of valve positions	2, 3, 4, 5, 6, 7, 8					
	5	Working ports	Large push-in connectors					
			(QS6)	(QS8)	(QS10)	1	Α	
			Small push-in connectors					
			(QS4)	(QS6)	(QS8)	1	В	
			None, threaded connectio		1			
			(M7)	(G ¹ / ₈)	(G1/4)		С	
	6	Electrical connection	Individual electrical conne	ection			-IC	-IC
	7	Manual override	Pushing				-N	
	_		Detenting				-R	
	8	Pneumatic supply	Internal pilot air supply, s				-U	
			Internal pilot air supply, s				-V	
			External pilot air supply, s				-W	
		<u></u>	External pilot air supply, s				-X -Y	
		Compressed air supply	Internal pilot air supply, s	supply at both ends, di	icted exhaust air		-Y	
		via end plates or	F	1 (1 (1 1 1			-	
		pneumatic multiple connector plate	External pilot air supply, s	supply at both ends, di	icted exnaust air		-Z	
		Compressed air supply	Internal pilot air supply, s	unnly at right flat plat	o ciloncor		-A	
		via end plates with flat	Internal pilot air supply, s				-A -B	
		plate silencer	External pilot air supply, s				-C	
		plate shelleel	External pilot air supply, s	,,,,			-D	
		Compressed air supply	External pilot air supply, s			2	-E	
		via pneumatic multiple	External pilot air supply, s		-	2	-F	
		connector plate with flat			<u> </u>	2	-G	
		connector plate with flat Internal pilot air supply, supply at both ends, flat plate silencer at left External pilot air supply, supply at both ends, flat plate silencers at both ends			,	2	-H	
			Internal pilot air supply, s	2	-J			
4			Internal pilot air supply, s	, , .	,	2	-K	

1 A, B Not if the other equipment consists solely of valve function T, S (plate with duct separation) 2 E, F, G, H, J, K and L (blanking plate)

Only with pneumatic multiple connector plate M, P, GQC, GQD, V as an accessory. Only with an even number of valve positions



Valve terminals type 10 CPV, Compact Performance – Individual connection Ordering data – Modular products



M Mand	atory data							
Equipment	t at valve position () 7						
9 Valve fui	nctions: M. J. N. C. H	H, G, D, I, F, A, E, T, S,	.L					
,	, ,,,,	., 0, 0, ., ., ., ., 2, ., 0,	-					
	O Options							
		ons at pneumatic v	alve position 0 7:	: P, Q, V				
	LO Additional funct	ons at pneumatic v	alve position 0 7:	: P, Q, V				
1	LO Additional funct	ions at pneumatic vo	alve position 0 7:	P, Q, V	5	6	7	

0r	derin	ig table						
Siz	ze		10	14	18	Condi-	Code	Enter
						tions		code
Ψ		Equipment at valve position 0 7				3	-	-
M	9	Valve functions	5/2-way valve, single solen	oid			M	Enter the
			5/2-way valve, double sole	noid			J	pneu-
			2x 3/2-way valve, normally	open			N	matic
			2x 3/2-way valve, normally	closed			С	equip-
			2x 3/2-way valve, 1x norma	ally open, 1x closed			Н	ment
			5/3-way valve, mid-position	n closed		4	G	selected
			2x 2/2-way valve, normally	closed			D	in the
			2x 2/2-way valve, 1x norma	ally open, 1x closed			I	order
			5/2-way valve, single	_	_		F	code
			solenoid, fast-switching					
			Vacuum generator			5	Α	
			Vacuum generator with ejec			5	E	
			Plate with duct separation,	1/11 closed		6	T	
			Plate with duct separation,	1/11 and 3/5 closed		6 7	S	
			Blanking plate				L	
0	10	Additional function at	2x one-way flow control val	ve, supply air	-	8	Р	
		valve position 0 7	2x one-way flow control val	ve, exhaust air	-	8	Q	
Ψ			Vacuum flow control modul	le	-	8 9	٧	

_				
	3 Equipmen	nt at valve position 0 7	7 S	If the equipment to the right of S consists solely of valve function D, I
		Valve positions must be equipped throughout without any gaps		(2x 2/2-way valve), L (blanking plate), then only with pneumatic supply Y, Z
	4 G	Not in first or last valve position		F, G and pneumatic multiple connector plate M, P as an accessory
	5 A, E	Note air supply and exhaust when using more than 2 vacuum generators	8 P, Q, V	Cannot be combined with valve function G (5/3-way valve).
	6 T, S	Only one valve function T or S (plate with duct separation) possible per valve terminal,		Not in first or last valve position with pneumatic multiple connector plate
		but not in first or last valve position		M, P as an accessory
		and only with pneumatic supply Y, Z, E, F, G, H, J, K (supply air at both ends);	9 V	Must be combined with valve function D, I (2x 2/2-way valve), E (vacuum
		the equipment to the right must consist of more than valve function L (blanking plate)		generator with ejector pulse)

	Transfer order code	Transfer order code											
	0	1	2	3	4	5	6	7					
-													

9 + 10

Valve terminals type 10 CPV, Compact Performance – Individual connection Ordering data – Modular products



→	O Option	Options											
	Acces- sories	Pneumatic multiple connector plate	Inscription label holder	Mounting	Connecting cable for individual	Fitting set for end plates	User documentation						
		M, P, GQC, GQD, V	Z, T	H, W, U, X	D,E,F	A	D, E, F, I, S, V						
	+	11				-	D 12						

Ore	derir	ig table								
Siz	е			10	14	18	Condi- tions	Code		Enter code
$oldsymbol{\Lambda}$		Accessories						+		+
0	11 Pneumatic multiple connector plate			Standard pneumatic multip	ole connector plate		10	M	İ	
				Special pneumatic multiple connector plate			10	P		ı
				Pneumatic multiple connector plate, with sealing ring,			10 11	GQC		ı
				with supply connections		_				ı
				· ·	ctor plate, with sealing ring,	_	11 12	GQD		Ī
				without supply connections						Ī
				, ,	eparation for pneumatic multiple connector plate			V		<u> </u>
	Inscription label holder			For inscription labels				Z		Ī
				Transparent				T		<u> </u>
		Mounting		H-rail mounting				Н		ı
				-	-	Wall mounting		W		ı
				Wall mounting		-		U		ı
				Mounting kit for ET200X		-		Х		I
		Connecting cable for indi-	2.5 m	1 99				D		
		vidual connection	5 m	1 99				Е		
			10 m	1 99		-		F		-
		Fitting set for end plates		Connector and silencer			14	Α		
	12	User documentation		German				-D		1
			English				-E		ı	
				French				-F		1
				Italian				-1		1
				Spanish				-S		İ
				Swedish				-V		i

10	M, P, GQC, V	Only with an even number of valve positions and only with pneumatic supply 4, 2, E, F, G, H,	13	V	Only with working port C (threaded connection).
		J, K (supply air at both ends)			Not with additional function P, Q, V
11	GQC, GQD	Not with additional function P, Q, V.	14	Α	Not with pneumatic multiple connector plate V (pre

eparation for pneumatic Cannot be combined with valve function G (5/3-way valve) multiple connector plate) an as accessory 12 GQD Only with pneumatic supply U, V, W, X, Y, Z, A, B, C, D




Valve terminals type 10 CPV, Compact Performance — Multi-pin plug Ordering data — Modular products

FESTO

M Mandatory data →											
Module No.	Valve terminal, pneumatic part	Size	No. of valve positions	Working ports	Electrical connection	Manual override	Pneumatic supply				
18 200	10P	10	4, 6, 8	A, B, C	MP	N, R, V	U, V, W, X, Y, Z,				
18 210		14					A, B, C, D, E, F,				
18 220		18					G, H, J, K				
Order											
example 18 200	10P	- 10	- 8	C	– MP	_ N] - U				
10 200	107	- 10] - <u>[8</u> 4	[_ MP	N	- U 8				

Orde	erir	ng table						
Size	j		10	14	18	Condi-	Code	Enter
						tions		code
M	1	Module No.	18 200	18 210	18 220			
		Basic configuration						
	2	Valve terminal, pneumatic part	Valve terminal type 10), CPV			10P	10P
	3	Size	10	14	18			
-	4	No. of valve positions	4, 6, 8					
:	5	Working ports	Large push-in connect					
			(QS6)	(QS8)	(QS10)	1	Α	
			Small push-in connect					
			(QS4)	(QS6)	(QS8)	1	В	
	None, threaded connection only				ı			
			(M7)	(G ¹ / ₈)	(G1/4)		С	
—	6	Electrical connection	Electrical multi-pin plug connection				-MP	-MP
	7	Manual override	Pushing				-N	
			Detenting				-R	
			Covered				-V	
	8	Pneumatic supply		ly, supply at right, ducted			-U	
			Internal pilot air supply, supply at left, ducted exhaust air				-V	
			External pilot air supply, supply at right, ducted exhaust air				-W	
			External pilot air supply, supply at left, ducted exhaust air				-X	
		Compressed air supply	Internal pilot air supply, supply at both ends, ducted exhaust air				-Y	
		via end plates or					1	
		pneumatic multiple connector plate	External pilot air supp	ly, supply at both ends, du	icted exhaust air		-Z	
		Compressed air supply	Internal nilot air sunn	ly, supply at right, flat plat	e silencer		-A	
		via end plates with flat		ly, supply at left, flat plate			-B	
		plate silencer		ly, supply at right, flat plat			-C	
		F		ly, supply at left, flat plate			-D	
		Compressed air supply External pilot air supply, supply at both ends, flat plate silencer at right			2	-E		
		via pneumatic multiple External pilot air supply, supply at both ends, flat plate silencer at left			<u> </u>	2	-F	
		connector plate with flat Internal pilot air supply, supply at both ends, flat plate silencer at left				2	-G	
		plate silencer			t plate silencers at both ends	2	-H	
		,			t plate silencers at both ends	2	-J	
Ψ				ly, supply at both ends, fla	•	2	-K	

1 A, B Not if the other equipment consists solely of valve function T, S (plate with duct separation), L 2 E, F, G, H, J, K (blanking plate) and R (relay plate) Only with pneumatic multiple connector plate M, P, GQC, GQD, V as an accessory



Valve terminals type 10 CPV, Compact Performance — Multi-pin plug Ordering data – Modular products



>	M Mandatory da	ita									
	Equipment at valve	e position 0 7									
	O Value functions, MINCHCDIEA ETCID										
	9 Valve functions: M, J, N, C, H, G, D, I, F, A, E, T, S, L, R										
	O Options										
	10 Addit	ional functions at p	neumatic valve pos	ition 0 7: P, Q, V							
	Valve position										
	0	1	2	3	4	5	6	7			
-	M 0 ± 10	М	М	М	M	M	М	J			

10	derir	g table						
Si	ze		10	14	18	Condi-	Code	Enter
						tions		code
Ψ		Equipment at valve position 0 7				3	-	-
M	9	Valve functions	5/2-way valve, single solen	oid			M	Enter the
			5/2-way valve, double sole	noid			J	pneu-
			2x 3/2-way valve, normally	open			N	matic
			2x 3/2-way valve, normally	2-way valve, normally closed				
			2x 3/2-way valve, 1x norma	2-way valve, 1x normally open, 1x closed				
			5/3-way valve, mid-position	way valve, mid-position closed				
			2x 2/2-way valve, normally	/2-way valve, normally closed				
			2x 2/2-way valve, 1x norma	ally open, 1x closed			I	order
			5/2-way valve, single				F	code
			solenoid, fast-switching	_	_			
			Vacuum generator			5	Α	
			Vacuum generator with ejec	ctor pulse		5	E	
			Plate with duct separation,	1/11 closed		6	T	
			Plate with duct separation,	1/11 and 3/5 closed		6 7	S	
		Blanking plate						
			Relay plate		-		R	
0	10	Additional function at	2x one-way flow control val	ve, supply air	-	8	Р	
		valve position 0 7	2x one-way flow control valve, exhaust air				Q	
Ψ		Vacuum flow control module –					٧	

3	Equipment a	at valve position 0 7	7 S	If the equipment to the right of S consists solely of valve function D, I
		Valve positions must be equipped throughout without any gaps		(2x 2/2-way valve), L (blanking plate), then only with pneumatic supply Y, Z,
4	G	Not in first or last valve position		F, G and pneumatic multiple connector plate M, P as an accessory
5	A, E	Note air supply and exhaust when using more than 2 vacuum generators	8 P, Q, V	Cannot be combined with valve function G (5/3-way valve).
6	T, S	Only one valve function T or S (plate with duct separation) possible per valve terminal,		Not in first or last valve position with pneumatic multiple connector plate
		but not in first or last valve position		M, P as an accessory
		and only with pneumatic supply Y, Z, E, F, G, H, J, K (supply air at both ends);	9 V	Must be combined with valve function D, I (2x 2/2-way valve), E (vacuum
		the equipment to the right must consist of more than valve function L (blanking plate), R		generator with ejector pulse)
		(relay plate)		

Transfer	order	code
----------	-------	------

	0	1	2	3	4	5	6	7
-[

Valve terminals type 10 CPV, Compact Performance — Multi-pin plug Ordering data — Modular products

FESTO

→	O Opti	ons					
	Acces- sories	Pneumatic multiple connector plate	Inscription label holder	Mounting	Electrical connection	Fitting set for end plates	User documentation
		M, P, GQC, GQD, V	Z, T	H, W, U	Y, R, S, K,L	A	D, E, F, I, S, V
	+	11					D 12

rderi	ng table								
ize			10	14	18	Condi- tions	Code	En	
1	Accessories						+	+	
- 1		nultiple connector plate	Standard pneumatic mult	inle connector plate		10	M	H	
1	i ilcullatic i	nuttiple connector plate	Special pneumatic multip	· · · · · · · · · · · · · · · · · · ·		10	P		
				ector plate, with sealing ring,		10 11	GQC		
			with supply connections	ector plate, with Seating ring,	-	10(11)	duc		
			Pneumatic multiple conne	ector plate, with sealing ring,		11 12	GQD		
			without supply connection	1S	_				
			Preparation for pneumation	multiple connector plate	'	10 13	V		
	Inscription I	abel holder	For inscription labels			14	Z		
			Transparent			14	T		
	Mounting		H-rail mounting				Н		
			-	-	Wall mounting		W		
			Wall mounting	<u> </u>	-		U		
	Electrical	9-pin with 4-fold,	Straight socket, IP65, Sub	-D, 9-/25-pin, for multi-pin pl	ug connection		Υ		
	connection	25-pin with 6-/8-fold	Pre-assembled multi-pin	cable, 5 m			R		
			Pre-assembled multi-pin	cable, 10 m			S		
		Connecting 2.5 m	1 99		_		К		
		cable for relay 5 m	1 99		-		L		
	Fitting set fo	r end plates	Connector and silencer			15	Α		
12	User docum	entation	German				-D		
			English				-E		
			French				-F		
			Italian				-1		
			Spanish				-S		
			Swedish				-V		

10	M, P, GQC, \	Only with pneumatic supply Y, Z, E, F, G, H, J, K (supply at both	ends)
----	--------------	---	-------


11 **GQC, GQD** Not with additional function P, Q, V.

Cannot be combined with valve function G (5/3-way valve) 12 GQD Only with pneumatic supply U, V, W, X, Y, Z, A, B, C, D

13 **V** Only with working port C (threaded connection). Not with additional function P, Q, V $\,$

14 **Z, T** Cannot be combined with valve function R (relay plate)

15 **A** Not with pneumatic multiple connector plate V (preparation for pneumatic multiple connector plate) an as accessory



Valve terminals type 10 CPV, Compact Performance – AS-interface Ordering data – Modular products



M Mandatory Module No.	Valve terminal,	7 1	Size	1	No. of valve positions	Working ports	$\overline{}$	Electrical	Manual override
modute No.	pneumatic part		JIZC		No. of valve positions	Working ports		connection	munuat overna
18 200	10P		10		2, 4, 8	A, B, C		AS, AZ, AE, AO, BE	N, R, V
18 210			14						
18 220			18						
Order									
example		_							
18 200	10P		10	-	8	С	_	AE	– N
1	2		3		4	5		6	7

Or	derir	ng table						
Siz	ze		10	14	18	Condi-	Code	Enter
						tions		code
M	1	Module No.	18 200	18 210	18 220			
		Basic configuration						
	2	Valve terminal, pneumatic part	Valve terminal type 10, CPV	1			10P	10P
	3	Size	10	14	18			
	4	No. of valve positions	2, 4, 8		2, 4			
	5	Working ports	Large push-in connectors in	. "				
			(QS6)	(QS8)	(QS10)	1	Α	
			Small push-in connectors in	n working port				
			(QS4)	(QS6)	(QS8)	1	В	
			None, threaded connection	only				
		Working ports	(M7)	(G1/8)	(G1/4)		C	
	6	Electrical connection	AS-interface node without a	dditional power supply		-1-2	-AS	
			AS-interface node			2	-AZ	
			AS-interface node electrical	inputs	-	2	-AE	
			AS-interface node electrical	inputs without additional		2	-AO	
			power supply					
			AS-interface node electrical	inputs, A/B slave	-	2	-BE	
	7	Manual override	Pushing				-N	
			Detenting				-R	
4			Covered				-V	

1 A, B Not if the other equipment consists solely of valve function T, S (plate with duct separation), L (blanking plate) and R (relay plate)

2 AS, AZ, AE, AO, BE

Note maximum number of coils and valve position equipment ightharpoonup Table on page

Type to be discontinued: Do not use for new designs!



Valve terminals type 10 CPV, Compact Performance – AS-interface Ordering data – Modular products



→	M Mandatory data	→
	Pneumatic supply	_
	U, V, W, X, Y, Z, A, B, C, D, E, F, G, H, J, K	J
_	U	
	8	

0	rderi	ng table						
S	ize		10	14	18	Condi-	Code	Enter
						tions		code
7	8	Pneumatic supply	Internal pilot air supply, su	ipply at right, dud	ted exhaust air		-U	
M]		Internal pilot air supply, su	ipply at left, duct	ed exhaust air		-V	
			External pilot air supply, su	upply at right, du	cted exhaust air		-W	
			External pilot air supply, su	upply at left, duct	ed exhaust air		-X	
		Compressed air supply	Internal pilot air supply, su	upply at both end	s, ducted exhaust air		-Y	
		via end plates or						
		pneumatic multiple	External pilot air supply, su	upply at both end	s, ducted exhaust air		-Z	
		connector plate						
		Compressed air supply	Internal pilot air supply, su		·		-A	
		via end plates with flat	Internal pilot air supply, su	upply at left, flat p	olate silencer		-B	
		plate silencer	External pilot air supply, su	11 / 0 !	<u>'</u>		-C	
			External pilot air supply, su				-D	
		Compressed air supply	1 11 2	117	s, flat plate silencer at right	3	-E	
		via pneumatic multiple	External pilot air supply, su			3	-F	
		connector plate with flat	Internal pilot air supply, su	* * * *		3	-G	
		plate silencer	External pilot air supply, su	upply at both end	s, flat plate silencers at both en		-H	
			Internal pilot air supply, su	ipply at both end	s, flat plate silencers at both en	ds 3	-J	
4			Internal pilot air supply, su	ipply at both end	s, flat plate silencer at right	3	-K	

3 E, F, G, H, J, K

Only with pneumatic multiple connector plate M, P, GQC, GQD, V

Valve terminals type 10 CPV, Compact Performance – AS-interface



Ordering data – Modular products

Equipment at valve position 0 7 9 Valve functions: M, J, N, C, H, G, D, I, F, A, E, T, S, L, R O Options 10 Additional functions at pneumatic valve position 0 7: P, Q, V								
Equipment at valve position 0 7 9 Valve functions: M, J, N, C, H, G, D, I, F, A, E, T, S, L, R O Options								
9 Valve fu	unctions: M, J, N, C, H	I, G, D, I, F, A, E, T, S,	L, R					
1 1		ons at pneumatic va	alve position 0 7	: P, Q, V				
Valve pos	ition							
_	1	2	3	4	5	6	7	
0								

01	derir	ng table						
Si	ze		10	14	18	Condi-	Code	Enter
						tions		code
T		Equipment at valve position 0 7				4	-	-
M	9	Valve functions	5/2-way valve, single solen	oid			M	Enter the
			5/2-way valve, double soler	noid			J	pneu-
			2x 3/2-way valve, normally	open			N	matic
			2x 3/2-way valve, normally	closed			С	equip-
			2x 3/2-way valve, 1x norma	illy open, 1x closed			Н	ment
			5/3-way valve, mid-position	n closed		5	G	selected
			2x 2/2-way valve, normally	closed			D	in the
			2x 2/2-way valve, 1x norma	illy open, 1x closed			I	order
			5/2-way valve, single				F	code
			solenoid, fast-switching	_	_			
			Vacuum generator			6	Α	
			Vacuum generator with ejec	tor pulse		6	E	
			Plate with duct separation,	1/11 closed		7	T	
			Plate with duct separation,	1/11 and 3/5 closed		7 8	S	
			Blanking plate				L	
			Relay plate	-	-		R	
0	10	Additional function at	2x one-way flow control valv	ve, supply air	-	9	Р	
		valve position 0 7	2x one-way flow control valv	ve, exhaust air	-	9	Q	
Ψ			Vacuum flow control modul	e	-	9 10	٧	



the equipment to the right must consist of more than valve function L (blanking plate),

	Transfer order code 0 1 2 3 4 5 6 7								
	0	1	2	3	4	5	6	7	
- [

R (relay plate)

Valve terminals type 10 CPV, Compact Performance – AS-interface Ordering data – Modular products

FESTO

→	O Option	ons					
	Acces- sories	Pneumatic multiple connector plate	Inscription label holder	Mounting	Connecting cable for relay plate	Fitting set for end plates	User documentation
		M, P, GQC, GQD, V	Z, T	H, W, U	K,L	A	D, E, F, I, S, V
	+					-	D
		11					12

Ord	derir	ng table							
Siz	e			10	14	18	Condi- tions	Code	Enter code
4		Accessories						+	+
0	11	Pneumatic multiple connector	or plate	Standard pneumatic multip	le connector plate		11	M	
				Special pneumatic multiple	connector plate		11	P	
				Pneumatic multiple connec	tor plate, with sealing ring,		11 12	GQC	
				with supply connections		_			
				Pneumatic multiple connec	tor plate, with sealing ring,		12 13	GQD	
				without supply connections					
				Preparation for pneumatic r	multiple connector plate		11 14	٧	
		Inscription label holder		For inscription labels			15	Z	
				Transparent			15	T	
		Mounting		H-rail mounting				Н	
				-	-	Wall mounting		W	
				Wall mounting		-		U	
		Connecting cable for relay	2.5 m	1 99	-	-		К	
		plate	5 m	1 99	-	-		L	
		Fitting set for end plates		Connector and silencer			16	Α	
	12	User documentation		German				-D	
				English				-E	
				French				-F	
				Italian				-1	
				Spanish				-S	
				Swedish				-V	

11	M, P, GQC, V	Only with compressed air supply Y, Z, E, F, G, H, J, K (supply at both ends)	14 V		Only with working port C (threaded connection).
12	GQC, GQD	Not with additional function P, Q, V.			Not with additional function P, Q, V
		Cannot be combined with valve function G (5/3-way valve)	15 Z,	T	Not with valve function R (relay plate)
13	GQD	Only with pneumatic supply U, V, W, X, Y, Z, A, B, C, D	16 A		Not with pneumatic multiple connector plate V (preparation for pneumatic
					multiple connector plate) an as accessory



Valve terminals type 10 CPV, Compact Performance – AS-interface

FESTO

Ordering data – Modular products

Electrical connection	Size	No. of valve positions/max. no. of solenoid	Permissi	ble valv	e positi/	on												
		coils	Valve fur	nction														
			M	J	N	С	Н	G 5	D	I	F	A 6	E 6	T 7	S 7 8	L	R	
			No. of so	lenoid	coils													
			1	2	2	2	2	2	2	2	1	1	2	0	0	0	2	
AS	10 - 7 -	2-fold/4					•	-						-	-			
	14 - 7 -			•			•	-			-	-		-	-	•	-	
	18 - 7 -	1						-			-			-	-		-	
	10	4-fold/4		0,2	0, 2	0, 2	0, 2	2	0, 2	0, 2		-	0, 2	1, 2	1, 2		0, 2	
	14			0, 2	0, 2	0,2	0, 2	2	0, 2	0, 2	-		0, 2	1,2	1, 2		_	
	18 - 7 -			-	-	-	-	-	-	-	-		-	1,2	1, 2		-	
AZ	10	2-fold/4						-						-	-			
	14]						-			_			_	-		-	
	18							-			-			-	-		-	
	10	4-fold/4		0,2	0, 2	0,2	0, 2	2	0, 2	0, 2			0, 2	1,2	1, 2		0, 2	
	14			0,2	0, 2	0,2	0,2	2	0,2	0, 2	-		0, 2	1,2	1, 2		-	
	18			-	-	-	-	-	-	-	-		-	1,2	1, 2		-	
AE	10	4-fold/4		0,2	0, 2	0, 2	0, 2	2	0, 2	0, 2			0, 2	1,2	1, 2		0, 2	
	14			0,2	0, 2	0,2	0, 2	2	0, 2	0, 2	-	-	0, 2	1, 2	1, 2		-	
	10	8-fold/8		0, 2,	0, 2,	0, 2,	0, 2,	2, 4,	0, 2,	0, 2,	-	-	0, 2,	1, 2, 3,	1, 2, 3,	-	0, 2,	
				4,6	4,6	4,6	4,6	6	4,6	4, 6			4, 6	4, 5, 6	4, 5, 6		4, 6	
	14			0, 2,	0, 2,	0, 2,	0, 2,	2, 4,	0, 2,	0, 2,	-	-	0, 2,	1, 2, 3,	1, 2, 3,	-	-	
				4,6	4,6	4,6	4,6	6	4,6	4,6			4,6	4, 5, 6	4, 5, 6			
AO	10	4-fold/4		0,2	0, 2	0,2	0,2	2	0, 2	0, 2			0, 2	1,2	1, 2		0, 2	
	14			0, 2	0, 2	0,2	0, 2	2	0, 2	0, 2	-		0, 2	1, 2	1, 2		-	
BE	10	4-fold/3	0, 1, 2	0	0	0	0	-	0	0	0, 1, 2	0, 1, 2	0	1,2	1, 2	3	0	
	14	1	0, 1, 2	0	0	0	0	-	0	0	-	0, 1, 2	0	1,2	1, 2	3	-	
	10	8-fold/6	0, 1, 2,	0,4	0,4	0,4	0,4	4	0,4	0,4	0, 1, 2,	0, 1, 2,	0,4	1, 2, 4,	1, 2, 4,	3 , 7	0,4	
			4, 5, 6								4, 5, 6	4, 5, 6		5,6	5,6			
	14		0, 1, 2,	0,4	0,4	0,4	0,4	4	0,4	0,4	-	0, 1, 2,	0,4	1, 2, 4,	1, 2, 4,	3 , 7	_	
			4, 5, 6									4, 5, 6		5,6	5,6			

- No restriction
- Must be selected at this valve position

 1 Type to be discontinued: Do not use for new designs!
- 5 **G** Not in first or last valve position
- 6 **A, E** Note air supply and exhaust when using more than 2 vacuum generators
- 7 **T, S** Only one valve function T or S (plate with duct separation) possible per valve terminal,

but not in first or last valve position

and only with pneumatic supply Y, Z, E, F, G, H, J, K (supply air at both ends);

the equipment to the right must consist of more than valve function L (blanking plate), R (relay plate)

8 **S** If the equipment to the right of S consists solely of valve function D, I (2x 2/2-way valve), L (blanking plate), then only with pneumatic supply Y, Z, F, G and pneumatic multiple connector plate M, P as


Valve terminals type 10 CPV, Compact Performance — Fieldbus Ordering data — Modular products

FESTO

M Mandatory data →											
Module No.	Valve terminal, pneumatic part	Size		No. of valve positions	Working ports		Electrical connection		Manual override		Pneumatic supply
18 200	10P	10		4, 6, 8	A, B, C	_	FB	'	N, R, V		U, V, W, X, Y, Z,
18 210		14									A, B, C, D, E, F,
18 220		18									G, H, J, K
Order example											
18 200	10P	- 10	-	8	С	-	FB	-	N]-	U
1	2	3		4	5		6	,	7	_	8

Ord	eriı	ng table						
Size	9		10	14	18	Condi-	Code	Enter
						tions		code
M	1	Module No.	18 200	18 210	18 220			
		Basic configuration						
	2	Valve terminal, pneumatic part	Valve terminal type 10	, CPV			10P	10P
	3	Size	10	14	18			
	4	No. of valve positions	4, 6, 8					
	5	Working ports	Large push-in connect					
			(QS6)	(QS8)	(QS10)	1	Α	
			Small push-in connect					
			(QS4)	(QS6)	(QS8)	1	В	
			None, threaded conne					
			(M7)	(G ¹ / ₈)	(G1/4)		С	
	6	Electrical connection	Festo CP bus node				-FB	-FB
	7	Manual override	Pushing				-N	
			Detenting				-R	
			Covered				-V	
	8	Pneumatic supply		ly, supply at right, ducted o			-U	
				ly, supply at left, ducted ex			-V	
				ly, supply at right, ducted			-W	
				ly, supply at left, ducted ex			-X	
		Compressed air supply	Internal pilot air supp	ly, supply at both ends, du	cted exhaust air		-Y	
		via end plates or						
		pneumatic multiple	External pilot air supp	ly, supply at both ends, du	cted exhaust air		-Z	
		connector plate						
		Compressed air supply		ly, supply at right, flat plat			-A	
		via end plates with flat		ly, supply at left, flat plate			-B	
		plate silencer		ly, supply at right, flat plat			-C	
				ly, supply at left, flat plate			-D	
		Compressed air supply		ly, supply at both ends, fla	· · · · · · · · · · · · · · · · · · ·	2	-E	
		via pneumatic multiple		ly, supply at both ends, fla	,	2	-F	
		connector plate with flat		ly, supply at both ends, fla	·	2	-G	
		plate silencer			t plate silencers at both ends	2	-H	
			, , , , , , , , , , , , , , , , , , , ,		t plate silencers at both ends	2	-J	
Ψ			Internal pilot air supp	ly, supply at both ends, fla	t plate silencer at right	2	-K	

1 A, B Not if the other equipment consists solely of valve function T, S (plate with duct separation), 2 E, F, G, H, J, K L (blanking plate) and R (relay plate) Only with pneumatic multiple connector plate M, P, GQC, GQD, V as an accessory



Valve terminals type 10 CPV, Compact Performance — Fieldbus Ordering data – Modular products



)	Mandatory da	ata									
	Equipment at valv	e position 0 7									
	9 Valve functions: M, J, N, C, H, G, D, I, F, A, E, T, S, L, R										
	9 Valve functions: M, J, N, C, H, G, D, I, F, A, E, T, S, L, R										
		ions									
	10 Addit	tional functions at p	neumatic valve pos	ition 0 7: P, Q, V							
	Valve position										
	0	1	2	3	4	5	6	7			
-	M	M	M	M	М	M	M	F			
	9 + 10										

Or	derir	ng table						
Siz	e.		10	14	18	Condi- tions	Code	Enter code
→	9	Equipment at valve position 0 7 Valve functions	5/2-way valve, single solen 5/2-way valve, double sole 2x 3/2-way valve, normally 2x 3/2-way valve, 1x normally 2x 3/2-way valve, mid-positio 2x 2/2-way valve, normally 2x 2/2-way valve, 1x normally 2x 2/2-way valve, single solenoid, fast-switching Vacuum generator	noid r open r closed ally open, 1x closed n closed r closed		4	M J N C C H G D D I F	- Enter the pneumatic equipment selected in the order code
			Vacuum generator with ejee Plate with duct separation, Plate with duct separation, Blanking plate Relay plate	1/11 closed	-	6 6 7	E T S L R	
•	10	Additional function at valve position 0 7	2x one-way flow control val 2x one-way flow control val Vacuum flow control modul	ve, exhaust air	-	8 8 9	P Q V	

3 Equipmen	at at valve position 0 7	7 9	S	If the equipment to the right of S consists solely of valve function D, I
	Valve positions must be equipped throughout without any gaps			(2x 2/2-way valve), L (blanking plate), then only with pneumatic supply Y, Z, F,
4 G	Not in first or last valve position			G and pneumatic multiple connector plate M, P as an accessory
5 A, E	Note air supply and exhaust when using more than 2 vacuum generators	8	P, Q, V	Cannot be combined with valve function G (5/3-way valve).
6 T, S	Only one valve function T or S (plate with duct separation) possible per valve terminal,			Not in first or last valve position with pneumatic multiple connector plate M, P
	but not in first or last valve position			as an accessory
	and only with pneumatic supply Y, Z, E, F, G, H, J, K (supply air at both ends);	9 \	V	Must be combined with valve function D, I (2x 2/2-way valve), E (vacuum
	the equipment to the right must consist of more than valve function L (blanking plate),			generator with ejector pulse)
	R (relay plate)			

	Transfer order code	9						
	0	1	2	3	4	5	6	7
- [

Valve terminals type 10 CPV, Compact Performance – Fieldbus Ordering data – Modular products

FESTO

→	O Optio	ons					
	Acces- sories	Pneumatic multiple connector plate	Inscription label holder	Mounting	Connecting cable for relay plate	Fitting set for end plates	User documentation
		M, P, GQC, GQD, V	Z, T	H, W, U	K,L	A	D, E, F, I, S, V
	+					-	D
		11					12

Ord	derir	ng table							
Siz	e			10	14	18	Condi- tions	Code	Enter code
4		Accessories						+	+
0	11	Pneumatic multiple connector	or plate	Standard pneumatic multip	le connector plate		10	M	
				Special pneumatic multiple	connector plate		10	Р	
				Pneumatic multiple connec with supply connections	tor plate, with sealing ring,	-	10 11	GQC	
				Pneumatic multiple connections	·	-	11 12	GQD	
				Preparation for pneumatic i	multiple connector plate		10 13	٧	
		Inscription label holder		For inscription labels			14	Z	
				Transparent			14	T	
		Mounting		H-rail mounting				Н	
				-	-	Wall mounting		W	
				Wall mounting		-		U	
		Connecting cable for relay	2.5 m	1 99		-		K	
		plate	5 m	1 99		-		L	
		Fitting set for end plates		Connector and silencer			15	Α	
	12	User documentation		German				-D	
				English				-E	
				French				-F	
				Italian				-l	
				Spanish				-S	
				Swedish	_			-V	

10	M. P. GOC. V	Only with pneumatic supply Y, Z, E, F, G, H, J, K (supply at both ends)	13	V	Only with working port C (threaded connection).
		Not with additional function P, Q, V.			Not with additional function P, Q, V
		Cannot be combined with valve function G (5/3-way valve)	14	Z, T	Not with valve function R (relay plate)
12	GQD	Only with pneumatic supply U, V, W, X, Y, Z, A, B, C, D	15	Α	Not with pneumatic multiple connector plate V (preparation for pneumatic
					multiple connector plate) an as accessory

Valve terminals type 10 CPV, Compact Performance – Direct Link Ordering data – Modular products

FESTO

M Mandatory data →											
Module No.	Valve terminal, pneumatic part	Size		No. of valve positions	Working ports	1	Electrical connection	Manual override			
18 200	10P	10		8	A, B, C	_	IP, D1, I1, N2, C2,	N, R, V			
18 210		14					CC				
18 220		18									
Order											
example 18 200	10P	- 10	_	8	С] -	IP	- N			
1	2	3		4	5		6	7			

Ordering table										
Size			10	14	18	Condi-	Code		Enter	
						tions			code	
M	1	Module No.	18 200	18 210	18 220					
		Basic configuration						Ī		
	2	Valve terminal, pneumatic part	Valve terminal type 10, CPV				10P		10P	
	3	Size	10	14	18					
	4	No. of valve positions	8				-8	-8		
	5	Working ports	Large push-in connectors in	_	1	_				
			(QS6)	(QS8)	(QS10)	1	Α			
			Small push-in connectors in							
			(QS4)	(QS6)	(QS8)	1	В			
			None, threaded connection only							
			(M7)	(G½)	(G1/4)		С			
	6	Electrical connection	Fieldbus node for IP-Link (without connection				-IP			
			ccessories)							
			Fieldbus node for Profibus DP including Festo fieldbus, ABB CS31, Moeller Suconet			2	-D1			
			K, with extension string							
			Fieldbus node for Interbus with extension string			2	-l1			
			Fieldbus node for DeviceNet with extension string			2	-N2			
			Fieldbus node for CANopen with extension string			2	-C2			
			Fieldbus node for CC-Link with extension string			2	-CC			
	7	Manual override	Pushing				-N			
			Detenting				-R			
4		Covered					-V			

1 A, B Not if the other equipment consists solely of valve function T, S (plate with duct separation), L (blanking plate) and R (relay plate)

2 **D1, I1, N2, C2, CC**

Only with selectable connection technology for fieldbus node GA, GB, GC, GD, GE, GF,



Valve terminals type 10 CPV, Compact Performance – Direct Link Ordering data – Modular products

FESTO

→	M Mandatory data	→
	Pneumatic supply	_
	U, V, W, X, Y, Z, A, B, C, D, E, F, G, H, J, K	J
_	U	
	8	

0	rderi	ng table						
S	ize		10	14	18	Condi-	Code	Enter
						tions		code
7	8	Pneumatic supply	Internal pilot air supply, su	ipply at right, dud	ted exhaust air		-U	
M]		Internal pilot air supply, su	ipply at left, duct	ed exhaust air		-V	
			External pilot air supply, su	upply at right, du	cted exhaust air		-W	
			External pilot air supply, su	upply at left, duct	ed exhaust air		-X	
		Compressed air supply	Internal pilot air supply, su	upply at both end	s, ducted exhaust air		-Y	
		via end plates or						
		pneumatic multiple	External pilot air supply, su	upply at both end	s, ducted exhaust air		-Z	
		connector plate						
		Compressed air supply	Internal pilot air supply, su		·		-A	
		via end plates with flat	Internal pilot air supply, su	upply at left, flat p	olate silencer		-B	
		plate silencer	External pilot air supply, su	11 / 0 !	<u>'</u>		-C	
			External pilot air supply, su				-D	
		Compressed air supply	1 11 2	117	s, flat plate silencer at right	3	-E	
		via pneumatic multiple	External pilot air supply, su			3	-F	
		connector plate with flat	Internal pilot air supply, su	* * * *		3	-G	
		plate silencer	External pilot air supply, su	upply at both end	s, flat plate silencers at both en		-H	
			Internal pilot air supply, su	ipply at both end	s, flat plate silencers at both en	ds 3	-J	
4			Internal pilot air supply, su	ipply at both end	s, flat plate silencer at right	3	-K	

3 E, F, G, H, J, K

Only with pneumatic multiple connector plate M, P, GQC, GQD, V as an accessory

Valve terminals type 10 CPV, Compact Performance – Direct Link Ordering data – Modular products



→	M Mandatory d	lata								
	Equipment at valve position 0 7									
	9 Valve functions: M, J, N, C, H, G, D, I, F, A, E, T, S, L, R									
		tions	pneumatic valve po	sition 0 7. D O V						
		icional functions at	pheumatic valve po	Sition o 7: P, Q, V						
	Valve position									
	0	1	2	3	4	5	6	7		
-	M	M	M	M	M	M	M	F		
	9+10									

10	Ordering table								
Si	ze		10	14	18	Condi-	Code	Enter	
						tions		code	
Ψ		Equipment at valve position 0 7							
M	9	Valve functions	5/2-way valve, single solen	5/2-way valve, single solenoid				Enter the	
			5/2-way valve, double sole	/2-way valve, double solenoid					
			2x 3/2-way valve, normally	open			N	matic	
			2x 3/2-way valve, normally	x 3/2-way valve, normally closed					
			2x 3/2-way valve, 1x norma	ally open, 1x closed			Н	ment	
			5/3-way valve, mid-position	n closed		5	G	selected	
			2x 2/2-way valve, normally	closed			D	in the	
			2x 2/2-way valve, 1x norma	ally open, 1x closed			I	order	
			5/2-way valve, single				F	code	
			solenoid, fast-switching						
			Vacuum generator			6	Α		
			Vacuum generator with ejec	ctor pulse		6	E		
			Plate with duct separation,	1/11 closed		7	T		
			Plate with duct separation,	1/11 and 3/5 closed		78	S		
			Blanking plate	Blanking plate					
			Relay plate		-		R		
0	10	Additional function at	2x one-way flow control val	ve, supply air	-	9	Р		
		valve position 0 7	2x one-way flow control val	ve, exhaust air	-	9	Q		
Ψ			Vacuum flow control modul	e	-	9 10	٧		

4	Equipment a	at valve position 0 7	8	S	If the equipment to the right of S consists solely of valve function D, I
		Valve positions must be equipped throughout without any gaps			(2x 2/2-way valve), L (blanking plate), then only with pneumatic supply Y, Z, F,
5	G	Not in first or last valve position			G and pneumatic multiple connector plate M, P as an accessory
6	A, E	Note air supply and exhaust when using more than 2 vacuum generators	9	P, Q, V	Cannot be combined with valve function G (5/3-way valve).
7	T, S	Only one valve function T or S (plate with duct separation) possible per valve terminal,			Not in first or last valve position with pneumatic multiple connector plate M, P
		but not in first or last valve position			as an accessory
		and only with pneumatic supply Y, Z, E, F, G, H, J, K (supply air at both ends);	10	٧	Must be combined with valve function D, I (2x 2/2-way valve), E (vacuum
		the equipment to the right must consist of more than valve function L (blanking plate),			generator with ejector pulse)
		R (relay plate)			

iranster	oraer	code

_	0	1	2	3	4	5	6	7
-								

Valve terminals type 10 CPV, Compact Performance – Direct Link Ordering data – Modular products

FESTO

→ 0 Op							
Acces-	Connection technology for fieldbus nodes	Pneumatic multiple connector plate					
sories							
	GA, GB, GC, GD, GE, GF, GI, GL, GM	M, P, GQC, GQD, V	_				
_							
т	11						

0	rderi	ng table							
S	Size		10	14	18	Condi- tions	Code	Ente code	
C		Accessories							
	11	Selectable connection technology for	Adapter, 2x M12, 5-pin, for	DeviceNet/CANopen		11	GA		
		fieldbus nodes	Connection set, 5-pin screw	terminal, for DeviceNet/CAN	open	11	GB		
			Without accessories for field	thout accessories for fieldbus connection					
			Straight plug, IP65, Sub-D,	ight plug, IP65, Sub-D, 9-pin, for DeviceNet/CANopen					
			Straight plug, IP65, Sub-D,	ight plug, IP65, Sub-D, 9-pin, for Profibus DP					
			Adapter, 2x M12 B-coded, f	or Profibus DP		13	GF		
			Connection set, IP65, 2xSul	b-D, 9-pin, for Interbus		14	GI		
			Adapter, 5-pin screw termin	nal, for CC-Link		15	GL		
			Straight plug, IP65 Sub-D, 9	9-pin, for CC-Link		15	GM		
		Pneumatic multiple connector plate	Standard pneumatic multip	le connector plate		16	M		
			Special pneumatic multiple	connector plate		16	Р		
			Pneumatic multiple connec	tor plate, with sealing ring,		16 17	GQC		
			with supply connections						
			Pneumatic multiple connec	tor plate, with sealing ring,	_	17 18	GQD		
			without supply connections						
1	1		Preparation for pneumatic r	multiple connector plate		16 19	٧		

11	GA, GB, GD	Only with electrical connection N2, C2
12	GC	Only with electrical connection D1, I1, N2, C2, CC
13	GE, GF	Only with electrical connection D1
14	GI	Only with electrical connection I1

Only with electrical connection CC

M, P, GQC, V Only with pneumatic supply Y, Z, E, F, G, H, J, K (supply at both ends)

17 **GQC, GQD** Not with additional function P, Q, V.

Cannot be combined with valve function G (5/3-way valve) Only with pneumatic supply U, V, W, X, Y, Z, A, B, C, D 19 **V** Only with working port C (threaded connection) Not with additional function P, Q, V $\,$

Transfer order code

15 GL, GM

Valve terminals type 10 CPV, Compact Performance – Direct Link Ordering data – Modular products



O Options					
Inscription label holder	Mounting	Selectable electrical connection sockets	Connecting cable for relay plate	Fitting set for end plates	User documentation
Z, T	H, W, U		K,L	A	D, E, F, I, S, V
					- D
11					12

Or	Ordering table									
Siz	Size			10	14	18	Condi- tions	Code	Enter code	
0	11	Inscription label holder		For inscription labels			20	Z		
Ψ.				Transparent			20	T		
	Mounting Selectable electrical connection			H-rail mounting				Н		
				-	-	Wall mounting		W		
				Wall mounting		-		U		
				Electrical connection socket M12 straight, 4-pin, Pg7				NA		
		sockets		Electrical connection socket M12 straight, 4-pin, Pg9				NB		
				Electrical connection socket M12 angled, 4-pin, Pg7				NC		
				Electrical connection socket M12 angled, 4-pin, Pg9				ND		
		Connecting cable for relay	2.5 m	1 99		-		K		
		plate	5 m	1 99		-		L		
		Fitting set for end plates		Connector and silencer			21	Α		
	12	User documentation		German				-D		
				English				-E		
				French				-F		
				Italian				-1		
				Spanish				-S		
				Swedish				-V		

20 **Z, T** Not with valve function R (relay plate) 21 **A**

Not with pneumatic multiple connector plate V (preparation for pneumatic multiple connector plate) an as accessory

] -]	
11		12


Valve terminals type 10 CPV, Compact Performance – ET200X Ordering data – Modular products

FESTO

Module No.	Valve terminal, pneumatic part	Size	No. of valve positions	Working ports	Electrical connection	Manual override	Pneumatic supply
18 200	10P	10	8	A, B, C	ET	N, R, V	U, V, W, X, Y, Z
18 210		14					A, B, C, D, E, F
							G, H, J, K
Order							
example					_		
18 200	10P	- 10	- 8	С	- ET	- N	- U

0	rderii	ng table					
Si	ze		10	14	Condi-	Code	Enter
					tions		code
M	1	Module No.	18 200	18 210			
		Basic configuration					
	2	Valve terminal, pneumatic part	Valve terminal type 10, CPV			10P	10P
	3	Size	10	14			
	4	No. of valve positions	8			-8	-8
	5	Working ports	Large push-in connectors in working port				
			(QS6)	(QS8)	1	Α	
			Small push-in connectors in working port				
			(QS4)	(QS6)	1	В	
			None, threaded connection only				
			(M7)	(G½)		С	
	6	Electrical connection	Electrical connection for ET200X			-ET	-ET
	7	Manual override	Pushing			-N	
			Detenting			-R	
			Covered			-V	
	8	Pneumatic supply	Internal pilot air supply, supply at right, o	lucted exhaust air		-U	
			Internal pilot air supply, supply at left, du			-V	
			External pilot air supply, supply at right, o	lucted exhaust air		-W	
			External pilot air supply, supply at left, du			-X	
		Compressed air supply	Internal pilot air supply, supply at both er	nds, ducted exhaust air		-Y	
		via end plates or					
		pneumatic multiple	External pilot air supply, supply at both e	nds, ducted exhaust air		-Z	
		connector plate					
		Compressed air supply	Internal pilot air supply, supply at right, f	lat plate silencer		-A	
		via end plates with flat	Internal pilot air supply, supply at left, fla			-B	
		plate silencer	External pilot air supply, supply at right, f			-C	
			External pilot air supply, supply at left, fla	•		-D	
		Compressed air supply	External pilot air supply, supply at both e	, -	2	-E	
		via pneumatic multiple	External pilot air supply, supply at both e		2	-F	
		connector plate with flat	Internal pilot air supply, supply at both er	•	2	-G	
		plate silencer	External pilot air supply, supply at both e	•	2	-H	
			Internal pilot air supply, supply at both er	•	2	-J	
Ψ			Internal pilot air supply, supply at both er	nds, flat plate silencer at right	2	-K	

1 A, B Not if the other equipment consists solely of valve function T, S (plate with duct separation) 2 E, F, G, H, J, K and L (blanking plate) Only with pneumatic multiple connector plate M, V as an accessory



Valve terminals type 10 CPV, Compact Performance – ET200X Ordering data – Modular products



Equipment at valve position 0 7 9 Valve functions: M, J, N, C, H, G, D, I, A, E, T, S, L O Options 10 Additional functions at pneumatic valve position 0 7: P, Q, V Valve position 0 1 2 3 4 5 6 7												
	Equipment at valv	ve position 0 7										
	9 Valve functions: M, J, N, C, H, G, D, I, A, E, T, S, L											
	O O p	tions										
	10 Addi	tional functions at p	neumatic valve pos	ition 0 7: P, Q, V								
	Valve position											
	0	1	2	3	4	5	6	7				
-	М	M	M	M	М	M	M	J				
	9+10											

10	deri	ng table					
Si	ze		10	14	Condi- tions	Code	Enter code
T		Equipment at valve position 0 7			3	-	-
M	9	Valve functions	5/2-way valve, single solenoid			M	Enter the
			5/2-way valve, double solenoid			J	pneu-
			2x 3/2-way valve, normally open			N	matic
			2x 3/2-way valve, normally closed			С	equip-
			2x 3/2-way valve, 1x normally open, 1x c	losed		Н	ment
			5/3-way valve, mid-position closed		4	G	selected
			2x 2/2-way valve, normally closed			D	in the
			2x 2/2-way valve, 1x normally open, 1x c	losed		I	order
			Vacuum generator		5	Α	code
			Vacuum generator with ejector pulse		5	E	
			Plate with duct separation, 1/11 closed		6	T	
			Plate with duct separation, 1/11 and 3/5	closed	6 7	S	
			Blanking plate			L	
0	10	Additional function at	2x one-way flow control valve, supply air		8	Р	
		valve position 0 7	2x one-way flow control valve, exhaust air	•	8	Q	
			Vacuum flow control module		89	٧	

3 Equipm	ent at valve position 0 7	7 S	If the equipment to the right of S consists solely of valve function D, I
	Valve positions must be equipped throughout without any gaps		(2x 2/2-way valve), L (blanking plate), then only with pneumatic supply Y, Z, F,
4 G	Not in first or last valve position		G and pneumatic multiple connector plate M, P as an accessory
5 A, E	Note air supply and exhaust when using more than 2 vacuum generators	8 P, Q, V	Cannot be combined with valve function G (5/3-way valve).
6 T, S	Only one valve function T or S (plate with duct separation) possible per valve terminal,		Not in first or last valve position with pneumatic multiple connector plate M, P
	but not in first or last valve position		as an accessory
	and only with pneumatic supply Y, Z, E, F, G, H, J, K (supply air at both ends);	9 V	Must be combined with valve function D, I (2x 2/2-way valve), E (vacuum
	the equipment to the right must consist of more than valve function L (blanking plate)		generator with ejector pulse)

Transfer order code								
	0	1	2	3	4	5	6	7

9 + 10

Valve terminals type 10 CPV, Compact Performance – ET200X Ordering data – Modular products

FESTO

• O C	Options			
Acces	- Pneumatic multiple connector	Inscription label holder	Fitting set for end plates	User documentation
sories	plate			
<u> </u>	M, P, V	Z, T	A	D, E, F, I, S, V
+	11			- D

Or	derir	ng table					
Si	ze		10	14	Condi- tions	Code	Enter code
0		Accessories				+	+
	11	Pneumatic multiple connector plate	Standard pneumatic multiple connector p	plate	10	M	
			Special pneumatic multiple connector pla	ate	10	Р	
			Preparation for pneumatic multiple conne	ector plate	10 11	٧	
		Inscription label holder	For inscription labels			Z	
			Transparent			T	
		Fitting set for end plates	Connector and silencer		12	Α	
	12	User documentation	German			-D	
			English			-E	
			French			-F	
			Italian			-l	
			Spanish			-S	
			Swedish			-V	


10 M, P, V Only with pneumatic supply Y, Z, E, F, G, H, J, K (supply at both en	nds)
--	------

Only with working port C (threaded connection). 11 **V**

Not with additional function P, Q, V

12 **A**

Not with pneumatic multiple connector plate V (preparation for pneumatic multiple connector plate) an as accessory



Valve terminal type 10 CPV, Compact Performance Accessories



	Code	Valve function	Туре	Part No.
ndividual valve s	lice, size 10/1	14/18		
⊋ba.	M	5/2-way valve, single solenoid	CPV10-M1H-5LS-M7	161 414
To the			CPV14-M1H-5LS-1/8	161 360
ordering data			CPV18-M1H-5LS-1/4	163 190
	F	5/2-way valve, single solenoid, fast-switching	CPV10-M11H-5LS-M7	187 439
	J	5/2-way valve, double solenoid	CPV10-M1H-5JS-M7	161 415
			CPV14-M1H-5JS-1/8	161 361
			CPV18-M1H-5JS-1/4	163 191
	N	2x 3/2-way valve,	CPV10-M1H-2x3-OLS-M7	161 417
		normally open	CPV14-M1H-2x3-OLS-1/8	161 363
			CPV18-M1H-2x3-OLS-1/4	163 188
	С	2 x 3/2-way valve,	CPV10-M1H-2x3-GLS-M7	161 416
		normally closed	CPV14-M1H-2x3-GLS-1/8	161 362
			CPV18-M1H-2x3-GLS-1/4	163 189
	Н	2x 3/2-way valve,	CPV10-M1H-30LS-3GLS-M7	176 064
		1x normally open,	CPV14-M1H-30LS-3GLS-1/8	176 067
		1x closed	CPV18-M1H-30LS-3GLS-1/4	176 070
	G	5/3-way valve,	CPV18-M1H-5/3GS-1/4	176 061
		mid-position closed		
	D	2x 2/2-way valve,	CPV10-M1H-2x2-GLS-M7	185 880
		normally closed	CPV14-M1H-2x2-GLS-1/8	185 883
			CPV18-M1H-2x2-GLS-1/4	185 886
	I	2x 2/2-way valve,	CPV10-M1H-2OLS-2GLS-M7	187 843
		1x normally open,	CPV14-M1H-20LS-2GLS-1/8	187 846
		1x closed	CPV18-M1H-20LS-2GLS-1/4	187 849

Valve terminal type 10 CPV, Compact Performance Accessories

Ordering data				
	Code	Designation	Туре	Part No.
Vacuum generator				
<u> </u>	А	Vacuum generator	CPV10-M1H-V70-M7	185 862
5 bl			CPV14-M1H-V95-1/8	185 868
			CPV18-M1H-V140-1/4	185 874
	E	Vacuum generator with ejector pulse	CPV10-M1H-VI70-2GLS-M7	185 865
			CPV14-M1H-VI95-2GLS-1/8	185 871
			CPV18-M1H-VI140-2GLS-1/4	185 877
5				
Functional module	T _C	NA 196 6/0 1 6 9 1 1/2 12 9 91 1 12 6\6	CDV4 0 DC F/2C MT	476055
	G	Valve kit for 5/3-way valve function, closed (in combination with valve slice C) for	CPV10-BS-5/3G-M7	176 055
		size 10 and 14	CDV4 / DC F /2C 1/-	476.057
			CPV14-BS-5/3G- ¹ / ₈	176 057
			<u> </u>	
Separator plates				
	Т	Separator plate, duct 1/11 closed	CPV10-DZP	161 369
			CPV14-DZP	162 551
			CPV18-DZP	163 282
	S	Separator plate, duct 1/11, 3/5 closed	CPV10-DZPR	178 678
			CPV14-DZPR	178 680
			CPV18-DZPR	184 543
Relay plate				
	R	Relay plate	CPV10-RP2	174 478
Dar B Th				
			CPV14-RP2	174 480
			CPV14-RP2	1/4 400
				· ·
Blanking plate				
	L	Blanking plate	CPV10-RZP	161 368
100			CDI/4 / DZD	460.550
			CPV14-RZP	162 550
			CPV18-RZP	163 283
			CI VIO NEI	103 203
				1
Additional functions	for valve po			
	Р	One-way flow control valve, 2x supply air	CPV-10-BS-2xGRZZ-M7	184 140
			CPV-14-BS-2xGRZZ-1/8	184 142
	Q	One-way flow control valve, 2x exhaust air	CPV-10-BS-2xGRAZ-M7	184 141
			CPV-14-BS-2xGRAZ-1/8	184 143
	V	One-way flow control valve for vacuum	CPV-10-BS-2xGRZ-V-M7	185 889
	ľ	one may now control valve for vacuality	5. 1 10 55 2AGRE-V-W/	10,000
			CPV-14-BS-2xGRZ-V-1/8	185 891
			0. 1 17 00 ENGINE-V-/0	10,0,1

Valve terminal type 10 CPV, Compact Performance Accessories

Ordering data				
	Code	Designation	Туре	Part No.
Inscription label hol	lder			
0	Z	Holder for inscription labels	CPV10-VI-BZ-T-2	162 560
			CPV10-VI-BZ-T-3	162 561
			CPV10-VI-BZ-T-4	162 562
			CPV10-VI-BZ-T-5	162 563
			CPV10-VI-BZ-T-6	162 564
			CPV10-VI-BZ-T-7	162 565
			CPV10-VI-BZ-T-8	162 566
			CPV14-VI-BZ-T-2	162 567
			CPV14-VI-BZ-T-3	162 568
			CPV14-VI-BZ-T-4	162 569
			CPV14-VI-BZ-T-5	162 570
			CPV14-VI-BZ-T-6	162 571
			CPV14-VI-BZ-T-7	162 572
			CPV14-VI-BZ-T-8	162 573
			CPV18-VI-BZ-T-2	163 293
			CPV18-VI-BZ-T-3	163 294
			CPV18-VI-BZ-T-4	163 295
			CPV18-VI-BZ-T-5	163 296
			CPV18-VI-BZ-T-6	163 297
			CPV18-VI-BZ-T-7	163 298
			CPV18-VI-BZ-T-8	163 299
0	Т	Holder for inscription labels, transparent	CPV10-VI-ST-T-2	194 066
			CPV10-VI-ST-T-3	194 067
			CPV10-VI-ST-T-4	194 068
			CPV10-VI-ST-T-5	194 069
			CPV10-VI-ST-T-6	194 070
			CPV10-VI-ST-T-7	194 071
			CPV10-VI-ST-T-8	194 072
			CPV14-VI-ST-T-2	194 073
			CPV14-VI-ST-T-3	194 074
			CPV14-VI-ST-T-4	194 075
			CPV14-VI-ST-T-5	194 076
			CPV14-VI-ST-T-6	194 077
			CPV14-VI-ST-T-7	194 078
			CPV14-VI-ST-T-8	194 079
			CPV18-VI-ST-T-2	194 080
			CPV18-VI-ST-T-3	194 081
			CPV18-VI-ST-T-4	194 082
			CPV18-VI-ST-T-5	194 083
			CPV18-VI-ST-T-6	194 084
			CPV18-VI-ST-T-7	194 085
			CPV18-VI-ST-T-8	194 086
	I	'	<u> </u>	L
Inscription labels				
^	-	6x10 mm in frames, 64 pieces	IBS 6x10	18 576
		9x20 mm in frames, 20 pieces (CPV18 only)	IBS 9x20	18 182
***		- 1 × × × × 9	<u> </u>	

Valve terminal type 10 CPV, Compact Performance Accessories

Ordering data					
	Code	Designation		Туре	Part No.
Mounting					
	Н	Attachment for H-rail		CPV10/14-VI-BG-NRH-35	162 556
				CPV18-VI-BG-NRH-35	163 291
W		Attachment for wall mounting		CPV18-VI-BG-RW	163 292
	U			CPV10/14-VI-BG-RWL-B	189 541
<u> </u>	Х	Attachment for individual connection and ET200X (included in the scope of delivery)		CPV10-VI-BG-ET200X	165 801
				CPV14-VI-BG-ET200X	165 803
Manual override					
Mandat override	<u> </u>	Locking clip (for manual override)		CPV10/14-HS	526 203
			country (or manage overhee)		526 204
V Locking clip (cover for manual override)		Locking clip (cover for manual override)		CPV10/14-HV	530 055
				CPV18-HV	530 056
Relay plate					
	K	Connecting cable for relay plate	2.5 m	KRP-1-24-2,5	165 612
(B) (A)	L		5 m	KRP-1-24-5	165 613
Cable for individu				T	
	D	Plug socket with cable (CPV10/14), suitable for chain link trunking	2.5 m	KMYZ-7-24-2,5-LED-PUR	193 683
	E		5 m	KMYZ-7-24-5-LED-PUR	193 685
	F		10 m	KMYZ-7-24-10-LED-PUR	196 070
//	D	Plug socket with cable (CPV18)	2.5 m	KMEB-2-24-2,5-LED	174 844
	E	7	5 m	KMEB-2-24-5-LED	174 845

Valve terminal type 10 CPV, Compact Performance Accessories

Ordering data					
	Code	Designation		Туре	Part No.
Multi-pin plug conn	ection, elect				
	Υ	Plug socket, 9-pin		SD-SUB-D-BU9	18 708
		Plug socket, 25-pin		SD-SUB-D-BU25	18 709
<i>))</i>	R	Connecting cable, 9-pin, polyvinyl chloride	5 m	KMP3-9P-08-5	18 698
200	_	Connecting cable, 25-pin, polyvinyl chloride		KMP3-25P-16-5	18 624
	S	Connecting cable, 9-pin, polyvinyl chloride	10 m	KMP3-9P-08-10	18 579
		Connecting cable, 25-pin, polyvinyl chloride		KMP3-25P-16-10	18 625
	-	Connecting cable, 9-pin, polyurethane	5 m	KMP4-9P-5-PUR	193 014
		Connecting cable, 25-pin, polyurethane		KMP4-25P-5-PUR	193 018
	-	Connecting cable, 9-pin, polyurethane	10 m	KMP4-9P-10-PUR	193 015
		Connecting cable, 25-pin, polyurethane		KMP4-25P-10-PUR	193 019
	-	Connecting cable, for chain link trunking, with 9-pin Sub-D plug, IP40,	2.5 m	KMP6-09P-8-2,5	531 184
		polyvinyl chloride cable	5 m	KMP6-09P-8-5	531 185
			10 m	KMP6-09P-8-10	531 186
	-	Connecting cable, for chain link trunking, with 25-pin Sub-D plug,	2.5 m	KMP6-25P-20-2,5	530 046
		IP40, polyvinyl chloride cable	5 m	KMP6-25P-20-5	530 047
			10 m	KMP6-25P-20-10	530 048
	I				
Fieldbus connection	for Fieldbu	s Direct			
	GA	Straight socket, Sub-D 9-pin for DeviceNet/CANopen, plug/socket M12		FBA-2-M12-5POL	525 632
		5-pin, IP65			
-	GB	GB Straight socket, Sub-D 9-pin for DeviceNet/CANopen, plug 5-pin, IP40		FBA-1-SL-5POL	525 634
See Land 3		, , , , , , , , , , , , , , , , , , ,			
4					
255		Angled socket 5-pin for DeviceNet/CANopen, screw terminal 5-pin, IP20		FBSD-KL-2x5POL	525 635
30000					
A Des	CD	DI O : C DC D : N //CAN ID/F		FDC CUD O DU O (DOI	407.060
	GD	GD Plug 9-pin, Sub-D for DeviceNet/CANopen, IP65		FBS-SUB-9-BU-2x4POL	197 960
	GE	Plug Sub-D, IP65, 9-pin for Profibus DP		FBS-SUB-9-GS-DP-B	532 216
	GF	Bus connection 2x M12 adapter plug (B-coded, ReverseKey) for Profibus		FBA-2-M12-5POL-RK	533 118
		DP			
0	GI	Plug socket 9-pin, Sub-D for Interbus nodes CPX and CPV		FBS-SUB-9-BU-IB-B	532 218
		Plug 9-pin, Sub-D for Interbus nodes CPX and CPV		FBS-SUB-9-GS-IB-B	532 217
		rtag / pini, sab b for interbus flodes er A and er v		103-300-7-03-10-0	332 217
•	GL	Straight socket, Sub-D 9-pin, screw terminal 5-pin, IP20		FBA-1-KL-5POL	197 962
0 2000					
- O-	GM	Plug 9-pin, Sub-D, for CC-Link CPX and CPV, IP65		FBS-SUB-9-GS-2x4POL-B	532 220
CD					

Valve terminal type 10 CPV, Compact Performance Accessories

Ordering data				
Designation			Туре	Part No.
Operating voltag	ge connection for Fieldbus Direct			
	Straight socket	M12, 4-pin, PG7, IP65	FBSD-GD-7	18 497
		M12, 4-pin, PG9, IP65	FBSD-GD-9	18 495
8	Angled plug socket	M12, 4-pin, PG7, IP65	FBSD-WD-7	18 524
		M12, 4-pin, PG9, IP65	FBSD-WD-9	18 525
Blanking plug				•
Diaming plug	Blanking plug		B-M5	3 843
		Didining prog		
			B-M7 B- ¹ /8	174 309 3 568
			B-1/4	3 569
			B-3/8	3 570
			B-1/2	3 571
	L		- /-	
Push-in fitting				
	Push-in fitting		QS-1/8-8-I	153 015
			QS-1/4-10-I	153 018
			QS-3/8-12-I	153 020
			QSM-M5-6-I	153 317
			QSM-M7-6-I	153 321
				<u> </u>
Silencer				
	Silencer		U-M5	4 645
			U-1/8-B	6 841
			U-1/4-B	6 842
			U-3/8-B	6 843
			U-1/2-B	6 844
			UC-M7	161 418
	•		1	L
User documenta	tion			
	CPV Pneumatics Description	German	P.BE-CPV-DE	165 100
		English	P.BE-CPV-EN	165 200
		French	P.BE-CPV-FR	165 130
		Italian	P.BE-CPV-IT	165 160
		Spanish	P.BE-CPV-ES	165 230
		Swedish	P.BE-CPV-SV	165 260