

Adding counters CCES Technical data

FESTO

1

Function:

The electric adding counter CCES can be used in combination with a proximity sensor to count the number of switching cycles performed by a cylinder.

Recommended proximity sensors SME/SMT → 2

Features:

- 8-digit LCD display
- Own power supply
- Designed for front panel mounting
- Connection via terminal strip
- Reset button



General technical data					
Constructional design		Electric adding counter with battery			
Type of mounting		Front panel mounting			
Power supply		Lithium battery (nominal value retention 7 years)			
Display		8-digit			
Reset method		Pushbutton or electric signal			
Min. pulse length for drive	[ms]	15			
Min. pulse length for reset	[ms]	15			
Product weight	[g]	30			
Electrical data					
Lower threshold value	[V DC]	< 0.7			
Upper threshold value	[V DC]	5 30			
Clock pulse input		Programmable			
Clock pulse input setting		Negative edge 30 Hz			
Max. counting rate	[kHz]	7.5			
Max. attenuated counting rate	[Hz]	30			
Materials					
Housing		Polycarbonate			
Note on materials		RoHS-compliant			


Operating and environmental conditions				
Ambient temperature	[°C]	-10 +50		
Corrosion resistance class CRC ¹⁾		2		

¹⁾ Corrosion resistance class 2 as per Festo standard 940 070 Components subject to moderate corrosion stress. Externally visible parts with primarily decorative surface requirements which are in direct contact with a normal industrial environment or media such as coolants or lubricating agents.



Adding counters CCES Technical data

FESTO



Ordering data		
	Part No.	Туре
Adding counter	549 403	CCES-P-C8-E

Ordering data - Pro	oximity sensor SME/SMT				Technical d	ata → Internet: sme-8m, smt-8m
	Switching element function	Switch output	Electrical connection	Cable length [m]	Part No.	Туре
	N/O contact	Contacting, bipolar	Cable, 3-wire	2.5	543 862	SME-8M-DS-24V-K-2,5-0E
		Contacting, bipolar PNP	Cable, 3-wire	2.5	543 862 543 867	SME-8M-DS-24V-K-2,5-0E SMT-8M-PS-24V-K-2,5-0E



Please note the following points:

- The abovementioned proximity sensor SME can be connected to the adding counter as a 2-wire switch without additional power supply.
- If using other proximity sensors, an additional power supply is needed
- and the clock pulse input of the adding counter must be reprogrammed from NPN to PNP.
- Screened cables must be used for cables longer than 3 m.
- The maximum permissible cable length is 30 m.