

## Proportional-pressure regulators VEAB

FESTO




## Key features



Innovative	Flexible	Operational safety	Easy to install
<ul style="list-style-type: none"><li>• Silent operation</li><li>• Very low power consumption</li><li>• Extremely precise</li><li>• Short switching times</li><li>• Piezo technology</li></ul>	<ul style="list-style-type: none"><li>• In-line valves</li><li>• Sub-base valves</li><li>• Simple electrical and pneumatic interfaces</li><li>• Choice of different setpoint specifications<ul style="list-style-type: none"><li>– Current input</li><li>– Voltage input</li></ul></li></ul>	<ul style="list-style-type: none"><li>• Integrated pressure sensor with separate output</li><li>• Diagnostics<ul style="list-style-type: none"><li>– Operating voltage: over- and undervoltage</li><li>– Setpoint value: falling below and exceeding</li></ul></li><li>• Consistent pressure regulation performance with long-term stability</li><li>• Long service life</li></ul>	<ul style="list-style-type: none"><li>• Mounting the in-line valve via three lateral through-holes</li><li>• Secure wall mounting or H-rail mounting</li></ul>


## Key features – Display and operation

### In-line valve



- [1] Power LED (green), fault LED (red)
- [2] Electrical connection, M8 plug
- [3] Port 2, working air
- [4] Port 1, compressed air
- [5] Port 3, exhaust air
- [6] Through-holes for mounting the valve

### Sub-base valve




- [1] Power LED (green), fault LED (red)
- [2] Electrical connection, M8 plug
- [3] Through-holes for mounting the valve on the sub-base
- [4] Port 2, working air
- [5] Port 3, exhaust air
- [6] Port 1, compressed air

## Key features – Mounting


### Mounting the valve manifold assembly

#### H-rail mounting



[1] H-rail mounting  
[2] Manifold rail


The H-rail mounting can be used to mount the manifold rail on H-rails in accordance with EN 60715.



[3] H-rail

To do this, the manifold rail with the H-rail mounting is mounted on the H-rail and latched in place.

#### Wall mounting




The manifold rail also has through-holes for wall mounting.

## Product range overview

## Peripherals overview

## Valve manifold assembly VEAB



Type	Description	→ Page/Internet
[1]	H-rail NRH352000	For control cabinet installation
[2]	H-rail mounting VAME	For mounting the H-rail
[3]	Manifold rail VABM-P7-G18M	Connection direction at the side, for control cabinet installation
[4]	Manifold rail VABM-P7-G18MB	Connection direction underneath, for wall mounting and control cabinet installation
[5]	Cover plate VABB	–
[6]	Proportional-pressure regulator VEAB	–
[7]	Connecting cable NEBU	–

## Type codes

<b>001</b>	<b>Series</b>		<b>005</b>	<b>Pneumatic connection</b>	
<b>VEAB</b>	Proportional pressure regulator		<b>Q4</b>	Push-in connector 4 mm	
<b>002</b>	<b>Valve function</b>		<b>F</b>	Flange/sub-base	
<b>26</b>	2x2/2-way valve, normally closed		<b>006</b>	<b>Setpoint input for individual valves</b>	
<b>003</b>	<b>Directional control valve type</b>		<b>A4</b>	4 ... 20 mA	
<b>L</b>	In-line valve		<b>V1</b>	0 ... 10 V	
<b>B</b>	Sub-base valve		<b>V2</b>	0 ... 5 V	
<b>004</b>	<b>Pressure range [bar]</b>		<b>007</b>	<b>Electrical connection</b>	
<b>D9</b>	0 ... 6		<b>R1</b>	Individual connector M8, 4-pin	
<b>D12</b>	0 ... 0.2		<b>008</b>	<b>Nominal operating voltage</b>	
<b>D7</b>	0 ... 1		<b>1</b>	24 V DC	
<b>D13</b>	-1 ... 1				
<b>D14</b>	-1 ... 0				
<b>D25</b>					
<b>D15</b>	-0.5 ... 0.5				
<b>D2</b>	0 ... 2				
<b>D18</b>	-1 ... 5				

## Datasheet

-  -	Flow rate 4.5 ... 20 l/min	-  -	Output pressure 2 (pressure regulation range) -0.1 ... -0.0005 MPa 0.0001 ... 0.02 MPa 0.0005 ... 0.1 MPa 0.001 ... 0.2 MPa 0.0025 ... 0.5 MPa 0.003 ... 0.6 MPa -0.1 ... 0.1 MPa -0.1 ... 0.5 MPa -0.05 ... 0.05 MPa
-  -	Voltage 24 V DC		



General technical data		
Type	VEAB-L	VEAB-B
Valve type	In-line valve	Sub-base valve
Valve function	3-way proportional-pressure regulator	
Dimensions W x L x H [mm]	18 x 60.5 x 85	18 x 67 x 66
Standard nominal flow rate	→ Page 11	
Pneumatic port 1, 2, 3	Push-in connector 4 mm	Flange/via sub-base
Sealing principle	Soft	
Actuation type	Electrical	
Display type	LED	
Type of control	Direct	
Reset method	Mechanical spring	
Type of mounting	Optionally with through-hole, with accessories	
Mounting position	Any	
Product weight [g]	70	

Electrical data		
Electrical connection	Plug, M8x1, 4-pin, to EN 60947-5-2	
Nominal operating voltage	[V DC]	24
Operating voltage range	[V DC]	19 ... 29
Residual ripple	[%]	10
Max. electrical power consumption	[W]	1
Setpoint input signal	Voltage type	0 ... 10
		0 ... 5
Analogue output signal range (actual value)	Current type	4 ... 20
		1 ... 5
Accuracy of analogue output	Voltage type	0 ... 10
		1 ... 5
Short circuit current rating	Current type	4 ... 20
		1 ... 5
Reverse polarity protection	For all electrical connections	
Degree of protection	IP65	

-  - **Note**  
Safety position VEAB:  
If the electrical power supply fails,  
the output pressure will be unregulated and may rise or fall – valve blocked.

## Datasheet

Operating and environmental conditions						
Output pressure 2 (pressure regulation range)	[MPa]	-0.1...-0.0005	-0.1 ... 0.1	-0.1 ... 0.5	-0.05 ... 0.05	0.0001 ... 0.02
Operating medium		Compressed air to ISO 8573-1:2010 [7:4:4]				
		Inert gases				
Note on the operating/pilot medium		Lubricated operation not possible				
Input pressure at port 1 <sup>1)</sup>	[MPa]	0.1	0 ... 0.2	0 ... 0.55	0 ... 0.2	0 ... 0.1
	[bar]	1	0 ... 2	0 ... 5.5	0 ... 2	0 ... 1
	[psi]	14.5	0 ... 29	0 ... 79.75	0 ... 29	0 ... 14.5
Input pressure at port 3	[MPa]	-0.1	-0.1	-0.1	-0.1	-
	[bar]	-1	-1	-1	-1	-
	[psi]	-14.5	-14.5	-14.5	-14.5	-
Hysteresis FS (full scale)	[%]	0.25	0.25	0.25	0.25	0.5
Linearity error FS (full scale)	[%]	0.5	0.5	0.5	0.5	0.8
Repetition accuracy FS (full scale)	[%]	0.4				
Absolute accuracy at room temperature FS (full scale)	[%]	0.75	0.75	0.75	0.75	0.8
Accuracy of analogue output FS (full scale)	[%]	2				
Temperature coefficient	[%/K]	0.05				
Ambient temperature	[°C]	0 ... 50				
Temperature of medium	[°C]	5 ... 50				
Storage temperature	[°C]	-20 ... +70				
Corrosion resistance class CRC <sup>2)</sup>		2				
CE marking (see declaration of conformity)		To EU EMC Directive <sup>3)</sup>				
		To EU RoHS Directive <sup>3)</sup>				
UKCA marking (see declaration of conformity)		To UK instructions for EMC <sup>3)</sup>				
		To UK RoHS instructions <sup>3)</sup>				
Certification		RCM				

1) Input pressure 1 should always be 1 bar greater than the maximum regulated output pressure.

2) Corrosion resistance class CRC 2 to Festo standard FN 940070

Moderate corrosion stress. Indoor applications in which condensation can occur. External visible parts with primarily decorative surface requirements which are in direct contact with a normal industrial environment.

3) For information about the area of use, see the EC declaration of conformity at: [www.festo.com/catalogue/...](http://www.festo.com/catalogue/) → Support/Downloads.

If the devices are subject to usage restrictions in residential, commercial or light-industrial environments, further measures for the reduction of the emitted interference may be necessary.

Operating and environmental conditions						
Output pressure 2 (pressure regulation range)	[MPa]	0.0005 ... 0.1	0.001 ... 0.2	0.0025 ... 0.5	0.003 ... 0.6	
Operating medium		Compressed air to ISO 8573-1:2010 [7:4:4]				
		Inert gases				
Note on the operating/pilot medium		Lubricated operation not possible				
Input pressure at port 1	[MPa]	0 ... 0.3	0 ... 0.4	0 ... 0.55	0 ... 0.65	
	[bar]	0 ... 3	0 ... 4	0 ... 5.5	0 ... 6.5	
	[psi]	0 ... 43.5	0 ... 58	0 ... 79.75	0 ... 94.25	
Hysteresis FS (full scale)	[%]	0.25				
Linearity error FS (full scale)	[%]	± 0.5				
Repetition accuracy FS (full scale)	[%]	± 0.4				
Absolute accuracy at room temperature FS (full scale)	[%]	0.75				
Accuracy of analogue output FS (full scale)	[%]	2				
Temperature coefficient	[%/K]	0.05				
Ambient temperature	[°C]	0 ... 50				
Temperature of medium	[°C]	5 ... 50				
Storage temperature	[°C]	-20 ... +70				
Corrosion resistance class CRC <sup>1)</sup>		2				
CE marking (see declaration of conformity)		To EU EMC Directive <sup>2)</sup>				
Certification		RCM				

1) Corrosion resistance class CRC 2 to Festo standard FN 940070

Moderate corrosion stress. Indoor applications in which condensation can occur. External visible parts with primarily decorative surface requirements which are in direct contact with a normal industrial environment.

2) For information about the area of use, see the EC declaration of conformity at: [www.festo.com/catalogue/...](http://www.festo.com/catalogue/) → Support/Downloads.


If the devices are subject to usage restrictions in residential, commercial or light-industrial environments, further measures for the reduction of the emitted interference may be necessary.

## Datasheet


## Materials

Seals	NBR
Housing	PA-reinforced
Note on materials	RoHS-compliant
PWIS conformity	VDMA24364 zone

## Pin allocation

	Pin	Function
	1	+24 V DC supply voltage
	2	+ setpoint value
	3	GND
	4	+ actual value

## Function





An integrated pressure sensor records the pressure at the working port and compares this value with the setpoint value.

The pressure is automatically readjusted in the event of deviations.

## Datasheet


VEAB-...-D14-..., output pressure 2 (pressure regulation range) -1 ... -0.005

Flow rate  $q_n$  from 1 → 2 as a function of output pressure  $p_2$ Flow rate  $q_n$  from 2 → 3 as a function of output pressure  $p_2$ 


## Datasheet

VEAB-...-D13-..., output pressure 2 (pressure regulation range) –1 ... 1

Flow rate  $q_n$  from 1 → 2 as a function of output pressure  $p_2$





Flow rate  $q_n$  from 2 → 3 as a function of output pressure  $p_2$



## Datasheet


VEAB-...-D18-..., output pressure 2 (pressure regulation range) –1 ... 5

Flow rate  $q_n$  from 1 → 2 as a function of output pressure  $p_2$ Flow rate  $q_n$  from 2 → 3 as a function of output pressure  $p_2$ 


## Datasheet

VEAB-...-D15-..., output pressure 2 (pressure regulation range) –0,5 ... 0,5

Flow rate  $q_n$  from 1 → 2 as a function of output pressure  $p_2$





Flow rate  $q_n$  from 2 → 3 as a function of output pressure  $p_2$



## Datasheet


VEAB-...-D12-..., output pressure 2 (pressure regulation range) -0.001 ... 0.2

Flow rate  $q_n$  from 1 → 2 as a function of output pressure  $p_2$ Flow rate  $q_n$  from 2 → 3 as a function of output pressure  $p_2$ 


## Datasheet

VEAB-...-D7-..., output pressure 2 (pressure regulation range) -0.005 ... 1

Flow rate  $q_n$  from 1 → 2 as a function of output pressure  $p_2$





Flow rate  $q_n$  from 2 → 3 as a function of output pressure  $p_2$



## Datasheet


VEAB-...-D2-..., output pressure 2 (pressure regulation range) -0.01 ... 2

Flow rate  $q_n$  from 1 → 2 as a function of output pressure  $p_2$ Flow rate  $q_n$  from 2 → 3 as a function of output pressure  $p_2$ 


## Datasheet

VEAB-...-D9-..., output pressure 2 (pressure regulation range) -0.03 ... 6

Flow rate  $q_n$  from 1 → 2 as a function of output pressure  $p_2$




Flow rate  $q_n$  from 2 → 3 as a function of output pressure  $p_2$



## Datasheet

## Dimensions

In-line valve

Download CAD data at [www.festo.com](http://www.festo.com)

[1] Plug M8x1, 4-pin

Type	B1	B2	D1 Ø	D2 Ø	H1	H2	H3	H4	H5	H6	H7
VEAB-L	18	9	4	3.2	85	76	14	19	9.5	9.6	4.8


Type	L1	L2	L3	L4	L5
VEAB-L	64	60.5	52.5	22.6	14.2

## Datasheet

## Dimensions

Download CAD data at [www.festo.com](http://www.festo.com)

Sub-base valve




Type	B1	B3	B4	B5	D3 Ø	H1	H2	H8
VEAB-B	18	1.1	1	1.5	3.2	66	58	6
Type	L1	L2	L3	L6	L7	L8	L9	L10
VEAB-B	67.2	60.5	52.5	63.6	3.6	43.3	33	22.3

## Datasheet

## Dimensions – Manifold rail

Connection direction on the side

Download CAD data at [www.festo.com](http://www.festo.com)

Type	B1	B2	B3	D1	D2 ∅	D5 ∅	D6	D7	D8 ∅	D9	H1	H2	H3	H4	H5	H9
VABM-P7-18M-G18-M5-4	15	7.5	8.5	G1/8	6	4.5	M3	M5	2.9	M4	67.8	44.8	28.2	60.2	3.8	31
VABM-P7-18M-G18-M5-6																
VABM-P7-18M-G18-M5-8																


Type	L1	L2	L3	L4	L5	L6	L10	L11	T1	T2	T4	T5	T6
VABM-P7-18M-G18-M5-4	72	54	36	18	9	18	58	7	13	6	7	5	7
VABM-P7-18M-G18-M5-6	108	90	72				94						
VABM-P7-18M-G18-M5-8	144	126	108				130						

## Datasheet

## Dimensions – Manifold rail

Download CAD data at [www.festo.com](http://www.festo.com)



Connection direction underneath






Type	B1	B2	B3	D1	D2 Ø	D3	D4	D5 Ø	D6	D7 Ø	H1	H2	H3	H4	H5	H6
VABM-P7-18MB-G18-M5-4	15	7.5	8.5	G1/8	6	G1/8	M5	4.5	M3	2.9	67.8	44.8	28.2	60.2	3.8	44.8
VABM-P7-18MB-G18-M5-6																
VABM-P7-18MB-G18-M5-8																

Type	H7	H8	L1	L2	L3	L4	L5	L6	L9	T1	T2	T3
VABM-P7-18MB-G18-M5-4	28.2	15	72	54	36	18	9	18	36	13	6	5
VABM-P7-18MB-G18-M5-6			108	90	72							
VABM-P7-18MB-G18-M5-8			144	126	108							



## Datasheet

Ordering data					
	Output pressure 2 (pressure regulation range) [MPa]	Part no.	Type		
<b>In-line valve</b>					
	Voltage type, 0 ... 5 V	-0.1 ... -0.0005 -0.1 ... 0.1 -0.1 ... 0.5 -0.05 ... 0.05 0.0001 ... 0.02 0.0005 ... 0.1 0.001 ... 0.2 0.0025 ... 0.5 0.003 ... 0.6	8153676 8153681 8153682 8153680 8153673 8153674 8153675 8153685 8153672	VEAB-L-26-D14-Q4-V2-1R1 VEAB-L-26-D13-Q4-V2-1R1 VEAB-L-26-D18-Q4-V2-1R1 VEAB-L-26-D15-Q4-V2-1R1 VEAB-L-26-D12-Q4-V2-1R1 VEAB-L-26-D7-Q4-V2-1R1 VEAB-L-26-D2-Q4-V2-1R1 VEAB-L-26-D25-Q4-V2-1R1 VEAB-L-26-D9-Q4-V2-1R1	
	Voltage type, 0 ... 10 V	-0.1 ... -0.0005 -0.1 ... 0.1 -0.1 ... 0.5 -0.05 ... 0.05 0.0001 ... 0.02 0.0005 ... 0.1 0.001 ... 0.2 0.003 ... 0.6	8046307 8067677 8067679 8067675 8046301 8046303 8046305 8046299	VEAB-L-26-D14-Q4-V1-1R1 VEAB-L-26-D13-Q4-V1-1R1 VEAB-L-26-D18-Q4-V1-1R1 VEAB-L-26-D15-Q4-V1-1R1 VEAB-L-26-D12-Q4-V1-1R1 VEAB-L-26-D7-Q4-V1-1R1 VEAB-L-26-D2-Q4-V1-1R1 VEAB-L-26-D9-Q4-V1-1R1	
	Current type, 4 ... 20 mA	-0.1 ... -0.0005 -0.1 ... 0.1 -0.1 ... 0.5 -0.05 ... 0.05 0.0001 ... 0.02 0.0005 ... 0.1 0.001 ... 0.2 0.003 ... 0.6	8046308 8067678 8067680 8067676 8046302 8046304 8046306 8046300	VEAB-L-26-D14-Q4-A4-1R1 VEAB-L-26-D13-Q4-A4-1R1 VEAB-L-26-D18-Q4-A4-1R1 VEAB-L-26-D15-Q4-A4-1R1 VEAB-L-26-D12-Q4-A4-1R1 VEAB-L-26-D7-Q4-A4-1R1 VEAB-L-26-D2-Q4-A4-1R1 VEAB-L-26-D9-Q4-A4-1R1	
	<b>Sub-base valve</b>				
		Voltage type, 0 ... 5 V	-0.1 ... -0.0005 -0.1 ... 0.1 -0.1 ... 0.5 -0.05 ... 0.05 0.0001 ... 0.02 0.0005 ... 0.1 0.001 ... 0.2 0.0025 ... 0.5 0.003 ... 0.6	8153671 8153678 8153679 8153677 8153668 8153669 8153670 8153684 8153667	VEAB-B-26-D14-F-V2-1R1 VEAB-B-26-D13-F-V2-1R1 VEAB-B-26-D18-F-V2-1R1 VEAB-B-26-D15-F-V2-1R1 VEAB-B-26-D12-F-V2-1R1 VEAB-B-26-D7-F-V2-1R1 VEAB-B-26-D2-F-V2-1R1 VEAB-B-26-D25-F-V2-1R1 VEAB-B-26-D9-F-V2-1R1
		Voltage type, 0 ... 10 V	-0.1 ... -0.0005 -0.1 ... 0.1 -0.1 ... 0.5 -0.05 ... 0.05 0.0001 ... 0.02 0.0005 ... 0.1 0.001 ... 0.2 0.003 ... 0.6	8046271 8067669 8067671 8067667 8046265 8046267 8046269 8046263	VEAB-B-26-D14-F-V1-1R1 VEAB-B-26-D13-F-V1-1R1 VEAB-B-26-D18-F-V1-1R1 VEAB-B-26-D15-F-V1-1R1 VEAB-B-26-D12-F-V1-1R1 VEAB-B-26-D7-F-V1-1R1 VEAB-B-26-D2-F-V1-1R1 VEAB-B-26-D9-F-V1-1R1
		Current type, 4 ... 20 mA	-0.1 ... -0.0005 -0.1 ... 0.1 -0.1 ... 0.5 -0.05 ... 0.05 0.0001 ... 0.02 0.0005 ... 0.1 0.001 ... 0.2 0.003 ... 0.6	8046272 8067670 8067672 8067668 8046266 8046268 8046270 8046264	VEAB-B-26-D14-F-A4-1R1 VEAB-B-26-D13-F-A4-1R1 VEAB-B-26-D18-F-A4-1R1 VEAB-B-26-D15-F-A4-1R1 VEAB-B-26-D12-F-A4-1R1 VEAB-B-26-D7-F-A4-1R1 VEAB-B-26-D2-F-A4-1R1 VEAB-B-26-D9-F-A4-1R1

## Datasheet

Ordering data		Description	Part no.	Type
<b>Manifold rail</b>				
	Connection direction on the side	4 valve positions	<b>8076386</b>	VABM-P7-18M-G18-M5-4
		6 valve positions	<b>8076388</b>	VABM-P7-18M-G18-M5-6
		8 valve positions	<b>8076390</b>	VABM-P7-18M-G18-M5-8
	Connection direction underneath	4 valve positions	<b>8076387</b>	VABM-P7-18MB-G18-M5-4
		6 valve positions	<b>8076389</b>	VABM-P7-18MB-G18-M5-6
		8 valve positions	<b>8076391</b>	VABM-P7-18MB-G18-M5-8
<b>Cover plate</b>				
	Including screws (2) and O-rings (3, premounted)		<b>4054658</b>	VABB-P7-M

## Accessories

Ordering data		Description	Part no.	Type
Connecting cable				Datasheets at Internet: <a href="#">nebu</a>
	Straight socket, M8x1, 4-pin Open end, 4-wire	2.5 m	541342	NEBU-M8G4-K-2.5-LE4
		5 m	541343	NEBU-M8G4-K-5-LE4
	Angled socket, M8x1, 4-pin Open end, 4-wire	2.5 m	541344	NEBU-M8W4-K-2.5-LE4
		5 m	541345	NEBU-M8W4-K-5-LE4
	Straight socket, M8x1, 4-pin Straight plug M8x1, 4-pin	2.5 m	554035	NEBU-M8G4-K-2.5-M8G4
H-rail				
	To EN 60715, 35 x 7.5 (WxH), for control cabinet installation	35430	NRH-35-2000	
H-rail mounting				
	For H-rail NRH-35-2000	4054652	VAME-P7-T	
Mounting plate				
	For in-line valve	4054656	VAME-P7-Y	

# Festo - Your Partner in Automation



## 1 Festo Inc.

5300 Explorer Drive  
Mississauga, ON L4W 5G4  
Canada

### Festo Customer Interaction Center

Tel: 1 877 463 3786  
Fax: 1 877 393 3786  
Email: [customer.service.ca@festo.com](mailto:customer.service.ca@festo.com)

## 2 Festo Pneumatic

Av. Ceylán 3,  
Col. Tequesquínáhuac  
54020 Tlalnepantla,  
Estado de México

### Multinational Contact Center

01 800 337 8669  
[ventas.mexico@festo.com](mailto:ventas.mexico@festo.com)

## 3 Festo Corporation

1377 Motor Parkway  
Suite 310  
Islandia, NY 11749

### Festo Customer Interaction Center

1 800 993 3786  
1 800 963 3786  
[customer.service.us@festo.com](mailto:customer.service.us@festo.com)

## 4 Regional Service Center

7777 Columbia Road  
Mason, OH 45040

### Connect with us



[www.festo.com/socialmedia](http://www.festo.com/socialmedia)



[www.festo.com](http://www.festo.com)