Soft-start/quick exhaust valves MS-SV, MS series

FESTO



Service unit components of the MS series

Solutions for every application

With its large product range, highly effective components and a wide choice of functions, the MS series from Festo offers a complete concept for compressed air preparation. It is suitable for simple standard applications as well as for application-specific solutions with very high quality requirements.

Available as individual components, pre-assembled combinations ex-stock, application-specific combinations or complete turnkey solutions. The five sizes in the MS series achieve maximum flow rates with low space requirements.

Freely combinable functional modules

Pressure regulators, on/off and softstart valves with safety function, filters, pressure and flow sensors, dryers, sensors and lubricators can be assembled into a suitable solution for every task. With the modular structure the components can be combined as required. The simple connection system saves time because there is no need to disassemble the entire combination when replacing individual modules. Many of the components are also UL and ATEX certified.

CAD models and configurator

Convenient tools for planning and selecting application-specific individual components and combinations. The product configurator can be used to configure customised solutions quickly and to transfer the order data without any hassle.

Engineering tools

Selection tool for choosing the right service unit combination without oversizing, and with the right air purity class:

→ www.festo.com/engineering/ service unit



Integrated sensors

Pressure and flow sensors

Safety functions


Soft-start/quick exhaust valves MS6-SV/MS9-SV

Saving energy

Service unit combinations MSE6

Intelligent mix of sizes





- Reliable compressed air preparation and system supply
- Integrated or stand-alone
- Easy to connect with M8/M12 plug



- Fast and reliable exhausting of systems up to Performance Level e, certified to EN ISO 13849-1
- · Integrated soft-start function



- Fully automatic monitoring and regulation of the compressed air supply
- Compressed air automatically shut off in stand-by mode
- Detection and notification of leakages
- Condition monitoring of relevant process data



- Optimum flow rate with a size that is up to 18% smaller
- Excellent energy efficiency
- Cost-optimised combinations save up to 30%!

| Size differences | | | | | | |
|--|---------|----------|------------------|------------------------|-----------------------------------|------------------------|
| Size | | MS2 | MS4 | MS6 | MS9 | MS12 |
| Grid dimension | [mm] | 25 | 40 | 62 | 90 | 124 |
| Connection sizes | | M5, QS-6 | G1/8, G1/4, G3/8 | G1/4, G3/8, G1/2, G3/4 | G1/2, G3/4, G1, G1 1/4, G1 1/2 | G1, G1 1/4, G1 1/2, G2 |
| Standard nominal flow rate qnN ¹⁾ | [l/min] | 350 | 1800 | 6500 | 20000 | 22000 |

Using pressure regulator MS-LR as an example

Note

Information

The next few pages provide a brief overview of the product range for the MS series service unit components.

You can find detailed information and all the technical data in the documentation for the relevant service unit component.

Accessories such as connecting plates or mounting brackets can be ordered either via the configurator or separately.

Design of a service unit combination

The order of the individual service unit components within a combination is relevant for safety and functionality. The service unit components cannot be combined in any order in the flow direction. They are subject to restrictions and rules.

The configurator for the service unit MSB is a reliable and convenient way of arranging individual service unit components and ensures compliance with the applicable rules. As a result, you get a fully assembled unit, including UL or ATEX certification, if necessary.

When combining a unit from individually configured and ordered service unit components, the points on the right must be adhered to under all circumstances.

- Regulators MS-LFR/LR/LRP/LRE are only permissible in the flow direction with the same or decreasing pressure regulation range
- Filters MS-LFR/LF/LFM/LFX are only permissible in the flow direction with an increasing grade of filtration
- Lubricators MS-LOE are not permitted in the flow direction upstream of a filter MS-LFR/LFM/LF/LFX, water separator MS-LWS or membrane air dryer MS-LDM1
- A micro filter MS-LFM must be installed in the flow direction upstream of an activated carbon filter MS-LFX or membrane air dryer MS-LDM1
- A flow sensor SFAM cannot be installed directly downstream of a regulator MS-LFR/LR; a branching module MS-FRM must be positioned between them
- A soft-start/quick exhaust valve MS-SV must be the last service unit component in the flow direction

| Гуре | Description | Size | Pneumatic o | connection | | | | | |
|-----------------|-------------------------------------|------|-------------|------------|---------------|--------|----------------------------|------------------------------|--|
| | | | Push-in | Female th | read | - | Connecting plate with thre | Connecting plate with thread | |
| | | | connector | M | G | NPT | G | NPT | |
| Combinations | | | | | | | | | |
| Service unit co | ombinations MSB-FRC | | | | | | | Datasheets → Internet: ms | |
| | Combinations of filter regu- | 4 | - | - | 1/8, 1/4 | - | - | - | |
| - | lator and lubricator | 6 | - | _ | 1/4, 3/8, 1/2 | _ | - | - | |
| J. Committee | | | | | | | | | |
| Service unit co | ombinations MSB | | | | | | | Datasheets → Internet: ms | |
| 7 | 7 combinations, predefined | 4 | - | - | 1/4 | - | - | - | |
| | | 6 | - | - | 1/2 | Ī- | - | _ | |
| T | | | | 1 | | 1 | 1410.414.010 | Tulo dili ala | |
| - Anna S | Freely configurable combi- | 4 | - | - | 1/8, 1/4 | - | 1/8, 1/4, 3/8 | 1/8, 1/4, 3/8 | |
| | nations | 6 | - | - | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 | |
| | | 9 | - | _ | 3/4, 1 | 3/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | |
| A. W. | | | | | | | | | |
| Service unit co | ombinations MSE6 | | | | | | | Datasheets → Internet: mse | |
| 4 15- | Combinations with fieldbus | 6 | - | - | - | - | 1/2 | - | |
| 100 | connection for measuring | | | , | | | | | |
| (3) | l d | 1 | | | | | | | |
| | pressure, flow rate and consumption | | | | | | | | |

| Гуре | Description | Size | Pneumatic | connection | | | | | | | | |
|----------------|---|------|-----------|------------|---------------|---------|-----------------------------------|--------------------------------|--|--|--|--|
| | | | Push-in | Female thi | read | | Connecting plate with thre | ad | | | | |
| | | | connector | M | G | NPT | G | NPT | | | | |
| dividual devi | ices | | | | | | | | | | | |
| lter regulator | rs MS-LFR | | | | | | Datasheets → Internet: ms2-lfr; m | s4-lfr; ms6-lfr; ms9-lfr; ms12 | | | | |
| - | Filter and pressure regula- | 2 | QS-6 | M5 | - | - | - | - | | | | |
| - 60 | tor in a single device, grade | 4 | - | - | 1/8, 1/4 | - | 1/8, 1/4, 3/8 | 1/8, 1/4, 3/8 | | | | |
| 100 | of filtration 5 or 40 μm | 6 | - | - | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 | | | | |
| Ш | | 9 | - | - | 3/4, 1 | 3/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | | | | |
| Ш | | 12 | - | _ | _ | _ | 1, 1 1/4, 1 1/2, 2 | - | | | | |
| lter regulator | rs MS-LFR-B | | | | | | Datasheets | → Internet: ms4-lfr-b; ms6- | | | | |
| | Filter and pressure regula- | 4 | - | - | 1/4 | _ | - | _ | | | | |
| - | tor in a single device in pol- | 6 | - | - | 1/2 | - | _ | _ | | | | |
| · 155 | ymer housing, grade of fil- | | | | | | L | | | | | |
| | tration 5 or 40 µm | | | | | | | | | | | |
| | | | | | | | | | | | | |
| T . | | | | | | | | | | | | |
| lters MS-LF | | | | | | | Datasheets → Internet | :: ms4-lf; ms6-lf; ms9-lf; ms1 | | | | |
| Sec. 1 | Grade of filtration 5 or | 4 | - | - | 1/8, 1/4 | - | 1/8, 1/4, 3/8 | 1/8, 1/4, 3/8 | | | | |
| I | 40 μm | 6 | - | - | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 | | | | |
| 1 | | 9 | - | - | 3/4, 1 | 3/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | | | | |
| 1 | | 12 | - | - | - | - | 1, 1 1/4, 1 1/2, 2 | _ | | | | |
| | | | | | | | | | | | | |
| ine and micro | filters MS-LFM | | | | | | Datasheets → Internet: ms4-li | fm: ms6-lfm: ms9-lfm: ms12- | | | | |
| - | Grade of filtration 0.01 or | 4 | - | _ | 1/8, 1/4 | _ | 1/8, 1/4, 3/8 | 1/8, 1/4, 3/8 | | | | |
| · | 1 μm | 6 | - | - | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 | | | | |
| 1 | | 9 | - | - | 3/4, 1 | 3/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | | | | |
| 1 | | 12 | - | - | - | - | 1, 1 1/4, 1 1/2, 2 | - | | | | |
| | | | | | | | | | | | | |
| | CIL MC LEV | | | | | | D. I. I. I. | | | | | |
| ctivated carbo | on filters MS-LFX | , | | 1 | 1/0 4// | 1_ | 1 | 4-lfx; ms6-lfx; ms9-lfx; ms12 | | | | |
| 7 | For removing liquid and gaseous oil particles | 6 | - - | - - | 1/8, 1/4 | - _ | 1/8, 1/4, 3/8 | 1/8, 1/4, 3/8 | | | | |
| - | gaseous on particles | | | + | 1/4, 3/8, 1/2 | | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 | | | | |
| 1 | | 9 | | - | 3/4, 1 | 3/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | | | | |
| | | 12 | - | - | _ | - | 1, 1 1/4, 1 1/2, 2 | _ | | | | |
| | | | | | | | | | | | | |
| later separato | | 1 . | | | T., | | 1 | et: ms6-lws; ms9-lws; ms12- | | | | |
| | Remove condensate from | 6 | - | - | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 | | | | |
| * | compressed air, mainte- | 9 | _ | - | 3/4, 1 | 3/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | | | | |
| | nance-free | 12 | | | l_ | _ | 1, 1 1/4, 1 1/2, 2 | _ | | | | |

| Туре | Description | Size | Pneumatic connection | | | | | | |
|-----------------|--|------|----------------------|------------|---------------|--------|-------------------------------|-------------------------------|--|
| | | | Push-in | Female thr | ead | | Connecting plate with three | ad | |
| | | | connector | М | G | NPT | G | NPT | |
| ndividual devic | es | | | | | | | | |
| ressure regulat | tors MS-LR | | | | | | Datasheets → Internet: ms2-lr | ; ms4-lr; ms6-lr; ms9-lr; ms1 | |
| - | For setting the required op- | 2 | QS-6 | M5 | _ | - | - | _ | |
| 100 | erating pressure, | 4 | - | - | 1/8, 1/4 | - | 1/8, 1/4, 3/8 | 1/8, 1/4, 3/8 | |
| - 46 | 4 pressure regulation rang- | 6 | - | - | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 | |
| 2 | es | 9 | - | - | 3/4, 1 | 3/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | |
| | | 12 | _ | - | - | - | 1, 1 1/4, 1 1/2, 2 | - | |
| ressure regulat | tors MS-I R-R | | | | | | Datasheet | s → Internet: ms4-lr-b; ms6- | |
| ressure regular | For setting the required op- | 4 | T_ | T_ | 1/4 | T_ | _ | - | |
| | erating pressure, in poly- | 6 | 1_ | - | 1/2 | _ | _ | | |
| | mer housing | | | | 1/2 | | | | |
| 10 | | | | | | | | | |
| | | | | | | | | | |
| roccuro roculat | tors MC LDD | | | | | | Datashas | | |
| ressure regulat | For configuring a regulator | 4 | 1_ | 1_ | 1/4 | T_ | 1/8, 1/4, 3/8 | ets → Internet: ms4-lrb; ms6 | |
| | manifold with independent | | - | 1_ | 1/4 | - | | - | |
| - 1 | pressure regulation ranges. | В | |]- | 1/2 | - | 1/4, 3/8, 1/2, 3/4 | - | |
| 1000 | Pressure output is to the | | | | | | | | |
| 1000 | front or rear. | | | | | | | | |
| | l. MCIPP | | | | | | | D. I | |
| recision pressu | ure regulators MS-LRP | | T_ | 1 | 111 212 112 | 1 | 1 | Datasheets → Internet: ms6 | |
| 418 | For precisely setting the required operating pressure, | 6 | - | - | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 | |
| - 11 | 4 pressure regulation rang- | | | | | | | | |
| | es, | | | | | | | | |
| . 00 | pressure hysteresis | | | | | | | | |
| | 0.02 bar | | | | | | | | |
| | | | | | | | | | |
| recision pressu | re regulators MS-LRPB | _ | | 1 | 1/2 | | 1 | latasheets → Internet: ms6-l | |
| 100 | For configuring a regulator manifold with independent | 6 | | - | 1/2 | - | 1/4, 3/8, 1/2, 3/4 | - | |
| - 10 | pressure regulation ranges. | | | | | | | | |
| -460 | Pressure output is to the | | | | | | | | |
| (A) (A) | front or rear. | | | | | | | | |
| | nont of real. | | | | | | | | |
| ubricators MS- | LOE | | | | | | Datasheets → Internet: ms4-l | oe; ms6-loe; ms9-loe; ms12 | |
| 4 | Add a precisely adjustable | 4 | - | - | 1/8, 1/4 | - | 1/8, 1/4, 3/8 | 1/8, 1/4, 3/8 | |
| | amount of oil to the com- | 6 | - | - | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 | |
| 1 | pressed air. The amount of | 9 | - | - | 3/4, 1 | 3/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | |
| | oil mist is proportional to | 12 | - | - | - | - | 1, 1 1/4, 1 1/2, 2 | - | |
| | the compressed air flow | | | | I | | | | |
| | rate. | | | | | | | | |

| Туре | Description | Size | ze Pneumatic connection | | | | | |
|----------------------|---|------|-------------------------|------------|---------------|--------|-----------------------------|------------------------------|
| ,, | ' | | Push-in | Female thr | ead | | Connecting plate with thre | ad |
| | | | connector | М | G | NPT | G | NPT |
| ndividual device | es | | | | | | | |
| n/off valves MS | S-EM | | | | | | Datasheets → Internet: ms4- | em; ms6-em; ms9-em; ms12- |
| | Manually actuated on/off | 4 | - | - | 1/8, 1/4 | _ | 1/8, 1/4, 3/8 | 1/8, 1/4, 3/8 |
| | valve for pressurising and | 6 | - | - | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 |
| 1 | exhausting pneumatic sys- | 9 | _ | - | 3/4, 1 | 3/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 |
| 1 | tems. | 12 | - | - | - | - | 1, 1 1/4, 1 1/2, 2 | - |
| | | | | | | | | |
| n/off valves MS | S-EE | | | | | | Datasheets → Internet: ms | 54-ee; ms6-ee; ms9-ee; ms12 |
| 78. | Electrically actuated on/off | 4 | _ | - | 1/8, 1/4 | _ | 1/8, 1/4, 3/8 | 1/8, 1/4, 3/8 |
| 1000 | valve for pressurising and | 6 | _ | - | 1/4, 3/8, 1/2 | _ | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 |
| 700 | exhausting pneumatic sys- | 9 | - | - | 3/4, 1 | 3/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 |
| 101 | tems. | 12 | - | - | _ | - | 1, 1 1/4, 1 1/2, 2 | - |
| - | | | | | | | | |
| n/off valves MS | S.FF.R | | | - | | | Natachoote . | → Internet: ms4-ee-b; ms6-e |
| ., 5.1. 741.765 1913 | Electrically actuated on/off | 4 | 1_ | T_ | 1/4 | Ī_ | _ Datasneets | |
| 900 | valve in polymer housing | 6 | 1_ | - - | 1/4 | - | | - - |
| | for pressurising and ex- | ا ا | | | 1-1- | 1 | | |
| • | hausting pneumatic sys- | | | | | | | |
| ~ | tems. | | | | | | | |
| | | | | | | | | |
| oft-start valves | | 1 | | | | | | iternet: ms4-dl; ms6-dl; ms1 |
| -803 | Pneumatically actuated | 4 | - | - | 1/8, 1/4 | - | 1/8, 1/4, 3/8 | 1/8, 1/4, 3/8 |
| 0000 | soft-start valve for slowly | 6 | - | - | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 |
| | pressurising and exhaust- ing pneumatic systems. | 12 | - | - | | - | 1, 1 1/4, 1 1/2, 2 | |
| | ing pheumatic systems. | | | | | | | |
| oft-start valves | MS-DE | | | | | | Datasheets → Inte | ernet: ms4-de; ms6-de; ms12 |
| * | Electrically actuated soft- | 4 | - | _ | 1/8, 1/4 | _ | 1/8, 1/4, 3/8 | 1/8, 1/4, 3/8 |
| | start valve for slowly pres- | 6 | - | - | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 |
| Sec. | surising and exhausting | 12 | - | - | _ | - | 1, 1 1/4, 1 1/2, 2 | - |
| | pneumatic systems. | | | | , | • | | , |
| - | | | | | | | | |
| n/off valves MS | S-EDE-B | | | | | | Datasheets → | Internet: ms4-ede-b; ms6-ed |
| - | Electrically actuated soft- | 4 | _ | _ | 1/4 | _ | _ | _ |
| 786. | start valve in polymer hous- | 6 | - | - | 1/2 | - | - | - |
| | ing for slowly pressurising | | | -1 | Į. | 1 | | , |
| | and exhausting pneumatic | | | | | | | |
| | systems. | | | | | | | |
| oft start/quick | exhaust valves MS-SV | | | | | | Datash | eets → Internet: ms6-sv; ms9 |
| oit-start/quick | For building up pressure | 6 | | T_ | 1/2 | 1_ | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 |
| | gradually and reducing | 9 | - | - | 3/4, 1 | 3/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 |
| 3 | pressure quickly and safely | - | | - | 3/4, 1 | 5/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 |
| ~ | in pneumatic piping sys- | | | | | | | |
| - 11 | tems. | | | | | | | |
| U | Up to category 1, PL c. | | | | | | | |
| 264 | Up to category 3, PL d. | 6 | _ | - | 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 |
| 518 | Up to category 4, PL e in the | | | | | | | |
| Ji | case of optional extension. | | | | | | | |
| / ■ | | | | | | | | |
| 1/100 | | | | | | | | |
| | Up to category 4, PL e. | 6 | - | _ | 1/2 | - | 1/4, 3/8, 1/2, 3/4 | - |
| A) = | | | · | | | | | |
| | | | | | | | | |
| H | | | | | | | | |
| CD | 1 | 1 | | | | | | |


| Туре | Description | Size | Pneumatic o | onnection | | | | |
|-----------------|---|------|-------------|------------|---------------|--------|-------------------------------|--------------------------------|
| | | | Push-in | Female thi | read | | Connecting plate with thre | ad |
| | | | connector | M | G | NPT | G | NPT |
| ndividual dev | ices | | | | | | | |
| Membrane air | dryers MS-LDM1 | | , | | | | Datasheets | → Internet: ms4-ldm; ms6-ld |
| 10 | Wear-free membrane dryer | 4 | - | - | 1/8, 1/4 | - | 1/8, 1/4, 3/8 | 1/8, 1/4, 3/8 |
| ï | with internal air consump- | 6 | - | _ | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | 1/4, 3/8, 1/2, 3/4 |
| | | | | | | | | |
| Branching mo | dules MS-FRM | | | | | | Datasheets → Internet: ms4-fr | m; ms6-frm; ms9-frm; ms12-f |
| Com | Compressed air distributors | 4 | - | _ | 1/8, 1/4 | _ | 1/8, 1/4, 3/8 | _ |
| - | with 4 connections | 6 | - | 1- | 1/4, 3/8, 1/2 | - | 1/4, 3/8, 1/2, 3/4 | _ |
| - | | 9 | - | - | 3/4, 1 | 3/4, 1 | 1/2, 3/4, 1, 1 1/4, 1 1/2 | 1/2, 3/4, 1, 1 1/4, 1 1/2 |
| | | 12 | - | - | _ | _ | 1, 1 1/4, 1 1/2, 2 | - |
| | | | | | | | | |
| Distributor blo | ocks MS-FRM-FRZ | | | | | | Datasheets → Ir | nternet: ms4-frm-frz; ms6-frm- |
| | Compressed air distributors | 4 | - | - | - | - | - | - |
| @1 | with 4 connections and half the grid width | 6 | - | - | - | - | - | - |
| 7 | the grid width | | | | | | | |
| Flow sensors S | SFAM | | | | | | | Datasheets → Internet: sfa |
| frame. | For absolute flow rate infor- | 6 | - | _ | _ | _ | 1/2 | 1/2 |
| 0.1 1 | mation and cumulative air | 9 | - | _ | _ | - | 1, 1 1/2 | 1, 1 1/2 |
| - 1 | consumption measurement | | | | | | | |
| | | | | | | | | |

Type codes MS6-SV

| 001 | Series | |
|------------|---|--|
| MS | MS series | |
| 002 | Size | |
| 6 | Grid dimension 62 mm | |
| 003 | Function | |
| SV | Soft-start/quick exhaust valve | |
| <u> </u> | John Starry quick Canadat valve | |
| 004 | Pneumatic connection | |
| 1/2 | Female thread G1/2 | |
| AGB | Sub-base G1/4 | |
| AGC | Sub-base G3/8 | |
| AGD | Sub-base G1/2 | |
| AGE | Sub-base G3/4 | |
| AQN | Sub-base 1/4 NPT | |
| AQP | Sub-base 3/8 NPT | |
| AQR | Sub-base 1/2 NPT | |
| AQS | Sub-base 3/4 NPT | |
| 005 | Performance Level | |
| C | Category 1, 1-channel to ISO 13849-1 | |
| D | Category 3, 1-channel to ISO 13849-1 | |
| E | Category 4, 2-channel with self-monitoring to ISO 13849-1 | |
| | | |
| 006 | Supply voltage | |
| 10V24P | 24 V DC, 10 bar, M12 plug socket adapter (connection pattern to EN 60947-5-2) | |
| 10V24 | 24 V DC, 10 bar, connection pattern to EN 175301 | |
| 10V24C | 24 V DC, 10 bar (connection pattern to EN 175301) without manual override | |
| 10V24D | 24 V DC, 10 bar, M12 (connection pattern to EN 60947-5-2) | |
| 10V24E | without manual override 24 V DC, 10 bar, M12 (connection pattern to EN 60947-5-2) | |
| 107241 | without manual override on the pilot actuator. With detenting | |
| 401/272 | internal manual override (can only be reset via 24 V). | |
| 10V24F | 24 V DC, 10 bar, M12 (connection pattern to EN 60947-5-2). Manual override on the pilot actuator non-detenting, internally | |
| | detenting | |
| ASIS | 22 V - 31.6 V DC, AS-i Safety at Work, SPEC3.0 Profile 7.5.5 | |
| 007 | Connection technology | |
| | None | |
| 20E | 2 SMT proximity sensors, 5 m, OE | |
| 2M8 | 2 SMT proximity sensors, 0.3 m, M8 | |
| 2M12 | 2 SMT proximity sensors, 0.3 m, M12 | |
| 008 | Extended sensing | |
| | None | |
| S 3 | Additional SMT proximity sensor; required to achieve Perfor- | |
| | mance Level "e"; corresponds to the selected connection tech- | |
| | nology | |
| 009 | Silencer | |
| | None | |
| S | Silencer | |
| | | |

| 010 | Pressure gauge alternatives | |
|------|---|--|
| | None | |
| A4 | Adapter for EN pressure gauge 1/4, without pressure gauge | |
| A8 | Adapter for EN pressure gauge 1/8, without pressure gauge | |
| AD7 | Pressure sensor with switching display, M8 plug, threshold val- | |
| | ue comparator, PNP, N/O | |
| AD8 | Pressure sensor with switching display, M8 plug, threshold value comparator, PNP, N/C | |
| AD9 | Pressure sensor with switching display, M8 plug, window comparator, PNP, N/O | |
| AD10 | Pressure sensor with operational status indicator, M8 plug, window comparator, PNP, N/C | |
| AD11 | Pressure sensor with LCD display, M12 plug, 4-pin, IO-Link®, PNP, NPN, 010 V, 15 V, 420 mA | |
| AD12 | Pressure sensor with LCD display, M8 plug, 4-pin, IO-Link®, PNP, NPN, 010 V, 15 V, 420 mA | |
| AG | MS pressure gauge | |
| RG | Integrated pressure gauge, red/green scale | |
| 011 | Alternative pressure gauge scale | |
| | MS pressure gauge | |
| PSI | psi | |
| MPA | MPa | |
| | | |
| 012 | Multi-pin plug socket | |
| | None | |
| MP1 | Multi-pin plug socket, Sub-D, 9-pin, screw terminal, without ca- | |
| | ble, static enable signals (EN1 = 24 V, EN2 = 24 V) | |
| MP3 | Multi-pin plug socket, Sub-D, 9-pin, screw terminal, without ca- ble, static enable signals (EN1 = 0 V, EN2 = 24 V), cross-circuit detection possible | |
| MP5 | Multi-pin plug socket, Sub-D, 9-pin, screw terminal, without ca- | |
| | ble, enable signals static (EN1=0 V, EN2=24 V), galvanic isolation of the enable signals from the supply voltage | |
| 013 | Type of mounting | |
| | Without mounting bracket | |
| WP | Mounting bracket basic design | |
| WPB | Mounting bracket for large wall gap | |
| WPM | Mounting bracket for hooking in service unit components | |
| WB | Mounting centrally at rear (wall mounting top and bottom), connecting plates not required | |
| 014 | Tamper protection | |
| | None | |
| MK | Full | |
| 015 | UL certification | |
| | None | |
| UL1 | cULus ordinary location for Canada and USA | |
| OLI | | |
| 016 | Flow direction | |
| - | Flow direction Flow direction from left to right | |

Peripherals overview MS6-SV-C





| Moun | ting attachments and accessories | | | | | | |
|------|-----------------------------------|--|--------------------------|-----------------------|--------------------------|-----------------------|----------|
| | | Single device | | | Combination | | |
| | | | Without connecting plate | With connecting plate | Without connecting plate | With connecting plate | |
| [1] | MS6-SV-C | Soft-start/quick exhaust valve | • | • | • | • | 11 |
| [2] | MS6-MV | Module connector | - | • | • | • | ms6-mv |
| [3] | MS6-WP, MS6-WPB, MS6-WPE, MS6-WPM | Mounting bracket | • | • | • | • | ms6-wp |
| [4] | MS6-WB | Mounting bracket | • | • | _ | _ | ms6-wb |
| [5] | MS6-SV-C-MK | Covering | • | • | • | • | 52 |
| [6] | MS6-END | Cover cap | - | _ | • | _ | ms6-end |
| [7] | MS6-AEND | Mounting plate | 1) | - | 1) | - | ms6-aend |
| [8] | MS6-AG | Connecting plate SET | _ | 1) | - | 1) | ms6-ag |
| | MS6-AQ | Connecting plate SET | _ | ■ 1) | - | 1) | ms6-aq |
| [9] | AD11 AD12 | Pressure sensor SPAU with LCD display | • | • | • | • | 17 |
| [10] | NEBU-M8LE4/NEBU-M12LE4 | Connecting cable | • | • | • | • | 54 |
| [11] | AD7 AD10 | Pressure sensor SDE5 with status indicator | • | • | • | • | 17 |
| [12] | NEBU-M8LE3 | Connecting cable | • | • | • | • | 54 |
| [13] | A4 | Adapter for EN pressure gauge 1/4 | • | - | • | - | 17 |
| [14] | MA | Pressure gauge | • | • | • | • | 54 |
| [15] | AG, RG | MS pressure gauge | | • | | • | 17 |
| [16] | U-3/4-B | Silencer | • | | | | 53 |

 $^{1) \\} Module connector MS6-MV [2] or mounting bracket MS6-WP, MS6-WPB, MS6-WPE, MS6-WPM [3] is required for mounting.$

Peripherals overview MS6-SV-C

Supply voltage Code: 10V24, 10V24C Supply voltage Code: 10V24D, 10V24E, 10V24F, 10V24P








Note

Additional accessories:


- Module connector for combination with size MS4, MS6 or size MS9
 - → Internet: amv rmv
- Adapter for mounting on profiles
 - → Internet: ipm


| Mount | ing attachments and accessories | | | | | | |
|-------|---------------------------------|------------------------|--------------------------|-----------------------|--------------------------|-----------------------|----------------------|
| | | | Single device | | Combination | | → Page/In- ternet |
| | | | Without connecting plate | With connecting plate | Without connecting plate | With connecting plate | |
| [1] | MEB-LD | Illuminating seal | • | • | • | • | 54 |
| [2] | KMEB | Plug socket with cable | • | • | • | • | 53 |
| [3] | MSSD-EB | Plug socket | • | • | | • | 53 |
| [4] | NEBU-M12G5 | Connecting cable | | • | • | • | 54 |
| [5] | NEBU-M12W5 | Connecting cable | | • | | • | 54 |

MS6-SV-...-10V24, 10V24F, 10V24P



















Electropneumatic soft-start/quick exhaust valve for gradual pressurisation and quick exhaust of system components (single channel).

The main restrictor in the cover permits a slow build-up of the output pressure p2. Once the output pressure p2 has reached the set pressure switchover point (switching pressure), the valve opens and the full operating pressure p1 is available at the output



- High volumetric flow rate for pressurisation and exhaust
- The filling flow rate can be set for slowly building up the pressure using a restrictor
- Adjustable pressure switchover point
- Optional pressure sensor
- Optional cover as tamper protection for the control parts

MS6-SV-...-10V24E



| Safety data | |
|--|--|
| Conforms to | EN ISO 13849-1 |
| Safety function | Exhausting |
| | Prevention of unexpected start-up (pressurisation) |
| Performance Level (PL) | Exhausting: up to category 1, PL c |
| | Prevention of unexpected start-up (pressurisation): up to category 1, PL c |
| Note on forced checking procedure | Switching frequency min. 1/month |
| CE marking (see declaration of conformity) ¹⁾ | To EU Machinery Directive |
| Shock resistance | Shock test with severity level 2 to FN 942017-5 and EN 60068-2-27 |
| Vibration resistance | Transport application test with severity level 2 to FN 942017-4 and EN 60068-2-6 |

1) More information: www.festo.com/catalogue/ms-sv \rightarrow Support/Downloads.



Note

The mechanical system is not tested in the controlled (i.e. pressurised) state.

Forced switch on/off: switching frequency should be at least once a month.

If the process-related switching frequency (safe exhausting) is less than once a month,

the machine operator must carry out a forced switch off.

| Pneumatic conne | ction 1, 2 | | | | | | |
|---------------------|---------------------|---|--|--|--|--|--|
| | Female thread | G1/2 | | | | | |
| | Connecting plate AG | G1/4, G3/8, G1/2 or G3/4 | | | | | |
| | Connecting plate AQ | 1/4 NPT, 3/8 NPT, 1/2 NPT or 3/4 NPT | | | | | |
| Pneumatic conne | | G3/4 | | | | | |
| Actuation type | , | Electrical | | | | | |
| Design | | Piston spool | | | | | |
| Type of mounting | | With accessories | | | | | |
| | | In-line installation | | | | | |
| Mounting position | n | Any | | | | | |
| Pressure indication | on | With pressure sensor for indicating the output pressure via LCD display and electrical output | | | | | |
| | | With pressure sensor for indicating the output pressure and electrical output via LCD display | | | | | |
| | | With pressure gauge for displaying the output pressure | | | | | |
| | | With pressure gauge with red/green scale for indicating the output pressure | | | | | |
| | | Prepared for G1/4 | | | | | |
| Valve function | | 3/2-way valve, closed, single solenoid | | | | | |
| | | Soft-start function, adjustable | | | | | |
| Non-overlapping | | Yes | | | | | |
| Exhaust air functi | on | Cannot be throttled | | | | | |
| Manual override | 10V24, 10V24F | At the pilot solenoid valve: non-detenting | | | | | |
| | | At the soft-start/quick exhaust valve: detenting, self-resetting | | | | | |
| | 10V24E | At the pilot solenoid valve: none | | | | | |
| | | At the soft-start/quick exhaust valve: detenting, self-resetting | | | | | |
| | 10V24P | At the pilot solenoid valve: non-detenting/detenting | | | | | |
| | 401/0 / C 401/0 / D | At the soft-start/quick exhaust valve: detenting, self-resetting | | | | | |
| D : 11 1 | 10V24C, 10V24D | None | | | | | |
| Reset method | | Mechanical spring | | | | | |
| Type of actuation | | Piloted | | | | | |
| Pilot air supply | | Internal | | | | | |
| Sealing principle | | Soft | | | | | |

| Characteristic flow rate values | | | | | | |
|---------------------------------------|--------------------|--|--|--|--|--|
| Pneumatic connection | Female thread G1/2 | | | | | |
| Standard nominal flow rate qnN1) [l/r | min] | | | | | |
| In main flow direction 1 → 2 | 5700 | | | | | |
| Standard flow rate qN [l/min], p2 = 6 | i bar | | | | | |
| In exhaust direction 2 → 3 | 7600 ²⁾ | | | | | |
| C value [l/s*min] | C value [l/s*min] | | | | | |
| In main flow direction 1 → 2 | 23.2 | | | | | |
| b value | | | | | | |
| In main flow direction 1 → 2 | 0.4 | | | | | |

¹⁾ Measured at p1 = 6 bar and p2 = 5 bar, $\Delta p = 1$ bar

²⁾ Measured with reference to atmosphere with silencer S.

| Electrical data | | |
|--------------------------|-----------------------------------|--|
| Characteristic coil data | 10V24, 10V24P | 24 V DC: 1.8 W; permissible voltage fluctuations –10%/+10% |
| | 10V24C, 10V24D, 10V24E, 10V24F | 24 V DC: 1.8 W; permissible voltage fluctuations –15%/+10% |
| Electrical connection | 10V24, 10V24C | Plug, 2-pin, to EN 175301-803, type C |
| | 10V24D, 10V24E, 10V24F, 10V24P | M12x1 to ISO 20401 in line with EN 61076-2-101 |
| Degree of protection | | IP65 with plug socket |
| Duty cycle | [%] | 100 |
| Switching time off | [ms] | 65 |
| Switching time on | [ms] | 370 |


| Operating and environmental co | Operating and environmental conditions | | | | | | |
|--|--|---|--|--|--|--|--|
| Operating pressure | [bar] | 310 | | | | | |
| Operating medium | | Compressed air to ISO 8573-1:2010 [7:4:4] | | | | | |
| Note on the operating/pilot medium | | Lubricated operation possible (in which case lubrication will always be required) | | | | | |
| Ambient temperature | [°C] | 0 +60 (0 +50) ¹⁾ | | | | | |
| Temperature of medium | [°C] | 0 +60 (0 +50) ¹⁾ | | | | | |
| Storage temperature | [°C] | -10 +60 (0 +50) ¹⁾ | | | | | |
| Corrosion resistance class CRC ²⁾ | | 2 | | | | | |
| CE marking (see declaration of conformity) ³⁾ | | To EU Machinery Directive | | | | | |
| Food-safe ³⁾ | | See supplementary material information (except for solenoid valve) | | | | | |

- 1) With pressure sensor AD...
- 2) More information: www.festo.com/x/topic/crc
- 3) More information: www.festo.com/catalogue/ms-sv \rightarrow Support/Downloads.

| Weight [g] | |
|--|------|
| Soft-start/quick exhaust valve | 886 |
| Soft-start/quick exhaust valve with silencer S | 1006 |

| Materials | |
|------------------------|----------------------------|
| Housing | Die-cast aluminium |
| Piston rod | High-alloy stainless steel |
| Seals | NBR |
| Note on materials | RoHS-compliant |
| LABS (PWIS) conformity | VDMA24364-B1/B2-L |

Adjusting elements



- [1] Screw for adjusting the pressure switchover point
- [2] Flow control screw for adjusting the filling time
- [3] Manual override at the soft-start/ quick exhaust valve:
 - detenting, self-resetting as soon as the solenoid coil or manual override on the pilot solenoid valve is actuated (with 10V24, 10V24E, 10V24F, 10V24P)
 - none (with 10V24C, 10V24D)
- [4] Manual override at the pilot solenoid valve:
 - non-detenting, actuation from above (with 10V24/10V24F)
 - non-detenting/detenting, actuation from above (with 10V24P)
 - none (with 10V24C, 10V24D, 10V24E)

Dimensions - Basic version Download CAD data → www.festo.com With female thread 1/2, with cover plate 1 = not assigned Supply voltage Supply voltage 2 = not assigned 3 = com(-)10V24, 10V24C 10V24D, 10V24E, 10V24F, 10V24P 4 = Signal (+) solenoid 14 2 1 [1] Plug connection to EN 175301-В4 B5 Electrical connection M12x1 to [2] ISO 20401 in line with EN 61076-2-101, 4-pin version for connecting cable NEBU-M12 Flow direction With silencer S Type В1 В4 В5 D1 D2 D5 MS6-SV-C G1/2 M12x1 128 62 31 76 G3/4 144 71 Type

10V24D, 10V24E, 10V24F,


10V24P

37

MS6-SV-C

Dimensions – Pressure gauges/pressure gauge alternatives

Integrated MS pressure gauge with standard scale AG or red/green scale RG, display unit [bar]



→ Flow direction

10V24, 10V24C

33

Download CAD data → www.festo.com

10V24D, 10V24E, 10V24F,


10V24P

26

Adapter A4 for EN pressure gauge 1/4, without pressure gauge

10V24, 10V24C

24



→ Flow direction


| Туре | B4 | B5 | D4 |
|----------|----|------|------|
| MS6-SVAG | 31 | 77 | - |
| MS6-SVRG | 31 | 78.5 | - |
| MS6-SVA4 | 31 | 78.5 | G1/4 |

Note: This product conforms to ISO 1179-1 and ISO 228-1.

[•] Note: This product conforms to ISO 1179-1 and ISO 228-1.

Dimensions - Pressure sensor

Pressure sensor with switching status indicator AD7 ... AD10



[AD7]:

SDE5-D10-O-...-P-M8 with 3-pin plug M8x1, threshold value comparator, 1 switching output PNP, N/O contact

[AD8]:

SDE5-D10-C-...-P-M8 with 3-pin plug M8x1, threshold value comparator, 1 switching output PNP, N/C contact

Download CAD data → www.festo.com

Datasheets → Internet: sde5


[AD9]:

SDE5-D10-O3-...-P-M8 with 3-pin plug M8x1, window comparator, 1 switching output PNP, N/O contact

[AD10]:

SDE5-D10-C3-...-P-M8 with 3-pin plug M8x1, window comparator, 1 switching output PNP, N/C contact

Pressure sensor with LCD display AD11 ... AD12



[AD11]:

SPAU-P10R-MS...-L-PNLK-M12D with 4-pin plug M12x1, A-coded, switching output 2x PNP or 2x NPN switchable and 0 ... 10 V, 1 ... 5 V, 4 ... 20 mA analogue

Datasheets → Internet: spau

[AD12]:

SPAU-P10R-MS...-L-PNLK-M8D with 4-pin plug M8x1, A-coded, switching output 2x PNP or 2x NPN switchable and 0 ... 10 V, 1 ... 5 V, 4 ... 20 mA analogue

| Туре | B2 | В3 | B4 | B5 | В6 | D6 | L5 | L6 |
|---------------------------|----|-------|------|----|----|-------|------|----|
| MS6-SVAD7, AD8, AD9, AD10 | 31 | 79.1 | - | 51 | 16 | M8x1 | - | - |
| MS6-SVAD11 | 31 | 101.8 | 93.7 | 51 | 32 | M12x1 | 41.2 | 39 |
| MS6-SVAD12 | | | | | | M8x1 | 37.9 | |

[♦] Note: This product conforms to ISO 1179-1 and ISO 228-1.

| Ordering data | | | | | | | |
|----------------|--|-----------------|---------------------|--|---------------|---------------------------|--|
| Size | Connection | Without silence | r | | With silencer | | |
| | | Part no. | Туре | | Part no. | Туре | |
| Without pressu | Without pressure gauge | | | | | | |
| MS6 | G1/2 | 589481 | MS6-SV-1/2-C-10V24 | | 8001469 | MS6-SV-1/2-C-10V24-S | |
| | | 589250 | MS6-SV-1/2-C-10V24P | | 578769 | MS6-SV-1/2-C-10V24P-S | |
| Pressure senso | Pressure sensor with switching display | | | | | | |
| MS6 | G1/2 | - | | | 8172785 | MS6-SV-1/2-C-10V24-S-AD7 | |
| | | - | | | 611243 | MS6-SV-1/2-C-10V24P-S-AD7 | |

Ordering data – Modular product system MS6N-SV-C

| Ordering table | | | | | |
|----------------------|------|--|------------|---------|------------|
| Grid dimension | [mm] | 62 | Conditions | Code | Enter code |
| Module no. | | 548713 | | | |
| Series | | Standard | | MS | MS |
| Size | | 6 | | 6 | 6 |
| Function | | Soft-start/quick exhaust valve | | -SV | -SV |
| Pneumatic connection | | Female thread G1/2 | | -1/2 | |
| | | Connecting plate G1/4 | | -AGB | |
| | | Connecting plate G3/8 | | -AGC | |
| | | Connecting plate G1/2 | | -AGD | |
| | | Connecting plate G3/4 | | -AGE | |
| | | Connecting plate 1/4 NPT | | -AQN | |
| | | Connecting plate 3/8 NPT | | -AQP | |
| | | Connecting plate 1/2 NPT | | -AQR | |
| | | Connecting plate 3/4 NPT | | -AQS | |
| Performance Level | | Category 1, single-channel, to EN ISO 13849-1 | | -C | -C |
| Supply voltage | | 24 V DC (plug pattern to EN 175301), 3 10 bar, Manual override • At the soft-start/quick exhaust valve: detenting, self-resetting • At the pilot solenoid valve: non-detenting | | -10V24 | |
| | | 24 V DC (plug pattern to EN 175301), 3 10 bar, no manual override | | -10V24C | |
| | | 24 V DC, M12x1 to ISO 20401 in line with EN 61076-2-101, 3 10 bar, no manual override | | -10V24D | |
| | | 24 V DC, M12x1 to ISO 20401 in line with EN 61076-2-101, 3 10 bar, Manual override • At the soft-start/quick exhaust valve: detenting, self-resetting • At the pilot solenoid valve: none | | -10V24E | |
| | | 24 V DC, M12x1 to ISO 20401 in line with EN 61076-2-101, 3 10 bar, Manual override • At the soft-start/quick exhaust valve: detenting, self-resetting • At the pilot solenoid valve: non-detenting | | -10V24F | |
| | | 24 V DC, M12x1 to ISO 20401 in line with EN 61076-2-101, 3 10 bar, Manual override At the soft-start/quick exhaust valve: detenting, self-resetting At the pilot solenoid valve: non-detenting/detenting | | -10V24P | |

Ordering data – Modular product system MS6N-SV-C

| Ordering table | | | | |
|--|---|------------|-------|------------|
| Grid dimension [mm] | 62 | Conditions | Code | Enter code |
| Silencer | Silencer | | -S | |
| Pressure gauge/pressure gauge alternatives | MS pressure gauge | [1] | -AG | |
| | Adapter for EN pressure gauge 1/4, without pressure gauge | | -A4 | |
| | Integrated pressure gauge, red/green scale | [1] | -RG | |
| | Pressure sensor SDE5 with switching status indicator, plug M8, threshold value comparator, PNP, N/O | [2] | -AD7 | |
| | Pressure sensor SDE5 with switching status indicator, M8 plug, threshold value comparator, PNP, N/C | [2] | -AD8 | |
| | Pressure sensor SDE5 with switching status indicator, plug M8, window comparator, PNP, N/O | [2] | -AD9 | |
| | Pressure sensor SDE5 with switching status indicator, plug M8, window comparator, PNP, N/C | [2] | -AD10 | |
| | Pressure sensor SPAU with LCD display, M12 plug, 4-pin, IO-Link®, PNP, NPN, 0 10 V, 1 5 V, 4 20 mA | [2] | -AD11 | |
| | Pressure sensor SPAU with LCD display, M8 plug, 4-pin, IO-Link®, PNP, NPN, 0 10 V, 1 5 V, 4 20 mA | [2] | -AD12 | |
| Alternative pressure gauge scale | psi | [3] | -PSI | |
| | MPa | [4] | -MPA | |
| Type of mounting | Mounting bracket standard design | | -WP | |
| | Mounting bracket for hooking in service unit components | [5] | -WPM | |
| | Mounting bracket for large wall gap | | -WPB | |
| | Mounting bracket centrally at rear (wall mounting top and bottom), connecting plates not required | | -WB | |
| Tamper protection | Complete (manual override at soft-start/quick exhaust valve blocked, setting screws blocked, manual override at pilot solenoid valve blocked) | | -MK | |
| Flow direction | Flow direction from right to left | | -Z | |

^[1] AG, RG Pressure gauge scale in bar


^[2] AD7 ... AD12 Measuring range max. 10 bar

^[3] **PSI** Only in combination with pressure gauge AG

^[4] MPA [5] WPM Only in combination with pressure gauge AG or RG

Only with connecting plate AGB, AGC, AGD, AGE, AQN, AQP, AQR or AQS

Peripherals overview MS6N-SV-D





Peripherals overview MS6N-SV-D

| | | | Single device | Single device Combination | | | → Page/In- ternet | |
|------|------------------------|---------------------------------------|--------------------------|---------------------------|--------------------------|-----------------------|----------------------|--|
| | | | Without connecting plate | With connecting plate | Without connecting plate | With connecting plate | | |
| [1] | MS6-SV-D | Soft-start/quick exhaust valve | • | • | • | • | 20 | |
| [2] | MS6-MV | Module connector | _ | • | • | • | ms6-mv | |
| [3] | MS6-WP | Mounting bracket | • | • | • | • | ms6-wp | |
| | MS6-WPB/WPE/WPM | Mounting bracket (not shown) | - | - | • | - | ms6-wp | |
| [4] | MS6-WB | Mounting bracket | • | • | - | - | ms6-wb | |
| [5] | MS6-END | Cover cap | _ | _ | • | - | ms6-end | |
| [6] | MS6-AEND | Mounting plate | 1) | _ | ■ 1) | _ | ms6-aend | |
| [7] | MS6-AG | Connecting plate SET | - | ■ 1) | _ | 1) | ms6-ag | |
| | MS6-AQ | Connecting plate SET | - | ■ 1) | - | ■ 1) | ms6-aq | |
| [8] | 2M8/S3, SMT-8M-AM8D | Proximity switch | • | • | • | • | 29,53 | |
| | 2M12/S3, SMT-8M-AM12 | Proximity switch | • | • | • | • | 29,53 | |
| | 20E/S3, SMT-8M-AOE | Proximity switch | • | • | • | • | 29,53 | |
| [9] | AD11 AD12 | Pressure sensor SPAU with LCD display | • | • | • | • | 17 | |
| [10] | NEBU-M8LE4/NEBU-M12LE4 | Connecting cable | • | • | • | • | 54 | |
| [11] | A4 | Adapter for EN pressure gauge 1/4 | • | - | • | • | 29 | |
| [12] | MA | Pressure gauge | • | • | • | • | 54 | |
| [13] | AG/RG | MS pressure gauge | • | • | • | • | 29 | |
| [14] | UOS-1-LF | Silencer | • | • | • | • | 51 | |
| [15] | SO, UOS-1 | Silencer | • | • | • | • | 51 | |
| [16] | MEB-LD | Illuminating seal | • | • | • | • | 54 | |
| [17] | KMEB | Plug socket with cable | • | • | • | • | 53 | |
| [18] | MSSD-EB | Plug socket | • | • | • | • | 53 | |
| [19] | NEBU-M12G5 | Connecting cable | • | • | • | • | 54 | |
| [20] | NEBU-M12W5 | Connecting cable | | • | • | • | 54 | |

¹⁾ Module connector MS6-MV [2] or mounting bracket MS6-WP/WPB/WPE/WPM [3] is required for mounting.

Function









The electropneumatic soft-start/quick exhaust valve is used to reduce pressure quickly and safely and to build up pressure gradually in industrial pneumatic piping systems and terminal equipment.

The MS6-SV-D has two safety functions:

- · Safe exhausting
- Protection against unexpected startup

The MS6-SV-D has a 2-channel design, i.e. it has two internal 2-way valves which can be controlled separately by pilot valves (V1 and V2) on the cover.

The directional control valves are actuated when both coils are energised simultaneously; this moves the MS6-SV-D from the normal position into the switching position. The output pressure p2 rises slowly according to the flow control setting. The main seat opens when the switch-through pressure is reached. The normal position is achieved by switching off both coils. Two proximity switches (S1 and S2) attached to the housing monitor the directional control valves. A further proximity switch (S3) can optionally be added to monitor the soft-start valve.

- Conforms to standard IEC 61508
- Switching time delay can be adjusted using a restrictor for slowly building up the pressure; main seat opens at approx. 50% of the operating pressure
- · Optional pressure sensor



The MS6-SV-D can achieve various categories and safety levels to EN ISO 13849-1 depending on whether the directional control valves are monitored.

When it is integrated appropriately in the control chain and the signals for initial position sensing are correctly linked with the control signals (plausibility checking)

 S1 and S2 Performance Level d / Category 3 to EN ISO 13849-1 and EN ISO 13849-2 S1, S2 and S3 Performance Level e / Category 4 to EN ISO 13849-1 and EN ISO 13849-2 are reached.



Note

To avoid back pressures, it is recommended that the device is operated with the silencer UOS-1. The silencer can be ordered via the modular product system (SO → page 29) or as an accessory (UOS-1 → page 51).



Note

Only devices that do not impair the pneumatic protective measure – safe exhausting – may be placed downstream of the MS6-SV-...-D.

The MS6-SV-...-D is not approved for use as a press safety valve.

| Safety data | Safety data | | | | | |
|--|---------------------|--|--|--|--|--|
| Conforms to | | EN ISO 13849-1 and EN ISO 13849-2 | | | | |
| Safety function | | Exhausting | | | | |
| | | Prevention of unexpected start-up (pressurisation) | | | | |
| Performance Level (PL) | With sensing by S1 | Exhausting: category 3, PL d or category 3, PL e ¹⁾ | | | | |
| | and S2 | Prevention of unexpected start-up (pressurisation): category 3, PL d or category 3, PL e ¹⁾ | | | | |
| | With sensing by S1, | Exhausting: category 4, PL e | | | | |
| | S2 and S3 | Prevention of unexpected start-up (pressurisation): category 4, PL e | | | | |
| Safety integrity level (SII | _) | Exhausting: SIL 3 | | | | |
| | | Prevention of unexpected start-up (pressurisation): SIL 3 | | | | |
| Note on forced checking | procedure | Switching frequency min. 1/month | | | | |
| CE marking (see declaration of conformity) ²⁾ | | To EU Machinery Directive | | | | |
| Shock resistance | | Shock test with severity level 2 to FN 942017-5 and EN 60068-2-27 | | | | |
| Vibration resistance | | Transport application test with severity level 2 to FN 942017-4 and EN 60068-2-6 | | | | |

Depending on the average number of actuations per year (n₀o).
 More information: www.festo.com/catalogue/ms·sv → Support/Downloads.


| - Note | 5 1 21 /6 21: 6 | | |
|--------------------------------------|--------------------------------------|---------------------------------------|-------------------------------------|
| The mechanical system is not tested | Forced switch on/off: switching fre- | If the process-related switching fre- | the machine operator must carry out |
| in the controlled (i.e. pressurised) | quency should be at least once a | quency (safe exhausting) is less than | a forced switch off. |
| state. | month. | once a month, | |

| Switching logic | | | | | | |
|--|----------------------------|------|--|----|----|---|
| | Voltage at the Pilot valve | | he Switching position Proximity switch | | | Status |
| | V1 | V2 | S1 | S2 | S3 | |
| Pilot valves V1 and V2 are not actuated in the normal position (MS6-SV-D completely ex- | 0 V | 0 V | 1 | 1 | 1 | Normal position Pneumatic connection 1 blocked, passage from pneumatic connection 2 to 3 open |
| hausted). If both pilot valves are actuated, the MS6-SV-D switches first into switching posi- | 24 V | 0 V | 0 | 1 | 1 | Normal position Pneumatic connection 1 blocked, passage from pneumatic connection 2 to 3 open |
| tion 1 and then, when the switch-through pressure is reached, automatically into switching position 2. | 0 V | 24 V | 1 | 0 | 1 | Normal position Reduced flow through the restrictor from pneumatic connection 1 to 2, passage from pneumatic connection 2 to 3 open |
| | 24 V | 24 V | 0 | 0 | 1 | Switching position 1 Reduced flow through the restrictor from pneumatic connection 1 to 2, passage from pneumatic connection 2 to 3 blocked |
| | 24 V | 24 V | 0 | 0 | 0 | Switching position 2 Full flow from pneumatic connection 1 to 2, passage from pneumatic connection 2 to 3 blocked |

| Proximity switch reaction times ¹⁾ | | |
|---|--|---|
| Proximity switch | Switching on | Switching off |
| S1 | Edge change max. 4 s after voltage signal at V1. | Edge change max. 4 s after voltage drop at V1. |
| S2 | Edge change max. 4 s after voltage signal at V2. | Edge change max. 4 s after voltage drop at V2. |
| S3 | Edge change after voltage signal at V1 and V2. | Edge change max. 5 s after voltage drop at V1 and V2. |
| | Dependent on operating pressure p1, flow control valve position and system volume p2 | Depending on system volume at p2. |

Bounce can occur when the proximity switches undergo an edge change. This bounce can be ignored by taking the reaction times into account.
 The maximum specified reaction times must be taken into account in the diagnostics. The reaction times are normally shorter.

Sample circuit



A1, A2:

Supply voltage

S1: Proximity switch S1

S2: Proximity switch S2

S3: Proximity switch S3

NH: Emergency stop (input circuit)

Safety device:

Safety relay unit or safety PLC

V1: Coil connection, pilot valve V1

V2: Coil connection, pilot valve V2

Y1: Diagnostic input 1

Y2: Diagnostic input 2

Y3: Diagnostic input 3

S: Monitored start (start circuit)

| General technical data | |
|----------------------------|---|
| Pneumatic connection 1, 2 | |
| Female thread | G1/2 |
| Connecting plate AG | G1/4, G3/8, G1/2 or G3/4 |
| Connecting plate AQ | 1/4 NPT, 3/8 NPT, 1/2 NPT or 3/4 NPT |
| Pneumatic connection 3 | G1 |
| Actuation type | Electrical |
| Design | Piston seat Piston seat |
| Type of mounting | With accessories |
| | In-line installation |
| Mounting position | Any |
| Pressure indication | With pressure sensor for indicating the output pressure via LCD display and electrical output |
| | With pressure gauge for displaying the output pressure |
| | With pressure gauge with red/green scale for indicating the output pressure |
| | Prepared for G1/4 |
| Position sensing principle | Magnetic piston principle |
| Valve function | 3/2-way valve, closed, single solenoid |
| | Soft-start function, adjustable |
| Non-overlapping | No |
| Exhaust air function | Cannot be throttled |
| Manual override | None |
| Reset method | Mechanical spring |
| Type of actuation | Piloted |
| Pilot air supply | Internal |
| Sealing principle | Soft |

Note: This product conforms to ISO 1179-1 and ISO 228-1.

| Characteristic flow rate values | racteristic flow rate values | | | | | | |
|---|------------------------------|--|--|--|--|--|--|
| Pneumatic connection | Female thread G1/2 | | | | | | |
| Standard nominal flow rate qnN1) [l/min] | | | | | | | |
| In main flow direction 1 → 2 | 4300 | | | | | | |
| Standard flow rate qN [l/min], p2 = 6 bar | | | | | | | |
| In exhaust direction 2 → 3 | 9000 ²⁾ | | | | | | |
| C value [l/s*min] | | | | | | | |
| In main flow direction 1 → 2 | 19.3 | | | | | | |
| b value | | | | | | | |
| In main flow direction 1 → 2 | 0.21 | | | | | | |

Measured at p1 = 6 bar and p2 = 5 bar, Δp = 1 bar
 Measured with reference to atmosphere with silencer UOS-1.

| Electrical data | | | | | | | | |
|--------------------------|------------|---|--|--|--|--|--|--|
| Pilot valve | | | | | | | | |
| Characteristic coil data | | 24 V DC: 1.8 W; permissible voltage fluctuations –15%/+10% | | | | | | |
| Electrical connection | 10V24 | 2x plug, 2-pin, to EN 175301-803, type C | | | | | | |
| | 10V24P | 2x M12x1 to ISO 20401 in line with EN 61076-2-101 | | | | | | |
| Degree of protection | | IP65 with plug socket | | | | | | |
| Duty cycle | [%] | 100 | | | | | | |
| Max. switching frequen | icy [Hz] | 0.5 | | | | | | |
| Switching time off | [ms] | 40 | | | | | | |
| Switching time on [ms] | | 130 | | | | | | |
| Proximity switch | | | | | | | | |
| Nominal operating volta | age [V DC] | 24 | | | | | | |
| Proximity switch elec- | 2M8 | 2 x cables with M8x1 plug, 3-pin, rotatable thread, cable length 0.3 m | | | | | | |
| trical connection | 2M12 | 2 x cables with M12x1 plug, 3-pin, rotatable thread, cable length 0.3 m | | | | | | |
| | 20E | 2x cable with open end, 3-core, cable length 5 m | | | | | | |
| | 2M8 + S3 | 3 x cables with M8x1 plug, 3-pin, rotatable thread, cable length 0.3 m | | | | | | |
| | 2M12 + S3 | 3 x cables with M12x1 plug, 3-pin, rotatable thread, cable length 0.3 m | | | | | | |
| | 20E + S3 | 3x cable with open end, 3-core, cable length 5 m | | | | | | |
| Switching element fund | tion | N/O | | | | | | |
| Measuring principle | | Magneto-resistive | | | | | | |
| Signal status indication | 1 | LED and switching outputs | | | | | | |
| Switching output | | PNP | | | | | | |

| Operating and environmental cond | ditions | |
|--|-----------------------|---|
| Operating pressure | [bar] | 3.5 10 |
| Operating medium | | Compressed air to ISO 8573-1:2010 [7:4:4] |
| Note on the operating/pilot medium | n | Lubricated operation possible (in which case lubrication will always be required) |
| Ambient temperature | [°C] | -10 +50 (0 +50) ¹⁾ |
| Temperature of medium | [°C] | -10 +50 (0 +50) ¹⁾ |
| Storage temperature | [°C] | -10 +50 (0 +50) ¹⁾ |
| Corrosion resistance class CRC ²⁾ | | 2 |
| Noise level | [dB(A)] | 75 (with silencer UOS-1) |
| CE marking (see declaration of conf | ormity) ³⁾ | To EU Machinery Directive |
| UL certification ³⁾ | | c UL us - Recognized (OL) |
| Certification | | RCM |
| KC marking | | KCEMC |

¹⁾ With pressure sensor AD...


More information: www.festo.com/x/topic/crc
 More information: www.festo.com/catalogue/ms-sv→Support/Downloads.

| Weight [g] | |
|--|------|
| Soft-start/quick exhaust valve | 1900 |
| Soft-start/quick exhaust valve with silencer | 2110 |
| UOS-1 | |

| Materials | |
|------------------------|----------------------------|
| Housing | Die-cast aluminium |
| Piston rod | High-alloy stainless steel |
| Seals | NBR |
| Note on materials | RoHS-compliant |
| LABS (PWIS) conformity | VDMA24364-B1/B2-L |

Switch-through pressure

Pressure p as a function of time t



- [1] Tolerance range
- 2] Switching point
- [3] Filling time is adjustable via a restrictor




The +20%/–10% switching pressure tolerance refers to the operating pressure p1.

Example: a switching pressure from 1.6 bar to 2.8 bar is permissible at an operating pressure of 4 bar.


Dimensions - Basic version

With supply voltage 10V24, with female thread 1/2, with cover plate



Download CAD data → www.festo.com

With supply voltage 10V24P, with female thread 1/2, with cover plate



- [1] Adjusting screw for flow control valve
- [2] Silencer UOS-1
- [3] Extended sensing,
 - Variant S3: additional third proximity switch SMT, connection depends on the selected connection technology
- [4] Connection technology,
 - Variant 2M8:
 - 2 proximity switches SMT with cable (M8x1 plug, 3-pin, rotatable thread, cable length 0.3 m)
 - Variant 2M12:
 2 proximity switches SMT with cable (M12x1 plug, 3-pin, rotatable thread, cable length 0.3 m)
 - Variant 20E:
 2 proximity switches SMT with cable (open end, 3-wire, cable length 5 m)

- [5] Supply voltage,
 - Variant 10V24:
 electrical connection to
 EN 175301-803, 2x plugs,
 2-pin, type C
 - Variant 10V24P: electrical connection 2x M12x1 to ISO 20401 in line with EN 61076-2-101, 4-pin version for connecting cable NE-BU-M12
- → Flow direction

| Туре | B1 | B2 | В3 | B4 | B5 | D1 | D5 | D6 Ø | L1 | L2 | L4 | L7 | L9 |
|--------------------|----|----|----|------|----|------|----|---------|-----|-----|-----|-----|----|
| MS6-SV-1/2-D-10V24 | | | | | | | | | 257 | 110 | | | 9 |
| | 62 | 45 | 90 | 1 21 | 76 | G1/2 | G1 | | -51 | | 147 | 147 | |

 $[\]mbox{\ensuremath{\psi}}$ · Note: This product conforms to ISO 1179-1 and ISO 228-1.

Dimensions - Pressure gauges/pressure gauge alternatives Integrated MS pressure gauge with standard scale AG or red/green scale RG, display unit [bar] B3 B3 B3 B3 B3 B4 B5 Flow direction Download CAD data → www.festo.com Adapter A4 for EN pressure gauge 1/4, without pressure gauge

В3

90

91.5

91.5

В2

44

44

44

В4

31

31

31

B5

77

78.5

78.5

D4

G1/4

Туре

MS6-SV-...-D-...-AG

MS6-SV-...-D-...-RG

MS6-SV-...-D-...-A4

 $[\]mbox{\ensuremath{\psi}}$ Note: This product conforms to ISO 1179-1 and ISO 228-1.

Soft-start/quick exhaust valves MS-SV, MS series

Datasheet MS6-SV-D

| Ordering data | | | | |
|----------------|------------------------------|--|----------|--------------------------------|
| Size | Connection | Description | Part no. | Туре |
| - | ar, connection pattern to EN | • | | |
| 2 proximity sv | vitches SMT with cable (M8 | x1 plug, 3-pin, rotatable thread, cable length 0.3 m) | | |
| MS6 | G1/2 | Without silencer, with cover plate | 8038489 | MS6-SV-1/2-D-10V24-2M8 |
| | | With silencer and MS pressure gauge with standard scale, display unit | 8038490 | MS6-SV-1/2-D-10V24-2M8-SO-AG |
| | | [bar] | | |
| - | | r (connection pattern to EN 60947-5-2), 2x1 plug, 3-pin, rotatable thread, cable length 0.3 m) With silencer | 8182930 | MS6-SV-1/2-D-10V24P-2M12-S0 |
| | | With silencer | 8182930 | <u>'</u> |
| | | With silencer and MS pressure gauge with standard scale, display unit [bar] | 8038491 | MS6-SV-1/2-D-10V24P-2M12-SO-AG |
| | | With silencer and integrated pressure gauge with red/green scale, display unit [bar] | 8165924 | MS6-SV-1/2-D-10V24P-2M12-SO-RG |
| - | ar, connection pattern to EN | • | | |
| 2 proximity sv | vitches SMT with cable (ope | en end, 3-core, cable length 5 m) | | |
| MS6 | G1/2 | With silencer and MS pressure gauge with standard scale, display unit [bar] | 8038492 | MS6-SV-1/2-D-10V24-20E-SO-AG |

Ordering data – Modular product system MS6N-SV-D

| Ordering table | | | | |
|--|--|------------|---------|------------|
| Grid dimension [mm] | 62 | Conditions | Code | Enter code |
| Module no. | 548713 | | | |
| Series | Standard | | MS | MS |
| Size | 6 | | 6 | 6 |
| Function | Soft-start/quick exhaust valve | | -SV | -SV |
| Pneumatic connection | Female thread G1/2 | | -1/2 | |
| | Connecting plate G1/4 | | -AGB | |
| | Connecting plate G3/8 | | -AGC | |
| | Connecting plate G1/2 | | -AGD | 1 |
| | Connecting plate G3/4 | | -AGE | |
| | Connecting plate 1/4 NPT | | -AQN | |
| | Connecting plate 3/8 NPT | | -AQP | |
| | Connecting plate 1/2 NPT | | -AQR | |
| | Connecting plate 3/4 NPT | | -AQS | 1 |
| Performance Level | Category 3, 2-channel to EN ISO 13849-1 | | -D | -D |
| Supply voltage | 24 V DC (plug pattern to EN 175301) | | -10V24 | |
| | 24 V DC, M12x1 to ISO 20401 in line with EN 61076-2-101 | | -10V24P | 1 |
| Connection technology | 2 proximity switches SMT with cable (M8x1 plug, 3-pin, rotatable thread, cable length 0.3 m) | | -2M8 | |
| | 2 proximity switches SMT with cable (M12x1 plug, 3-pin, rotatable thread, cable length 0.3 m) | | -2M12 | |
| | 2 proximity switches SMT with cable (open end, 3-core, cable length 5 m) | | -20E | |
| Extended sensing | Additional proximity switch SMT; required to achieve Performance Level e; connection depends on the selected connection technology | | -\$3 | |
| Silencer | Open silencer | | -S0 | |
| Pressure gauge/pressure gauge alternatives | MS pressure gauge | [1] | -AG | |
| | Adapter for EN pressure gauge 1/4, without pressure gauge | | -A4 | |
| | Integrated pressure gauge, red/green scale | [1] | -RG | |
| | Pressure sensor SPAU with LCD display, M12 plug, 4-pin, IO-Link®, PNP, NPN, 0 10 V, 1 5 V, 4 20 mA | [2] | -AD11 | |
| | Pressure sensor SPAU with LCD display, M8 plug, 4-pin, IO-Link®, PNP, NPN, 0 10 V, | [2] | -AD12 | |
| | 1 5 V, 4 20 mA | [[[] | | |
| Alternative pressure gauge scale | psi | [3] | -PSI | |
| | MPa | [4] | -MPA | |
| Type of mounting | Mounting bracket standard design | [-] | -WP | |
| | Mounting bracket for hooking in service unit components | [5] | -WPM | |
| | Mounting bracket for large wall gap | | -WPB | |
| | Mounting bracket centrally at rear (wall mounting top and bottom), connecting plates not required | | -WB | |
| UL certification | cULus, ordinary location for Canada and USA | | -UL1 | |
| Flow direction | Flow direction from right to left | | -Z | |

^[1] AG, RG Pressure gauge scale in bar


^[2] AD11, AD12 Measuring range max. 10 bar

^[3] **PSI** Only in combination with pressure gauge AG

^[4] MPA [5] WPM Only in combination with pressure gauge AG or RG

Only with connecting plate AGB, AGC, AGD, AGE, AQN, AQP, AQR or AQS

Peripherals overview MS6N-SV-E



- Note

Additional accessories:


- Module connector for combination with size MS4/MS6 or size MS9
 - → Internet: amv rmv
- Adapter for mounting on profiles
 - → Internet: ipm

Peripherals overview MS6N-SV-E

| Moun | ting attachments and accessories | | | | | | |
|------|----------------------------------|---------------------------------------|--------------------------|-----------------------|--------------------------|-----------------------|----------------------|
| | | | Single device | | Combination | | → Page/In- ternet |
| | | | Without connecting plate | With connecting plate | Without connecting plate | With connecting plate | |
| [1] | MS6-SV-E | Soft-start/quick exhaust valve | • | • | • | • | 32 |
| [2] | MS6-MV | Module connector | _ | - | • | • | ms6-mv |
| [3] | MS6-WPB | Mounting bracket | • | • | • | • | ms6-wpb |
| [4] | MS6-WPE | Mounting bracket | • | • | • | • | ms6-wpe |
| [5] | MS6-END | Cover cap | _ | - | • | - | ms6-end |
| [6] | MS6-AEND | Mounting plate | ■ 1) | _ | ■ 1) | - | ms6-aend |
| [7] | MS6-AG | Connecting plate SET | _ | 1) | _ | ■ 1) | ms6-ag |
| | MS6-AQ | Connecting plate SET | _ | ■ 1) | _ | ■ 1) | ms6-aq |
| [8] | AD11 AD12 | Pressure sensor SPAU with LCD display | • | - | • | • | 17 |
| [9] | NEBU-M8LE4/NEBU-M12LE4 | Connecting cable | • | • | • | • | 54 |
| [10] | A4 | Adapter for EN pressure gauge 1/4 | • | • | • | • | 39 |
| [11] | MA | Pressure gauge | • | • | • | • | 54 |
| [12] | AG/RG | MS pressure gauge | • | • | • | • | 39 |
| [13] | UOS-1-LF | Silencer | • | • | • | • | 51 |
| [14] | UOS-1 | Silencer | • | • | • | • | 51 |
| [15] | NECA | Multi-pin plug socket | • | • | • | • | 49 |

¹⁾ Module connector MS6-MV [2] or mounting bracket MS6-WPB [3] or MS6-WPE [4] is required for assembly.

Function





Flow rate 4300 l/min




Temperature range −10 ... +50°C



Operating pressure 3.5 ... 10 bar



www.festo.com



safety-related pneumatic protection objective of safe exhausting is also guaranteed in the event of faults inside the valve (e.g. due to wear, contamination, electronic faults). The 2-channel design and its monitoring enables the device to meet controller

category 3 and 4 requirements. This

enables a Performance Level of max.

The device receives the secure enable signals (EN1/EN2) via the electrical connection (multi-pin plug socket NECA Sub-D, 9-pin or AS-i connecting cable). The signals are generated by commercially available electronic or electromechanical safety switching devices which monitor the protective equipment of the machine (e.g. emergency stop, light curtain, electrical door switch of a protective enclosure, etc.).

 Performance Level "e" / Category 4 to EN ISO 13849-1

The electropneumatic soft-start/quick

exhaust valve is used to reduce pres-

sure quickly and safely and to build up

pressure gradually in industrial pneu-

The device is a self-testing, redundant

mechatronic system conforming to the

requirements of EN ISO 13849-1. The

matic piping systems and terminal

equipment.

- Conforms to standard IEC 61508
- Switching time delay adjustable via a restrictor for slowly building up the pressure
- Optional pressure sensor



Note

The MS6N-SV-...-E-10V24 should only be used in combination with the multi-pin plug socket NECA for which it is approved.

The multi-pin plug socket can be ordered via the modular product system (MP → page 39) or as an accessory (NECA → page 49).



Note

To avoid back pressures, it is recommended that the device is operated with the silencer UOS-1. The silencer can be ordered via the modular product system (SO → page 39) or as an accessory (UOS-1 → page 51).



Note

Only devices that do not impair the pneumatic protective measure -"safe exhausting" - may be placed downstream of the MS6-SV-...-E. The MS6-SV-...-E is not approved for use as a press safety valve.

| Safety data | |
|--|--|
| Туре | MS6-SVE-10V24 |
| Conforms to | EN ISO 13849-1 |
| Safety function | Exhausting |
| | Prevention of unexpected start-up (pressurisation) |
| Performance Level (PL) | Exhausting: up to category 4, PL e |
| | Prevention of unexpected start-up (pressurisation): up to category 4, PL e |
| Safety integrity level (SIL) | Exhausting: SIL 3 |
| | Prevention of unexpected start-up (pressurisation): SIL 3 |
| Note on forced checking procedure | Switching frequency min. 1/month |
| Certificate issuing authority ¹⁾ | IFA 1001180 |
| CE marking (see declaration of conformity) ¹⁾ | To EU Machinery Directive |
| | To EU EMC Directive |
| Shock resistance | Shock test with severity level 2 to FN 942017-5 and EN 60068-2-27 |
| Vibration resistance | Transport application test with severity level 2 to FN 942017-4 and EN 60068-2-6 |

More information: www.festo.com/catalogue/ms-sv → Support/Downloads.



The mechanical system is not tested in the controlled (i.e. pressurised) state.


Forced switch on/off: switching frequency should be at least once a month.


If the process-related switching frequency (safe exhausting) is less than once a month,

the machine operator must carry out a forced switch off.


| Enable signal status | | Status of MS6-SVE-10V24 with multi- | Status of MS6-SVE-10V24 with multi-pin plug socket | | | |
|----------------------|------|---------------------------------------|--|---|--|--|
| EN1 | EN2 | NECAMP1 | NECAMP3 | NECAMP5 | | |
| 0 V | 0 V | Unpressurised | MS6-SVE-10V24 switches to fault mode. | MS6N-SVE-10V24 does not switch to fault mode, but remains in the safe, unpressurised state. Note: Detection of cross-circuits and error detection, evaluation necessary using an external controller. | | |
| 0 V | 24 V | MS6-SVE-10V24 switches to fault mode. | Pressurised | Pressurised | | |
| 24 V | 24 V | Pressurised | MS6-SVE-10V24 switches to fault mode. | MS6N-SVE-10V24 does not switch to fault mode, but remains in the safe, unpressurised state. Note: Detection of cross-circuits and error detection, evaluation necessary using an external controller. | | |
| 24 V | 0 V | MS6-SVE-10V24 switches to fault mode. | Unpressurised | Unpressurised | | |

MS6-SV-...-E-10V24 with multi-pin plug socket NECA





• Static enable signals (EN1 = 24 V, EN2 = 24 V).




• Clocked enable signals (EN1 = 0 ... 24 V, EN2 = 0 ... 24 V) for detection of cross-circuits.

Detection of cross-circuits by clock pulse signals is always carried out by the safety relay unit/safety PLC.



Note

Since the clock pulse outputs from different controller manufacturers are not standardised, their usability must be checked in each case. If the clock pulse is outside the specified limits, the MS6N-SV-...-E-10V24 detects it as an error and a safe shutdown is initiated.



| General technical data | | |
|----------------------------|---|--|
| Pneumatic connection 1, 2 | | |
| Female thread | G1/2 | |
| Connecting plate AG | G1/4, G3/8, G1/2 or G3/4 | |
| Connecting plate AQ | 1/4 NPT, 3/8 NPT, 1/2 NPT or 3/4 NPT | |
| Pneumatic connection 3 | G1 | |
| Actuation type | Electrical | |
| Design | Piston seat Piston seat | |
| Type of mounting | With accessories | |
| | In-line installation | |
| Mounting position | Any | |
| Pressure indication | With pressure sensor for indicating the output pressure via LCD display and electrical output | |
| | With pressure gauge for displaying the output pressure | |
| | With pressure gauge with red/green scale for indicating the output pressure | |
| | Prepared for G1/4 | |
| Position sensing principle | Magnetic piston principle | |
| Valve function | 3/2-way valve, closed, single solenoid | |
| | Soft-start function, adjustable | |
| Non-overlapping | No | |
| Exhaust air function | Cannot be throttled | |
| Manual override | None | |
| Reset method | Mechanical spring | |
| Type of actuation | Piloted | |
| Pilot air supply | Internal | |
| Sealing principle | Soft | |

Note: This product conforms to ISO 1179-1 and ISO 228-1.

| Characteristic flow rate values | | | |
|---|--------------------|--|--|
| Pneumatic connection | Female thread G1/2 | | |
| Standard nominal flow rate qnN1) [l/min] | | | |
| In main flow direction 1 → 2 | 4300 | | |
| Standard flow rate qN [l/min], p2 = 6 bar | | | |
| In exhaust direction 2 → 3 | 9000 ²⁾ | | |
| C value [l/s*min] | | | |
| In main flow direction 1 → 2 | 19.3 | | |
| b value | | | |
| In main flow direction 1 → 2 | 0.21 | | |

- Measured at p1 = 6 bar and p2 = 5 bar, Δp = 1 bar
 Measured with reference to atmosphere with silencer UOS-1.

| Electrical data | | |
|------------------------------------|--------|--------------------------|
| Туре | | MS6-SVE-10V24 |
| Electrical connection | | Sub-D 9-polig |
| Nominal operating voltage | [V DC] | 24 |
| Permissible voltage fluctuations | [%] | ±10 |
| Operating voltage range for AS-In- | [V DC] | - |
| terface | | |
| Duty cycle | [%] | 100 |
| Max. switching frequency | [Hz] | 0.5 |
| Switching time off | [ms] | 40 |
| Switching time on | [ms] | 130 |
| Signal status indication | | LED and floating contact |
| Degree of protection | | IP65 with plug socket |

Soft-start/quick exhaust valves MS-SV, MS series

Datasheet MS6-SV-E

| Operating and environmental conditions | | |
|--|---------|---|
| Туре | | MS6-SVE-10V24 |
| Operating pressure | [bar] | 3.5 10 |
| Operating medium | | Compressed air to ISO 8573-1:2010 [7:4:4] |
| Note on the operating/pilot mediur | n | Lubricated operation possible (in which case lubrication will always be required) |
| Ambient temperature | [°C] | -10 +50 (0 +50) ¹⁾ |
| Temperature of medium | [°C] | -10 +50 (0 +50) ¹⁾ |
| Storage temperature | [°C] | -10 +50 (0 +50) ¹⁾ |
| Corrosion resistance class CRC ²⁾ | | 2 |
| Noise level | [dB(A)] | 75 (with silencer UOS-1) |
| CE marking (see declaration of conformity) ³⁾ | | To EU EMC Directive |
| | | To EU Machinery Directive |
| UL certification ³⁾ | | c UL us - Recognized (OL) |
| Certification | | RCM |
| KC marking | | KCEMC |

- With pressure sensor AD...
 More information: www.festo.com/x/topic/crc
 More information: www.festo.com/catalogue/ms-sv → Support/Downloads.


| Weight [g] | | |
|--|------|--|
| Soft-start/quick exhaust valve | 2000 | |
| Soft-start/quick exhaust valve with silencer | 2200 | |
| UOS-1 | | |

| Materials | | |
|------------------------|----------------------------|--|
| Housing | Die-cast aluminium | |
| Piston rod | High-alloy stainless steel | |
| Seals | NBR | |
| Note on materials | RoHS-compliant | |
| LABS (PWIS) conformity | VDMA24364-B1/B2-L | |

Datasheet MS6-SV-E

Switching point

Pressure p as a function of time t



ВЗ

Flow direction

- Tolerance range
- Switching point
- Filling time is adjustable via a restrictor



Note


The +20%/-10% switching point tolerance refers to the operating pressure p1.

Example: A switching point from 1.6 bar to 2.8 bar is permissible at an operating pressure of 4 bar.

Dimensions - Basic version

В2





Download CAD data → www.festo.com

- [1] Regulating screw for flow control valve
- [2] Silencer UOS-1
- Multi-pin plug socket NECA
- Dimension without cable

| Туре | B1 | B2 | В3 | B4 | D1 | D5 | D6 | L1 | L2 | L3 | L4 |
|--------------------|----|----|-----|----|------|----|----|-----|----|----|-----|
| MS6-SV-1/2-E-10V24 | 62 | 59 | 104 | 23 | G1/2 | G1 | 55 | 228 | 81 | 61 | 145 |

 $[\]mbox{\ensuremath{\psi}}$ Note: This product conforms to ISO 1179-1 and ISO 228-1.

Datasheet MS6-SV-E

Dimensions – Pressure gauges/pressure gauge alternatives Download CAD data → www.festo.com Integrated MS pressure gauge AG with standard scale AG or red/green scale RG, Adapter A4 for EN pressure gauge 1/4, without pressure gauge display unit [bar] В2 В2 D4 Flow direction Flow direction Туре В2 ВЗ D4 MS6-SV-...-E-...-AG 59 105 MS6-SV-...-E-...-RG 106.5 59

MS6-SV-...-E-...-A4

| Ordering data | | | | | | | | |
|---|---------------------------------------|-----------------|-----------------------|--|---------------|--------------------------------------|--|--|
| Size | Connection | Without silence | Without silencer | | With silencer | | | |
| | | Part no. | Туре | | Part no. | Туре | | |
| MS pressure ga | MS pressure gauge, display unit [bar] | | | | | | | |
| MS6 | G1/2 | 548715 | MS6-SV-1/2-E-10V24-AG | | 548717 | MS6-SV-1/2-E-10V24-SO-AG | | |
| | | - | | | 8190258 | MS6-SV-1/2-E-10V24-SO-AG-MP1 | | |
| Adapter for EN pressure gauge 1/4, without pressure gauge | | | | | | | | |
| MS6 | G1/2 | _ | | | 611497 | MS6-SV-1/2-E-10V24-SO-A4-MP1-WPB-UL1 | | |

59

106.5

G1/4

 $[\]phi$ Note: This product conforms to ISO 1179-1 and ISO 228-1.

Ordering data – Modular product system MS6N-SV-E

| Ordering table | | | | |
|--|---|------------|--------|------------|
| Grid dimension [mm] | 62 | Conditions | Code | Enter code |
| Module no. | 548713 | | | |
| Series | Standard | | MS | MS |
| Size | 6 | | 6 | 6 |
| Function | Soft-start/quick exhaust valve | | -SV | -SV |
| Pneumatic connection | Female thread G1/2 | | -1/2 | |
| | Connecting plate G1/4 | | -AGB | |
| | Connecting plate G3/8 | | -AGC | |
| | Connecting plate G1/2 | | -AGD | |
| | Connecting plate G3/4 | | -AGE | |
| | Connecting plate 1/4 NPT | | -AQN | |
| | Connecting plate 3/8 NPT | | -AQP | |
| | Connecting plate 1/2 NPT | | -AQR | |
| | Connecting plate 3/4 NPT | | -AQS | |
| Performance Level | Category 4, 2-channel with self-monitoring to ISO 13849-1 | | -E | -E |
| Supply voltage | 24 V DC | | -10V24 | |
| Silencer | Open silencer | | -50 | |
| Pressure gauge/pressure gauge alternatives | MS pressure gauge | [1] | -AG | |
| | Adapter for EN pressure gauge 1/4, without pressure gauge | | -A4 | |
| | Integrated pressure gauge, red/green scale | [1] | -RG | |
| | Pressure sensor SPAU with LCD display, M12 plug, 4-pin, IO-Link®, PNP, NPN, 0 10 V, | [2] | -AD11 | |
| | 1 5 V, 4 20 mA | | | |
| | Pressure sensor SPAU with LCD display, M8 plug, 4-pin, IO-Link®, PNP, NPN, 0 10 V, 1 5 V, 4 20 mA | [2] | -AD12 | |
| Alternative pressure gauge scale | psi | [3] | -PSI | |
| | MPa | [4] | -MPA | |
| Multi-pin plug socket | Sub-D, 9-pin, screw terminal, without cable, static enable signals (EN1 = 24 V, EN2 = 24 V) | | -MP1 | |
| | Sub-D, 9-pin, screw terminal, without cable, static enable signals (EN1 = 0 V, EN2 = 24 V), Cross-circuit detection possible | | -MP3 | |
| | Sub-D, 9-pin, screw terminal, without cable, static enable signals (EN1 = 0 V, EN2 = 24 V), galvanic isolation of enable signal from the supply voltage | | -MP5 | |
| Type of mounting | Mounting bracket for large mounting spacing | | -WPB | |
| UL certification | cULus, ordinary location for Canada and USA | | -UL1 | |
| Flow direction | Flow direction from right to left | | -Z | |

^[1] AG, RG Pressure gauge scale in bar

^[2] **AD11, AD12** Measuring range max. 10 bar

^[3] **PSI** Only in combination with pressure gauge AG


^[4] **MPA** Only in combination with pressure gauge AG or RG

Type codes MS9-SV

| 001 | Series | |
|--------|--|--|
| MS | MS series | |
| 1 | | |
| 002 | Size | |
| 9 | Grid dimension 90 mm | |
| 003 | Function | |
| SV | Soft-start/quick exhaust valve | |
| 004 | Pneumatic connection | |
| 3/4 | Female thread G3/4 | |
| 1 | Female thread G1 | |
| AGD | Sub-base G1/2 | |
| AGE | Sub-base G3/4 | |
| AGF | Sub-base G1 | |
| AGG | Connecting plate G1 1/4 | |
| AGH | Connecting plate G1 1/2 | |
| N3/4 | Female thread 3/4 NPT | |
| N1 | Female thread 1 NPT | |
| AQR | Sub-base 1/2 NPT | |
| AQS | Sub-base 3/4 NPT | |
| AQT | Sub-base 1 NPT | |
| AQU | Sub-base 1 1/4 NPT | |
| AQV | Sub-base 1 1/2 NPT | |
| G | Module without connecting thread, without sub-base | |
| NG | Module without connecting thread, without sub-base (inch) | |
| 005 | Performance Level | |
| С | Category 1, 1-channel to ISO 13849-1 | |
| 006 | Supply voltage | |
| 10V24P | 24 V DC, 10 bar, M12 plug socket adapter (connection pattern | |
| | to EN 60947-5-2) | |
| V110 | 110 V AC (connection pattern to EN 175301) | |
| V230 | 230 V AC (connection pattern to EN 175301) | |
| V24 | 24 V DC (connection pattern to EN 175301) | |


| 007 | Silencer | |
|------|---|----------|
| | None | |
| S | Silencer | |
| 1 | 1 | |
| 008 | Pressure gauge alternatives | |
| | None | |
| AG | MS pressure gauge | |
| VS | Cover plate | |
| A8 | Adapter for EN pressure gauge 1/8, without pressure gauge | |
| A4 | Adapter for EN pressure gauge 1/4, without pressure gauge | |
| RG | Integrated pressure gauge, red/green scale | |
| AD7 | Pressure sensor with switching display, M8 plug, threshold value comparator, PNP, N/O | |
| AD8 | Pressure sensor with switching display, M8 plug, threshold value comparator, PNP, N/C | |
| AD9 | Pressure sensor with switching display, M8 plug, window comparator, PNP, N/O | |
| AD10 | Pressure sensor with operational status indicator, M8 plug, window comparator, PNP, N/C | |
| 009 | Alternative pressure gauge scale | |
| | MS pressure gauge | |
| PSI | psi | |
| BAR | bar | |
| MPA | MPa | |
| 010 | Type of mounting | |
| WP | Mounting bracket basic design | |
| WPB | Mounting bracket for large wall gap | |
| WPM | Mounting bracket for hooking in service unit components | |
| 011 | Tamper protection | |
| | None | |
| MK | Full | |
| МН | Without manual override | |
| 012 | Flow direction | |
| | Flow direction from left to right | |
| Z | Flow direction from right to left | \vdash |


Peripherals overview MS9-SV-C



| Mount | ting attachments and accessories | | | | | | |
|-------|----------------------------------|---|-------------------------------------|-----------------------------|--|------------|--|
| | | | Single device | | Combination | → Page/In- | |
| | | | With female thread 3/4, 1, N3/4, N1 | With connecting plate AG/AQ | Module without connect- ing thread, without con- necting plate G, NG | ternet | |
| [1] | MS9-SV-C | Soft-start/quick exhaust valve | • | • | • | 43 | |
| [2] | MS9-AG | Connecting plate SET | - | • | | ms9-ag | |
| | MS9-AQ | Connecting plate SET | - | • | | ms9-aq | |
| [3] | MS9-MV | Module connector | - | - | | ms9-mv | |
| [4] | MS9-WP | Mounting bracket | • | • | | ms9-wp | |
| [5] | MS9-WPB | Mounting bracket | - | • | | ms9-wp | |
| [6] | MS9-WPM | Mounting bracket | • | | | ms9-wp | |
| [7] | U-1-B | Silencer | • | • | | 53 | |
| [7] | VS | Cover plate | • | • | | 48 | |
| [9] | AG/RG | MS pressure gauge | - | • | | 48 | |
| [10] | AD7 AD10 | Pressure sensor with switching status indicator | • | • | • | 48 | |
| [11] | NEBU-M8LE3 | Connecting cable | • | | | 54 | |
| [12] | A4 | Adapter for EN pressure gauge 1/4 | • | • | • | 48 | |
| [13] | MA | Pressure gauge | | | | 54 | |
| [14] | MS9-SV-MH/MK | Covering | • | • | | 52 | |


Peripherals overview MS9-SV-C






| Moun | Mounting attachments and accessories | | | | | | | | |
|------|--------------------------------------|--------------------|-------------------------------------|--------------------------------|--|------------|--|--|--|
| | | | Single device | | Combination | → Page/In- | | | |
| | | | With female thread 3/4, 1, N3/4, N1 | With connecting plate AG/AQ | Module without connect- ing thread, without con- necting plate G, NG | ternet | | | |
| [1] | MC-LD | Illuminating seal | | • | • | 54 | | | |
| [2] | KMC | Connecting cable | • | • | • | 53 | | | |
| [2] | MSSD-C | Plug socket | • | • | • | 53 | | | |
| [4] | NEBU-M12G5 | Connecting cable | | • | | 54 | | | |
| [5] | NEBU-M12W5 | Connecting cable | • | • | • | 54 | | | |
| [6] | SIE-GD | Sensor socket | | • | | 54 | | | |
| [7] | SIE-WD | Angled plug socket | | | • | 54 | | | |

Function



Electropneumatic soft-start/quick exhaust valve for gradual pressurisation and quick exhausting of system components (single channel).




0 ... +60°C

Operating pressure
0.35 ... 1.6 MPa

- www.festo.com

The main restrictor in the cover permits a gradual build-up of output pressure p2. Once the output pressure p2 has reached the set pressure switchover point (switching pressure), the valve opens and the full operating pressure p1 is available at the output.







- The filling flow rate can be set for slowly building up the pressure using a restrictor
- Adjustable pressure switchover point
- · Optional pressure sensor
- Optional cover as tamper protection for the control parts

| Safety data | |
|------------------------|--|
| Conforms to | EN ISO 13849-1 |
| Safety function | Exhausting |
| Performance Level (PL) | Exhausting: up to category 1, PL c |
| Shock resistance | Shock test with severity level 1 to FN 942017-5 and EN 60068-2-27 |
| Vibration resistance | Transport application test with severity level 1 to FN 942017-4 and EN 60068-2-6 |

| General technical data | | | | | |
|--|---|--|--|--|--|
| Pneumatic connection 1, 2 | | | | | |
| Female thread | G3/4, G1, 3/4 NPT or 1 NPT | | | | |
| Connecting plate AG | G1/2, G3/4, G1, G1 1/4 or G1 1/2 | | | | |
| Connecting plate AQ | 1/2 NPT, 3/4 NPT, 1 NPT, 1 1/4 NPT or 1 1/2 NPT | | | | |
| Module without connecting thread/connecting plate G/NG | - | | | | |
| Pneumatic connection 3 | G1 (1 NPT) ¹⁾ | | | | |
| Actuation type | Electrical | | | | |
| Design | Piston spool | | | | |
| Type of mounting | With accessories | | | | |
| | In-line installation | | | | |
| Mounting position | Any | | | | |
| Pressure indication | With pressure sensor for indicating the output pressure and electrical output via LCD display | | | | |
| | With pressure gauge for displaying the output pressure | | | | |
| | With pressure gauge with red/green scale for indicating the output pressure | | | | |
| | Prepared for G1/4 | | | | |
| Valve function | 3/2-way valve, closed, single solenoid | | | | |
| | Soft-start function, adjustable | | | | |
| Exhaust air function | Cannot be throttled | | | | |
| Reset method | Mechanical spring | | | | |
| Type of actuation | Piloted | | | | |
| Sealing principle | Soft | | | | |

- 1) Only with N3/4/N1/AQ.../NG without silencer S
- Note: This product conforms to ISO 1179-1 and ISO 228-1.

| Electrical data | | | | | | |
|--------------------------|-----------------|---|--|--|--|--|
| Characteristic coil data | V24 | 24 V DC: 8.4 W; permissible voltage fluctuations ±10% | | | | |
| | 10V24P | 24 V DC: 2.7 W; permissible voltage fluctuations ±10% | | | | |
| V110 | | 10 V AC: 50/60 Hz; pick-up power 14.5 VA; holding power 10.5 VA; permissible voltage fluctuations ±10% | | | | |
| | V230 | 230 V AC: 50/60 Hz; pick-up power 14.5 VA; holding power 10.5 VA; permissible voltage fluctuations ±10% | | | | |
| Nominal operating volta | ge DC [V] | 110 | | | | |
| | | 230 | | | | |
| | | 24 | | | | |
| Electrical connection | V24, V110, V230 | Plug, square design to EN 175301-803, type A | | | | |
| | 10V24P | M12x1, 4-pin, to IEC 61076-2-101, to DESINA | | | | |
| Degree of protection | | IP65 with plug socket | | | | |
| Duty cycle | [%] | 100 | | | | |

| Characteristic flow rate values | | | | | | | | |
|---|---------------|---------------|---------|------------------|---------|---------|---------|--|
| Pneumatic connection | Female thread | Female thread | | Connecting plate | | | | |
| | 3/4/N3/4 | 1/N1 | AGD/AQR | AGE/AQS | AGF/AQT | AGG/AQU | AGH/AQV | |
| Standard nominal flow rate qnN1) [l/mir | 1] | | | | | | | |
| In main flow direction 1 → 2 | 14150 | 16460 | 8300 | 13250 | 16340 | 16550 | 15910 | |
| Standard flow rate qn [l/min] | | | | | | | | |
| Exhaust 6 → 0 bar with silencer S | 21450 | 20870 | 21720 | 20900 | 20370 | 19730 | 19850 | |
| C value [l/s*min] | | | | | | | | |
| In main flow direction 1 → 2 | 57.61 | 69.59 | 31.43 | 54.24 | 68.24 | 68.45 | 66.07 | |
| In exhaust direction 2 → 3 | 55.52 | 54.01 | 56.22 | 54.07 | 52.73 | 51.06 | 51.36 | |
| b value | | | | | | | | |
| In main flow direction 1 → 2 | 0.37 | 0.32 | 0.47 | 0.37 | 0.34 | 0.35 | 0.35 | |
| In exhaust direction 2 → 3 | 0.49 | 0.46 | 0.60 | 0.49 | 0.47 | 0.45 | 0.44 | |

¹⁾ Measured at p1 = 6 bar and p2 = 5 bar, Δ p = 1 bar

| Operating and environmental con | Operating and environmental conditions | | | | | | |
|--|--|--|-------------------------------------|-------------------------------------|--|--|--|
| Variant | | Coil coefficient | Coil coefficient | Coil coefficient | | | |
| | | V24 | 10V24P | V110, V230 | | | |
| Operating pressure | [MPa] | 0.35 1.6 (0.35 1) ²⁾ | 0.35 1 | 0.35 1.6 (0.35 1) ²⁾ | | | |
| | [bar] | 3.5 16 (3.5 10) ²⁾ | 3.5 10 | 3.5 16 (3.5 10) ²⁾ | | | |
| | [psi] | 50.75 232 (50.75 145) ²⁾ | 50.75 145 | 50.75 232 (50.75 145) ²⁾ | | | |
| Operating medium | | Compressed air to ISO 8573-1:2010 [7:4:4] | | | | | |
| Note on the operating/ | | Lubricated operation possible (in which case l | ubrication will always be required) | | | | |
| pilot medium | | | | | | | |
| Ambient temperature | [°C] | 0 +60 (0 +50) ²⁾ | | | | | |
| Temperature of medium | [°C] | 0 +60 (0 +50) ²⁾ | | | | | |
| Storage temperature | [°C] | 0 +60 (0 +50) ²⁾ | | | | | |
| Corrosion resistance class CRC ¹⁾ | | 2 | | | | | |
| Noise level ³⁾ | [dB(A)] | 93 (with silencer S) | | | | | |
| CE marking (see declaration of con | formity) ⁴⁾ | To EU EMC Directive | | | | | |
| | | To EU Machinery Directive | | | | | |
| | | To EU RoHS Directive | | | | | |
| UKCA marking (see declaration of o | conformity) ⁴⁾ | To UK EMC regulations | | | | | |
| | | To UK regulations for machines | | | | | |
| | | To UK RoHS regulations | | | | | |

¹⁾ More information: www.festo.com/x/topic/cro

⁴⁾ More information: www.festo.com/catalogue/ms-sv → Support/Downloads.


| Weight [g] | |
|--|------|
| Soft-start/quick exhaust valve | 2970 |
| Soft-start/quick exhaust valve with silencer S | 3200 |

²⁾ With pressure sensor AD...

³⁾ Exhaust at 10 bar at a distance of 1 m.


Materials

Sectional view



| Soft-start/quick exhaust valve | | | | | | |
|--------------------------------|-------------------|--------------------|--|--|--|--|
| [1] | Housing | Die-cast aluminium | | | | |
| [2] | Piston spool | Brass | | | | |
| - | Seals | NBR | | | | |
| Note | on materials | RoHS-compliant | | | | |
| LABS | (PWIS) conformity | VDMA24364-B1/B2-L | | | | |

Adjusting elements




- [1] Screw for adjusting the pressure switchover point
- [2] Flow control screw for adjusting the filling time
- [3] Manual override at the soft-start/ quick exhaust valve:
 - detenting/self-resetting as soon as the solenoid coil or manual override at the pilot solenoid valve is actuated.
- [4] Manual override at the pilot solenoid valve:
 - non-detenting, actuation from above


Dimensions - Basic version

Module without connecting thread, without connecting plate G/NG, with cover plate VS

Supply voltage V24/V110/V230 Supply voltage 10V24P

With silencer S





Download CAD data → www.festo.com


- [1] Plug connection to EN 175301-803
- [2] Electrical connection to
 IEC 61076-2-101, M12x1 plug,
 4-pin in
 accordance with DESINA
- 3] Manual override
- → Flow direction

| Туре | B1 | B2 | В3 | D2 | D5 | L1 | L2 | L3 | L4 | L5 | L6 |
|----------------------------|----|-------------|-----|-------|-----------------------|-----|----|----|------|----|-----|
| MS9-SV-G/NGV24, V110, V230 | 90 | <i>4.</i> E | 109 | - | G1 | 200 | 02 | 22 | 36.4 | 12 | 189 |
| MS9-SV-G/NG10V24P | 90 | 45 | 109 | M12x1 | (1 NPT) ¹⁾ | 200 | 63 | 23 | 39.2 | 10 | 109 |

1) Only with N3/4/N1/AQ.../NG without silencer S


Dimensions - Connecting thread/connecting plate

With female thread 3/4, 1, N3/4, N1



[1] Retaining screw M6xmin. 90 to DIN 912 (not included in the scope of delivery) for wall mounting without mounting bracket

With connecting plate AG.../AQ...



➤ Flow direction


Download CAD data → www.festo.com

| Туре | B4 | B5 | В6 | B7 | B8 | D1 | D6 | D7 | L6 | T1 | =© |
|-------------|----|-----|------|-----|-----|-----------|----|-----|----|----|----|
| MS9-SV-3/4 | 00 | 104 | 91.5 | | | G3/4 | 11 | 6.5 | 66 | (| |
| MS9-SV-1 | 90 | 104 | 91.5 | _ | _ | G1 | 11 | 0.5 | 00 | 6 | - |
| MS9-SV-AGD | | | | | 132 | G1/2 | | | | | 30 |
| MS9-SV-AGE | | | | | 132 | G3/4 | | | | | 36 |
| MS9-SV-AGF | - | _ | _ | 112 | 142 | G1 | _ | _ | _ | - | 41 |
| MS9-SV-AGG | | | | | 162 | G1 1/4 | | | | | 50 |
| MS9-SV-AGH | | | | | 176 | G1 1/2 | | | | | 55 |
| MS9-SV-N3/4 | 90 | 104 | 91.5 | | | 3/4 NPT | 11 | 6.5 | 66 | 6 | _ |
| MS9-SV-N1 | 90 | 104 | 91.5 | _ | _ | 1 NPT | 11 | 0.5 | 00 | 0 | _ |
| MS9-SV-AQR | | | | | 132 | 1/2 NPT | | | | | 30 |
| MS9-SV-AQS | | | | | 132 | 3/4 NPT | | | | | 36 |
| MS9-SV-AQT | - | _ | _ | 112 | 142 | 1 NPT | _ | _ | _ | - | 41 |
| MS9-SV-AQU | | | | | 162 | 1 1/4 NPT | | | | | 50 |
| MS9-SV-AQV | | | | | 176 | 1 1/2 NPT | | | | | 55 |

Note: This product conforms to ISO 1179-1 and ISO 228-1.


Dimensions - Pressure gauges/pressure gauge alternatives

Integrated MS pressure gauge with standard scale AG or red/green scale RG



Download CAD data → www.festo.com

Adapter A4 for EN pressure gauge 1/4, without pressure gauge




→ Flow direction

| Туре | B2 | B3 | В9 | D3 |
|-------------|-----|-----|-----|------|
| MS9-SVAG/RG | 4.5 | 109 | - | - |
| MS9-SVA4 | 45 | - | 110 | G1/4 |

 $[\]cdot \ | \ \cdot \ |$ Note: This product conforms to ISO 1179-1 and ISO 228-1.

Dimensions - Pressure gauges/pressure gauge alternatives

Pressure sensor with switching status indicator AD7 ... AD10



[AD7]:

SDE5-D10-O-...-P-M8 with 3-pin plug M8x1, threshold value comparator, 1 switching output PNP, N/O contact

[AD8]:

SDE5-D10-C-...-P-M8 with 3-pin plug M8x1, threshold value comparator, 1 switching output PNP, N/C contact

Download CAD data → www.festo.com

Datasheets → Internet: sde5

[AD9]:

SDE5-D10-O3-...-P-M8 with 3-pin plug M8x1, window comparator, 1 switching output PNP, N/O contact

[AD10]:

SDE5-D10-C3-...-P-M8 with 3-pin plug M8x1, window comparator, 1 switching output PNP, N/C contact

| Туре | B2 | B11 | D3 |
|---------------------------|----|-----|----|
| MS9-SVAD7, AD8, AD9, AD10 | 45 | 112 | M8 |

| Ordering data | | | | | | |
|--------------------|----------|---------------------|--|--|--|--|
| Size With silencer | | | | | | |
| | Part no. | Туре | | | | |
| Cover plate | | | | | | |
| MS9 | 570737 | MS9-SV-G-C-V24-S-VS | | | | |

Ordering data – Modular product system MS9N-SV-C

| Ordering table Grid dimension [mm] | 90 | Conditions | Code | Enter co |
|---|---|------------|---------|----------|
| Module no. | 562176 | | | |
| eries | Standard | | MS | MS |
| Size | 9 | | 9 | 9 |
| unction | Soft-start/quick exhaust valve | | -SV | -SV |
| Pneumatic connection | Female thread G3/4 | | -3/4 | -31 |
| neumane connection | Female thread G1 | | -3/4 | |
| | Connecting plate G1/2 | | -AGD | |
| | Connecting plate G1/2 Connecting plate G3/4 | | -AGE | |
| | Connecting plate G374 Connecting plate G1 | | -AGE | |
| | Connecting plate G1 Connecting plate G1 1/4 | | -AGG | |
| | Connecting plate G1 1/4 Connecting plate G1 1/2 | | -AGG | |
| | | | | |
| | Female thread 3/4 NPT Female thread 1 NPT | | -N3/4 | |
| | | | -N1 | |
| | Connecting plate 1/2 NPT | | -AQR | |
| | Connecting plate 3/4 NPT | | -AQS | |
| | Connecting plate 1 NPT | | -AQT | |
| | Connecting plate 1 1/4 NPT | | -AQU | |
| | Connecting plate 1 1/2 NPT | | -AQV | |
| | Module without connecting thread, without connecting plate | | -G | |
| | Module without connecting thread, without connecting plate | | -NG | |
| erformance Level | Category 1, single-channel, to EN ISO 13849-1 | | -C | -C |
| Supply voltage | 24 V DC (plug pattern to EN 175301), 16 bar | | -V24 | |
| | 24 V DC, M12 to IEC 61076-2-101, 10 bar | | -10V24P | |
| | 110 V AC (plug pattern to EN 175301), 16 bar | | -V110 | |
| | 230 V AC (plug pattern to EN 175301), 16 bar | | -V230 | |
| ilencer | Silencer | | -S | |
| ressure gauge/pressure gauge alternatives | MS pressure gauge | | -AG | |
| | Cover plate | | -VS | |
| | Adapter for EN pressure gauge 1/8, without pressure gauge | | -A8 | |
| | Adapter for EN pressure gauge 1/4, without pressure gauge | | -A4 | |
| | Integrated pressure gauge, red/green scale | [1] | -RG | |
| | Pressure sensor with status indicator, M8 plug, threshold value comparator, PNP, N/O contact | [2] | -AD7 | |
| | Pressure sensor with status indicator, M8 plug, threshold value comparator, PNP, N/C contact | [2] | -AD8 | |
| | Pressure sensor with status indicator, M8 plug, window comparator, PNP, N/O contact | [2] | -AD9 | |
| | Pressure sensor with status indicator, M8 plug, window comparator, PNP, N/C contact | [2] | -AD10 | |
| lternative pressure gauge scale | psi | [3] | -PSI | |
| | MPa | [3] | -MPA | |
| | bar | [3] | -BAR | |
| ype of mounting | Mounting bracket standard design | [4] | -WP | |
| ,, | Mounting bracket for hooking in service unit components | [4] | -WPM | |
| | Mounting bracket for large wall gap | [4] | -WPB | \vdash |
| amper protection | Without manual override (manual override at soft-start/quick exhaust valve blocked, set- | 173 | -MH | |
| lamper protection | ting screws open, manual override at pilot solenoid valve blocked) | | | |
| | 1 g = 1. = 1. = pen, manaar oremae ar prior solemola faire blocked | 1 | | |
| | Complete (manual override at soft-start/quick exhaust valve blocked, setting screws blocked, manual override at pilot solenoid valve blocked) | | -MK | |

 $[\]begin{tabular}{ll} [1] & \textbf{RG} & \textbf{Not with alternative pressure gauge scale PSI.} \end{tabular}$

PSI scale is only an auxiliary scale (inner scale), outer scale in bar

 [2]
 AD7, AD8, AD9, AD10
 Measuring range max. 10 bar

 [3]
 PSI, MPA, BAR
 Only in combination with pressure gauge AG or RG

 [4]
 WP, WPM, WPB
 Not with pneumatic connection G, NG

Multi-pin plug socket NECA

(Order code in the modular product system: MP1/MP3/MP5)

• for soft-start/quick exhaust valve MS6N-SV-E-10V24




| Technical data | | |
|-----------------------------------|--------------------|-----------------------------------|
| Type of mounting | | With through-hole |
| Electrical connection 1 | | Socket, sub-D, 9-pin |
| Electrical connection 2 | | Screw terminal, 9-pin |
| Operating voltage range | [V DC] | 21.6 26.4 |
| Nominal operating voltage | [V DC] | 24 |
| Current rating at 40°C | [A] | 1.0 |
| Connection cross section | [mm ²] | 0.34 1.0 without wire end sleeves |
| | [mm ²] | 0.34 0.5 with wire end sleeves |
| Permissible cable diameter | [mm] | 5.0 10.0 |
| Degree of protection to IEC 60529 | | IP65 |

| Operating and environmental cor | perating and environmental conditions | | | | | |
|--|---------------------------------------|---------------------|--|--|--|--|
| Relative humidity | | 95%, non-condensing | | | | |
| Ambient temperature | [°C] | 0+50 | | | | |
| Storage temperature | [°C] | -20 +70 | | | | |
| Corrosion resistance class CRC ¹⁾ | | 2 | | | | |

¹⁾ More information: www.festo.com/x/topic/crc

| Materials | | | | | |
|------------------------|-------------------|--|--|--|--|
| Housing | Reinforced PA | | | | |
| Screws | Steel | | | | |
| Union nut | Brass | | | | |
| Seals | NBR | | | | |
| LABS (PWIS) conformity | VDMA24364-B1/B2-L | | | | |



| Ordering data | | | | |
|--------------------|--|--------|----------|------------------|
| Description | Connection | Weight | Part no. | Type |
| | | [g] | | |
| For MS6-SV-E-10V24 | Without cable, static enable signals (EN1 = 24 V, EN2 = 24 V) | 60 | 548719 | NECA-S1G9-P9-MP1 |
| | Without cable, static enable signals (EN1 = 0 V, EN2 = 24 V), cross-circuit detection possi- | 60 | 552703 | NECA-S1G9-P9-MP3 |
| | ble | | | |
| | Without cable, static enable signals (EN1 = 0 V, EN2 = 24 V), galvanic isolation of enable signals from the supply voltage | 60 | 573695 | NECA-S1G9-P9-MP5 |

Silencer UOS-1

(Order code in the modular product system: SO)

• For soft-start/quick exhaust valve MS6-SV-D/E

Silencer UOS-1-LF

• For soft-start/quick exhaust valve MS6-SV-D/E



Note

The space-saving silencer UOS-1-LF may only be used for applications with low exhaust rates. Pneumatic connection 2 at the soft-start/quick exhaust valve MS6-SV-D/E must be reduced to G1/4 by a connecting plate MS6-AGB.






| Technical data | |
|----------------------------------|------------------|
| Pneumatic connection | G1 |
| Design | Open silencer |
| Type of mounting | With male thread |
| Mounting position | Any |
| Type of seal on screwed trunnion | No seal |
| Noise level | 75 dB(A) |

| Operating and environmental cor | Operating and environmental conditions | | | |
|--|--|---|--|--|
| Operating pressure [MPa] | | 01 | | |
| | [bar] | 010 | | |
| Operating medium | | Compressed air to ISO 8573-1:2010 [-:-:-] | | |
| Ambient temperature | [°C] | -10 +50 | | |
| Corrosion resistance class CRC ¹⁾ | | 2 | | |

¹⁾ More information: www.festo.com/x/topic/crc

| Materials | | |
|------------------------|-------------------------|-------------------------|
| Туре | UOS-1 | UOS-1-LF |
| Housing | РОМ | Wrought aluminium alloy |
| Sleeve | Wrought aluminium alloy | - |
| Silencer insert | PE | |
| Note on materials | RoHS-compliant | |
| LABS (PWIS) conformity | VDMA24364-B1/B2-L | |



| Туре | D1 | D2 | L1 | L2 |
|----------|----|-----|-------|------|
| | | Ø | | |
| UOS-1 | C1 | E E | 156.5 | 11.5 |
| UOS-1-LF | GI | 25 | 72.2 | 13 |

| Ordering data | | | | |
|----------------|-----------------------|------------|----------|----------|
| Description | | Weight [g] | Part no. | Туре |
| For MS6-SV-D/E | For high exhaust rate | 200 | 552252 | UOS-1 |
| | For low exhaust rate | 157.9 | 1901207 | UOS-1-LF |

Covering MS-SV-MH/MK

(Order code in the modular product system: MH/MK)

• For soft-start/quick exhaust valve MS6/9-SV-C

Note on materials: RoHS-compliant

LABS (PWIS) conformity: VDMA24364-B1/B2-L







MS9-SV-MK



MS9-SV-MH

| Ordering data | | | | |
|---------------|--|-------------------|----------|-------------|
| Description | | CRC ¹⁾ | Part no. | Туре |
| For MS6-SV-C | Tamper protection for manual override at the soft-start/quick exhaust valve, flow control screw, setting screw for pressure switchover point and manual override at the pilot solenoid valve | 2 | 8001479 | MS6-SV-C-MK |
| For MS9-SV-C | Tamper protection for manual override at the soft-start/quick exhaust valve, flow control screw, setting screw for pressure switchover point and manual override at the pilot solenoid valve | 2 | 1457669 | MS9-SV-MK |
| | Tamper protection for manual override at the soft-start/quick exhaust valve and manual override at the pilot solenoid valve | 2 | 1457670 | MS9-SV-MH |

¹⁾ Corrosion resistance class. More information: www.festo.com/x/topic/crc

| Ordering data – Silencer UB | | | | | | |
|-----------------------------|--------------|------|---|----------|---------|--|
| | Description | | Order code in the modular product sys- tem | Part no. | Туре | |
| | For MS6-SV-C | G3/4 | S | 6845 | U-3/4-B | |
| | For MS9-SV-C | G1 | S | 151990 | U-1-B | |

| Ordering data – Proxim | nity switch SMT | | | | | | | Datasheets → Internet: smt |
|------------------------|-----------------|------------------|----------------------------------|------------------------------|---------------------|---|----------|----------------------------|
| | Description | Switching output | Switching element function | Electrical connection | Cable length [m] | Order code in the modular product sys- tem | Part no. | Туре |
| | For MS6-SV-D | PNP | N/O | Cable with M8x1 plug, 3-pin | 0.3 | 2M8/S3 | 574334 | SMT-8M-A-PS-24V-E-0.3-M8D |
| | | | | Cable with M12x1 plug, 3-pin | 0.3 | 2M12/S3 | 574337 | SMT-8M-A-PS-24V-E-0.3-M12 |
| | For MS6-SV-D | PNP | N/O | Cable, 3-wire | 5 | 20E/S3 | 574336 | SMT-8M-A-PS-24V-E-5.0-OE |

| Ordering data - Plug | socket MSSD | | | | Datasheets → Internet: mssd |
|----------------------|----------------|-----------------------|---------------------------------------|----------|-----------------------------|
| | Description | Electrical connection | Type of mounting for cable connection | Part no. | Туре |
| | For MS6-SV-C/D | 3-pin | Clamping screws | 151687 | MSSD-EB |
| 1~() | | 4-pin | Insulation displacement technology | 192745 | MSSD-EB-S-M14 |
| | | 3-pin | Clamping screws | 539712 | MSSD-EB-M12 |
| | For MS9-SV-C | 3-pin | Clamping screws | 34583 | MSSD-C |
| | | 4-pin | Insulation displacement technology | 192748 | MSSD-C-S-M16 |

| Ordering data – Plug s | ocket with cable KMEB | /Connecting cable KM | С | | | | Datasheets → Internet: kmeb, kmc |
|---|-----------------------|----------------------|-----------------------|-----------------------------|---------------------|----------|----------------------------------|
| | Description | Operating voltage | Electrical connection | Switching status indication | Cable length [m] | Part no. | Туре |
| | For MS6-SV-C/D | 24 V DC | 2-pin | LED | 2.5 | 547268 | KMEB-3-24-2.5-LED |
| () () () () () () () () () () | | | | | 5 | 547269 | KMEB-3-24-5-LED |
| | | | | _ | 2.5 | 547270 | KMEB-3-24-2.5 |
| | | | | | 5 | 547271 | KMEB-3-24-5 |
| | | | 3-pin | LED | 2.5 | 151688 | KMEB-1-24-2.5-LED |
| | | | | | 5 | 151689 | KMEB-1-24-5-LED |
| | | | | | 10 | 193457 | KMEB-1-24-10-LED |
| | | 230 V AC | 3-pin | - | 2.5 | 151690 | KMEB-1-230AC-2.5 |
| | | | | | 5 | 151691 | KMEB-1-230AC-5 |
| | For MS9-SV-C | 24 V DC | 3-pin | LED | 2.5 | 30931 | KMC-1-24DC-2.5-LED |
| | | | | | 5 | 30933 | KMC-1-24DC-5-LED |
| | | | | | 10 | 193459 | KMC-1-24-10-LED |
| | | 230 V AC | 3-pin | - | 2.5 | 30932 | KMC-1-230AC-2.5 |
| 101 | | | | | 5 | 30934 | KMC-1-230AC-5 |

| | Description | | | Operating voltage range | | | Part no. | Туре |
|---------------------|---|-------------------------------|------|--------------------------------|-------|--------------|----------|----------------------------|
| _ | | r cable KMEB and plug socke | n# | 12 24 V DC | | | 151717 | MEB-LD-12-24DC |
| | MSSD-EB | i cable kivied and plug socke | ει | | | | 151717 | MEB-LD-230AC |
| | For connecting cable KMC and plug socket MSSD-C | | | 230 V DC/AC ±10% 12 24 V DC | | | - | MC-LD-12-24DC |
| • | roi connecting cabi | e kinc and plug socket insst | D-C | 230 V DC/AC ±10% | | | 19145 | MC-LD-230AC |
| | | | | 230 V DC/AC ±10% | | | 19146 | MC-LD-230AC |
| dering data – Conn | ecting cable NEBU-M | 3 | | | | | | Datasheets → Internet: ne |
| 0 | Electrical connection | i i | mber | of wires | | Cable length | Part no. | Туре |
| | | | | | | [m] | | 7,77 |
| | M8x1, straight sock | xet 3 | | | | 2.5 | 541333 | NEBU-M8G3-K-2.5-LE3 |
| | | | | | | 5 | 541334 | NEBU-M8G3-K-5-LE3 |
| | M8x1, angled sock | et 3 | | | | 2.5 | 541338 | NEBU-M8W3-K-2.5-LE3 |
| | | | | | | 5 | 541341 | NEBU-M8W3-K-5-LE3 |
| <u>'</u> | | | | | | | | |
| dering data – Conn | ecting cable NEBU-M | 12 | | | | | | Datasheets → Internet: ne |
| • | Electrical connection | | mber | of wires | | Cable length | Part no. | Туре |
| | | | | | | [m] | | |
| | M12x1, straight so | cket 4 | | | | 2.5 | 550326 | NEBU-M12G5-K-2.5-LE4 |
| | | | | | | 5 | 541328 | NEBU-M12G5-K-5-LE4 |
| | M12x1, angled soc | ket 4 | | | | 2.5 | 550325 | NEBU-M12W5-K-2.5-LE4 |
| 8 | | | | | | 5 | 541329 | NEBU-M12W5-K-5-LE4 |
| | | | | | | | | |
| dering data – Sens | or socket SIE-GD | | | | | | | Datasheets → Internet: sie |
| | Electrical connection | n | | | | | Part no. | Туре |
| ₹ | M12x1, 4-pin | | | | | | 18494 | SIE-GD |
| | | | | | | | | |
| | | | | | | | | |
| dering data – Angl | ed plug socket SIE-WD | | | | | | l p | Datasheets → Internet: sie |
| | Electrical connection | n | | | | | Part no. | Туре |
| 9 | M12x1, 4-pin | | | | | | 12956 | SIE-WD-TR |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| dering data – Press | sure gauge MA | | | | | | | |
| | Nominal size Pneumatic connection | | | isplay range | | | Part no. | Туре |
| | | | [b | ar] | [psi] | | | |
| | Pressure gauge MA | N, EN 837-1 | | | | | | Datasheets → Internet: |
| | 40 | R1/4 | 0 | 16 | 0 232 | | 187080 | MA-40-16-R1/4-EN |
| | | G1/4 | _ | 16 | 0 232 | | 183901 | MA-40-16-G1/4-EN |
| = | D | | | | 1 | | | |
| | Pressure gauge MA | , EN 837-1, with red/green | rang | e | | | | Datasheets → Internet: |
| | 50 | R1/4 | | 16 | | | 525729 | MA-50-16-R1/4-E-RG |