Membrane air dryers MS-LDM1, MS series

FESTO



Service unit components of the MS series

Solutions for every application

With its large product range, highly effective components and a wide choice of functions, the MS series from Festo offers a complete concept for compressed air preparation. It is suitable for simple standard applications as well as application-specific solutions with very high quality requirements. Available as individual components, pre-assembled combinations ex-stock,

application-specific combinations or complete turnkey solutions. The five sizes in the MS series achieve maximum flow rates with minimum space requirements.

Freely combinable function modules

Pressure regulators, on/off and softstart valves with safety function, filters, pressure and flow sensors, dryers, sensors and lubricators can be assembled into a suitable solution for every task. The modular structure enables the components to be combined as required. The simple connection system saves time because the entire combination doesn't need to be disassembled when replacing individual mod-

Many of the components are also UL and ATEX certified.


CAD models and configurator

Convenient tools for planning and selecting application-specific individual devices and combinations. The product configurator lets you configure customised solutions quickly and transfer the order data without any hassle.

Engineering tools

Selection tool for choosing the right combination of service unit components without oversizing, and with the right air purity class:

→ www.festo.com/engineering/ service unit



Integrated sensors

Pressure and flow sensors

Safety functions

Soft-start/quick exhaust valves MS6-SV/MS9-SV

Saving energy

Service unit combinations MSE6

Intelligent mix of sizes



- · Maximum machine availability thanks to controlled processes
- Reliable air preparation and supply for systems
- Integrated or stand-alone
- Easy to connect with M8/M12 plug



- · Fast and reliable exhausting of systems up to Performance Level e, certified to EN ISO 13849-1
- Integrated soft-start function



- · Fully automatic monitoring and regulation of compressed air supply
- · Automatic shut-off of the compressed air in stand-by mode
- Detection and notification of leakag-
- Condition monitoring of relevant process data



- Optimum flow rate with a size that is up to 18% smaller
- Excellent energy efficiency
- Cost-optimised combinations save up to 30%!

						_
Grid dimension	[mm]	25	40	62	90	12
Size		MS2	MS4	MS6	MS9	M
Size differences						

Size		IVI.5.2	W154	MISO	MS9	M312
Grid dimension	[mm]	25	40	62	90	124
Connection sizes		M5, QS-6	G1/8, G1/4, G3/8	G1/4, G3/8, G1/2, G3/4	G1/2, G3/4, G1, G1 1/4, G1 1/2	G1, G1 1/4, G1 1/2, G2
Standard nominal flow rate gnN1)	[l/min]	350	1800	6500	20000	22000

Using pressure regulator MS-LR as an example

Note

Information

The next few pages provide a brief overview of the product range for the MS series service unit components.

You can find detailed information and all the technical data in the documentation for the relevant service unit component.

Accessories such as connecting plates or mounting brackets can be ordered either via the configurator or separately.

Design of a service unit combination

The order of the individual service unit components within a combination is relevant for safety and functionality. The service unit components cannot be combined in any order in the flow direction. They are subject to restrictions and rules.

The configurator for the service unit combination MSB is a reliable and convenient way of arranging individual service unit components and ensures compliance with the applicable rules. As a result, you get a completely assembled combination with UL or ATEX certification, if necessary. When combining a unit from individually configured and ordered service unit components, the following points must be adhered to under all circumstances.

- Regulators MS-LFR/LR/LRP/LRE are only permissible in the flow direction with the same or decreasing pressure regulation range
- Filters MS-LFR/LF/LFM/LFX are only permissible in the flow direction with an increasing grade of filtration
- Lubricators MS-LOE are not permitted in the flow direction upstream of a filter MS-LFR/LFM/LF/LFX, water separator MS-LWS or membrane air dryer MS-LDM1
- A micro filter MS-LFM must be installed in the flow direction upstream of an activated carbon filter MS-LFX or membrane air dryer MS-LDM1
- A flow sensor SFAM cannot be installed directly downstream of a regulator MS-LFR/LR; a branching module MS-FRM must be positioned between them
- A soft-start/quick exhaust valve MS-SV must be the last service unit component in the flow direction

Туре	Description	Size	Pneumatic o	connection				
			Push-in	Female thi	read		Connecting plate with thre	ad
			connector	M	G	NPT	G	NPT
Combinations								
Service unit combin	nations MSB-FRC							Datasheets → Internet: ms
	Combinations of filter regu-	4	-	-	1/8, 1/4	-	_	_
	lator and lubricator	6	-	-	1/4, 3/8, 1/2	_	-	-
Service unit combin	nations MSB							Datasheets → Internet: ms
	7 predefined combinations	4	-	_	1/4	_	_	-
		6	_	_	1/2	_	_	_
to Lot	Freely configurable combi-	4	-	_	1/8, 1/4	_	1/8, 1/4, 3/8	1/8, 1/4, 3/8
	nations	6	-	-	1/4, 3/8, 1/2	-	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
		9	_	_	3/4, 1	3/4, 1	1/2, 3/4, 1, 1 1/4, 1 1/2	1/2, 3/4, 1, 1 1/4, 1 1/2
. Time								
Service unit combin	nations MSE6							Datasheets → Internet: mse
a ===	Combinations with fieldbus	6	-	_	_	_	1/2	_
7	connection for measuring							,
THE PERSON NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TWO IS NAMED IN COLUMN TW	pressure, flow rate and con-							
And the second s	sumption	1						

Гуре	Description	Size	Pneumatic					
			Push-in	Female th	read		Connecting plate with thre	ad
			connector	M	G	NPT	G	NPT
ndividual devi	ices							
lter regulator	rs MS-LFR					[Datasheets → Internet: ms2-lfr; m	ıs4-lfr; ms6-lfr; ms9-lfr; ms12
1	Filter and pressure regula-	2	QS-6	M5	_	_	_	-
100	tor in a single device, grade	4	_	-	1/8, 1/4	-	1/8, 1/4, 3/8	1/8, 1/4, 3/8
3	of filtration 5 or 40 μm	6	-	-	1/4, 3/8, 1/2	-	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
		9	-	-	3/4, 1	3/4, 1	1/2, 3/4, 1, 1 1/4, 1 1/2	1/2, 3/4, 1, 1 1/4, 1 1/2
		12	-	-	_	-	1, 1 1/4, 1 1/2, 2	_
ilter regulator	rs MS-I FR-R						Datasheets	→ Internet: ms4-lfr-b; ms6-l
— Coulutor	Filter and pressure regula-	4	1_	1_	1/4	Ī_		
	tor in a single device in pol-	6		-	1/2	_		
015	ymer housing, grade of fil-				11/2			
4 1	tration 5 or 40 µm							
1								
7								
ilters MS-LF							Datasheets → Interne	t: ms4-lf; ms6-lf; ms9-lf; ms1
	Grade of filtration 5 or	4	_	1_	1/8, 1/4	I_	1/8, 1/4, 3/8	1/8, 1/4, 3/8
	40 μm	6	_	-	1/4, 3/8, 1/2	-	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
1		9	_	-	3/4, 1	3/4, 1	1/2, 3/4, 1, 1 1/4, 1 1/2	1/2, 3/4, 1, 1 1/4, 1 1/2
		12	-	-	-	-	1, 1 1/4, 1 1/2, 2	-
	Cit MC LEM						D. 1	
ine and micro	filters MS-LFM		1	1	140.44	1	Datasheets → Internet: ms4-l	
	Grade of filtration 0.01 or	4	-	-	1/8, 1/4	-	1/8, 1/4, 3/8	1/8, 1/4, 3/8
-	1 μm	6	-	-	1/4, 3/8, 1/2	-	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
1		9	-	-	3/4, 1	3/4, 1	1/2, 3/4, 1, 1 1/4, 1 1/2	1/2, 3/4, 1, 1 1/4, 1 1/2
		12	-	-		-	1, 1 1/4, 1 1/2, 2	
				-				
ctivated carb	on filters MS-LFX						Datasheets → Internet: ms	4-lfx; ms6-lfx; ms9-lfx; ms12
	For removing liquid and	4	-	-	1/8, 1/4	-	1/8, 1/4, 3/8	1/8, 1/4, 3/8
1	gaseous oil particles	6	-	-	1/4, 3/8, 1/2	-	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
1		9	_	-	3/4, 1	3/4, 1	1/2, 3/4, 1, 1 1/4, 1 1/2	1/2, 3/4, 1, 1 1/4, 1 1/2
1		12	-	-	_	-	1, 1 1/4, 1 1/2, 2	_
				<u> </u>				
later separato	ors MS-IWS						Datacheets → Intern	et: ms6-lws; ms9-lws; ms12-
ator separate	Remove condensate from	6	I_	T_	1/4, 3/8, 1/2	T_	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
	compressed air, mainte-	9		-	3/4, 1	3/4, 1	1/2, 3/4, 1, 1 1/4, 1 1/2	1/2, 3/4, 1, 1 1/4, 1 1/2
1000		<u> </u>	+	-		-	1, 1 1/4, 1 1/2, 2	-1-, -1 ,, -, - 1 -1 -7, - 1/2
	nance-free	12	1 -	I _	I –			


Гуре	Description	Size	Pneumatic o	connection				
			Push-in	Female thr	ead		Connecting plate with thre	ad
			connector	M	G	NPT	G	NPT
ndividual devic	es							
ressure regula	tors MS-LR		,				Datasheets → Internet: ms2-lr	; ms4-lr; ms6-lr; ms9-lr; ms1
10	For setting the required op-	2	QS-6	M5	-	-	_	-
1 1	erating pressure,	4	-	-	1/8, 1/4	-	1/8, 1/4, 3/8	1/8, 1/4, 3/8
	4 pressure regulation rang-	6	_	-	1/4, 3/8, 1/2	-	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
2 1	es	9	-	-	3/4, 1	3/4, 1	1/2, 3/4, 1, 1 1/4, 1 1/2	1/2, 3/4, 1, 1 1/4, 1 1/2
		12	-	-	-	-	1, 1 1/4, 1 1/2, 2	-
roccuro rogula	tors MC ID D				·		Datachoot	s → Internet: ms4-lr-b; ms6-
ressure regula	For setting the required op-	1.	1		1/4	1	Datasneet	.S → IIIternet: IIIS4-ti-b; IIIS6-
	erating pressure, in poly-	6		1_	1/4	-		-
	mer housing	6	-	-	1/2	-		
0 7	mer nousing							
ressure regula	tors MS-LRB						Datashee	ets → Internet: ms4-lrb; ms6
	For configuring a regulator	4	-	-	1/4	-	1/8, 1/4, 3/8	-
1.7	manifold with independent	6	-	-	1/2	-	1/4, 3/8, 1/2, 3/4	_
1	pressure regulation ranges.							•
	Pressure output is to the							
	front or rear.							
recision pressi	ure regulators MS-LRP					_		Datasheets → Internet: ms6
	For precisely setting the re-	6	_	-	1/4, 3/8, 1/2	-	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
	quired operating pressure,							
	4 pressure regulation rang-							
· (1)	es,							
	pressure hysteresis							
	0.02 bar							
recision press	ure regulators MS-LRPB							oatasheets → Internet: ms6-l
	For configuring a regulator	6	-	-	1/2	-	1/4, 3/8, 1/2, 3/4	-
	manifold with independent							•
	pressure regulation ranges.							
0	Pressure output is to the							
0 00	front or rear.							
000	'							
ubricators MS-	front or rear.						Natasheets → Internet-ms4-	lne· ms6-lne· ms9-lne· ms12
ubricators MS-	front or rear.	4		 -	1/8 1/4	T_	Datasheets → Internet: ms4-	
ubricators MS-	front or rear. LOE Add a precisely adjustable	4		- -	1/8, 1/4	- -	1/8, 1/4, 3/8	1/8, 1/4, 3/8
ubricators MS-	front or rear.	6	-	- -	1/4, 3/8, 1/2	- - 3/4 1	1/8, 1/4, 3/8 1/4, 3/8, 1/2, 3/4	1/8, 1/4, 3/8 1/4, 3/8, 1/2, 3/4
ubricators MS-	front or rear. Add a precisely adjustable amount of oil to the compressed air. The amount of	6	-	-	1/4, 3/8, 1/2 3/4, 1	3/4, 1	1/8, 1/4, 3/8 1/4, 3/8, 1/2, 3/4 1/2, 3/4, 1, 1 1/4, 1 1/2	1/8, 1/4, 3/8 1/4, 3/8, 1/2, 3/4 1/2, 3/4, 1, 1 1/4, 1 1/2
ubricators MS-	front or rear. LOE Add a precisely adjustable amount of oil to the com-	6	-		1/4, 3/8, 1/2		1/8, 1/4, 3/8 1/4, 3/8, 1/2, 3/4	1/8, 1/4, 3/8 1/4, 3/8, 1/2, 3/4

Гуре	Description	Size	Pneumatic (connection				
			Push-in	Female thr	ead		Connecting plate with three	ad
			connector	M	G	NPT	G	NPT
ndividual device	es							
n/off valves MS	S-EM						Datasheets → Internet: ms4-	em; ms6-em; ms9-em; ms12-
	Manually actuated on/off	4	_	-	1/8, 1/4	_	1/8, 1/4, 3/8	1/8, 1/4, 3/8
	valve for pressurising and	6	-	-	1/4, 3/8, 1/2	-	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
	exhausting pneumatic sys-	9	-	-	3/4, 1	3/4, 1	1/2, 3/4, 1, 1 1/4, 1 1/2	1/2, 3/4, 1, 1 1/4, 1 1/2
0	tems.	12	-	-	-	-	1, 1 1/4, 1 1/2, 2	_
						1		
m / aff walles a BAC	` FF						Detections between	
n/off valves MS		1,			1/0 1//	1	1	54-ee; ms6-ee; ms9-ee; ms12
	Electrically actuated on/off valve for pressurising and	4	-	-	1/8, 1/4	- -	1/8, 1/4, 3/8	1/8, 1/4, 3/8
	exhausting pneumatic sys-	6		-	1/4, 3/8, 1/2		1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
01	tems.	9	-	-	3/4, 1	3/4, 1	1/2, 3/4, 1, 1 1/4, 1 1/2	1/2, 3/4, 1, 1 1/4, 1 1/2
	l como	12	-	-	-	-	1, 1 1/4, 1 1/2, 2	-
n/off valves MS							Datasheets	→ Internet: ms4-ee-b; ms6-e
	Electrically actuated on/off	4	-	-	1/4	-	-	-
1	valve in polymer housing	6	_	_	1/2	_	_	_
7	for pressurising and ex-							
	hausting pneumatic systems.							
	tellis.							
oft-start valves	MS-DI						Datachoots -> Ir	iternet: ms4-dl; ms6-dl; ms12
ont-start valves	Pneumatically actuated	4	1_	1_	1/8, 1/4	T_	1/8, 1/4, 3/8	1/8, 1/4, 3/8
	soft-start valve for slowly	6	1_	1_	1/4, 3/8, 1/2	-	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
(3)	pressurising and exhaust-	12	1_	1_	-	- -	1, 1 1/4, 1 1/2, 2	_
* **	ing pneumatic systems.	12				-	1, 1 1/4, 1 1/2, 2	
oft-start valves							Datasheets → Into	ernet: ms4-de; ms6-de; ms12-
The same of the sa	Electrically actuated soft-	4	_	_	1/8, 1/4	-	1/8, 1/4, 3/8	1/8, 1/4, 3/8
	start valve for slowly pres-	6	_	_	1/4, 3/8, 1/2	-	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
	surising and exhausting	12	-	_		-	1, 1 1/4, 1 1/2, 2	_
	pneumatic systems.							
n/off valves MS							Datasheets →	Internet: ms4-ede-b; ms6-ed
	Electrically actuated soft-	4	-	-	1/4	-	_	-
	start valve in polymer hous-	6		_	1/2	-	_	_
7	ing for slowly pressurising							
	and exhausting pneumatic							
	systems.							
oft-start/quick	exhaust valves MS-SV							eets → Internet: ms6-sv; ms9
on start/ quick	For building up pressure	6	1_	1_	1/2	Ī_	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
	gradually and reducing	9	1_	1-	3/4, 1	3/4, 1	1/2, 3/4, 1, 1 1/4, 1 1/2	1/2, 3/4, 1, 1 1/4, 1 1/2
01	pressure quickly and safely	 			7/7, 1	J/7, 1	1/2, 2/7, 1, 1 1/4, 1 1/2	1/2, 2/7, 1, 1 1/4, 1 1/2
	in pneumatic piping sys-							
1	tems.							
U	Up to category 1, PL c.							
2	Up to category 3, PL d.	6	-	-	1/2	_	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
010	Up to category 4, PL e in the							
	case of optional extension.							
. BH								
₩								
	Up to category 4, PL e.	6	_	 -	1/2	_	1/4, 3/8, 1/2, 3/4	_
0 1 00			1	1	- L			
1								
100 pt 100								
Tru .								

Туре	Description	Size	Pneumatic o	onnection				
			Push-in	Female thr	ead		Connecting plate with thre	ad
			connector	M	G	NPT	G	NPT
ndividual devic	es							
Membrane air d	ryers MS-LDM1						Datasheets	→ Internet: ms4-ldm; ms6-lo
•1	Wear-free membrane dryer	4	-	-	1/8, 1/4	1-	1/8, 1/4, 3/8	1/8, 1/4, 3/8
Ĭ	with internal air consump- tion	6	-	-	1/4, 3/8, 1/2	-	1/4, 3/8, 1/2, 3/4	1/4, 3/8, 1/2, 3/4
Branching mod	ıles MS-FRM						Datasheets → Internet: ms4-fr	m; ms6-frm; ms9-frm; ms12-f
94	Compressed air distributors	4	-	_	1/8, 1/4	-	1/8, 1/4, 3/8	-
1	with 4 connections	6	-	-	1/4, 3/8, 1/2	-	1/4, 3/8, 1/2, 3/4	-
		9	-	-	3/4, 1	3/4, 1	1/2, 3/4, 1, 1 1/4, 1 1/2	1/2, 3/4, 1, 1 1/4, 1 1/2
		12	-	-	_	-	1, 1 1/4, 1 1/2, 2	_
 Distributor bloc	ks MS-FRM-FRZ						Datachaate - 1	nternet: ms4-frm-frz; ms6-frm-
Distributor bloc	Compressed air distributors	4	T_	Τ_		T_		_
31	with 4 connections and half		_	-	_	-	-	_
	the grid width							
Flow sensors SF	AM							Datasheets → Internet: sfa
Service 1	For absolute flow rate infor-	6	-	-	-	-	1/2	1/2
015	mation and cumulative air	9	-	-	-	-	1, 1 1/2	1, 1 1/2
- 1	consumption measurement							

Peripherals overview

Membrane air dryer MS4/MS6-LDM1





Additional accessories:

- Module connector for combination with size MS4/MS6 or size MS9
 - → Internet: amv, rmv, armv
- Adapter for mounting on profiles
 - → Internet: ipm-80, ipm-40-80, ipm-80-80

Mour	nting attachments and accessories					
		Individual device Combination				→ Page/
		Without connecting plate	With connecting plate	Without connecting plate	With connecting plate	Internet
[1]	Cover cap		_		_	ms4-end,
	MS4/6-END	_		_		ms6-end
[2]	Connecting plate SET	_		_		ms4-ag,
	MS4/6-AG	_	_	_	_	ms6-ag
	Connecting plate SET				_	ms4-aq,
	MS4/6-AQ	_	-		•	ms6-aq
[3]	Mounting bracket	_				ms4-wb,
	MS4/6-WB	•	_		_	ms6-wb
[5]	Module connector			•	•	ms4-mv,
	MS4/6-MV	_	_			ms6-mv
_	Mounting bracket	_				ms4-wbm
	MS4-WBM	•	-	_	_	
-	Mounting bracket		_	_	_	ms4-wp,
	MS4/6-WP/WPB/WPE/WPM	_	-	•	•	ms6-wp

Type codes

MS4-LDM1

001	Series
MS4	MS series, size 4
002	Function
LDM1	Membrane air dryer
003	Pneumatic connection
1/8	Female thread G1/8
1/4	Female thread G1/4
AGA	Sub-base G1/8
AGB	Sub-base G1/4
AGC	Sub-base G3/8
AQK	Sub-base 1/8 NPT
AQN	Sub-base 1/4 NPT
AQP	Sub-base 3/8 NPT
004	Flow cartridge
P05	50 l/min
P10	100 l/min
005	Purge air
	Unducted
PAC	Ducted

006	Type of mounting	
	Without mounting bracket	
WP	Mounting bracket basic design	
WPM	Mounting bracket for hooking in service unit components	
WB	Mounting centrally at rear (wall mounting top and bottom), connecting plates not required	
WBM	Mounting centrally at rear (wall mounting top), connecting plates not required	

	None	
EX4	II 2GD	
800	UL certification	
	None	
UL1	cULus ordinary location for Canada and USA	

EU certification

009	Flow direction	
	Flow direction from left to right	
Z	Flow direction from right to left	

MS6-LDM1

001	Series
MS6	MS-series, size 6
1	
002	Function
LDM1	Membrane air dryer
003	Pneumatic connection
1/4	Female thread G1/4
3/8	Female thread G3/8
1/2	Female thread G1/2
AGB	Sub-base G1/4
AGC	Sub-base G3/8
AGD	Sub-base G1/2
AGE	Sub-base G3/4
AQN	Sub-base 1/4 NPT
AQP	Sub-base 3/8 NPT
AQR	Sub-base 1/2 NPT
AQS	Sub-base 3/4 NPT
004	Flow cartridge
P20	200 l/min

005	Purge air	
	Unducted	
PAC	Ducted	
اممد	I- a a	
006	Type of mounting	
	Without mounting bracket	
WP	Mounting bracket basic design	
WPM	Mounting bracket for hooking in service unit components	
WB	Mounting centrally at rear (wall mounting top and bottom),	
	connecting plates not required	
	Laurence de la companya del companya del companya de la companya d	
007	EU certification	
	None	
EX4	II 2GD	
	1	
EX4	II 2GD UL certification	
	1	
	UL certification	
008	UL certification None	
008	UL certification None	
008 UL1	UL certification None cULus ordinary location for Canada and USA	

300 l/min

400 l/min

P30

P40

Membrane air dryers MS4/MS6-LDM1, MS series

Datasheet

Function




Flow rate
50 ... 400 l/min
Temperature range
+2 ... +50°C

Operating pressure 3 ... 12.5 bar

Pressure dew point reduction: 20 K

- Optimum final dryer with excellent operational reliability
- Suitable for use as an individual device or for integration into existing service unit combinations
- Flow rate-dependent dew point reduction
- Wear-free function requiring no external energy
- The composition of the compressed air remains almost unchanged due to the drying process
- 15% purge air flow rate
- Optional purge ring for ducting the purge air
- Optional device variant EX4 for use in potentially explosive areas in zones 1, 2, 21 and 22

Typical areas of application:



- Measurement technology
- Rinsing of precision glass scales
- Painting systems
- Paper and packaging machines





Prefiltration of the compressed air using a micro filter MS-LFM-A, grade of filtration 0.01 μ m (residual particles < 0.1 μ m, residual oil content < 0.1 mg/m³) is vital for correct functioning of the component.

General technical data						
Size		MS4	MS6			
Pneumatic connection 1	1, 2					
Female thread		G1/8 or G1/4	G1/4, G3/8 or G1/2			
Connecting plate	[AG]	G1/8, G1/4 or G3/8	G1/4, G3/8, G1/2 or G3/4			
	[AQ]	1/8 NPT, 1/4 NPT or 3/8 NPT	1/4 NPT, 3/8 NPT, 1/2 NPT or 3/4 NPT			
Design		Membrane dryer with internal air consumption				
Type of mounting		Via accessories				
		In-line installation	In-line installation			
Mounting position		Vertical ±5°	Vertical ±5°			
Air purity class at the output		Compressed air to ISO 8573-1:2010 [1:3:2]	Compressed air to ISO 8573-1:2010 [1:3:2]			

Standard flow rate qn ¹⁾ [l/min]							
Size	MS4		MS6				
Flow cartridge	P05	P10	P20	P30	P40		
Input a	59	118	235	353	471		
Input q _{n in}	1 1 2	110	233	222	4/1		
Output q _{n out}	50	100	200	300	400		

¹⁾ Measured at p1 = 6.9 bar, $\vartheta_{pd in}$ = 25°C, $\vartheta_{pd out}$ = 5°C ± 1.5°C ($\vartheta_{pa out}$ = -21.5°C ± 1.2°C), ϑ_{amb} = 25°C

Operating and environmental co	Operating and environmental conditions					
Operating pressure	[bar]	3 12.5 (3 10) ¹⁾				
Operating medium		Compressed air to ISO 8573-1:2010 [1:4:2]				
Note on the operating/		Lubricated operation not possible				
pilot medium						
Pressure dew point reduction	[K]	20				
Ambient temperature	[°C]	+2+50				
Temperature of medium	[°C]	+2+50				
Storage temperature	[°C]	-20 +60				
Corrosion resistance class CRC ²⁾		2				
Food-safe ³⁾		See supplementary material information				
UL certification ³⁾		c UL us - Recognized (OL)				

- 1) Value in brackets applies to MS4/MS6-LDM1 with UL certification.
- 2) More information www.festo.com/x/topic/crc
- 3) More information: www.festo.com/catalogue/ms-ldm → Support/Downloads.


ATEX	
EU certification	EX4
ATEX category for gas	II 2G
Type of (ignition) protection for gas	Ex h IIC T6 Gb X
ATEX category for dust	II 2D
Type of (ignition) protection for dust	Ex h IIIC T60°C Db X
Explosion ambient temperature	+2°C ≤ Ta ≤ +50°C
Explosion protection certification outside the	EPL Db (GB)
EU	EPL Gb (GB)
CE marking (see declaration of conformity) ¹⁾²⁾	To EU Explosion Protection Directive (ATEX)
UKCA marking (see declaration	To UK regulations for explosions
of conformity) ¹⁾²⁾	

- 1) Note operating range of proximity switches.
- 2) More information: www.festo.com/catalogue/ms-ldm \rightarrow Support/Downloads.

Weight [g]							
Size	MS4		MS6				
Flow cartridge	P05	P10	P20	P30	P40		
Membrane air dryer	420	530	1050	1200	1300		

Materials

Sectional view




Membrane air dryer				
[1] Housing	Die-cast aluminium			
[2] Bowl	Wrought aluminium alloy			
– Seals	NBR			
Note on materials RoHS-compliant				
LABS (PWIS) conformity	VDMA24364-B1/B2-L			




MS4-LDM1-...-P05 20 3 bar 10 5 bar †pd [°C] 0 -10 6,9 bar, -20 -30 10 bar -40 20 40 Ó 60 80 100 120


qn [l/min]



MS6-LDM1-...-P20 30 20 10 5 bar 0 -10 -20 -30 10 bai -40 -0 100 200 300 400 500 qn [l/min]





MS6-LDM1-...-P40



1) Measured at pressure dew point t_{pd} (input) = 25°C.

Example using MS6-LDM1-...-P40 at 10 bar operating pressure: at a standard flow rate of $q_n = 550$ l/min the pressure dew point reduction is 25 K.





 $^{\ \ \}phi$ - Note: This product conforms to ISO 1179-1 and ISO 228-1.

Ordering data	Ordering data							
Size	Flow cartridge	Connection	Part no.	Туре				
Flow direction	Flow direction from left to right							
MS4	P10	G1/4	543632	MS4-LDM1-1/4-P10				
MS6	P20	G1/4	543640	MS6-LDM1-1/4-P20				
		G1/2	543644	MS6-LDM1-1/2-P20				
	P40	G1/2	543650	MS6-LDM1-1/2-P40				
Flow direction	Flow direction from right to left							
MS4	P10	G1/4	543633	MS4-LDM1-1/4-P10-Z				

Ordering data – Modular product system

Ordering table	[1	1,0	162	Camalitian	ا دعاء	F=+===================================
Grid dimension	[mm]	40	62	Conditions	Code	Enter code
Module no.		543628	543638			
eries Standard				MS	MS	
Size		4	6			
Function		Membrane air dryer			-LDM1	-LDM1
Pneumatic connection		Female thread G1/8	-	[1]	-1/8	
		Female thread G1/4	Female thread G1/4	[1]	-1/4	
		-	Female thread G3/8	[1]	-3/8	
		-	Female thread G1/2	[1]	-1/2	
		Connecting plate G1/8	-		-AGA	
		Connecting plate G1/4	Connecting plate G1/4		-AGB	
		Connecting plate G3/8	Connecting plate G3/8		-AGC	
		-	Connecting plate G1/2		-AGD	
		-	Connecting plate G3/4		-AGE	
		Connecting plate 1/8 NPT	-	[1]	-AQK	
		Connecting plate 1/4 NPT	Connecting plate 1/4 NPT	[1]	-AQN	
		Connecting plate 3/8 NPT	Connecting plate 3/8 NPT	[1]	-AQP	
		-	Connecting plate 1/2 NPT	[1]	-AQR	
		-	Connecting plate 3/4 NPT	[1]	-AQS	
Flow cartridge		50 l/min	-		-P05	
		100 l/min	-		-P10	
		-	200 l/min		-P20	
		-	300 l/min		-P30	
		-	400 l/min		-P40	
Purge air		Unducted				
		Ducted purge air			-PAC	
Type of mounting		Without mounting bracket		[1]		
,,		Mounting bracket standard design			-WP	
		Mounting bracket for hooking in service unit components			-WPM	
		Mounting bracket centrally at rear (wall mounting		[1] [2]	-WB	
		Mounting bracket centrally at rear (wall mount-	-		-WBM	
		ing top), connecting plates not required				
EU certification		None				
		II 2GD to EU Explosion Protection Directive (ATEX)			-EX4	
UL certification		None				
		cULus, ordinary location for Canada and USA			-UL1	
Flow direction		Flow direction from left to right				
		Flow direction from right to left			-Z	

^{[1] 1/8, 1/4, 3/8,} 1/2, AQK, AQN,

Not with EU EX4 certification.

AQP, AQR, AQS, PAC, WPM

Only with connecting plate AGA, AGB, AGC, AGD, AGE, AQK, AQN, AQP, AQR or AQS.

Festo - Your Partner in Automation





1 Festo Inc.

5300 Explorer Drive Mississauga, ON L4W 5G4 Canada

Festo Customer Interaction Center

Tel: 1877 463 3786 Fax: 1877 393 3786



2 Festo Pneumatic

Av. Ceylán 3, Col. Tequesquináhuac 54020 Tlalnepantla, Estado de México

Multinational Contact Center

01 800 337 8669



3 Festo Corporation

1377 Motor Parkway Suite 310 Islandia, NY 11749



Regional Service Center

7777 Columbia Road Mason, OH 45040

Festo Customer Interaction Center

1 800 993 3786 1 800 963 3786 customer.service.us@festo.com

Connect with us









